

# 5210, 5310, 5410, and 5510 Tractors



## TECHNICAL MANUAL 5210, 5310, 5410, and 5510 Tractors TM1716 26APR04 (ENGLISH)

For complete service information also see:

Component Technical Manual 3029 2.9L	
Engine .....	CTM125
Component Technical Manual 4045 4.5L	
Engine .....	CTM104
Component Technical Manual 4045 4.5L	
Mechanical Fuel Systems .....	CTM207
Alternators and Starting Motors .....	CTM77

**John Deere Augusta Works**  
LITHO IN U.S.A.



# Introduction

## Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

DX,TMIFC -19-29SEP98-1/1



# Contents

## SECTION 10—General Information

- Group 05—Safety
- Group 10—General Specifications
- Group 20—Fuel and Lubricants
- Group 25—Serial Number Locations
- Group 30—Features and Accessories

## SECTION 20—Engine Repair

- Group 05—Engine
- Group 10—Cooling System

## SECTION 30—Fuel and Air Repair

- Group 05—Fuel System
- Group 10—Air Intake System
- Group 15—Speed Control Linkage

## SECTION 40—Electrical Repair

- Group 05—Battery, Starter and Alternator
- Group 10—Electrical System Components
- Group 15—Wiring Harness

## SECTION 50—Power Train Repair

- Group 05—Clutch Housing
- Group 10—Clutch Assembly—  
CollarShift/SyncShuttle™ Transmissions
- Group 11—Clutch Assembly—PowrReverser™  
Transmission
- Group 12—PowrReverser™
- Group 15—CollarShift/SyncShuttle™ Transmission
- Group 16—PowrReverser™ Transmission
- Group 20—Rear PTO Drive Shaft
- Group 25—Differential
- Group 30—Final Drives
- Group 35—Mechanical Front Wheel Drive
- Group 40—Creeper Assembly

## SECTION 60—Steering and Brake Repair

- Group 05—Steering Repair
- Group 10—Brake Repair

## SECTION 70—Hydraulic Repair

- Group 05—Hydraulic Pump and Filter
- Group 06—Hydraulic Oil Cooler
- Group 10—Rockshaft
- Group 15—Dual Selective Control Valve

- Group 16—Single (Third) Selective Control Valve
- Group 20—Hydraulic Mid Mount Coupler
- Group 25—Hydraulic Power Beyond

## SECTION 80—Miscellaneous Repair

- Group 05—Front Axle—2WD
- Group 10—Wheels
- Group 15—3-Point Hitch

## SECTION 90—Operator Station Repair

- Group 05—Seat and Support
- Group 06—Control Console and Panel—Tractors  
Without Cab
- Group 10—ROLL-GARD
- Group 15—Cab Components
- Group 20—Air Conditioning System
- Group 25—Heating System

## SECTION 210—Operational Checkout Procedures

- Group 10—Operational Checkout Procedures

## SECTION 220—Engine Operation, Tests, and Adjustments

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests, and Adjustments

## SECTION 230—Fuel/Air Operation, Tests, and Adjustments

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests and Adjustments

## SECTION 240—Electrical System Operation, Tests & Adjust

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Test and Adjust
- Group 20—Wiring Schematics

## SECTION 250—Power Train Operation, Tests, and Adjustments

- Group 05—Component Location—Collar Shift and

Continued on next page

*All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

COPYRIGHT © 2004  
DEERE & COMPANY  
Moline, Illinois  
All rights reserved  
A John Deere ILLUSTRATION® Manual  
Previous Editions  
Copyright © 2000

10  
  
  
  
  
  
  
20  
  
  
  
  
  
  
30  
  
  
  
  
  
  
40  
  
  
  
  
  
  
50  
  
  
  
  
  
  
60  
  
  
  
  
  
  
70  
  
  
  
  
  
  
80  
  
  
  
  
  
  
90  
  
  
  
  
  
  
210

- SyncShuttle™ Transmissions
- Group 06—Component Location—PowrReverser™ Transmission
- Group 10—Theory of Operation—Collar Shift and SyncShuttle™ Transmissions
- Group 11—Theory of Operation—PowrReverser™ Transmission
- Group 15—Diagnosis, Tests, and Adjustments—CS/SS Transmissions
- Group 16—Diagnosis, Tests, and Adjustments—PowrReverser™

**SECTION 260—Steering and Brake Operation, Tests, and Adjustments**

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests and Adjustments

**SECTION 270—Hydraulic System Operation, Tests, and Adjustments**

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis
- Group 16—Hydraulic Tests—Without SCV
- Group 17—Hydraulic Tests—With SCV
- Group 18—Hydraulic Tests—All
- Group 19—Adjustments
- Group 20—Hydraulic Schematics

**SECTION 290—Operator Station**

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests, and Adjustments

**SECTION 299—Dealer Fabricated Tools**

- Group 00—Dealer Fabricated Tools

220

230

240

250

260

270

290

299

INDX

220

230

240

250

260

270

290

299

INDX

# Section 10

## General Information

### Contents

	Page		Page
<b>Group 05—Safety</b> . . . . .	10-05-1	<b>Mechanical Front Wheel Drive (MFWD) Serial</b>	
		Number Location . . . . .	10-25-3
<b>Group 10—General Specifications</b>		<b>Air Conditioning Compressor Serial Number</b>	
Machine Specifications—5210 and 5310 . . . . .	10-10-1	Location . . . . .	10-25-3
Travel Speeds—5210 and 5310 . . . . .	10-10-7		
Machine Specifications—5410 . . . . .	10-10-10	<b>Group 30—Features and Accessories</b>	
Travel Speeds—5410 . . . . .	10-10-13	Features and Accessories . . . . .	10-30-1
Machine Specifications—5510 . . . . .	10-10-16	Standard Features—5210 and 5310 . . . . .	10-30-2
Travel Speeds—5510 . . . . .	10-10-19	Standard Features—5410 and 5510 . . . . .	10-30-3
Service Recommendations for O-Ring		Standard Features—5210 through 5510 . . . . .	10-30-4
Boss Fittings . . . . .	10-10-21	Factory Installed Optional Equipment	
Service Recommendations for Flat Face		(5210—5510) . . . . .	10-30-5
O-Ring Seal Fittings . . . . .	10-10-23	Field Installed Optional Kits and	
Metric Cap Screw Torque Values—Grade		Accessories—5210 Through 5510 . . . . .	10-30-6
7 . . . . .	10-10-24		
Metric Bolt and Cap Screw Torque Values . . . . .	10-10-25		
Unified Inch Bolt and Cap Screw Torque			
Values . . . . .	10-10-26		
Abbreviations . . . . .	10-10-27		
<b>Group 20—Fuel and Lubricants</b>			
Diesel Fuel Specifications . . . . .	10-20-1		
Storing Fuel . . . . .	10-20-1		
Do Not Use Galvanized Containers . . . . .	10-20-2		
Fill Fuel Tank . . . . .	10-20-2		
Diesel Engine Oil . . . . .	10-20-3		
Diesel Engine Coolant . . . . .	10-20-4		
Liquid Coolant Conditioner . . . . .	10-20-5		
Transmission and Hydraulic Oil . . . . .	10-20-6		
MFWD Gear Oil . . . . .	10-20-7		
Grease (Specific Application) . . . . .	10-20-7		
Grease . . . . .	10-20-8		
Alternative and Synthetic Lubricants . . . . .	10-20-9		
Lubricant Storage . . . . .	10-20-9		
<b>Group 25—Serial Number Locations</b>			
Serial Numbers . . . . .	10-25-1		
Product Identification Number Location . . . . .	10-25-1		
Engine Serial Number Location . . . . .	10-25-1		
Fuel Injection Pump Serial Number Location . . . . .	10-25-1		
Alternator Serial Number Location . . . . .	10-25-2		
Power Steering Valve Serial Number			
Location . . . . .	10-25-2		
Starter Serial Number Location . . . . .	10-25-2		
Transmission Serial Number Location . . . . .	10-25-2		
Front Axle (2WD) Serial Number Location . . . . .	10-25-3		



## Recognize Safety Information

This is a safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-29SEP98-1/1

TS1389 -UN-07DEC88

## Understand Signal Words

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



DX,SIGNAL -19-03MAR93-1/1

TS187 -19-30SEP88

## Follow Safety Instructions

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.



TS201 -UN-23AUG88

DX,READ -19-03MAR93-1/1

## Handle Fluids Safely—Avoid Fires

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.



TS227 -UN-23AUG88

DX,FLAME -19-29SEP98-1/1

## Prevent Battery Explosions

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).



TS204 -UN-23AUG88


DX,SPARKS -19-03MAR93-1/1

## Prepare for Emergencies

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



TS291 -UN-23AUG88

DX,FIRE2 -19-03MAR93-1/1



## Prevent Acid Burns

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:

1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 15—30 minutes. Get medical attention immediately.

If acid is swallowed:

1. Do not induce vomiting.
2. Drink large amounts of water or milk, but do not exceed 2 L (2 quarts).
3. Get medical attention immediately.




TS203 -UN-23AUG88

DX,POISON -19-21APR93-1/1

## Service Cooling System Safely

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.



TS281 -UN-23AUG88

DX,RCAP -19-04JUN90-1/1


## Handle Chemical Products Safely

Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.

Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

(See your John Deere dealer for MSDS's on chemical products used with John Deere equipment.)



TS1132 -UN-26NOV90

DX,MSDS,NA -19-03MAR93-1/1


## Avoid High-Pressure Fluids

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.




X9811 -UN-23AUG88

DX,FLUID -19-03MAR93-1/1

## Park Machine Safely

Before working on the machine:

- Lower all equipment to the ground.
- Shift transmission to PARK.
- Engage park brake if equipped.
- Stop the engine and remove the key.
- Disconnect the battery ground strap.
- Hang a "DO NOT OPERATE" tag in operator station.




TS230 -UN-24MAY89

CED,OUO1085,7 -19-26JUL00-1/1

## Support Machine Properly

Always lower the attachment or implement to the ground before you work on the machine. If you must work on a lifted machine or attachment, securely support the machine or attachment.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.



TS229 -UN-23AUG88

CED,OUO1085,8 -19-26JUL00-1/1


## Wear Protective Clothing

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.




TS206 -UN-23AUG88

DX,WEAR -19-10SEP90-1/1

## Work in Clean Area

Before starting a job:

- Clean work area and machine.
- Make sure you have all necessary tools to do your job.
- Have the right parts on hand.
- Read all instructions thoroughly; do not attempt shortcuts.




DX,CLEAN -19-04JUN90-1/1

T6642EJ -JUN-18OCT88

## Service Machines Safely

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.




DX,LOOSE -19-04JUN90-1/1

TS228 -JUN-23AUG88

## Work in Ventilated Area

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area



DX,AIR -19-17FEB99-1/1

TS220 -JUN-23AUG88

## Illuminate Work Area Safely

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.




DX,LIGHT -19-04JUN90-1/1

TS223 -JUN-23AUG88

## Replace Safety Signs

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.



DX,SIGNS1 -19-04JUN90-1/1


TS201 -UN-23AUG88

10  
05  
7

## Use Proper Lifting Equipment

Lifting heavy components incorrectly can cause severe injury or machine damage.

Follow recommended procedure for removal and installation of components in the manual.




DX,LIFT -19-04JUN90-1/1

TS226 -UN-23AUG88

## Keep ROPS Installed Properly

Make certain all parts are reinstalled correctly if the roll-over protective structure (ROPS) is loosened or removed for any reason. Tighten mounting bolts to proper torque.

The protection offered by ROPS will be impaired if ROPS is subjected to structural damage, is involved in an overturn incident, or is in any way altered by welding, bending, drilling, or cutting. A damaged ROPS should be replaced, not reused.



DX,ROPS3 -19-03MAR93-1/1

TS212 -UN-23AUG88

## Service Tires Safely


Explosive separation of a tire and rim parts can cause serious injury or death.

Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job.

Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure. Never weld or heat a wheel and tire assembly. The heat can cause an increase in air pressure resulting in a tire explosion. Welding can structurally weaken or deform the wheel.

When inflating tires, use a clip-on chuck and extension hose long enough to allow you to stand to one side and NOT in front of or over the tire assembly. Use a safety cage if available.

Check wheels for low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.



TS211 -UN-23AUG88

DX,RIM -19-24AUG90-1/1


## Avoid Harmful Asbestos Dust

Avoid breathing dust that may be generated when handling components containing asbestos fibers. Inhaled asbestos fibers may cause lung cancer.

Components in products that may contain asbestos fibers are brake pads, brake band and lining assemblies, clutch plates, and some gaskets. The asbestos used in these components is usually found in a resin or sealed in some way. Normal handling is not hazardous as long as airborne dust containing asbestos is not generated.

Avoid creating dust. Never use compressed air for cleaning. Avoid brushing or grinding material containing asbestos. When servicing, wear an approved respirator. A special vacuum cleaner is recommended to clean asbestos. If not available, apply a mist of oil or water on the material containing asbestos.

Keep bystanders away from the area.



TS220 -UN-23AUG88

DX,DUST -19-15MAR91-1/1

## Avoid Heating Near Pressurized Fluid Lines

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.



DX,TORCH -19-03MAR93-1/1

TS953 -UN-15MAY90

## Remove Paint Before Welding or Heating


Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Do all work outside or in a well ventilated area. Dispose of paint and solvent properly.

Remove paint before welding or heating:

- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.



DX,PAINT -19-03MAR93-1/1

TS220 -UN-23AUG88

## Use Proper Tools

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards.

Use power tools only to loosen threaded parts and fasteners.

For loosening and tightening hardware, use the correct size tools. DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only service parts meeting John Deere specifications.



TS779 -UN-08NOV89

DX,REPAIR -19-17FEB99-1/1

## Dispose of Waste Properly


Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.



TS1133 -UN-26NOV90

DX,DRAIN -19-03MAR93-1/1



## Live With Safety

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.



DX,LIVE -19-25SEP92-1/1

TS231 -19-07OCT88

10  
05  
11



## Machine Specifications—5210 and 5310

*NOTE: Specifications and design subject to change without notice.*

### 5210 Tractor

Item	Measurement	Specification
Engine	Make	John Deere
	Type	Diesel
	Model	CD3029DLV50
	Aspiration	Natural
	Horsepower	40 kW (53 hp)
	Rated Engine Speed	2400 rpm
	Operating Range	1600—2400 rpm
	Number of Cylinders	3
	Displacement	2.9 L (179 cu in.)
	Bore and Stroke	106 x 110 mm (4.19 x 4.33 in.)
	Compression Ratio	17.8:1
	Fast Idle	2625 ± 25 rpm
	Slow Idle	825 ± 25 rpm
	Start Aid	Air heater
	Firing Order	1-2-3
	Timing	18° BTDC
	Lubrication	Pressurized
	Cooling	Liquid cooled
Fuel System	Air Cleaner	Dry type w/safety element
	Engine Shutoff	Key switch
Electrical System	Type	Direct injection
	Injection Pump Type	Rotary w/electric shutoff
Electrical System	Type	12 Volt
	Battery Size	700 cold cranking amps at -18° C
	Alternator Without Cab	40 amp
	Alternator With Cab	60 amp
Drive Train	Transmission Type	CollarShift (standard) SyncShuttle™ (optional) PowrReverser™ (optional)
	Number of Speeds	9 forward, 3 reverse (SyncShuttle™) 12 forward, 12 reverse (PowrReverser™)
	Final Drive	Planetary
	Clutch	Dual, dry
		Multi-disk, wet (PowrReverser™)

Continued on next page

CED,OUO1085,9 -19-03APR02-1/6

## General Specifications

10  
10  
2

Item	Measurement	Specification
Steering/Brakes	Steering Brakes	Hydrostatic power Wet disk Self-equalizing Self-adjusting
Hydraulic System	Type Working Pressure  Pump Type Capacity Hitch Lift Capacity at 610 mm (24 in.) Behind Hitch Balls Lift Control Type	Open Center 18995—19700 kPa (190—197 bar) (2755—2855 psi) Tandem gear (68.8 L/min 18.2 gpm) 1530 kg (3374 lb)  Position and depth
Rear PTO <sup>1</sup>	Type Horsepower (Standard Mode) Speed (540 Standard Mode) @ 2400 rpm Engine Speed Speed (540E Economy Mode) @ 1700 rpm Engine Speed	Fully independent 34 kW (45 hp) 540 rpm 540 rpm
Capacities	Fuel Tank (Open Station) Fuel Tank (Cab Tractors) Cooling System Engine Crankcase w/Filter Hydraulic System MFWD Wheel Hubs MFWD Differential Housing	68 L (18 U.S. gal) 83 L (22 U.S. gal) 9.5 L (10 U.S. qt) 8.5 L (9 U.S. qt) 38 L (10 U.S. gal) 0.6 L (0.63 U.S. qt) 5 L (5.3 U.S. qt)

<sup>1</sup>540E Economy Mode available only on SyncSuttle™ Transmission.

Continued on next page

CED.OUO1085,9 -19-03APR02-2/6

## General Specifications

10  
10  
3

Item	Measurement	Specification
Tires (Standard Equipment)	2WD Front	6.50—16 6PR F2
	2WD Rear	13.6—28 4PR R1
	MFWD Front	8.3—24 4PR R1
	MFWD Rear	13.6—28 4PR R1
Overall Dimensions (Standard Equipment) <sup>2</sup>	Drawbar Ground Clearance	364 mm (14.3 in.)
	Front Axle Ground Clearance (2WD)	478 mm (19 in.)
	Front Axle Ground Clearance (MFWD)	430 mm (17 in.)
	Overall Length without Hitch and Drawbar	3150 mm (124 in.)
	Overall Width (Maximum)	2402 mm (94.6 in.)
	Height to Top of Steering Wheel	1600 mm (63 in.)
	Height to Top of ROPS (Add 4 Inches if Equipped with a Canopy)	2254 mm (88.7 in.) extended
		1948 mm (76.7 in.) folded
	Height to Top of Cab from Center Line of Rear Axle	1844 mm (72.6 in.)
	Approximate Weight (2WD)	1982 kg (4370 lb)
	Approximate Weight (MFWD)	2145 kg (4730 lb)

<sup>2</sup>Weights will vary slightly with optional tires. Add 1000 lbs. to weight of tractor if equipped with a cab.

Continued on next page

CED,OUO1085,9 -19-03APR02-3/6

10  
10  
4

**5310 Tractor**

Item	Measurement	Specification
Engine	Make	John Deere
	Type	Diesel
	Model	CD3029TLV50
	Aspiration	Turbocharged
	Horsepower	48 kW (64 hp)
	Rated Engine Speed	2400 rpm
	Operating Range	1600—2400 rpm
	Number of Cylinders	3
	Displacement	2.9 L (179 cu in.)
	Bore and Stroke	106 x 110 mm (4.19 x 4.33 in.)
	Compression Ratio	17.8:1
	Fast Idle	2625 ± 25 rpm
	Slow Idle	825 ± 25 rpm
	Start Aid	Air heater
	Firing Order	1-2-3
	Timing	18° BTDC
	Lubrication	Pressurized
	Cooling	Liquid cooled
	Air Cleaner	Dry type w/safety element
	Engine Shutoff	Key switch
Fuel System	Type	Direct injection
	Injection Pump Type	Rotary w/electric shutoff
Electrical System	Type	12 volt
	Battery Size	700 cold cranking amps at -18° C
	Alternator Without Cab	40 amp
	Alternator With Cab	60 amp
Drive Train	Transmission Type	CollarShift (standard) SyncShuttle™ (optional) PowrReverser™ (optional)
	Number of Speeds	9 forward, 3 reverse (SyncShuttle™) 12 forward, 12 reverse (PowrReverser™)
	Final Drive	Planetary
	Clutch	Dual, dry Multi-disk, wet (PowrReverser™)
Steering/Brakes	Steering	Hydrostatic power
	Brakes	Wet disk
		Self-equalizing
		Self-adjusting

Continued on next page

CED,OUC1085,9 -19-03APR02-4/6

## General Specifications

10  
10  
5

Item	Measurement	Specification
Hydraulic System	Type	Open center
	Working Pressure	18 995—19 700 kPa (190—197 bar) (2755—2855 psi)
	Pump Type	Tandem gear
	Capacity	68.8 L/min (18.2 gpm)
	Hitch Lift Capacity at 610 mm (24 in.) Behind Hitch Balls	1530 kg (3374 lb)
	Lift Control Type	Position and depth
Rear PTO <sup>3</sup>	Type	Fully independent
	Horsepower (Standard Mode)	41 kW (55 hp)
	Speed (540 Standard Mode) @ 2400 rpm Engine Speed	540 rpm
	Speed (540E Economy Mode) @ 1700 rpm Engine Speed	540 rpm
Capacities	Fuel Tank (Open Station)	68 L (18 U.S. gal)
	Fuel Tank (Cab Tractors)	83 L (22 U.S. gal)
	Cooling System	9.5 L (10 U.S. qt)
	Engine Crankcase w/Filter	8.5 L (9 U.S. qt)
	Hydraulic System	38 L (10 U.S. gal)
	MFWD Wheel Hubs	0.6 L (0.63 U.S. qt)
	MFWD Differential Housing	5 L (5.3 U.S. qt)
<sup>3</sup> 540E Economy Mode available only on SyncShuttle™ Transmission.		

Continued on next page

CED\_OUO1085,9 -19-03APR02-5/6

## General Specifications

10  
10  
6

Item	Measurement	Specification
Tires (Standard Equipment)	2WD Front	7.50—16 6PR F2
	2WD Rear	14.9—28 6PR R1
	MFWD Front	9.5—24 4PR R1
	MFWD Rear	14.9—28 6PR R1
Overall Dimensions (Standard Equipment) <sup>2</sup>	Drawbar Ground Clearance	364 mm (14.3 in.)
	Front Axle Ground Clearance (2WD)	478 mm (19 in.)
	Front Axle Ground Clearance (MFWD)	430 mm (17 in.)
	Overall Length without Hitch and Drawbar	3150 mm (124 in.)
	Overall Width (Maximum)	2402 mm (94.6 in.)
	Height to Top of Steering Wheel	1625 mm (64 in.)
	Height to Top of ROPS (Add 4 Inches to Top of ROPS if Equipped with a Canopy)	2254 mm (88.7 in.) extended
		1973 mm (77.7 in.) folded
	Height to Top of Cab from Center Line of Rear Axle	1844 mm (72.6 in.)
	Approximate Weight (2WD)	2064 kg (4550 lb)
	Approximate Weight (MFWD)	2250 kg (4960 lb)

<sup>2</sup>Weights will vary slightly with optional tires. Add 1000 lbs. to weight of tractor if equipped with a cab.

CED,OUO1085.9 -19-03APR02-6/6



**Travel Speeds—5210 and 5310**

Item	Measurement	Specification
Travel Speeds for CollarShift or SyncShuttle™ Units at Full Engine RPM with 14.9—28 R1 Rear Tire Types <sup>1</sup>		
Creeper-1 Gear in Forward	Speed	0.3 km/h (0.2 mph)
Creeper-2 Gear in Forward	Speed	0.5 km/h (0.3 mph)
Creeper-3 Gear in Forward	Speed	0.7 km/h (0.4 mph)
A-1st Gear in Forward	Speed	2.0 km/h (1.2 mph)
A-2nd Gear in Forward	Speed	2.1 km/h (1.3 mph)
A-3rd Gear in Forward	Speed	4.0 km/h (2.5 mph)
B-1st Gear in Forward	Speed	4.7 km/h (2.9 mph)
B-2nd Gear in Forward	Speed	6.7 km/h (4.2 mph)
B-3rd Gear in Forward	Speed	9.2 km/h (5.7 mph)
C-1st Gear in Forward	Speed	12.8 km/h (7.9 mph)
C-2nd Gear in Forward	Speed	18.4 km/h (11.5 mph)
C-3rd Gear in Forward	Speed	25.1 km/h (15.6 mph)
Creeper-R Gear in Reverse	Speed	0.6 km/h (0.34 mph)
Reverse-1st Gear	Speed	3.4 km/h (2.1 mph)
Reverse-2nd Gear	Speed	7.8 km/h (4.8 mph)
Reverse-3rd Gear	Speed	21.3 km/h (13.2 mph)

<sup>1</sup>Travel speeds will vary with optional rear tires. Creeper assembly is optional.

Continued on next page

OUO1080,0000287 -19-23JUL02-1/3

Item	Measurement	Specification
Travel Speeds for PowrReverser™ Units at Full Engine RPM with 16.9— 30 R1 Rear Tire Types¹		
Creeper-1 Gear in Forward	Speed	0.24 km/h (0.15 mph)
Creeper-2 Gear in Forward	Speed	0.31 km/h (0.19 mph)
Creeper-3 Gear in Forward	Speed	0.40 km/h (0.25 mph)
Creeper-4 Gear in Forward	Speed	0.54 km/h (0.34 mph)
A-1 Gear in Forward	Speed	1.49 km/h (0.93 mph)
A-2 Gear in Forward	Speed	1.87 km/h (1.16 mph)
A-3 Gear in Forward	Speed	2.42 km/h (1.50 mph)
A-4 Gear in Forward	Speed	2.87 km/h (1.79 mph)
B-1 Gear in Forward	Speed	4.33 km/h (2.69 mph)
B-2 Gear in Forward	Speed	5.42 km/h (3.37 mph)
B-3 Gear in Forward	Speed	7.00 km/h (4.34 mph)
B-4 Gear in Forward	Speed	9.56 km/h (5.94 mph)
C-1 Gear in Forward	Speed	12.2 km/h (7.61 mph)
C-2 Gear in Forward	Speed	15.3 km/h (9.51 mph)
C-3 Gear in Forward	Speed	19.8 km/h (12.3 mph)
C-4 Gear in Forward	Speed	27.0 km/h (16.8 mph)
Creeper-1 Gear in Reverse	Speed	0.28 km/h (0.18 mph)
Creeper-2 Gear in Reverse	Speed	0.35 km/h (0.22 mph)
Creeper-3 Gear in Reverse	Speed	0.46 km/h (0.28 mph)
Creeper-4 Gear in Reverse	Speed	0.62 km/h (0.39 mph)

¹Travel speeds will vary with optional rear tires. Creeper assembly is optional.

## General Specifications

10  
10  
9

Item	Measurement	Specification
A-1 Gear in Reverse	Speed	1.72 km/h (1.07 mph)
A-2 Gear in Reverse	Speed	2.16 km/h (1.34 mph)
A-3 Gear in Reverse	Speed	2.79 km/h (1.74 mph)
A-4 Gear in Reverse	Speed	3.32 km/h (2.07 mph)
B-1 Gear in Reverse	Speed	5.01 km/h (3.11 mph)
B-2 Gear in Reverse	Speed	6.26 km/h (3.89 mph)
B-3 Gear in Reverse	Speed	8.10 km/h (5.04 mph)
B-4 Gear in Reverse	Speed	11.0 km/h (6.87 mph)
C-1 Gear in Reverse	Speed	14.2 km/h (8.80 mph)
C-2 Gear in Reverse	Speed	17.7 km/h (11.0 mph)
C-3 Gear in Reverse	Speed	22.9 km/h (14.2 mph)
C-4 Gear in Reverse	Speed	31.2 km/h (19.4 mph)

OUO1080,0000287 -19-23JUL02-3/3

## Machine Specifications—5410

### 5410 Tractor

Item	Measurement	Specification
Engine	Make	John Deere
	Type	Diesel
	Model	CD4045DLV50
	Aspiration	Natural
	Horsepower	48 kW (65 hp)
	Rated Engine Speed	2400 rpm
	Number of Cylinders	4
	Displacement	4.5 L (274 cu in.)
	Bore and Stroke	106 x 127 mm (4.19 x 5.00 in.)
	Compression Ratio	17.6:1
	Fast Idle	2625 ± 25 rpm
	Slow Idle	825 ± 25 rpm
	Start Aid	Air heater
	Firing Order	1-3-4-2
	Timing	17° BTDC
	Lubrication	Pressurized
	Cooling	Liquid cooled
	Air Cleaner	Dry type w/safety element
	Engine Shutoff	Key switch
Fuel System	Type	Direct injection
	Injection Pump Type	Rotary w/electric shutoff
Electrical System	Type	12 volt
	Battery Size	700 cold cranking amps at -18°C
	Alternator	40 amp without cab 65 amp with cab
Drive Train	Transmission Type	CollarShift
		SyncShuttle™ (optional)
		PowrReverser™ (optional)
	Number of Speeds	9 Foward, 3 Reverse (SyncShuttle™)
		12 Forward, 12 Reverse (PowrReverser™)
	Final Drive	Planetary
	Clutch	Dual, dry
		Multi-disk, wet (PowrReverser™)

Continued on next page

OUO1080,0000288 -19-23JUL02-1/3

## General Specifications

10  
10  
11

Item	Measurement	Specification
Steering/Brakes	Steering Brakes	Hydrostatic power Wet disk Self-equalizing Self-adjusting
Hydraulic System	Type Working Pressure  Pump Type Capacity Hitch Lift Capacity at 610 mm (24 in.) Behind Hitch Balls Lift Control Type	Open center 18995—19700 kPa (190—197 bar) (2755—2855 psi) Tandem gear 85 L/min (22.5 gpm) 1530 kg (3374 lb)  Position and depth
Rear PTO <sup>1</sup>	Type Horsepower Speed (540 Standard Mode) @ 2400 rpm Engine Speed Speed (540E Economy Mode) @ 1700 rpm Engine Speed	Fully independent 48 kW (65 hp) 540 rpm 540 rpm
Capacities	Fuel Tank (Open Station) Fuel Tank (Cab Tractors) Cooling System Engine Crankcase w/Filter Hydraulic System MFWD Wheel Hubs MFWD Axle Housing	68 L (18 U.S. gal) 83 L (22 U.S. gal) 10.8 L (11.4 U.S. qt) 8.5 L (9 U.S. qt) 38 L (10 U.S. gal) 0.6 L (0.63 U.S. qt) 5 L (5.3 U.S. qt)
<sup>1</sup> Economy Mode available only on SyncShuttle™ Transmission.		

Continued on next page

OUC1080,0000288 -19-23JUL02-2/3

## General Specifications

10  
10  
12

Item	Measurement	Specification
Tires (Standard Equipment)	2WD Front	7.50—16 6PR F2
	2WD Rear	16.9—30 6PR R1
	MFWD Front	11.2—24 4PR R1
	MFWD Rear	16.9—30 6PR R1
Overall Dimensions (Standard Equipment) <sup>2</sup>	Drawbar Ground Clearance (2WD)	497.8 mm (19.6 in.)
	Drawbar Ground Clearance (MFWD)	477.5 mm (18.8 in.)
	Front Axle Ground Clearance (2WD)	464.8 mm (18.3 in.)
	Front Axle Ground Clearance (MFWD)	391.1 mm (15.4 in.)
	Overall Length without Hitch, Drawbar, and Weights (2WD)	3197.8 mm (125.9 in.)
	Overall Length without Hitch, Drawbar, and Weights (MFWD)	3309.6 mm (130.3 in.)
	Overall Width (2WD)	1744.9mm (68.7 in.) maximum
	Overall Width (MFWD)	1744.9 mm (68.7 in.) maximum
	Height to Top of Steering Wheel	1661 mm (65.4 in.)
	Height to Top of ROPS (Add 4 Inches to Top of ROPS if Equipped with a Canopy)	2316.4 mm (91.2 in.) extended
		1981 mm (78 in.) folded
	Height to Top of Cab from Center Line of Rear Axle	1844 mm (72.6 in.)
	Approximate Weight (2WD)	2390 kg (5270 lb)
	Approximate Weight (MFWD)	2581 kg (5690 lb)

<sup>2</sup>Weights will vary slightly with optional tires. Add 1000 lbs. to weight of tractor if equipped with a cab.

OUO1080,0000288 -19-23JUL02-3/3

**Travel Speeds—5410**

Item	Measurement	Specification
Travel Speeds for CollarShift or SyncShuttle™ Units at Full Engine RPM with 14.9—28 R1 Rear Tire Types <sup>1</sup>		
Creeper-1 Gear in Forward	Speed	0.3 km/h (0.2 mph)
Creeper-2 Gear in Forward	Speed	0.5 km/h
Creeper-3 Gear in Forward	Speed	0.7 km/h (0.4 mph)
A-1st Gear in Forward	Speed	2.0 km/h (1.2 mph)
A-2nd Gear in Forward	Speed	2.1 km/h (1.3 mph)
A-3rd Gear in Forward	Speed	4.0 km/h (2.5 mph)
B-1st Gear in Forward	Speed	4.7 km/h (2.9 mph)
B-2nd Gear in Forward	Speed	6.7 km/h (4.2 mph)
B-3rd Gear in Forward	Speed	9.2 km/h (5.7 mph)
C-1st Gear in Forward	Speed	12.8 km/h (7.9 mph)
C-2nd Gear in Forward	Speed	18.4 km/h (11.5 mph)
C-3rd Gear in Forward	Speed	25.1 km/h (15.6 mph)
Creeper-Reverse Gear	Speed	0.6 km/h (0.34 mph)
Reverse-1st Gear	Speed	3.4 km/h (2.1 mph)
Reverse-2nd Gear	Speed	7.8 km/h (4.8 mph)
Reverse-3rd Gear	Speed	21.3 km/h (13.2 mph)

<sup>1</sup>Travel speeds will vary with optional rear tires. Creeper assembly is optional.

Item	Measurement	Specification
Travel Speeds for PowrReverser™ Units at Full Engine RPM with 16.9— 30 R1 Rear Tire Types¹		
Creeper-1 Gear in Forward	Speed	0.24 km/h (0.15 mph)
Creeper-2 Gear in Forward	Speed	0.31 km/h (0.19 mph)
Creeper-3 Gear in Forward	Speed	0.40 km/h (0.25 mph)
Creeper-4 Gear in Forward	Speed	0.54 km/h (0.34 mph)
A-1 Gear in Forward	Speed	1.49 km/h (0.93 mph)
A-2 Gear in Forward	Speed	1.87 km/h (1.16 mph)
A-3 Gear in Forward	Speed	2.42 km/h (1.50 mph)
A-4 Gear in Forward	Speed	2.87 km/h (1.79 mph)
B-1 Gear in Forward	Speed	4.33 km/h (2.69 mph)
B-2 Gear in Forward	Speed	5.42 km/h (3.37 mph)
B-3 Gear in Forward	Speed	7.00 km/h (4.34 mph)
B-4 Gear in Forward	Speed	9.56 km/h (5.94 mph)
C-1 Gear in Forward	Speed	12.2 km/h (7.61 mph)
C-2 Gear in Forward	Speed	15.3 km/h (9.51 mph)
C-3 Gear in Forward	Speed	19.8 km/h (12.3 mph)
C-4 Gear in Forward	Speed	27.0 km/h (16.8 mph)
Creeper-1 Gear in Reverse	Speed	0.28 km/h (0.18 mph)
Creeper-2 Gear in Reverse	Speed	0.35 km/h (0.22 mph)
Creeper-3 Gear in Reverse	Speed	0.46 km/h (0.28 mph)
Creeper-4 Gear in Reverse	Speed	0.62 km/h (0.39 mph)

¹Travel speeds will vary with optional rear tires. Creeper assembly is optional.



## General Specifications

10  
10  
15

Item	Measurement	Specification
A-1 Gear in Reverse	Speed	1.72 km/h (1.07 mph)
A-2 Gear in Reverse	Speed	2.16 km/h (1.34 mph)
A-3 Gear in Reverse	Speed	2.79 km/h (1.74 mph)
A-4 Gear in Reverse	Speed	3.32 km/h (2.07 mph)
B-1 Gear in Reverse	Speed	5.01 km/h (3.11 mph)
B-2 Gear in Reverse	Speed	6.26 km/h (3.89 mph)
B-3 Gear in Reverse	Speed	8.10 km/h (5.04 mph)
B-4 Gear in Reverse	Speed	11.0 km/h (6.87 mph)
C-1 Gear in Reverse	Speed	14.2 km/h (8.80 mph)
C-2 Gear in Reverse	Speed	17.7 km/h (11.0 mph)
C-3 Gear in Reverse	Speed	22.9 km/h (14.2 mph)
C-4 Gear in Reverse	Speed	31.2 km/h (19.4 mph)

OUO1080,0000289 -19-23JUL02-3/3

## Machine Specifications—5510

### 5510 Tractor

Item	Measurement	Specification
Engine	Make	John Deere
	Type	Diesel
	Model	CD4045TLV50
	Aspiration	Turbocharged
	Horsepower	56 kW (75 hp)
	Rated Engine Speed	2400 rpm
	Number of Cylinders	4
	Displacement	4.5 L (274 cu in.)
	Bore and Stroke	106 x 127 mm (4.19 x 5.00 in.)
	Compression Ratio	17.0:1
	Fast Idle	2625 ± 25 rpm
	Slow Idle	825 ± 25 rpm
	Start Aid	Air heater
	Firing Order	1-3-4-2
	Timing	17° BTDC
	Lubrication	Pressurized
	Cooling	Liquid cooled
Fuel System	Air Cleaner	Dry type w/safety element
	Engine Shutoff	Key switch
Fuel System	Type	Direct injection
	Battery Size	700 cold cranking amps at -18°C
	Alternator	40 amp without cab 65 amp with cab
Drive Train	Transmission Type	CollarShift (standard)
		SyncShuttle™ (optional)
		PowrReverser™ (optional)
	Number of Speeds	9 Forward, 3 Reverse (SyncShuttle™)
		12 Forward, 12 Reverse (PowrReverser™)
Steering/Brakes	Final Drive	Planetary
	Clutch	Dual, dry
		Multi-disk, wet (PowrReverser™)
Steering/Brakes	Steering Brakes	Hydrostatic Power
		Wet Disk
		Self-equalizing
		Self-adjusting

Continued on next page

OUO1080,000028A -19-23JUL02-1/3

## General Specifications

10  
10  
17

Item	Measurement	Specification
Hydraulic System	Type	Open center
	Working Pressure	18995—19700 kPa (190—197 bar) (2755—2855 psi)
	Pump Type	Tandem gear
	Capacity	85 L/min (22.5 gpm)
	Hitch Lift Capacity at 610 mm (24 in.) Behind Hitch Balls	1530 kg (3374 lb)
	Lift Control Type	Position and depth
Rear PTO <sup>1</sup>	Type	Fully independent
	Horsepower	56 kW (75 hp)
	Speed (540 Standard Mode) @ 2400 rpm Engine Speed	540 rpm
	Speed (540E Economy Mode) @ 1700 rpm Engine Speed	540 rpm
Capacities	Fuel Tank (Open Station)	83 L (22 U.S. gal)
	Fuel Tank (Cab Tractors)	83 L (22 U.S. gal)
	Cooling System	10.8 L (11.4 U.S. qt)
	Engine Crankcase w/Filter	8.5 L (9 U.S. qt)
	Hydraulic System	41.8 L (11 U.S. gal)
	MFWD Wheel Hubs	0.6 L (0.63 U.S. qt)
	MFWD Axle Housing	5 L (5.3 U.S. qt)
<sup>1</sup> Economy Mode available only on SyncShuttle™ Transmission.		

Continued on next page

OUO1080,000028A -19-23JUL02-2/3

## General Specifications

Item	Measurement	Specification
Tires (Standard Equipment)	2WD Front	7.50—16 6PR F2
	2WD Rear	16.9—30 6PR R1
	MFWD Front	11.2—24 4PR R1
	MFWD Rear	16.9—30 6PR R1
Overall Dimensions (Standard Equipment) <sup>2</sup>	Drawbar Ground Clearance (2WD)	497.8 mm (19.6 in.)
	Drawbar Ground Clearance (MFWD)	3309.6 mm (130.3 in.)
	Front Axle Ground Clearance (2WD)	464.8 mm (18.3 in.)
	Front Axle Ground Clearance (MFWD)	391.1 mm (15.4 in.)
	Overall Length without Hitch, Drawbar and Weights (2WD)	3510.2 mm (138.2 in.)
	Overall Length without Hitch, Drawbar, and Weights (MFWD)	3510.2 mm (138.2 in.)
	Overall Width (2WD)	1744.9 mm (68.7 in.) maximum
	Overall Width (MFWD)	1744.9 mm (68.7 in.) maximum
	Height to Top of Steering Wheel	1696.7 mm (66.8 in.)
	Height to Top of ROPS (Add 4 Inches to Top of ROPS if Equipped with Canopy)	2481.5 mm (97.7 in.) extended
		2024.3 mm (79.7 in.) folded
	Height to Top of Cab from Center Line of Rear Axle	1844 mm (72.6 in.)
	Approximate Weight (2WD)	2599 kg (5730 lb)
	Approximate Weight (MFWD)	2785.1 kg (6140 lb)

<sup>2</sup>Weights will vary slightly with optional tires. Add 1000 lbs. to weight of tractor if equipped with cab.

OUO1080,000028A -19-23JUL02-3/3

**Travel Speeds—5510**

Item	Measurement	Specification
Travel Speeds for CollarShift or SyncShuttle™ Units at Full Engine RPM with 16.9—30 R1 Rear Tire Types		
Creeper-1 Gear in Forward	Speed	13.7 km/h (8.5 mph)
Creeper-2 Gear in Forward	Speed	19.8 km/h (12.3 mph)
Creeper-3 Gear in Forward	Speed	27.0 mph (16.7 mph)
A-1st Gear in Forward	Speed	2.1 km/h (1.3 mph)
A-2nd Gear in Forward	Speed	3.1 km/h (1.9 mph)
A-3rd Gear in Forward	Speed	4.2 km/h (2.6 mph)
B-1st Gear in Forward	Speed	4.9 km/h (3.1 mph)
B-2nd Gear in Forward	Speed	7.2 km/h (4.4 mph)
B-3rd Gear in Forward	Speed	9.8 km/h (6.1 mph)
C-1st Gear in Forward	Speed	13.7 km/h (8.5 mph)
C-2nd Gear in Forward	Speed	19.8 km/h (12.3 mph)
C-3rd Gear in Forward	Speed	27.0 km/h (16.7 mph)
Creeper-Reverse Gear	Speed	0.59 km/h (0.37 mph)
Reverse-1st Gear	Speed	0.35 km/h (0.25 mph)
Reverse-2nd Gear	Speed	0.51 km/h (0.32 mph)
Reverse-3rd Gear	Speed	0.70 km/h (0.43 mph)

Continued on next page

OUO1080,000028B -19-23JUL02-1/3

Item	Measurement	Specification
Travel Speeds for PowrReverser™ Units at Full Engine RPM with 16.9— 30 R1 Rear Tire Types¹		
Creeper-1 Gear in Forward	Speed	0.24 km/h (0.15 mph)
Creeper-2 Gear in Forward	Speed	0.31 km/h (0.19 mph)
Creeper-3 Gear in Forward	Speed	0.40 km/h (0.25 mph)
Creeper-4 Gear in Forward	Speed	0.54 km/h (0.34 mph)
A-1 Gear in Forward	Speed	1.49 km/h (0.93 mph)
A-2 Gear in Forward	Speed	1.87 km/h (1.16 mph)
A-3 Gear in Forward	Speed	2.42 km/h (1.50 mph)
A-4 Gear in Forward	Speed	2.87 km/h (1.79 mph)
B-1 Gear in Forward	Speed	4.33 km/h (2.69 mph)
B-2 Gear in Forward	Speed	5.42 km/h (3.37 mph)
B-3 Gear in Forward	Speed	7.00 km/h (4.34 mph)
B-4 Gear in Forward	Speed	9.56 km/h (5.94 mph)
C-1 Gear in Forward	Speed	12.2 km/h (7.61 mph)
C-2 Gear in Forward	Speed	15.3 km/h (9.51 mph)
C-3 Gear in Forward	Speed	19.8 km/h (12.3 mph)
C-4 Gear in Forward	Speed	27.0 km/h (16.8 mph)
Creeper-1 Gear in Reverse	Speed	0.28 km/h (0.18 mph)
Creeper-2 Gear in Reverse	Speed	0.35 km/h (0.22 mph)
Creeper-3 Gear in Reverse	Speed	0.46 km/h (0.28 mph)
Creeper-4 Gear in Reverse	Speed	0.62 km/h (0.39 mph)

¹Travel speeds will vary with optional rear tires. Creeper assembly is optional.


Item	Measurement	Specification
A-1 Gear in Reverse	Speed	1.72 km/h (1.07 mph)
A-2 Gear in Reverse	Speed	2.16 km/h (1.34 mph)
A-3 Gear in Reverse	Speed	2.79 km/h (1.74 mph)
A-4 Gear in Reverse	Speed	3.32 km/h (2.07 mph)
B-1 Gear in Reverse	Speed	5.01 km/h (3.11 mph)
B-2 Gear in Reverse	Speed	6.26 km/h (3.89 mph)
B-3 Gear in Reverse	Speed	8.10 km/h (5.04 mph)
B-4 Gear in Reverse	Speed	11.0 km/h (6.87 mph)
C-1 Gear in Reverse	Speed	14.2 km/h (8.80 mph)
C-2 Gear in Reverse	Speed	17.7 km/h (11.0 mph)
C-3 Gear in Reverse	Speed	22.9 km/h (14.2 mph)
C-4 Gear in Reverse	Speed	31.2 km/h (19.4 mph)

OUO1080,000028B -19-23JUL02-3/3

## Service Recommendations for O-Ring Boss Fittings

### Straight Fitting

1. Inspect O-ring boss seat for dirt or defects.
2. Lubricate O-ring with petroleum jelly. Place electrical tape over threads to protect O-ring. Slide O-ring over tape and into O-ring groove of fitting. Remove tape.
3. Tighten fitting to torque value shown on chart.



T6243AE -JUN-18OCT88

Continued on next page


04T,90,K66 -19-19MAR96-1/2

## Angle Fitting

1. Back-off lock nut (A) and back-up washer (B) completely to head-end (C) of fitting.
2. Turn fitting into threaded boss until back-up washer contacts face of boss.
3. Turn fitting head-end counterclockwise to proper index (maximum of one turn).

**NOTE:** Do not allow hoses to twist when tightening fittings.

4. Hold fitting head-end with a wrench and tighten locknut and back-up washer to proper torque value.



A—Lock Nut  
B—Washer  
C—Fitting

T6520AB -UN-18OCT88

**STRAIGHT FITTING OR SPECIAL NUT TORQUE CHART**

Thread Size	N•m	lb-ft
3/8-24 UNF	8	6
7/16-20 UNF	12	9
1/2-20 UNF	16	12
9/16-18 UNF	24	18
3/4-16 UNF	46	34
7/8-14 UNF	62	46
1-1/16-12 UN	102	75
1-3/16-12 UN	122	90
1-5/16-12 UN	142	105
1-5/8-12 UN	190	140
1-7/8-12 UN	217	160


**NOTE:** Torque tolerance is  $\pm 10\%$ .

04T,90,K66 -19-19MAR96-2/2



## Service Recommendations for Flat Face O-Ring Seal Fittings

1. Inspect the fitting sealing surfaces. They must be free of dirt or defects.
2. Inspect the O-ring. It must be free of damage or defects.
3. Lubricate O-rings and install into groove using petroleum jelly to hold in place.
4. Push O-ring into the groove with plenty of petroleum jelly so O-ring is not displaced during assembly.
5. Index angle fittings and tighten by hand pressing joint together to insure O-ring remains in place.
6. Tighten fitting or nut to torque value shown on the chart per dash size stamped on the fitting. Do not allow hoses to twist when tightening fittings.



T6243AD -UN-18OCT88

**FLAT FACE O-RING SEAL FITTING TORQUE**

Nominal Tube O.D.		Dash Size	Thread Size in.	Swivel Nut Torque		Bulkhead Nut Torque	
mm	in.	N•m	lb-ft	N•m	lb-ft		
6.35	0.250	-4	9/16-18	16	12	5.0	3.5
9.52	0.375	-6	11/16-16	24	18	9.0	6.5
12.70	0.500	-8	13/16-16	50	37	17.0	12.5
15.88	0.625	-10	1-14	69	51	17.0	12.5
19.05	0.750	-12	1 3/16-12	102	75	17.0	12.5
22.22	0.875	-14	1 3/16-12	102	75	17.0	12.5
25.40	1.000	-16	1 7/16-12	142	105	17.0	12.5
31.75	1.250	-20	1 11/16-12	190	140	17.0	12.5
38.10	1.500	-24	2-12	217	160	17.0	12.5

**NOTE:** Torque tolerance is +15 -20%.

04T,90,K67 -19-01AUG94-1/1


**Metric Cap Screw Torque Values—Grade 7**

*NOTE: When bolting aluminum parts, tighten to 80% of torque specified in table.*

Size	N•m	(lb-ft)
M6	9.5 - 12.2	(7-9)
M8	20.3 - 27.1	(15-20)
M10	47.5 - 54.2	(35-40)
M12	81.4 - 94.9	(60-70)
M14	128.8 - 146.4	(95-108)
M16	210.2 - 240	(155-177)

CED,OUO1085,12 -19-31JUL00-1/1

## Metric Bolt and Cap Screw Torque Values



Top, Property Class and Head Markings; Bottom, Property Class and Nut Markings

	Class 4.8		Class 8.8 or 9.8		Class 10.9		Class 12.9	
Size	Lubricated <sup>a</sup> N•m (lb-ft)	Dry <sup>b</sup> N•m (lb-ft)	Lubricated <sup>a</sup> N•m (lb-ft)	Dry <sup>b</sup> N•m (lb-ft)	Lubricated <sup>a</sup> N•m (lb-ft)	Dry <sup>b</sup> N•m (lb-ft)	Lubricated <sup>a</sup> N•m (lb-ft)	Dry <sup>b</sup> N•m (lb-ft)
M6	4.7 (3.5)	6 (4.4)	9 (6.6)	11.5 (8.5)	13 (9.5)	16.5 (12.2)	15.5 (11.5)	19.5 (14.5)
M8	11.5 (8.5)	14.5 (10.7)	22 (16)	28 (20.5)	32 (23.5)	40 (29.5)	37 (27.5)	47 (35)
M10	23 (17)	29 (21)	43 (32)	55 (40)	63 (46)	80 (59)	75 (55)	95 (70)
M12	40 (29.5)	50 (37)	75 (55)	95 (70)	110 (80)	140 (105)	130 (95)	165 (120)
M14	63 (46)	80 (59)	120 (88)	150 (110)	175 (130)	220 (165)	205 (150)	260 (190)
M16	100 (74)	125 (92)	190 (140)	240 (175)	275 (200)	350 (255)	320 (235)	400 (300)
M18	135 (100)	170 (125)	265 (195)	330 (245)	375 (275)	475 (350)	440 (325)	560 (410)
M20	190 (140)	245 (180)	375 (275)	475 (350)	530 (390)	675 (500)	625 (460)	790 (580)
M22	265 (195)	330 (245)	510 (375)	650 (480)	725 (535)	920 (680)	850 (625)	1080 (800)
M24	330 (245)	425 (315)	650 (480)	820 (600)	920 (680)	1150 (850)	1080 (800)	1350 (1000)
M27	490 (360)	625 (460)	950 (700)	1200 (885)	1350 (1000)	1700 (1250)	1580 (1160)	2000 (1475)
M30	660 (490)	850 (625)	1290 (950)	1630 (1200)	1850 (1350)	2300 (1700)	2140 (1580)	2700 (2000)
M33	900 (665)	1150 (850)	1750 (1300)	2200 (1625)	2500 (1850)	3150 (2325)	2900 (2150)	3700 (2730)
M36	1150 (850)	1450 (1075)	2250 (1650)	2850 (2100)	3200 (2350)	4050 (3000)	3750 (2770)	4750 (3500)

<sup>a</sup> "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings.

<sup>b</sup> "Dry" means plain or zinc plated without any lubrication.

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.


Fasteners should be replaced with the same or higher property class. If higher property class fasteners are used, these should only be tightened to the strength of the original.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical property class.

Make sure fastener threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

# Unified Inch Bolt and Cap Screw Torque Values



Top, SAE Grade and Head Markings; Bottom, SAE Grade and Nut Markings

Size	Grade 1 (No Mark)		Grade 2 <sup>a</sup> (No Mark)		Grade 5, 5.1 or 5.2		Grade 8 or 8.2	
	Lubricated <sup>b</sup> N•m (lb-ft)	Dry <sup>c</sup> N•m (lb-ft)	Lubricated <sup>b</sup> N•m (lb-ft)	Dry <sup>c</sup> N•m (lb-ft)	Lubricated <sup>b</sup> N•m (lb-ft)	Dry <sup>c</sup> N•m (lb-ft)	Lubricated <sup>b</sup> N•m (lb-ft)	Dry <sup>c</sup> N•m (lb-ft)
1/4	3.8 (2.8)	4.7 (3.5)	6 (4.4)	7.5 (5.5)	9.5 (7)	12 (9)	13.5 (10)	17 (12.5)
5/16	7.7 (5.7)	9.8 (7.2)	12 (9)	15.5 (11.5)	19.5 (14.5)	25 (18.5)	28 (20.5)	35 (26)
3/8	13.5 (10)	17.5 (13)	22 (16)	27.5 (20)	35 (26)	44 (32.5)	49 (36)	63 (46)
7/16	22 (16)	28 (20.5)	35 (26)	44 (32.5)	56 (41)	70 (52)	80 (59)	100 (74)
1/2	34 (25)	42 (31)	53 (39)	67 (49)	85 (63)	110 (80)	120 (88)	155 (115)
9/16	48 (35.5)	60 (45)	76 (56)	95 (70)	125 (92)	155 (115)	175 (130)	220 (165)
5/8	67 (49)	85 (63)	105 (77)	135 (100)	170 (125)	215 (160)	240 (175)	305 (225)
3/4	120 (88)	150 (110)	190 (140)	240 (175)	300 (220)	380 (280)	425 (315)	540 (400)
7/8	190 (140)	240 (175)	190 (140)	240 (175)	490 (360)	615 (455)	690 (510)	870 (640)
1	285 (210)	360 (265)	285 (210)	360 (265)	730 (540)	920 (680)	1030 (760)	1300 (960)
1-1/8	400 (300)	510 (375)	400 (300)	510 (375)	910 (670)	1150 (850)	1450 (1075)	1850 (1350)
1-1/4	570 (420)	725 (535)	570 (420)	725 (535)	1280 (945)	1630 (1200)	2050 (1500)	2600 (1920)
1-3/8	750 (550)	950 (700)	750 (550)	950 (700)	1700 (1250)	2140 (1580)	2700 (2000)	3400 (2500)
1-1/2	990 (730)	1250 (930)	990 (730)	1250 (930)	2250 (1650)	2850 (2100)	3600 (2650)	4550 (3350)

<sup>a</sup> Grade 2 applies for hex cap screws (not hex bolts) up to 6 in. (152 mm) long. Grade 1 applies for hex cap screws over 6 in. (152 mm) long, and for all other types of bolts and screws of any length.

<sup>b</sup> "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings.

<sup>c</sup> "Dry" means plain or zinc plated without any lubrication.

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Make sure fastener threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

## Abbreviations

*NOTE: Abbreviations are used in place of some words.*

- CTM—Component Technical Manual
- ID—Inside Diameter
- OD—Outside Diameter
- SCV—Selective Control Valve
- MFWD—Mechanical Front-Wheel Drive
- PTO—Power Take-Off
- SMV—Slow Moving Vehicle
- CS—CollarShift
- POW REV—PowrReverser™
- SS—SyncShuttle™

AG.OUO1085,13 -19-31JUL00-1/1

10  
10  
28

## Diesel Fuel Specifications

Use either Grade No. 1-D or Grade No. 2-D fuel as defined by ASTM Designation D975 for diesel fuels. Find expected air temperature at time of start on thermometer scale in chart. Correct diesel fuel grade is shown to the right of scale.


**NOTE:** At altitudes above 1500 m (5000 ft) use grade 1-D for all temperatures.

Fuel sulphur content should be less than 1.0 percent, preferably less than 0.5 percent. Diesel fuel having sulphur content higher than 1.0 percent may cause increase wear on metal engine parts because of acids produced by sulphur during combustion.

**IMPORTANT:** If fuel sulphur content exceeds 0.7 percent, the engine oil drain interval must be reduced by 50 percent to 125 hours.

Cetane number should be no less than 40 to assure satisfactory starting and overall performance.

Cloud point should be at least -12°C (10°F) below lowest expected air temperature at time of starting. Wax can separate from fuel when temperature decreases to cloud point and may plug filter.



E20380 -19-13MAR89

AG,OUO1085,14 -19-31JUL00-1/1

## Storing Fuel

If there is a very slow turnover of fuel in the fuel tank or supply tank, it may be necessary to add a fuel conditioner to prevent water condensation. Contact your John Deere dealer for proper service or maintenance recommendations.

DX,FUEL -19-03MAR93-1/1

## Do Not Use Galvanized Containers

**IMPORTANT:** Diesel fuel stored in galvanized containers reacts with zinc coating on the container to form zinc flakes. If fuel contains water, a zinc gel will also form. The gel and flakes will quickly plug fuel filters and damage fuel injectors and fuel pumps.

DO NOT USE a galvanized container to store diesel fuel.

Store fuel in:

- plastic containers.
- aluminum containers.
- specially coated steel containers made for diesel fuel.

DO NOT USE brass-coated containers: brass is an alloy of copper and zinc.

M21,FLQ,B1 -19-02AUG85-1/1

## Fill Fuel Tank

**CAUTION:** Handle fuel carefully. Do not refuel the machine while smoking or when near open flame or sparks.

Always stop engine before refueling machine.

Fill fuel tank at end of each day's operation. Fill fuel tank only to bottom of filler neck.

### Specification

5210, 5310 and 5410 Fuel Tank—Capacity .....	68 L (18.0 U.S. gal)
5510 and All Tractors with Cab Fuel Tank—Capacity .....	83 L (22.0 U.S. gal)

**IMPORTANT:** The fuel tank uses a sealed filler cap. If a new filler cap is required, always replace it with a sealed cap.



TS202 -UN-23AUG88



LV095 -UN-21NOV91

OUC1043,0000E90 -19-24JUN02-1/1



## Diesel Engine Oil

Use oil viscosity based on the expected air temperature range during the period between oil changes.

The following oil is preferred:

- John Deere PLUS-50®

The following oil is also recommended:

- John Deere TORQ-GARD SUPREME®


Other oils may be used if they meet one or more of the following:

- API Service Classification CH-4
- API Service Classification CG-4
- API Service Classification CF-4
- ACEA Specification E3
- ACEA Specification E2

### Multi-viscosity diesel engine oils are preferred.

If diesel fuel with sulfur content greater than 0.5% is used, reduce the service interval by 50%.

Extended service intervals may apply when John Deere preferred engine oils are used. Consult your John Deere dealer for more information.



*PLUS-50 is a registered trademark of Deere & Company.*

*TORQ-GARD SUPREME is a registered trademark of Deere & Company*

DX,ENOIL -19-24JAN00-1/1

## Diesel Engine Coolant

The engine cooling system is filled to provide year-round protection against corrosion and cylinder liner pitting, and winter freeze protection to -37°C (-34°F).

### John Deere COOL-GARD

The following engine coolant is preferred for service:

- John Deere COOL-GARD Prediluted Coolant

The following engine coolant is also recommended:

- John Deere COOL-GARD Coolant Concentrate in a 40 to 60% mixture of concentrate with quality water.

John Deere COOL-GARD coolants do not require use of supplemental coolant additives, except for periodic replenishment of additives during the drain interval.

### Ethylene glycol base coolants

Other fully formulated low silicate ethylene or propylene glycol base coolants for heavy-duty engines may be used if they meet one of the following specifications:

- ASTM D6210 prediluted coolant
- ASTM D6210 coolant concentrate in a 40 to 60% mixture of concentrate with quality water

Coolants meeting ASTM D6210 do not require use of supplemental coolant additives, except for periodic replenishment of additives during the drain interval.

Other low silicate ethylene glycol base coolants for heavy-duty engines may also be used if they meet one of the following specifications:

- ASTM D5345 prediluted coolant
- ASTM D4985 coolant concentrate in a 40 to 60% mixture of concentrate with quality water

Coolants meeting ASTM D5345 or ASTM D4985 require an initial charge of supplemental coolant

additives, formulated for protection of heavy duty diesel engines against corrosion and cylinder liner erosion and pitting. They also require periodic replenishment of additives during the drain interval.

### Propylene glycol base coolants

Fully formulated low silicate propylene glycol base coolants for heavy-duty engines may be used if they meet one of the following specifications:

- ASTM D6211 prediluted coolant
- ASTM D6211 coolant concentrate in a 40 to 60% mixture of concentrate with quality water

Coolants meeting ASTM D6211 do not require use of supplemental coolant additives, except for periodic replenishment during the drain interval.

### Freeze protection

A 50% mixture of ethylene glycol engine coolant in water provides freeze protection to -37°C (-34°F).

A 50% mixture of propylene glycol engine coolant in water provides freeze protection to -33°C (-27°F).

If protection at lower temperatures is required, consult your John Deere dealer for recommendations.

### Water quality

Water quality is important to the performance of the cooling system. Distilled, deionized, or demineralized water is recommended for mixing with ethylene glycol and propylene glycol base engine coolant concentrate.

**IMPORTANT: Do not use cooling system sealing additives or antifreeze that contains sealing additives.**

**IMPORTANT: Do not mix ethylene glycol and propylene glycol base coolants.**

## Liquid Coolant Conditioner

John Deere Liquid Coolant Conditioner is recommended for wet-sleeve diesel engines not having a coolant filter option. Other conditioners may be used if it contains non-chromate inhibitors.

**IMPORTANT:** If engine is equipped with a John Deere Coolant Filter Conditioner, the correct inhibitors are contained in the filter. If both are used, a gel-type deposit is created which could inhibit heat transfer and block coolant flow. John Deere Liquid Coolant Conditioner does not protect against freezing.

Various sizes of coolant conditioners are available from your John Deere dealer.



RG4690 -UN-14DEC88

DX,COOL1 -19-04JUN90-1/1

## Transmission and Hydraulic Oil

Use oil viscosity based on the expected air temperature range during the period between oil changes.

The following oils are preferred:


- John Deere HY-GARDHY-GARD®
- John Deere Low Viscosity HY-GARDHY-GARD®

Other oils may be used if they meet one of the following:

- John Deere Standard JDM J20C
- John Deere Standard JDM J20D

Use the following oil when a biodegradable fluid is required:

- John Deere BIO-HY-GARD™<sup>1</sup>



HY-GARD is a registered trademark of Deere & Company.  
BIO-HY-GARD is a trademark of Deere & Company.

<sup>1</sup>BIO-HY-GARD meets or exceeds the minimum biodegradability of 80% within 21 days according to CEC-L-33-T-82 test method. BIO-HY-GARD should not be mixed with mineral oils because this reduces the biodegradability and makes proper oil recycling impossible.

DX,ANTI -19-10OCT97-1/1

## MFWD Gear Oil


Use oil viscosity based on the expected air temperature range during the period between oil changes.

John Deere GL-5 Gear Lubricant is recommended.

Other oils may be used if they meet one or more of the following:

- API Service Classification GL-5
- Military Specification MIL-L-2105D
- Military Specification MIL-L-2105C
- Military Specification MIL-L-2105B

Oils meeting Military Specification MIL-L-10324A may be used as arctic oils.



TS245 -19-28NOV90

LV,1020HA,A3 -19-19JAN95-1/1

## Grease (Specific Application)

Lithium Grease with Molybdenum Disulphide is recommended for use on internal components of transmission.

TY6333 or TY6347 John Deere Moly High Temperature EP Grease is recommended for use on the traction clutch and PTO clutch splines.

LV,1020HA,A4 -19-27JUN94-1/1

## Grease

Use grease based on NLGI consistency numbers and the expected air temperature range during the service interval.

The following greases are preferred:

- John Deere SD POLYUREA GREASE


The following greases are also recommended:

- John Deere HD MOLY GREASE
- John Deere HD LITHIUM COMPLEX GREASE
- John Deere HD WATER RESISTANT GREASE
- John Deere GREASE-GARD

Other greases may be used if they meet the following:

- NLGI Performance Classification GC-LB

**IMPORTANT:** Some types of grease thickener are not compatible with others. Consult your grease supplier before mixing different types of grease.



TS1667 -UN-30JUN99

DX,GREA1 -19-24JAN00-1/1

## Alternative and Synthetic Lubricants

Conditions in certain geographical areas may require lubricant recommendations different from those printed in this manual.

Some John Deere brand coolants and lubricants may not be available in your location.

Consult your John Deere dealer to obtain information and recommendations.

Synthetic lubricants may be used if they meet the performance requirements as shown in this manual.

The temperature limits and service intervals shown in this manual apply to both conventional and synthetic oils.

Re-refined base stock products may be used if the finished lubricant meets the performance requirements.

DX,ALTER -19-15JUN00-1/1

## Lubricant Storage

Your equipment can operate at top efficiency only when clean lubricants are used.

Use clean containers to handle all lubricants.

Whenever possible, store lubricants and containers in an area protected from dust, moisture, and other contamination. Store containers on their side to avoid water and dirt accumulation.

Make certain that all containers are properly marked to identify their contents.

Properly dispose of all old containers and any residual lubricant they may contain.

DX,LUBST -19-18MAR96-1/1





## Serial Numbers

When working on machines or components that are covered by warranty, it is IMPORTANT that you include the machine's Product Identification Number and the component serial number on the warranty claim form.

The location of component serial number plates are shown below.

MX,1025FT,A4 -19-15JAN91-1/1

## Product Identification Number Location

The machine's product identification number plate (A) is located on the right-hand side of the front support.

**A—Product Identification Number Plate**




LV093 -UN-21NOV91

AG,OUO1085,16 -19-31JUL00-1/1

## Engine Serial Number Location

The engine serial number plate (A) is located on the right-hand side of the engine block, between the starter and the hydraulic pump.

**A—Engine Serial Number Plate**




LV094 -UN-21NOV91

OUO1043,0000E91 -19-24JUN02-1/1

## Fuel Injection Pump Serial Number Location

The fuel injection pump serial number plate (A) is located on the side of the pump.

**A—Fuel Injection Serial Number Plate**



LV2245 -UN-02JUL97

AG,OUO1085,18 -19-31JUL00-1/1

## Alternator Serial Number Location

The alternator serial number plate (A) is located on the side of the housing.

A—Alternator Serial Number Plate



LV097 -UN-21NOV91

AG,OUO1085,19 -19-31JUL00-1/1

## Power Steering Valve Serial Number Location

The power steering valve serial number plate (A) is located on the bottom of the valve.

A—Power Steering Valve Serial Number Plate




LV098 -UN-21NOV91

AG,OUO1032,2849 -19-18JAN00-1/1

## Starter Serial Number Location

The starter serial number plate (A) is located on the side of the starter housing.

A—Starter Serial Number Location




LV472 -UN-25FEB92

OUO1043,0000E92 -19-24JUN02-1/1

## Transmission Serial Number Location

The transmission (drive train) serial number (A) is located at the rear of the machine on the bottom left-hand corner of the differential housing.

A—Transmission Serial Number




LV629 -UN-17JUN94

AG,OUO1085,21 -19-31JUL00-1/1

## Front Axle (2WD) Serial Number Location

The 2WD front axle serial number plate (A) is located on the rear right-hand side of the axle.

A—Front Axle Serial Number Plate




AG,OUO1085,22 -19-31JUL00-1/1

10  
25  
3

## Mechanical Front Wheel Drive (MFWD) Serial Number Location

The MFWD serial number plate (A) is located on the rear side of the right-hand axle housing.

A—MFWD Serial Number Plate




AG,OUO1085,23 -19-31JUL00-1/1

## Air Conditioning Compressor Serial Number Location

The air conditioning compressor serial number plate (A) is located on the rear of the housing.

A—Air Conditioning Compressor Serial Number Plate



AG,OUO1085,24 -19-31JUL00-1/1



## **Features and Accessories**

The information covered in this group pertains to the features of the machines covered in this Technical Manual. It can be used in addition to the normal advertising literature or may help in determining which specific feature requires service. A list of all the available accessories and kits is also included.

LV,1030HA,A2 -19-07MAY96-1/1

10  
30  
1

**Standard Features—5210 and 5310**

- John Deere 3000 Series Engine
  - 5210 CD3029DLV50 40 kw (53 hp)
  - 5310 CD3029TLV50 47 kw (63 hp)
  - 3-cylinder diesel engine
  - Wet sleeved
  - Direct injection
  - Intake air heater starting aid
  - Key switch controlled fuel shut-off
  - 5210 is naturally aspirated
  - 5310 is turbocharged
- CollarShift Transmission
  - Nine speeds forward, three reverse
  - Inboard planetary final drives
  - Differential lock
- Dual Clutch
  - Provides continuous live PTO
  - Stops tractor without disengaging PTO
- PTO
  - Rear, 540 rpm
  - 540/540E PTO available on SyncShuttle™ transmission only
  - Fully independent clutch
- Hydrostatic Power Steering
  - Power is supplied by a tandem gear hydraulic pump mounted to the engine
- Hydraulic Brakes
  - Wet disc
  - Individually hydraulic controlled
  - Self-adjusting
  - Self-equalizing
- Open-Center Hydraulic System
  - Tandem gear hydraulic pumps
  - Pumps are driven directly off engine timing gears

The rear pump supplies oil to the power steering, provides brake valve make-up oil and lubricates top shaft of the transmission.

The front pump supplies oil to the rockshaft and the selective control valves, if equipped.



LV1886

Model 5210

LV1886 –UN-01JUL97



LV1887

Model 5310

LV1887 –UN-01JUL97



**Standard Features—5410 and 5510**

- John Deere 4000 Series Engine
  - 5410 CD4045DLV50 56 kw (75 hp)
  - 5510 CD4045TLV50 63 kw (85 hp)
  - 4-cylinder diesel engine
  - Wet sleeved
  - Direct injection
  - Intake air heater starting aid
  - Key switch controlled fuel shut-off
  - 5410 is naturally aspirated
  - 5510 is turbocharged
- CollarShift Transmission
  - Nine speeds forward, three reverse
  - Inboard planetary final drives
  - Differential lock
- Dual Clutch
  - Provides continuous live PTO
  - Stops tractor without disengaging PTO
- PTO
  - Rear, 540 rpm
  - 540/540E PTO available on SyncShuttle™ transmission only
  - Fully independent clutch
- Hydrostatic Power Steering
  - Power is supplied by a tandem gear hydraulic pump mounted to the engine
- Tilt Steering Wheel
- Hydraulic Brakes
  - Wet disc
  - Individually hydraulic controlled
  - Self-adjusting
  - Self-equalizing
- Open-Center Hydraulic System
  - Tandem gear hydraulic pumps
  - Pumps are driven directly off engine timing gears

The rear pump supplies oil to the power steering, provides brake valve make-up oil and lubricates top shaft of the transmission.

The front pump supplies oil to the rockshaft and the selective control valves, if equipped.



LV1888

Model 5410

LV1888 –UN-01JUL97



LV1890

Model 5510

LV1890 –UN-01JUL97



Tilt Steering Wheel

LV1891 –UN-09JUN97

## Standard Features—5210 through 5510

- Standard Adjustable Front Axle
- Hitch
  - Category II, convertible to category I
  - Position and draft control levers
- PTO Warning System
  - Warning horn sounds for 8—10 seconds when operator leaves seat with PTO engaged. Engine and PTO continue to run.
- Two-Post Foldable ROPS with Seat Belt
  - Protects operator in the event of a tip-over



*Adjustable Front Axle*

LV1892 –UN–09JUN97



*Foldable ROPS*

LV1893 –UN–09JUN97

AG,OUO1085,27 –19–31JUL00–1/1




## Factory Installed Optional Equipment (5210—5510)

- Mechanical Front Wheel Drive (MFWD) Axle
  - Center line design
  - Limited slip differential
  - High pivot point for better ground clearance and axle oscillation
- SyncShuttle™ Transmission
  - Nine speeds forward, three reverse
  - Synchronized forward to reverse shift
- PowrReverser™ Transmission
  - 12 speeds forward, 12 reverse
  - Hydraulic forward to reverse shift
- Telescopic Draft Links
- Dual Selective Control Valve (SCV)
  - One lever “joystick” control
  - Float and regenerative spool values
- Weather Enclosure (Cab)
  - Left-hand exterior mirror
  - Sun visor
  - Cup holder
- Rear Work Light
- Cold Weather Package
  - 900 CCA Battery
  - Engine Coolant Heater
  - Heavy-Duty Intake Heater



*Mechanical Front Wheel Drive*



LV1895

*MFWD Front Fender*



LV2219

*Cab Tractor*

AG.OUO1085,28 -19-31JUL00-1/1


LV1894 -UN-09JUN97

LV1895 -UN-01JUL97

LV2219 -UN-08AUG97

## Field Installed Optional Kits and Accessories—5210 Through 5510

- Dual selective control valve (SCV)
  - One lever “joystick” control
  - Float and regenerative spool values
- Single (third) selective control valve
  - Single lever operation
- Creeper gear kit
- Front drive shaft coupler
- Horizontal rear exhaust extension
- Seat arm rests
- Single horn
- 7-pin electrical outlet socket
- Soft weather enclosure
- Front weight bracket and weights
- FOPS canopy
- Deluxe canopy
- Narrow front axle kit (2WD only)
- Interchangeable, category 2-to-category 1 hitch balls
- Work lights for tractors without fender mounted lights
- Larger tool box
- Available for factory installed cab
  - Right-hand exterior mirror
  - Rear wiper and windshield washer
  - Sun visor
  - AM and FM radio with speakers and antenna
- Cold Weather Package
  - 900 CCA Battery
  - Engine Coolant Heater
  - Heavy-Duty Intake Heater



LV1896 –UN-09JUN97

*Front Weight Bracket and Weights*



LV1897 –UN-01JUL97

LV1897

*Deluxe Canopy*

AG,OUO1085,29 –19-02AUG00-1/1

# Section 20

## Engine Repair

### Contents

#### Page

#### Group 05—Engine

Service Equipment and Tools . . . . .	20-05-1
Specifications . . . . .	20-05-2
John Deere Engine Repair—Use CTM104 or CTM125. . . . .	20-05-2
Remove Engine—Tractors without Cab. . . . .	20-05-3
Install Engine—Tractors without Cab. . . . .	20-05-9
Remove Engine—Tractors with Cab . . . . .	20-05-14
Install Engine—Tractors with Cab . . . . .	20-05-22

#### Group 10—Cooling System

Specifications . . . . .	20-10-1
Engine Water Pump Repair—Use CTM104 or CTM125. . . . .	20-10-1
Remove and Inspect Radiator. . . . .	20-10-2
Install Radiator . . . . .	20-10-5
Replace Thermostat . . . . .	20-10-8
Inspect and Replace Belt Tensioner— Models 5410 and 5510 . . . . .	20-10-10



Service Equipment and Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.

SERVICEGARD is a trademark of Deere & Company

OUC1089,0000244 -19-25JUN02-1/3

Lifting Bracket . . . . . JDG19

Used to remove and install engine.

OUC1089,0000244 -19-25JUN02-2/3

Lifting Bracket . . . . . JT01748

Used to remove and install engine.

OUC1089,0000244 -19-25JUN02-3/3

## Specifications


Item	Measurement	Specification
<b>3-Cylinder Engine (Tractors without Cab)</b>		
Engine-to-Clutch Housing Cap Screws	Torque	300 N•m (225 lb-ft)
Engine-to-Clutch Housing Nuts	Torque	300 N•m (225 lb-ft)
<b>4-Cylinder Engine (Tractors without Cab)</b>		
Engine-to-Clutch Housing Cap Screws	Torque	350 N•m (255 lb-ft)
Engine-to-Clutch Housing Nuts	Torque	350 N•m (255 lb-ft)
<b>3- and 4-Cylinder Engines (Tractors with Cab)</b>		
Engine-to-Clutch Housing Cap Screws	Torque	318 N•m (235 lb-ft)
Engine-to-Clutch Housing Nuts	Torque	318 N•m (235 lb-ft)
Front End Support-to-Engine Upper Cap Screws and Nuts	Torque	305 N•m (225 lb-ft)
Front End Support-to-Engine Lower Cap Screws	Torque	176 N•m (130 lb-ft)

OUO1089,0000247 -19-25JUN02-1/1

## John Deere Engine Repair—Use CTM104 or CTM125

For complete repair information the component technical manual (CTM) is also required. Use the component technical manual in conjunction with this machine manual.

- 3-cylinder 2.9 L engines—Use CTM125
- 4-cylinder 4.5 L engines—Use CTM104



TS225 -UN-17JAN89

AG,OUO1085,30 -19-02AUG00-1/1


## Remove Engine—Tractors without Cab

1. Remove hood from tractor.
2. Remove radiator. (See Remove and Inspect Radiator in Group 10.)
3. Remove battery. (See Remove and Install Battery—Tractors Without Cab in Section 40, Group 05.)
4. Remove fuel filter/primer pump. (See Remove and Install Fuel Filter/Primer Pump Assembly—5210 and 5310 or Remove and Install Fuel Filter/Primer Pump Assembly—5410 and 5510 in Section 30, Group 05.)
5. Remove MFWD drive shaft, if equipped. (See Remove, Inspect and Install MFWD Drive Shaft in Section 50, Group 35.)

**NOTE:** Close all openings using caps and plugs.

*Support suction line (C). Transmission/hydraulic oil will spill out of hose if line drops below transmission/reservoir oil level.*

6. Disconnect hydraulic lines (A, B, and C) from pump.
7. Loosen hydraulic lines retaining clamp under right-side floor and step plate and move lines away from engine.



A—Hydraulic Pump-to-Inlet Housing Line  
B—Hydraulic Pump-to-Steering Valve Line  
C—Suction Line

LV2289 -JUN-16DEC97


Continued on next page

AG.OUO1085,31 -19-25JUN02-1/8

20  
05  
3

8. Tractors equipped with 4-cylinder engines, remove four cap screws (A).
9. Remove oil filter and bracket (B).
10. Remove oil tubes (C and D) from engine oil cooler manifold.

A—Cap Screw (4 used)  
B—Oil Filter and Bracket  
C—Oil Tube  
D—Oil Tube



Continued on next page


AG,OUO1085,31 -19-25JUN02-2/8




*NOTE: Cut all tie straps as necessary.*

11. Disconnect two main harness wiring connectors (A and B).
12. Disconnect fuel return hose (C).
13. Disconnect red wire lead #002C from right-side post (D) of fuse link junction block.


A—Wiring Connector  
 B—Wiring Connector  
 C—Fuel Return Line  
 D—Right-Side Post (At Fuse Link Junction Block)



LV2290 -UN-16DEC97



LV2291 -UN-18DEC97




LV2293 -UN-16DEC97

Continued on next page

AG,OUO1085,31 -19-25JUN02-3/8

14. Disconnect hydraulic steering lines (A and B).
15. Remove clamps (C and D).
16. Disconnect hydraulic oil cooler lines (E and F).
17. Remove throttle control rod (G).

A—Hydraulic Steering Line  
 B—Hydraulic Steering Line  
 C—Clamp  
 D—Clamp  
 E—Hydraulic Oil Cooler Line  
 F—Hydraulic Oil Cooler Line  
 G—Throttle Control Rod



LV2292 -UN-16DEC97

AG,OUO1085,31 -19-25JUN02-4/8

**CAUTION:** Front weights and bracket must be removed from tractor before removing any frame-to-engine mounting hardware.

18. Remove front weights and bracket, if equipped.
19. Install lifting brackets such as JDG19 or JT01748 Lifting Brackets.
20. Install a support stand under clutch housing.
21. Attach a hoist to engine.
22. Install a floor jack under front axle.
23. Install a wood block between front axle and frame on both sides.




LV213 -UN-25FEB92

Continued on next page

AG,OUO1085,31 -19-25JUN02-5/8

24. Pull battery cable (B) through grommet.
25. Disconnect ground cable (D).
26. Disconnect wiring connectors (A) at headlights.
27. Pull wiring harness (C) through grommet.

A—Headlight Wiring Connectors  
 B—Positive (+) Battery Cable  
 C—Wiring Harness  
 D—Ground Cable




LV2294 -UN-16DEC97

AG,OUO1085,31 -19-25JUN02-6/8

28. Remove front end support-to-engine cap screws (A and B) and nut (C) from each side of frame.
29. Roll front end away from tractor.

A—Cap Screw  
 B—Cap Screw  
 C—Nut



LV2295 -UN-16DEC97

Continued on next page

AG,OUO1085,31 -19-25JUN02-7/8



30. Remove engine-to-clutch housing cap screws (A) and nuts and washers (B).


31. Remove engine.

32. Remove clutch. (See Remove and Install Clutch Assembly in Section 50, Group 10 for CollarShift/SyncShuttle™ Transmission or Remove and Install Clutch Assembly in Section 50, Group 11 for PowrReverser™ Transmission.)

33. Make repairs as necessary. (See CTM104 or CTM125.)

A—Cap Screw

B—Nut and Washer



LV2333 -UN-16DEC97

AG,OUO1085,31 -19-25JUN02-8/8

## Install Engine—Tractors without Cab

1. Install clutch. (See Remove and Install Clutch Assembly in Section 50, Group 10 for CollarShift/SyncShuttle™ Transmission or Remove and Install Clutch Assembly in Section 50, Group 11 for PowrReverser™ Transmission.)

**NOTE:** Turning PTO shaft at rear of tractor during engine installation will aid in alignment of PTO clutch and shaft.


2. Put transmission shift levers in neutral to ease clutch shaft alignment with engine.
3. Apply multipurpose grease to end of PTO clutch shaft.
4. Install engine to clutch housing.
5. Install engine-to-clutch housing cap screws (A) and nuts and washers (B). Tighten to specifications below.

### 3-Cylinder Engine—Specification

Engine-to-Clutch Housing Cap	
Screws—Torque .....	300 N•m (225 lb-ft)
Engine-to-Clutch Housing Nuts—	
Torque .....	300 N•m (225 lb-ft)

### 4-Cylinder Engine—Specification

Engine-to-Clutch Housing Cap	
Screws—Torque .....	350 N•m (255 lb-ft)
Engine-to-Clutch Housing Nuts—	
Torque .....	350 N•m (255 lb-ft)



A—Cap Screw  
B—Nut and Washer

LV2333 -UN-16DEC97

Continued on next page

AG,OUO1085,32 -19-25JUN02-1/7


**NOTE:** Hollow dowels are installed in bores of cap screws (B).

6. Align studs in engine with front end. Install front end to tractor. Tighten front end support-to-engine cap screws (A and B) and nuts (C) to specifications.

#### Specification

Front End Support-to-Engine	
Upper Cap Screws and Nuts—	
Torque .....	305 N•m (225 lb-ft)
Front End Support-to-Engine	
Lower Cap Screws—Torque .....	176 N•m (130 lb-ft)

A—Cap Screw  
B—Cap Screw  
C—Nut




LV2295 -UN-16DEC97

AG,OUO1085,32 -19-25JUN02-2/7

7. Pull wiring harness (C) and cable (B) through grommets.
8. Connect wiring connectors (A).
9. Connect ground cable (D).
10. Remove wood blocks, floor jack, support stands, and lifting brackets.
11. Install muffler and exhaust pipe.

A—Headlight Wiring Connector  
B—Positive (+) Battery Cable  
C—Wiring Harness  
D—Ground Cable




LV2294 -UN-16DEC97

Continued on next page


AG,OUO1085,32 -19-25JUN02-3/7

12. Connect wiring connectors (A and B).
13. Connect fuel return hose (C).
14. Connect red wire lead #002C on right-side post (D) of fuse link junction block.


A—Wiring Connector  
 B—Wiring Connector  
 C—Fuel Return Hose  
 D—Right-Side Post



LV2290 -UN-16DEC97



LV2291 -UN-18DEC97



LV2293 -UN-16DEC97


Continued on next page

AG,OUO1085,32 -19-25JUN02-4/7



15. Connect hydraulic steering lines (A and B).
16. Connect oil cooler lines (E and F).
17. Install clamps (C and D).
18. Install throttle control rod (G).

A—Hydraulic Steering Line  
 B—Hydraulic Steering Line  
 C—Clamp  
 D—Clamp  
 E—Oil Cooler Line  
 F—Oil Cooler Line  
 G—Throttle Control Rod




LV2292 -UN-16DEC97

AG,OUO1085,32 -19-25JUN02-5/7

**NOTE:** Install high mount oil filter, if equipped.

19. Install oil tubes (C and D) into engine oil cooler manifold.
20. Install oil filter and bracket (B).
21. Install four cap screws (A).

A—Cap Screw (4 used)  
 B—Oil Filter and Bracket  
 C—Oil Tube  
 D—Oil Tube




LV2332 -UN-16DEC97

Continued on next page

AG,OUO1085,32 -19-25JUN02-6/7



22. Install lines (A and B).
23. Connect suction line (C).
24. Install hydraulic line support clamp under right-side floor plate.
25. Install MFWD drive shaft, if equipped. (See Remove, Inspect and Install MFWD Drive Shaft in Section 50, Group 35.)
26. Install fuel filter/primer pump. (See Remove and Install Fuel Filter/Primer Pump Assembly—5210 and 5310 or Remove and Install Fuel Filter/Primer Pump Assembly—5410 and 5510 in Section 30, Group 05).
27. Install battery. (See Remove and Install Battery—Tractors Without Cab in Section 40, Group 05.)
28. Install radiator. (See Install Radiator in Group 10.)
29. Adjust fast idle. (See Fast Idle Adjustment in Section 220, Group 15.)
30. Install hood.



A—Line  
B—Line  
C—Suction Line

20  
05  
13

LV2289 -JUN-16DEC97


AG,OUO1085,32 -19-25JUN02-7/7

## Remove Engine—Tractors with Cab


**NOTE:** 4-cylinder cab tractor shown, 3-cylinder cab tractors are similar.

1. Recover/recycle air conditioning refrigerant. (See Recover/Recycle Air Conditioning Refrigerant in Section 90, Group 20).
2. Remove hood and side grille panels.
3. Disconnect battery, negative (—) cable first.
4. Remove fuel filter/primer pump assembly. (See Remove and Install Fuel Filter/Primer Pump Assembly—5210 and 5310 or Remove and Install Fuel Filter/Primer Pump Assembly—5410 and 5510 in Section 30, Group 05.)
5. Remove MFWD drive shaft, if equipped. (See Remove, Inspect and Install MFWD Drive Shaft in Section 50, Group 35.)
6. Remove brace (A) and disconnect lower radiator hose (B) from water pump.
7. Remove cap screws (C) on both sides of tractor.
8. Remove finger guard (D), intake pipe (E), and disconnect upper radiator hose (F) from radiator.
9. Remove four cap screws (G) and five grommets (H).
10. Disconnect air filter restriction indicator wire connector (I).


A—Brace  
 B—Lower Radiator Hose  
 C—Cap Screw (2 used)  
 D—Finger Guard  
 E—Intake Pipe  
 F—Upper Radiator Hose  
 G—Cap Screw (4 used)  
 H—Grommet (5 used)  
 I—Wire Connector



LV2411 -UN-16DEC97



LV2412 -UN-16DEC97



LV2413 -UN-16DEC97

Continued on next page


AG,OUO1085,33 -19-25JUN02-1/10

11. Disconnect two headlight connectors (A).


*NOTE: Close all openings using caps and plugs to prevent contamination.*

12. Disconnect oil cooler lines (B) and condenser lines (C). Close all openings using caps and plugs.
13. Remove cap screw and lock nut (D) and nut (E) on both sides of oil cooler and condenser.


A—Headlight Connector (2 used)  
B—Oil Cooler Line (2 used)  
C—Condenser Line (2 used)  
D—Cap Screw and Lock Nut  
E—Nut



LV2414 -UN-16DEC97



LV2415 -UN-16DEC97



LV2416 -UN-16DEC97

Continued on next page


AG,OUO1085,33 -19-25JUN02-2/10

14. Tilt condenser and oil cooler forward. Remove cap screws (A) and ground wire (B).

**NOTE:** Make sure to route oil lines, condenser lines, and headlight harness through holes where grommets were removed.

15. Tilt condenser and oil cooler back and lift out front grille/radiator assembly. Route oil lines, condenser lines, and headlight harness through holes where grommets were removed.

**A—Cap Screw**  
**B—Ground Wire**



LV2417 -UN-16DEC97


Continued on next page

AG,OUO1085,33 -19-25JUN02-3/10




16. Disconnect and remove oil cooler lines (A).
17. Disconnect hydraulic steering lines (B).
18. Remove cap screws (C) and remove bracket (D) from engine.
19. Remove rod (E) from injection pump.
20. Disconnect hydraulic lines (F).


A—Oil Cooler Line (2 used)  
 B—Hydraulic Steering Line (2 used)  
 C—Cap Screw  
 D—Bracket  
 E—Rod  
 F—Hydraulic Line (3 used)



LV2419 -UN-16DEC97



LV2420 -UN-15DEC97



LV2421 -UN-15DEC97

Continued on next page


AG,OUO1085,33 -19-25JUN02-4/10

21. Disconnect coolant lines (A) from engine.
22. Disconnect hydraulic line (B).
23. Remove exhaust pipe.
24. Disconnect low pressure line (C), ground wire (D), and compressor clutch wire connector (E).


*NOTE: Muffler removed for clarity of photo.*

25. Remove fuel return line (F).


A—Coolant Line (2 used)  
 B—Hydraulic Line  
 C—Low Pressure Line  
 D—Ground Wire  
 E—Clutch Wire Connector  
 F—Fuel Line



LV2422 -UN-15DEC97



LV2423 -UN-15DEC97




LV2424 -UN-15DEC97

Continued on next page


AG.OUO1085,33 -19-25JUN02-5/10

26. Disconnect red wires #002C and #002D/E from right post (A) of fuse link junction block.
27. Disconnect two main harness wiring connectors (B).
28. Disconnect hydraulic line (C).


A—Fuse Link Post  
B—Wire Connector  
C—Hydraulic Line



LV2329 -UN-16DEC97



LV2425 -UN-15DEC97



LV2426 -UN-15DEC97

Continued on next page

AG,OUO1085,33 -19-25JUN02-6/10



29. Disconnect hydraulic line (A) from hydraulic pump.


**NOTE:** Support suction line (B). Transmission/hydraulic oil will spill out of hose if line drops below transmission/reservoir oil level.

30. Disconnect suction line (B).

31. Move hose (C) away from engine.

32. Disconnect battery positive (+) cable from starter terminal (D).

A—Hydraulic Line  
B—Suction Line  
C—Hose  
D—Starter Terminal



LV2427 -UN-15DEC97

AG,OUO1085,33 -19-25JUN02-7/10

**CAUTION:** Front weights and bracket must be removed from tractor before removing any frame to engine mounting hardware.

33. Remove front weights and bracket, if equipped.
34. Install lifting brackets such as JDG19 or JT01748 to engine.
35. Remove engine fan belt.
36. Remove muffler, if necessary.
37. Use a hoist and appropriate straps to prevent the front axle from tipping to the front or the back.
38. Install a wood block between front axle and frame on both sides.



LV2428 -UN-15DEC97


Continued on next page

AG,OUO1085,33 -19-25JUN02-8/10



39. Remove front end support-to-engine cap screws (A and B) and nut (C) from both sides of frame.

A—Cap Screw (2 used)  
B—Cap Screw (2 used)  
C—Nut (2 used)




LV2429 -UN-16DEC97

AG,OUO1085,33 -19-25JUN02-9/10

40. Roll front end away from tractor.
41. Remove engine-to-clutch housing cap screw (A) and nuts (B) from both sides.
42. Remove engine.
43. Remove clutch. (See Remove and Install Clutch Assembly in Section 50, Group 10 for CollarShift/SyncShuttle™ Transmission or Remove and Install Clutch Assembly in Section 50, Group 11 for PowrReverser™ Transmission.)
44. Make repairs as necessary. (See CTM104 or CTM125.)

A—Cap Screw  
B—Nut



LV2430 -UN-15DEC97

AG,OUO1085,33 -19-25JUN02-10/10

Install Engine—Tractors with Cab

- 1. Install clutch. (SeeRemove and Install Clutch Assembly in Section 50, Group 10 for CollarShift/SyncShuttle™ Transmission or Remove and Install Clutch Assembly in Section 50, Group 11 for PowrReverser™ Transmission.)

NOTE: Turning PTO shaft at rear of tractor during engine installation will aid in alignment of PTO clutch and shaft.

- 2. Put transmission shift levers in neutral to ease clutch shaft alignment with engine.
- 3. Apply multipurpose grease to end of PTO clutch shaft.
- 4. Install engine.


AG,OUO1085,34 -19-25JUN02-1/10

- 5. Install engine-to-clutch housing cap screws (A) and nuts (B). Tighten to specifications.

Specification

Engine-to-Clutch Housing Cap	
Screws—Torque .....	318 N•m (235 lb-ft)
Engine-to-Clutch Housing Nuts—	
Torque .....	318 N•m (235 lb-ft)

A—Cap Screw  
B—Nut



LV2430 -JUN-15DEC97

Continued on next page

AG,OUO1085,34 -19-25JUN02-2/10

**NOTE:** Hollow dowels are installed in bores of cap screws (B).


6. Align studs in engine with front end. Install front end to tractor. Tighten front end support-to-engine cap screws (A and B) and nuts (C) to specifications.

#### Specification

Front End Support-to-Engine	
Upper Cap Screws and Nuts—	
Torque .....	305 N•m (225 lb-ft)
Front End Support-to-Engine	
Lower Cap Screws—Torque .....	176 N•m (130 lb-ft)

7. Install engine fan belt.

- A—Cap Screw (2 used)  
B—Cap Screw (2 used)  
C—Nut (2 used)



AG,OUO1085,34 -19-25JUN02-3/10

LV2429 -UN-16DEC97

8. Connect battery positive (+) cable to starter terminal (D).


9. Route hose (C) along engine towards front.

10. Connect suction line (B).

**NOTE:** Replace all O-rings and seals. Used or damaged O-rings and seals will leak.

11. Connect hydraulic line (A) to hydraulic pump.

- A—Hydraulic Line  
B—Suction Line  
C—Hose  
D—Starter Terminal



LV2427 -UN-15DEC97




Continued on next page

AG,OUO1085,34 -19-25JUN02-4/10



12. Connect hydraulic line (C).
13. Connect two main wiring harness connectors. (B).
14. Connect red wires #002C and #002D/E to right post (A) of fuse link junction block.

A—Fuse Link Post  
B—Wire Connector  
C—Hydraulic Line




Continued on next page


AG.OUO1085,34 -19-25JUN02-5/10

15. Connect fuel return line (F).
16. Connect low pressure line (C), ground wire (D), and compressor clutch wire connector (E).
17. Install exhaust pipe.
18. Connect hydraulic line (B).
19. Connect coolant lines (A).


A—Coolant Line (2 used)  
 B—Hydraulic Line  
 C—Low Pressure Line  
 D—Ground Wire  
 E—Clutch Wire Connector  
 F—Fuel Line



LV2424 -UN-15DEC97



LV2423 -UN-15DEC97




LV2422 -UN-15DEC97

Continued on next page


AG,OUO1085,34 -19-25JUN02-6/10

20. Connect hydraulic lines (F).
21. Install rod (E) to injection pump.
22. Install cap screws (C) through bracket (D) to engine.
23. Connect hydraulic steering lines (B).
24. Install oil cooler lines (A).


A—Oil Cooler Line (2 used)  
 B—Hydraulic Steering Line (2 used)  
 C—Cap Screw  
 D—Bracket  
 E—Rod  
 F—Hydraulic Line (3 used)



LV2421 -UN-15DEC97



LV2420 -UN-16DEC97



LV2419 -UN-16DEC97


Continued on next page

AG.OUO1085,34 -19-25JUN02-7/10

**NOTE:** Make sure to route oil lines, condenser lines, and headlight harness through holes where grommets were removed.

25. Install front grille/radiator assembly, being sure to route hoses, lines, and wire harness through holes.
26. Tilt condenser and oil cooler forward. Install cap screws (A) and ground wire (B).

**A—Cap Screw**  
**B—Ground Wire**



LV2417 -UN-16DEC97

20  
05  
27


Continued on next page

AG,OUO1085,34 -19-25JUN02-8/10




27. Install cap screws and lock nuts (D) and nuts (E) to both sides.
28. Connect oil cooler lines (B) and condenser lines (C).
29. Connect two headlight connectors (A).


A—Headlight Connector (2 used)  
 B—Oil Cooler Line (2 used)  
 C—Condenser Line (2 used)  
 D—Cap Screw and Lock Nut  
 E—Nut



LV2416 -UN-16DEC97



LV2415 -UN-16DEC97



LV2414 -UN-16DEC97


Continued on next page

AG.OUO1085,34 -19-25JUN02-9/10




30. Connect air filter restriction indicator wire connector (I).
31. Install four cap screws (G) and five grommets (H).
32. Install finger guard (D), intake pipe (E) and connect upper radiator hose (F).
33. Install cap screws (C) to both sides.
34. Install brace (A) and lower radiator hose (B).
35. Install MFWD drive shaft, if equipped. (See Remove, Inspect and Install MFWD Drive Shaft in Section 50, Group 35.)
36. Install fuel filter/primer pump assembly. (See Remove and Install Fuel Filter/Primer Pump Assembly—5210 and 5310 or Remove and Install Fuel Filter/Primer Pump Assembly—5210 and 5310 in Section 30, Group 05.)
37. Connect battery, positive (+) cable first.
38. Install hood and side grille panels.
39. Fill cooling system with proper coolant. Run engine to circulate coolant. Check coolant level and replenish as necessary.
40. Adjust fast idle. (See Fast Idle Adjustment in Section 220, Group 15.)
41. Flush, evacuate, and charge air conditioning system. (See Flush Air Conditioning System, Evacuate Air Conditioning System and Charge Air Conditioning System in Section 90, Group 20.)


**A—Brace**  
**B—Lower Radiator Hose**  
**C—Cap Screw (2 used)**  
**D—Finger Guard**  
**E—Intake Pipe**  
**F—Upper Radiator Hose**  
**G—Cap Screw (4 used)**  
**H—Grommet**  
**I—Wire Connector**



LV2413 -UN-16DEC97



LV2412 -UN-16DEC97



LV2411 -UN-16DEC97



Specifications


Item	Measurement	Specification
Belt Tensioner Spring	Tension	18—22 N•m (13—16 lb-ft)

OUO1089,000024B    -19-25JUN02-1/1

Engine Water Pump Repair—Use CTM104 or CTM125

For complete repair information the component technical manual (CTM) is also required. Use the component technical manual in conjunction with this machine manual.

- 3-cylinder 2.9 L engines—Use CTM125
- 4-cylinder 4.5 L engines—Use CTM104



AG,OUO1085,35    -19-04AUG00-1/1

## Remove and Inspect Radiator



**CAUTION:** Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

*NOTE: 4-cylinder cab tractor shown; 3-cylinder tractors without cabs are similar.*

1. Remove left- and right-side grille panels.
2. In tractors equipped with cab, remove air conditioning condenser. (See Remove, Inspect, and Install Air Conditioning Condenser in Section 90, Group 20.)
3. Remove hydraulic oil cooler, if equipped. (See Remove, Inspect, and Install Hydraulic Oil Cooler in Section 70, Group 06.)

*NOTE: Cooling system capacity is approximately 10.8 L (11.5 qt).*

4. Drain coolant.
5. Remove air cleaner.




TS281 -JUN-23AUG88

Continued on next page

AG,OUO1085,36 -19-25JUN02-1/4

6. Remove finger guard (A) and recovery tank (B).
7. Disconnect bracket (C) from radiator support.
8. Remove air cleaner support bracket (D).
9. Disconnect upper radiator hose (E) from radiator.

A—Finger Guard  
B—Recovery Tank  
C—Bracket  
D—Air Cleaner Support  
E—Upper Radiator Hose




LV2255 -UN-26NOV97

20  
10  
3

AG,OUO1085,36 -19-25JUN02-2/4

10. Remove brackets (A) from radiator support.
11. Disconnect lower radiator hose (B) from water pump. Close all openings using caps and plugs.
12. Remove four cap screws (C), two cap screws (D), and radiator support (E) to both sides.

A—Radiator Support Bracket  
B—Lower Radiator Hose  
C—Cap Screw (8 used)  
D—Cap Screw (4 used)  
E—Radiator Support



LV2256 -UN-26NOV97

Continued on next page

AG,OUO1085,36 -19-25JUN02-3/4




**NOTE:** Move fan shroud (B) rearward over fan to aid during removal of radiator.

13. Remove four cap screws (A) and separate fan shroud (B) from radiator.
14. Remove radiator.
15. Remove hose clamp (C) and hose (D).


**CAUTION:** Reduce compressed air to less than 210 kPa (2 bar) (30 psi) when using for cleaning purposes. Clear area of bystanders, guard against flying chips, and wear personal protection equipment, including eye protection.

16. Check radiator for debris lodged in fins. Clean radiator using compressed air or pressure washer.
17. Inspect radiator for bent fins, cracks, and damaged seams. Repair as necessary.

A—Cap Screw (4 used)  
 B—Fan Shroud  
 C—Hose Clamp  
 D—Lower Radiator Hose



LV2257 -UN-26NOV97





LV2258 -UN-26NOV97

## Install Radiator

1. Place fan shroud (A) over cooling fan, with hose notch (B) at top.
2. Install lower radiator hose (D) and hose clamp (C). Tighten clamp.

A—Fan Shroud  
B—Hose Notch  
C—Clamp  
D—Lower Radiator Hose




Continued on next page

AG.OUO1085,37 -19-25JUN02-1/4

3. Install radiator on front of tractor.
4. Install fan shroud (B) and four cap screws (A). Adjust shroud for fan clearance.

A—Cap Screw (4 used)  
B—Fan Shroud




LV2257 -UN-26NOV97

AG,OUO1085,37 -19-25JUN02-2/4

5. Install radiator support (E), four cap screws (C), and two cap screws (D) to both sides.
6. Install lower radiator hose (B) and brackets (A).

A—Radiator Support Bracket  
B—Lower Radiator Hose  
C—Cap Screw (8 used)  
D—Cap Screw (4 used)  
E—Radiator Support




LV2256 -UN-26NOV97

Continued on next page

AG,OUO1085,37 -19-25JUN02-3/4



7. Install upper radiator hose (E) and bracket (C).
8. Install finger guard (A) and air cleaner support bracket (D).
9. Install recovery tank (B).
10. Install hydraulic oil cooler if equipped. (See Remove, Inspect, and Install Hydraulic Oil Cooler in Section 70, Group 06.)
11. Tractors with cab: Install air conditioning condenser. (See Remove, Inspect, and Install Air Conditioning Condenser in Section 90, Group 20.)
12. Close drain valve and fill radiator with proper coolant to top of filler neck. (See Diesel Engine Coolant in Section 10, Group 20.)
13. Start engine and allow it to reach proper operating temperature. Check radiator, hoses, and connections for leaks. Adjust coolant level in recovery tank.
14. Install side grille panels.



A—Finger Guard  
B—Recovery Tank  
C—Bracket  
D—Air Cleaner Support Bracket  
E—Upper Radiator Hose

AG,OUO1085,37 -19-25JUN02-4/4

## Replace Thermostat



**CAUTION:** Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.




1. Partially drain radiator.

**NOTE:** Tractor with cab shown; procedure for tractors without cabs is similar.

*Finger guard removed for clarity of photo only.*

2. Remove left-side grille panel.
3. Disconnect bypass tube (A) from thermostat housing.
4. Remove upper radiator hose (B) and two cap screws (C).
5. Disconnect temperature sender wire connector (D).
6. Tractors with cab: Disconnect heater hose (E).

A—Bypass Tube  
B—Upper Radiator Hose  
C—Cap Screw (2 used)  
D—Wire Connector  
E—Heater Hose (Cab Tractors Only)



TS281 -UN-23AUG88

LV2200 -UN-16DEC97

Continued on next page


AG,OUO1085,38 -19-25JUN02-1/3

7. Remove housing (A) and replace thermostat (B).
8. Clean mating surfaces of thermostat housing and engine block.

**NOTE:** *Install new thermostat with jiggle pin at top to improve de-aeration of coolant.*

9. Replace thermostat (B) and install new gasket.

A—Housing  
B—Thermostat




LV2202 -UN-16DEC97

AG,OUO1085,38 -19-25JUN02-2/3

10. Install thermostat housing and cap screws (C).
11. Connect bypass tube (A) and upper radiator hose (B).
12. Connect wire connector (D) and cab heater hose (E), if equipped.
13. Fill radiator with proper coolant to top of filler neck.  
(See Diesel Engine Coolant in Section 10, Group 20.)
14. Install left-side grille panel.

A—Bypass Tube  
B—Upper Radiator Hose  
C—Cap Screw (2 used)  
D—Wire Connector  
E—Heater Hose (Cab Tractors Only)



LV2200 -UN-16DEC97


AG,OUO1085,38 -19-25JUN02-3/3

## Inspect and Replace Belt Tensioner—Models 5410 and 5510


**NOTE:** Pulley and spring tensioner are not serviceable.

1. Remove right-side grille panel.
2. Remove nut (A), cap screw (B), and right-side radiator support bracket (C).
3. Release tension on belt using a 3/8" drive long handle breaker bar (D). Remove belt (E) from alternator pulley.
4. Release tension on tensioner arm and remove tool.

A—Nut  
B—Cap Screw  
C—Radiator Support Bracket  
D—3/8" Drive Breaker Bar  
E—Belt



LV2398 —UN-16DEC97



LV2399 —UN-16DEC97

Continued on next page


AG,OUO1085,40 —19-04AUG00-1/3



**NOTE:** A belt tension gauge will not give an accurate measurement of the belt tension when automatic belt tensioner is used. Measure tensioner spring tension using a torque wrench and procedure outlined below.

5. Put a mark (A) on swing arm of tensioner as shown.
6. Measure 21 mm (0.83 in.) from (A) and put a mark (B) on tensioner mounting base.

A—Mark—Swing Arm  
B—Mark—Tensioner Mounting Base



AG,OUO1085,40 -19-04AUG00-2/3


7. Rotate the swing arm using a torque wrench until marks (A and B) are aligned.
8. Record torque wrench measurement and compare with specification below. Replace belt tensioner assembly if recorded measurement is under specification.

**Specification**

Belt Tensioner Spring—Tension ..... 18—22 N•m (13—16 lb-ft)

9. Make sure belt is in place and release tension on tensioner arm.
10. Install right-side grille panel.

A—Mark  
B—Mark



AG,OUO1085,40 -19-04AUG00-3/3



# Section 30

## Fuel and Air Repair

### Contents

	Page
<b>Group 05—Fuel System</b>	
Specifications . . . . .	30-05-1
Injection Pump, Nozzle and Governor	
Repair—Use CTM104 or CTM125 . . . . .	30-05-1
Remove, Inspect and Install Fuel Tank—	
Without Cab . . . . .	30-05-1
Remove, Inspect and Install Fuel Tank—	
With Cab . . . . .	30-05-4
Replace Fuel Filter—5210 and 5310 . . . . .	30-05-7
Remove and Install Fuel Filter/Primer	
Pump Assembly—5210 and 5310 . . . . .	30-05-8
Replace Fuel Filter—5410 and 5510 . . . . .	30-05-9
Remove and Install Fuel Filter/Primer	
Pump Assembly—5410 and 5510 . . . . .	30-05-9
<b>Group 10—Air Intake System</b>	
Other Material . . . . .	30-10-1
Specifications . . . . .	30-10-1
Turbocharger Repair—Use CTM104 or	
CTM125 . . . . .	30-10-1
Remove, Inspect, and Install Air Cleaner	
Elements—5210 and 5310 . . . . .	30-10-2
Remove, Inspect, and Install Air Cleaner	
Elements—5410 and 5510 . . . . .	30-10-4
Remove Turbocharger—5310 . . . . .	30-10-6
Install Turbocharger—5310 . . . . .	30-10-7
Remove Turbocharger—5510 . . . . .	30-10-8
Install Turbocharger—5510 . . . . .	30-10-9
Turbocharger Break-In . . . . .	30-10-10
<b>Group 15—Speed Control Linkage</b>	
Inspect and Repair Speed Control	
Linkage—Without 540/540E PTO . . . . .	30-15-1
Inspect and Repair Speed Control	
Linkage—With 540/540E PTO . . . . .	30-15-2





## Specifications

Item	Measurement	Specification
Fuel Tank-to-Bracket Screws	Torque	35 N•m (26 lb-ft)
Rear Cab Mounting Nuts	Torque	203 N•m (150 lb-ft)

OUO1080,000023E -19-24JUN02-1/1

30  
05  
1

## Injection Pump, Nozzle and Governor Repair—Use CTM104 or CTM125

For complete repair information the component technical manual (CTM) is also required. Use the component manual in conjunction with this machine manual.

- 3-cylinder 2.9 L engines—Use CTM125
- 4-cylinder 4.5 L engines—Use CTM104



TS225 -UN-17JAN89

AG,OUO1085,43 -19-04AUG00-1/1


## Remove, Inspect and Install Fuel Tank—Without Cab

**NOTE:** Fuel tank capacity for model series tractors 5210 through 5410 is approximately 68 L (18 U.S. gal). The 5510 series tractor fuel tank capacity is approximately 83 L (22 U.S. gal).

1. Drain fuel tank.
2. Remove seat and support. (See Remove and Install Seat and Support—Tractors Without Cab in Section 90, Group 05.)
3. Remove left-side control console and panel. (See Remove and Install Left-Side Control Console and Panel—Tractors Without Cab in Section 90, Group 06.)

**NOTE:** Close all openings using caps and plugs to prevent contamination of fuel system.

4. Disconnect fuel supply hose (A). Close all openings using caps and plugs.



A—Fuel Supply Hose

LV2300 -UN-26NOV97

Continued on next page

AG,OUO1085,44 -19-04AUG00-1/5

5. Loosen clamps (A).
6. Disconnect fuel hose (B). Close all openings using caps and plugs.

*NOTE: Tag or label wiring leads to aid during installation.*

7. Disconnect wiring leads (C).


A—Clamp (2 used)  
B—Fuel Hose  
C—Wiring Lead (2 used)



LV1903 -UN-19MAY97

AG,OUO1085,44 -19-04AUG00-2/5

8. Remove two screws and nuts (A).
9. Remove two cap screws (B) and nuts (C).
10. Lift retaining strap away from tank and remove fuel tank.
11. Inspect fuel tank for damage. Replace if necessary.
12. Wash tank out with a small amount of fuel to remove any debris.
13. Inspect rubber isolator, located between bottom of tank and rockshaft case, for excessive wear or damage. Replace if necessary.
14. Install fuel tank, cap screws, and nuts (A).
15. Install two screws (B) and nuts (C). Tighten to specification.



LV2301 -UN-26NOV97

A—Screw and Nut (2 used)  
B—Screw (2 used)  
C—Nut (2 used)

#### Specification


Fuel Tank-to-Bracket Screws—  
Torque ..... 35 N•m (26 lb-ft)

Continued on next page

AG,OUO1085,44 -19-04AUG00-3/5

16. Connect wiring leads (C).
17. Connect fuel hose (B) and tighten clamps (A).


A—Clamp (2 used)  
 B—Fuel Hose  
 C—Wiring Lead (2 used)



LV1903 -UN-19MAY97

AG,OUO1085,44 -19-04AUG00-4/5

18. Connect fuel supply hose (A).
19. Install left-side control console and panel. (See Remove and Install Left-Side Control Console and Panel—Tractors Without Cab in Section 90, Group 06.)
20. Install seat and support. (See Remove and Install Seat and Support—Tractors Without Cab in Section 90, Group 05.)
21. Fill fuel tank with proper fuel. (See Diesel Fuel Specifications in Section 10, Group 20.)
22. Bleed the fuel system. (See Bleed Fuel System in Section 220, Group 15.)



LV2300 -UN-26NOV97

A—Fuel Supply Hose

AG,OUO1085,44 -19-04AUG00-5/5

## Remove, Inspect and Install Fuel Tank—With Cab

**NOTE:** Fuel tank capacity is approximately 83 L (22 U.S. gal).


1. Open drain valve (A) and drain fuel tank into proper container. (See Do Not Use Galvanized Containers in Section 10, Group 20.)

2. Remove screw (B) and nut (C) on both sides of fuel tank.

**NOTE:** Rear of cab must be lifted upward approximately 25.4 mm (1.000 in.) for clearance of fuel tank during removal.

3. Remove rear cab mounting nuts (D) on both sides of cab.

A—Fuel Tank Drain  
B—Screw (2 used)  
C—Nut (2 used)  
D—Nut (2 used)




LV2262 -UN-16DEC97

Continued on next page

AG,OUO1085,45 -19-07AUG00-1/3

4. Remove slow moving vehicle (SMV) emblem (A) and hydraulic oil dipstick (B) to aid during removal and installation of fuel tank.
5. Lower lifting arms (C) and center link (D) to aid during removal and installation of fuel tank.
6. At location in front of left rear axle:
  - Disconnect fuel supply line and fuel return line going to fuel tank. Cap or plug all openings.
  - Cut all tie straps as necessary.
7. At location in front of right rear axle:
  - Disconnect fuel level sender wiring connector.
  - Cut all tie straps as necessary.
8. Using a suitable hoist, raise rear of cab. Remove fuel tank.
9. Inspect fuel tank for damage. Replace if necessary.
10. Wash tank out with a small amount of fuel to remove any debris.



A—SMV Emblem  
B—Dipstick  
C—Lifting Arm  
D—Center Link

LV2263 -UN-20NOV97

30  
05  
5

Continued on next page

AG,OUO1085,45 -19-07AUG00-2/3



11. Install fuel tank and lower cab.
12. Install nuts (C) and screws (B) on both sides of fuel tank. Tighten screws (B) to specification.

**Specification**

Fuel Tank-to-Bracket Screws—

Torque ..... 35 N•m (26 lb-ft)

Make sure drain valve (A) is fully closed.

13. Install rear cab mounting nuts (D). Tighten nuts to specification.

**Specification**

Rear Cab Mounting Nuts—

Torque ..... 203 N•m (150 lb-ft)

14. Install hydraulic oil dipstick and SMV emblem.

15. At location in front of left rear axle:


- Connect fuel supply line and fuel return line going to fuel tank.
- Install tie straps as necessary.

16. At location in front of right rear axle:

- Connect fuel level sender wiring connector.
- Install tie straps as necessary.

17. Fill fuel tank with proper fuel. (See Diesel Fuel Specifications in Section 10, Group 20.)

18. Bleed the fuel system. (See Bleed Fuel System in Section 220, Group 15.)



A—Fuel Tank Drain  
B—Screw (2 used)  
C—Nut (2 used)  
D—Nut (2 used)

LV2262 -UN-16DEC97


AG,OUO1085,45 -19-07AUG00-3/3



## Replace Fuel Filter—5210 and 5310

1. Turn shut-off valve (A) to off position.
2. Loosen retaining ring (B).
3. Replace filter (C).
4. Tighten retaining ring.
5. Open shut-off valve.
6. Bleed the fuel system. (See Bleed Fuel System in Section 220, Group 15.)

A—Shut-Off Valve  
B—Retaining Ring  
C—Filter




LV1898 -UN-26NOV97

30  
05  
7

AG,OUO1085,46 -19-07AUG00-1/1

## Remove and Install Fuel Filter/Primer Pump Assembly—5210 and 5310

1. Close fuel shut-off valve (A).
2. Disconnect fuel lines (B and C). Close all openings using caps and plugs.
3. Remove cap screws, lock washers, and flat washers (D). Remove fuel filter/primer pump assembly.
4. Install fuel filter/primer pump assembly, washers and cap screws.
5. Connect fuel lines (B and C).
6. Open fuel shut-off valve (A).
7. Bleed fuel system. (See Bleed Fuel System in Section 220, Group 15.)



LV2361 -UN-28JAN98


- A—Fuel Filter Shut-Off Valve  
B—Fuel Line  
C—Fuel Line  
D—Cap Screw, Lock Washer, and Flat Washer (2 used)

AG,OUO1085,47 -19-07AUG00-1/1

## Replace Fuel Filter—5410 and 5510

1. Turn shut-off valve (A) to off position.
2. Loosen retaining ring (B).
3. Replace filter (C).
4. Tighten retaining ring.
5. Open shut-off valve.
6. Bleed the fuel system. (See Bleed Fuel System in Section 220, Group 15.)

A—Shut-Off Valve  
B—Retaining Ring  
C—Filter




LV1900 -UN-19MAY97

30  
05  
9

AG,OUO1085,48 -19-07AUG00-1/1

## Remove and Install Fuel Filter/Primer Pump Assembly—5410 and 5510

1. Close fuel shut-off valve (A).
2. Disconnect fuel lines (B and C). Close all openings using caps and plugs.
3. Remove cap screws (D). Remove fuel filter/primer pump assembly.
4. Install fuel filter/primer pump assembly and cap screws.
5. Connect fuel lines.
6. Open fuel shut-off valve.
7. Bleed fuel system. (See Bleed Fuel System in Section 220, Group 15.)



LV1901 -UN-19MAY97

A—Fuel Filter Shut-Off Valve  
B—Fuel Line  
C—Fuel Line  
D—Cap Screw (2 used)

AG,OUO1085,49 -19-07AUG00-1/1



## Other Material

Number	Name	Use
R36757 (U.S.)	John Deere Filter Element Cleaner	Cleans filter element

OUO1080,0000241 -19-24JUN02-1/1

30  
10  
1

## Specifications


Item	Measurement	Specification
Turbocharger Oil Drain Line	Torque	27 N•m (20 lb-ft)
Turbocharger Oil Inlet Line	Torque	27 N•m (20 lb-ft)
Turbocharger-to-Intake Manifold Cap Screws	Torque	47 N•m (35 lb-ft)
Muffler-to-Turbocharger Clamp	Torque	47 N•m (35 lb-ft)

OUO1080,0000245 -19-24JUN02-1/1

## Turbocharger Repair—Use CTM104 or CTM125

For complete repair information the component technical manual (CTM) is also required. Use the component manual in conjunction with this machine manual.

- 3-cylinder 2.9 L engines—Use CTM125
- 4-cylinder 4.5 L engines—Use CTM104




TS225 -UN-17JAN89

AG,OUO1085,50 -19-07AUG00-1/1

## Remove, Inspect, and Install Air Cleaner Elements—5210 and 5310

1. Open hood and remove left-side grille panel.
2. Remove strap (A).
3. Disconnect three retaining clips (B) and remove air cleaner cover (C).
4. Remove primary element (D).




**IMPORTANT:** Remove secondary safety element (E) **ONLY** if it is to be replaced. Do not attempt to clean secondary element. Install new element immediately to prevent dust from entering air intake system. Dust can damage internal engine components and turbocharger, if equipped.

5. Replace secondary safety element (E), if dirty or damaged.



- A—Retaining Strap
- B—Cover Retaining Clip (3 used)
- C—Air Cleaner Cover
- D—Primary Element
- E—Secondary Element



Continued on next page

AG,OUO1008,230 -19-13OCT99-1/2



6. Pat primary element with your hand, NOT ON HARD SURFACE.
7. If this does not remove dust, use compressed air under 690 kPa (6.9 bar) (100 psi). Direct air up and down the pleats, blowing from inside to outside. Be careful not to make a break in the element.
8. After you clean the primary element, put a lighted bulb inside it. Inspect the element and seal (A) for damage. Throw away an element that has the smallest break. If the seal is broken or cracked install a new element.



A—Seal (2 used)

- IMPORTANT: DO NOT wash element in fuel oil, oil, gasoline, or solvent. DO NOT use compressed air to remove water from an element.**
9. Add John Deere R36757 Filter Element Cleaner or an equivalent non-sudsing detergent to water. Move the element up and down in this solution to loosen dirt.
  10. Flush with clean water. Use water pressure under 280 kPa (2.80 bar) (40 psi).
- IMPORTANT: Air dry element for 24 to 36 hours before installing.**
11. Shake the element to remove water. Do not install element in the machine until it is completely dry.
  12. Before you install primary element, clean the inside of air cleaner housing and unloader valve with a damp cloth.
  13. Install primary element.
  14. Install air cleaner cover and retaining strap.

AG,OUO1008,230 -19-13OCT99-2/2

LV2108 -UN-19MAY97

30  
10  
3



## Remove, Inspect, and Install Air Cleaner Elements—5410 and 5510

1. Open hood and remove right-side grill panel.
2. Remove air cleaner retaining strap (A).


**NOTE:** Lift up on cover end of air cleaner to aid during release of retaining clips (B) and removal of cover (C).

3. Release three air cleaner cover retaining clips (B) and remove air cleaner cover (C).
4. Remove primary element (D).

**IMPORTANT:** Remove secondary safety element (E) **ONLY** if replacement is necessary. Do not attempt to clean secondary element. Install new element immediately to prevent dust from entering air intake system. Dust can damage internal engine components and turbocharger, if equipped.

5. Replace secondary safety element (E), if dirty or damaged.


A—Retaining Strap  
B—Cover Retaining Clip (3 used)  
C—Air Cleaner Cover  
D—Primary Element  
E—Secondary Element



LV1904 -UN-26NOV97



LV2106 -UN-28NOV97



LV2305 -UN-26NOV97

Continued on next page

AG,OUO1085,51 -19-07AUG00-1/2

6. Pat primary element with the palm of your hand, NOT ON HARD SURFACE.
7. If this does not remove dust, use compressed air under 690 kPa (6.9 bar) (100 psi). Direct air up and down the pleats, blowing from inside to outside. Be careful not to make a break in the element.
8. After you clean the primary element, put a lighted bulb inside it. Inspect the element and seal (A) for damage. Throw away an element that has the smallest break. If the seal is broken or cracked install a new element.



A—Seal (2 used)

**IMPORTANT: DO NOT wash element in fuel oil, oil, gasoline, or solvent. DO NOT use compressed air to remove water from an element.**

9. Add John Deere R36757 Filter Element Cleaner or an equivalent non-sudsing detergent to water. Move the element up and down in this solution to loosen dirt.
10. Flush with clean water. Use water pressure under 280 kPa (2.80 bar) (40 psi).

**IMPORTANT: Air dry element for 24 to 36 hours before installing.**

11. Shake the element to remove water. Do not install element in the machine until it is completely dry.
12. Before you install primary element, clean the inside of air cleaner housing and unloader valve with a damp cloth.
13. Install primary element.
14. Install air cleaner cover and retaining strap.

AG,OUO1085,51 -19-07AUG00-2/2

LV2108 -UN-19MAY97

30  
10  
5

## Remove Turbocharger—5310



**CAUTION:** Turbocharger may be hot. Allow turbocharger to cool before removal. Hot turbocharger can cause serious burns.



**IMPORTANT:** Do not clean exterior of turbocharger if inspection is required. Cleaning can remove evidence for failure analysis.

**NOTE:** Hood removed for clarity of photo.

1. Disconnect air intake hose (A) from turbocharger.
2. Disconnect air intake pipe (B). Close all openings using caps and plugs.

A—Air Intake Hose

B—Air Intake Pipe




TS271 -UN-23AUG88

LV2109 -UN-19MAY97

AG,OUO1085,52 -19-07AUG00-1/2

3. Remove cap screw from clamp (A).
4. Disconnect lines (B and C). Close all openings using caps and plugs.
5. Remove four cap screws, lock washers, and nuts (D).
6. Remove turbocharger and gasket. Close all openings using caps and plugs.
7. Make repairs as necessary. (See CTM104 or CTM125.)



A—Muffler Clamp

B—Oil Inlet Line

C—Oil Drain Line

D—Cap Screw, Lock Washer, and Nut (4 used)

LV384 -UN-25FEB92

AG,OUO1085,52 -19-07AUG00-2/2

## Install Turbocharger—5310

1. Install clamp (A) on muffler flange.
2. Install new gasket between manifold and turbocharger.
3. Install four cap screws, lock washers, and nuts (D). Leave nuts loose.
4. Connect oil drain line (C). Tighten to specification.

### Specification

Turbocharger Oil Drain Line—  
Torque ..... 27 N•m (20 lb-ft)

5. Fill oil line inlet port (B) with clean engine oil. Rotate turbine wheel by hand to lubricate bearings.
6. Connect oil inlet line (B). Tighten to specification.


### Specification

Turbocharger Oil Inlet Line—  
Torque ..... 27 N•m (20 lb-ft)

7. Tighten cap screw in clamp (A).
8. Tighten cap screws (D) to specification.

### Specification

Turbocharger-to-Intake Manifold  
Cap Screws—Torque ..... 47 N•m (35 lb-ft)



A—Muffler Clamp  
B—Oil Inlet Line  
C—Oil Drain Line  
D—Cap Screw, Lock Washer, and Nut (4 used)

LV384 -UN-25FEB92


30  
10  
7

AG,OUO1085,55 -19-07AUG00-1/2

**IMPORTANT:** With the greatest suction force occurring between air cleaner and turbocharger, ensure that hose connections are tight to prevent entry of dirt into the system.

9. Connect air intake pipe (B).
10. Connect air intake hose (A).
11. Perform turbocharger break-in. (See Turbocharger Break-In in this group.)

A—Air Intake Hose  
B—Air Intake Pipe



LV2109 -UN-19MAY97

AG,OUO1085,55 -19-07AUG00-2/2

## Remove Turbocharger—5510

**CAUTION:** Turbocharger may be hot. Allow turbocharger to cool before removal. Hot turbocharger can cause serious burns.

**IMPORTANT:** Do not clean exterior of turbocharger if inspection is required. Cleaning can remove evidence for failure analysis.



**NOTE:** Tractor without cab shown. Procedure with cab is the same.

1. Raise hood and remove left-hand hood side shield.

**NOTE:** Close all openings using caps and plugs to prevent contamination.

2. Remove air intake tube (A).
3. Disconnect oil inlet line (B).
4. Remove air intake tube (C).

A—Air Intake Tube  
B—Oil Inlet Line  
C—Air intake Tube



TS271 -JUN-23AUG88


LV2110 -JUN-19MAY97

AG,OUO1085,56 -19-07AUG00-1/2

**NOTE:** Exhaust stack removed for clarity of photo.

5. Remove oil drain line (A), muffler clamp (B), and four cap screws (C).
6. Remove turbocharger from intake manifold. Remove and discard gasket. Seal intake manifold opening to prevent entry of dirt.
7. Make repairs as necessary. (See CTM104 or CTM125.)

A—Oil Drain Line  
B—Muffler Clamp  
C—Cap Screw (4 used)



LV2111 -JUN-14MAY97

AG,OUO1085,56 -19-07AUG00-2/2



## Install Turbocharger—5510


**NOTE:** Exhaust stack removed for clarity of photo.

1. Install new gasket and turbocharger on intake manifold.
2. Install four cap screws (C), muffler clamp (B), and oil drain line (A). Tighten to specifications.

### Specification

Turbocharger Oil Drain Line—	
Torque .....	27 N•m (20 lb-ft)
Muffler Clamp—Torque .....	47 N•m (35 lb-ft)
Turbocharger-to-Intake Manifold	
Cap Screws—Torque .....	47 N•m (35 lb-ft)

A—Oil Drain Line  
B—Muffler Clamp  
C—Cap Screw (4 used)



LV2111 —UN-14MAY97

30  
10  
9

AG,OUO1085,57 —19-07AUG00-1/2


3. Fill turbocharger with clean engine oil through opening in top of turbocharger. Rotate turbine wheel by hand to lubricate bearings.
4. Connect oil inlet line (B). Tighten to specification.

### Specification

Turbocharger Oil Inlet Line—	
Torque .....	27 N•m (20 lb-ft)

**IMPORTANT:** With the greatest suction force occurring between air cleaner and turbocharger, ensure that hose connections are tight to prevent entry of dirt into the system.

5. Connect air intake tubes (A and C). Tighten securely.
6. Install left-hand hood side shield.
7. Perform turbocharger break-in. (See Turbocharger Break-In in this group.)



A—Air Intake Tube  
B—Oil Inlet Line  
C—Air Intake Tube

LV2110 —UN-19MAY97


AG,OUO1085,57 —19-07AUG00-2/2

## Turbocharger Break-In

**IMPORTANT:** A new or repaired turbocharger does not have an adequate oil supply for initial start-up of engine. Perform the steps below to prevent damage to turbocharger bearings.

1. Disconnect wire lead (A) from fuel shut-off solenoid at injection pump.
2. Crank engine over with starting motor for 10 seconds. DO NOT crank engine longer than 30 seconds at a time to avoid damage to starting motor.

A—Wire Lead




LV2112 -UN-19MAY97

AG,OUO1085,58 -19-07AUG00-1/1



**Inspect and Repair Speed Control Linkage—Without 540/540E PTO**



A—Swivel  
B—Cotter Pin (6 used)  
C—Linkage Rod  
D—Spring Pin  
E—Nylon Split Bushing

F—Lever  
G—Rod  
H—Extension Spring  
I—Adjustment Spring  
J—Washer (2 used)


K—Throttle Lever  
L—Knob  
M—Bushings  
N—Plate  
O—Linkage Rod

P—Linkage Rod  
Q—Foot Pedal  
R—Nylon Split Bushing  
S—Shoulder Bolt

1. Remove dash side panels.
2. Remove right-hand step plate on tractors without cab.
3. Inspect parts for wear or damage. Replace as necessary.
4. Adjust throttle lever. (See Throttle Lever Adjustment in Section 220, Group 15.)
5. Install step plate, if removed.
6. Install dash side panels.
7. Adjust fast and slow idle. (See Slow Idle Adjustment and Fast Idle Adjustment in Section 220, Group 15.)

LV2113 -UN-09JUN97

# Inspect and Repair Speed Control Linkage—With 540/540E PTO



- |                   |                   |                        |                        |
|-------------------|-------------------|------------------------|------------------------|
| 1—Nut (3 used)    | 9—Washer (2 used) | 17—Linkage Rod         | 25—Nylon Split Bushing |
| 2—Swivel          | 10—Nut            | 18—Foot Pedal          | 26—Lever               |
| 3—Linkage Rod     | 11—Throttle Lever | 19—Shoulder Bolt       | 27—Swivel              |
| 4—Adjustment Stop | 12—Knob           | 20—Nylon Split Bushing | 28—Nut (4 used)        |
| 5—Control Bracket | 13—Cap Screw      | 21—Washer (5 used)     | 29—Control Cable       |
| 6—Tension Nut     | 14—Bushing        | 22—Cotter Pin (6 used) | 30—Adjustment Nut      |
| 7—Washer          | 15—Plate          | 23—Extension Spring    | 31—Locking Pin         |
| 8—Tension Spring  | 16—Linkage Rod    | 24—Lever               |                        |

1. Remove dash side panels.
2. Remove right-hand step plate on tractors without cab.
3. Inspect parts for wear or damage. Replace as necessary.
4. Adjust throttle lever. (See Throttle Lever Adjustment in Section 220, Group 15.)
5. Install step plate, if removed.
6. Install dash side panels.

LV2449 -UN-16DEC97

Continued on next page

AG,OUO1085,60 -19-07AUG00-1/2

## *Speed Control Linkage*

7. Adjust fast and slow idle. (See Slow Idle Adjustment and Fast Idle Adjustment in Section 220, Group 15.)

AG,OUO1085,60 -19-07AUG00-2/2

30  
15  
3



# Section 40

## Electrical Repair

### Contents

	Page		Page
<b>Group 05—Battery, Starter and Alternator</b>			
Starter Repair—Use CTM77 . . . . .	40-05-1	Replace Fuel Level Sender—Tractors Without Cab. . . . .	40-10-18
Remove and Install Battery—Tractors Without Cab. . . . .	40-05-2	Replace Fuel Level Sender—Tractors With Cab . . . . .	40-10-19
Remove and Install Battery—Tractors With Cab . . . . .	40-05-3	Replace Wiper Control Switch. . . . .	40-10-21
Remove and Install Starter—5210 and 5310 . . . . .	40-05-4	Replace Wiper Motor . . . . .	40-10-22
Remove and Install Starter—5410 and 5510 . . . . .	40-05-5	Replace Blower Control Switch . . . . .	40-10-22
Replace Alternator/Regulator—40 Amp Without Cab. . . . .	40-05-6	Replace Air Conditioning Temperature Control Switch . . . . .	40-10-23
Replace Alternator/Regulator—60 and 65 Amp with Cab . . . . .	40-05-7	Replace Dome Light . . . . .	40-10-25
		Replace Dome Light Switch . . . . .	40-10-26
<b>Group 10—Electrical System Components</b>			
Specifications . . . . .	40-10-1	<b>Group 15—Wiring Harness</b>	
Service Equipment and Tools . . . . .	40-10-1	Special or Essential Tools . . . . .	40-15-1
Other Material . . . . .	40-10-1	Service Equipment and Tools . . . . .	40-15-1
Replace Air Filter Restriction Switch—5210 and 5310 . . . . .	40-10-2	Service Parts Kits . . . . .	40-15-2
Replace Air Filter Restriction Switch—5410 and 5510 . . . . .	40-10-2	Replace Connector Body—Blade Terminals . . . . .	40-15-2
Replace Coolant Temperature Sender—5210 and 5310 . . . . .	40-10-3	Replace WEATHER PACK™ Connector . . . . .	40-15-2
Replace Coolant Temperature Sender—5410 and 5510 . . . . .	40-10-3	Install WEATHER PACK™ Contact . . . . .	40-15-3
Replace Engine Speed Sensor . . . . .	40-10-4	Replace Front Wiring Harness—3 Cylinder . . . . .	40-15-6
Replace Engine Oil Pressure Switch . . . . .	40-10-4	Replace Front Wiring Harness—4 Cylinder . . . . .	40-15-7
Replace Air Intake Heater . . . . .	40-10-5	Replace Rear Wiring Harness—Tractors Without Cab. . . . .	40-15-8
Replace Air Intake Heater Relay . . . . .	40-10-5	Replace Rear Wiring Harness—Tractors With Cab . . . . .	40-15-10
Replace Key Switch . . . . .	40-10-6	Replace Cab Wiring Harness—Lights . . . . .	40-15-12
Replace Tractor Light Switch. . . . .	40-10-7	Replace Cab Wiring Harness— Radio/Antenna . . . . .	40-15-14
Replace Radio . . . . .	40-10-8	Replace Cab Wiring Harness—Main . . . . .	40-15-16
Replace Speakers . . . . .	40-10-8		
Replace Antenna . . . . .	40-10-9		
Replace Turn Signal Controller . . . . .	40-10-10		
Replace Instrument Panel— CollarShift/SyncShuttle™ Transmission . . . . .	40-10-11		
Replace Instrument Panel—PowrReverser™ Transmission . . . . .	40-10-13		
Replace Rear PTO Switch—Tractors Without Cab. . . . .	40-10-16		
Replace Rear PTO Switch—Tractors With Cab . . . . .	40-10-16		
Replace Neutral Start Switch. . . . .	40-10-17		
Replace Seat Switch. . . . .	40-10-17		



### Starter Repair—Use CTM77

For complete repair information the component technical manual (CTM) is also required. Use the component technical manual in conjunction with this machine manual.



TS225 -UN-17JAN89

LV.4005HA,A1 -19-08JUN94-1/1



## Remove and Install Battery—Tractors Without Cab



**CAUTION:** Keep all sparks and flames away from batteries, as gas given off by electrolyte is explosive. To avoid sparks, connect ground cable last and disconnect it first.


To avoid shocks and burns, disconnect battery ground cable before servicing any part of electrical system.

*NOTE: Air cleaner removed for illustration purposes only.*

1. Remove side grille panels.
2. Disconnect negative (–) first, then positive (+), battery cables.
3. Loosen nuts (A) and rotate hold-down bracket (B) away from battery.
4. Disconnect vent tube (C).
5. Remove battery. Clean and service as necessary.
6. Install battery.
7. Connect vent tube.
8. Install hold-down bracket and tighten nuts.
9. Connect positive (+) then negative (–) cables.
10. Apply petroleum jelly on battery terminals.
11. Install grille panels.



TS204 –UN-23AUG88



LV390 –UN-25FEB92

A—Nut  
B—Hold-Down Bracket  
C—Vent Tube

AG,OUO1085,61 –19-07AUG00-1/1




## Remove and Install Battery—Tractors With Cab

**CAUTION:** Keep all sparks and flames away from batteries, as gas given off by electrolyte is explosive. To avoid sparks, connect ground cable last and disconnect it first.

To avoid shocks and burns, disconnect battery ground cable before servicing any part of electrical system.

1. Remove one screw between clutch pedal and center floor cover. Pull back left side floor mat to expose battery access floor plate (A).
2. Remove floor plate (A).
3. Disconnect negative (–) first, then positive (+), battery cables.
4. Remove four cap screws (B) and cover (C).
5. Remove two nuts (D) and hold-down bracket (E).
6. Disconnect vent tube (F).
7. Remove battery. Clean and service as necessary.
8. Install battery.
9. Connect vent tube.
10. Install hold-down bracket and tighten nuts.
11. Connect positive (+) then negative (–) cables.
12. Apply petroleum jelly on battery terminals.
13. Install battery box cover and floor access plate.

A—Floor Plate  
B—Cap Screw (4 used)  
C—Battery Box Cover  
D—Nut (2 used)  
E—Bracket  
F—Vent Tube



TS204 –UN–23AUG88

LV2248 –UN–08AUG97

LV1386 –UN–05DEC95

LV1387 –UN–05DEC95

Continued on next page

AG,OUO1085,62 –19–07AUG00–1/2

14. Position floor mat and install screw in center floor panel.

AG,OUO1085,62 -19-07AUG00-2/2


## Remove and Install Starter—5210 and 5310

*NOTE: Tractor without cab air conditioning shown.*


1. Remove right front grille panel.
2. Disconnect negative (–) battery cable.

*NOTE: If equipped with air conditioning, cut all tie straps as necessary and move air conditioning lines away from starter.*

3. Remove nut (A) and cover (B).
4. Disconnect cables at stud (C).
5. Disconnect wire lead at stud.
6. Remove cap screws and lock washers (E).
7. Remove starter.
8. Make repairs as necessary. (See CTM77.)
9. Install starter using cap screws and lock washers (E).
10. Connect wire lead to stud (D).
11. Install cover.
12. Connect cables at stud (C). Install cover (B) and nut (A).
13. Connect negative (–) battery cable and install front grille panel.



LV2320 -UN-16DEC97



LV2321 -UN-16DEC97

- A—Nut
- B—Cover
- C—Starter Solenoid “B” Stud
- D—Starter Solenoid “S” Stud
- E—Cap Screws and Lock Washers

AG,OUO1085,63 -19-08AUG00-1/1



## Remove and Install Starter—5410 and 5510

*NOTE: Tractor with cab air conditioning shown.*

1. Remove right front grille panel.
2. Disconnect battery negative (–) cable.



*NOTE: Close all openings using caps and plugs to prevent contamination.*

3. Disconnect line (A) at hydraulic pump. Move line away from starter.

*NOTE: If equipped with air conditioning, cut all tie straps as necessary and move air conditioning lines away from starter.*


4. Disconnect cables at stud (B).
5. Remove cover (C).
6. Disconnect wiring lead (D).
7. Remove cap screws and lock washer (E).
8. Remove starter.
9. Make repairs as necessary. (See CTM77.)
10. Install starter using cap screws and lock washers (E).
11. Connect wiring lead (D).
12. Install cover (C).
13. Connect cables at stud (B).
14. Connect hydraulic line (A).
15. Install new wire ties as necessary.
16. Connect battery negative (–) cable and install grille panel.

A—Hydraulic Pump-to-Inlet Housing Supply Line  
 B—Starter Solenoid “B” Stud  
 C—Cover  
 D—Wire Lead  
 E—Cap Screws and Lock Washers



## Replace Alternator/Regulator—40 Amp Without Cab

1. Remove right grille panel.
2. Disconnect negative (–) cable at battery.
3. Disconnect wiring connector (A) and cable (B).
4. Loosen cap screws (C and F).
5. Move alternator/regulator (D) towards engine. Lift belt (E) off pulley.
6. Remove adjustment and pivot cap screws.
7. Replace alternator/regulator.
8. Install cap screws.
9. Adjust belt tension. (See Fan/Alternator V-Belt Adjustment (5210 and 5310) in Section 220, Group 15.)
10. Connect wiring connector and cable.
11. Connect negative (–) cable at battery.
12. Install right grille panel.




A—Wiring Connector  
B—Cable  
C—Adjustment Cap Screw  
D—Alternator/Regulator  
E—Belt  
F—Pivot Cap Screw

AG,OUO1085,67 –19–08AUG00–1/1

## Replace Alternator/Regulator—60 and 65 Amp with Cab

1. Remove right grille panel.
2. Disconnect negative (–) cable at battery.
3. Disconnect wiring connector (A) and cable (B).
4. Remove bracket (E).
5. Put a wrench on upper pulley of belt tensioner (D) and turn tensioner counterclockwise to relieve belt tension. Remove belt from alternator/regulator pulley.
6. Remove cap screws (C and F).
7. Replace alternator/regulator.
8. Install cap screws (C and F).
9. Install belt on alternator pulley.
10. Connect wiring connector (A) and cable (B).
11. Install bracket (E).
12. Connect negative (–) cable at battery.
13. Install right grille panel.



A—Wiring Connector  
B—Cable  
C—Cap Screw  
D—Upper Tensioner Pulley  
E—Bracket  
F—Cap Screw

LV2279 -UN-26NOV97

40  
05  
7

AG,OUO1085,68 -19-08AUG00-1/1

40  
05  
8



Specifications

Item	Measurement	Specification
Fuel Tank Retaining Strap Nut	Torque	35 N•m (26 lb-ft)
Rear Cab Mounting Nuts	Torque	203 N•m (150 lb-ft)

OUO1010,0000561 -19-24JUL02-1/1

Service Equipment and Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.

SERVICEGARD is a trademark of Deere & Company

OUO1010,0000564 -19-24JUL02-1/2

- Special Socket . . . . . JDG465
- Engine Oil Pressure Switch

OUO1010,0000564 -19-24JUL02-2/2

Other Material

Number	Name	Use
TY9375 (U.S.) TY9480 (Canadian) 592 (LOCTITE®)	Pipe Sealant	Apply to threads of air restriction switch. Apply to threads of coolant temperature sender.
T43512 (U.S.) TY9473 (Canadian) 242 LOCTITE® (LOCTITE®)	Thread Lock and Sealer (Medium Strength)	Apply to threads of engine oil pressure switch.


LOCTITE is a registered trademark of Loctite Corp.

OUO1010,0000565 -19-24JUL02-1/1

## Replace Air Filter Restriction Switch—5210 and 5310

**NOTE:** Right grille panel removed for illustration purposes only.

1. Disconnect wiring connector (B) and remove switch (A).
2. Apply pipe sealant with TEFLON® tape to threads of switch before installation.
3. Install air filter restriction switch.
4. Connect wiring connector.



LV2323 -UN-16DEC97


**A—Air Filter Restriction Switch**

TEFLON is a registered trademark of Du Pont Co.

AG,OUO1085,70 -19-08AUG00-1/1

## Replace Air Filter Restriction Switch—5410 and 5510

1. Remove left grille panel.
2. Disconnect wiring connector (A) and remove switch (B).
3. Apply pipe sealant with TEFLON® tape to threads of switch before installation.
4. Install air filter restriction switch.
5. Connect wiring connector.



LV2114 -UN-14MAY97

**A—Wiring Connector  
B—Air Filter Restriction Switch**


TEFLON is a registered trademark of Du Pont Co.

AG,OUO1085,71 -19-08AUG00-1/1

## Replace Coolant Temperature Sender—5210 and 5310

**NOTE:** In 5210 and 5310 model tractors the coolant temperature sender is located at the left hand rear corner on top of cylinder head.

1. Disconnect wiring connector (A).
2. Remove and discard coolant temperature sender (B).
3. Apply John Deere Pipe Sealant with TEFLON®, or an equivalent, to threads of new temperature sender.
4. Install new temperature sender.
5. Connect wiring connector.



A—Wiring Connector  
B—Coolant Temperature Sender


TEFLON is a registered trademark of the Du Pont Co.

AG,OUO1085,72 -19-08AUG00-1/1

## Replace Coolant Temperature Sender—5410 and 5510

**NOTE:** In 5410 and 5510 model tractors the coolant temperature sender is located on the thermostat housing.

1. Disconnect wiring connector (A).
2. Remove and discard coolant temperature sender (B).
3. Apply John Deere Pipe Sealant with TEFLON®, or an equivalent, to threads of new temperature sender.
4. Install new temperature sender.
5. Connect wiring connector.



A—Wiring Connector  
B—Coolant Temperature Sender

TEFLON is a registered trademark of Du Pont Co.

AG,OUO1085,73 -19-08AUG00-1/1

## Replace Engine Speed Sensor


**NOTE:** 4-cylinder engine shown. 3-cylinder engines are similar.

1. Disconnect wiring connector (A).

**IMPORTANT:** Speed sensor is plastic. Do not overtighten or sensor will be damaged.

2. Replace speed sensor and O-ring (B).
3. Connect wiring connector.

A—Wiring Connector  
B—Engine Speed Sensor and O-Ring



AG,OUO1023,258 -19-06OCT99-1/1


## Replace Engine Oil Pressure Switch

**NOTE:** 5210/5310 tractor shown, 5410/5510 is similar.

1. Disconnect wiring connector (A).

**NOTE:** JDG465 special socket may be used to replace switch.

2. Remove and discard oil pressure switch (B).
3. Apply thread lock and sealer (medium strength) to threads of new oil pressure switch.
4. Install switch.
5. Connect wiring connector.



A—Wiring Connector  
B—Engine Oil Pressure Switch


AG,OUO1085,74 -19-08AUG00-1/1

## Replace Air Intake Heater

*NOTE: 5210/5310 tractor shown; 5410/5510 is similar.*

1. Disconnect wiring lead (A).
2. Replace air intake heater (B).
3. Connect wiring lead.

A—Wiring Lead  
B—Air Intake Heater



LV2119 -UN-15MAY97

40  
10  
5


OUC1023,0000011 -19-07APR04-1/1

## Replace Air Intake Heater Relay


*NOTE: Model 5410/5510 tractor shown. 5210/5310 is similar and is located next to the fuel filter primer pump.*

1. Disconnect battery negative (-) cable.
2. Disconnect wiring connectors.
3. Remove cap screw (A) and relay.
4. Install new relay and cap screw.
5. Connect wiring leads (B—E).
6. Connect battery negative (-) cable.

A—Cap Screw  
B—385 Green Wiring Lead  
C—002 Red Wiring Lead  
D—010 Black Wiring Lead  
E—383 Orange Wiring Lead



LV2120 -UN-08AUG97



Blades (Terminals) on End of Relay

LV566AE -UN-09MAR92

OUC1023,0000012 -19-07APR04-1/1




## Replace Key Switch


**NOTE:** Tractor equipped with tilt steering wheel shown.  
Tractors without tilt steering are similar.

1. Disconnect battery negative (–) cable.
2. Remove key switch nut (A).
3. Remove key switch panel (B).
4. Disconnect wiring lead (C).
5. Disconnect wiring connector (D) and replace key switch.
6. Connect wiring connector (D) and wire lead (C).
7. Install key switch panel.
8. Install nut.
9. Connect battery negative (–) cable.

A—Nut  
B—Key Switch Panel  
C—010 Black Wire Lead  
D—Wiring Connector



LV2121 –UN-15MAY97




LV2122 –UN-15MAY97


AG,OUO1085,77 –19-08AUG00-1/1

## Replace Tractor Light Switch

1. Disconnect battery negative (–) cable.
2. Remove mounting hardware from left dash panel but do not remove panel.
3. Remove right dash panel.
4. Disconnect wiring connectors.
5. Remove cap screw and knob (A).
6. Remove nut and lock washer (B) under knob.
7. Replace light switch.
8. Install lock washer and nut.
9. Install knob and cap screw.
10. Connect wiring leads (C–H).
11. Install right dash panel.
12. Install mounting hardware for left dash panel.
13. Connect battery negative (–) cable.



LV684 –UN–21SEP94



*Blades (Terminals) on End of Switch*

- A—Light Switch Knob
- B—Nut and Lock Washer
- C—113 Orange Wire Lead
- D—102 Red Wire Lead
- E—122 Red Wire Lead
- F—137 Purple Wire Lead
- G—134 Yellow Wire Lead
- H—103 Orange Wire Lead

40  
10  
7

LV2123 –UN–09JUN97

AG,QUO1085,78 –19–08AUG00–1/1




## Replace Radio

1. Insert two radio removal tools (A) into small holes on the left and right side of radio (B).
2. Push inward on tools (A) to remove radio from mounting bracket.
3. Pull radio out of control panel. Disconnect wiring connector and antenna cable on back of radio.

**NOTE:** Push inward until radio locks in place into mounting bracket.

4. Replace radio. Connect wiring connector and antenna cable.




A—Radio Removal Tool (2 used)  
B—Radio

AG,OUO1085,79 -19-08AUG00-1/1

## Replace Speakers

**NOTE:** Speakers are located above side windows on each side of cab.

1. Remove rear headliner. (See Remove and Install Rear Headliner in Section 90, Group 15.)
2. Remove four screws (A) securing speaker to cab panel.
3. Tag and disconnect wires from speaker.
4. Connect wires to new speaker using tags for identification.
5. Install speaker with four screws (A).
6. Install rear headliner. (See Remove and Install Rear Headliner in Section 90, Group 15.)




A—Screw (4 used)

AG,OUO1085,80 -19-08AUG00-1/1

## Replace Antenna

1. Remove nut, washer, and screw (A), and antenna mast (B).
2. Remove nut (C), ferrule (D), and washer (E).

A—Nut, Washer, and Screw  
 B—Antenna Mast  
 C—Nut  
 D—Ferrule  
 E—Washer




LV1441 -UN-10NOV95

AG,OUO1085,81 -19-08AUG00-1/3

40  
10  
9

3. Remove antenna mount (A) and locking ring from plate (C).
4. If necessary, remove ground wire (D) from plate.
5. To remove antenna cable, unplug cable from back of radio. (See Replace Radio in this group.)
6. Connect ground wire (D) to plate (C).
7. Install locking ring (B) and antenna mount (A) on plate and push through hole in roof.

A—Antenna Mount  
 B—Locking Ring  
 C—Plate  
 D—Ground Wire




LV1442 -UN-10NOV95

Continued on next page

AG,OUO1085,81 -19-08AUG00-2/3

8. Fasten the antenna mount to cab roof using washer (E), ferrule (D), and nut (C).
9. Fasten antenna mast (B) to the antenna mount using nut, washer, and screw (A).

A—Nut, Washer, and Screw  
 B—Antenna Mast  
 C—Nut  
 D—Ferrule  
 E—Washer




LV1441 -UN-10NOV95

AG,OUO1085,81 -19-08AUG00-3/3

## Replace Turn Signal Controller

1. Disconnect battery negative (-) cable.
2. Remove left dash panel.
3. Disconnect wiring connector (C).
4. Remove screw, lock washer and lever (A).
5. Remove nut (B) and controller.
6. Install new controller and nut.
7. Install lever, lock washer and screw.
8. Connect wiring connector.
9. Install dash panel.
10. Connect battery negative (-) cable.



A—Lever  
 B—Nut  
 C—Wiring Connector


LV559 -UN-09MAR92

AG,OUO1023,261 -19-06OCT99-1/1

## Replace Instrument Panel— CollarShift/SyncShuttle™ Transmission

1. Remove right and left dash panels.
2. Remove turn signal controller. (See Replace Turn Signal Controller in this group.)
3. Remove light switch. (See Replace Tractor Light Switch in this group.)
4. Remove throttle lever knob (A).
5. Disconnect wiring connectors (B and C).
6. Remove instrument panel assembly.

A—Throttle Lever Knob  
B—Wiring Connector  
C—Wiring Connector




Continued on next page

AG,OUO1085,82 -19-27JUN02-1/2

LV2133 -UN-14MAY97

40  
10  
11



Exploded View of Instrument Panel

- |                      |                           |                                 |                                    |
|----------------------|---------------------------|---------------------------------|------------------------------------|
| A—Wiring Harness     | D—Glass                   | G—Bulb (10 used)                | I—Tach Switch                      |
| B—Instrument Cluster | E—Instrument Panel        | H—Bulb Dust Cover (rectangular) | J—Phillips Head Cap Screw (8 used) |
| C—Gasket             | F—Bulb Dust Cover (round) |                                 |                                    |

7. Inspect and replace parts (A—J) as necessary.

**NOTE:** The tach switch (I) is located underneath the small rubber dust cap.

8. Make sure 2-position tach switch (I) is in the correct position for 3-cylinder or 4-cylinder engines.

- 3-Cylinder: Tab on tach switch must be in the UP position. (24 pulse/engine revolution)
- 4-Cylinder: Tab on tach switch must be in the DOWN position. (30 pulse/engine revolution)

9. Install instrument panel assembly.

10. Connect wiring connectors.

11. Install throttle lever knob.

12. Install light switch.

13. Install turn signal controller.

14. Install right and left dash panels.

LV2132 -UN-22AUG01


AG,OUO1085,82 -19-27JUN02-2/2




## Replace Instrument Panel—PowrReverser™ Transmission

1. Remove right and left dash panels.
2. Remove two cap screws (A) and plate (B).
3. Remove two screws (C), knob (D), and bracket (E).
4. Remove light switch. (See Replace Tractor Light Switch in this group.)
5. Remove throttle lever knob.

A—Cap Screw (2 used)  
 B—Plate  
 C—Screw (2 used)  
 D—Knob  
 E—Bracket



LV1373 -UN-15SEP95




LV1374 -UN-15SEP95

40  
10  
13


AG, OOU1085,83 -19-27JUN02-1/4

6. Disconnect F-N-R linkage (A) and park brake linkage (B).
7. Remove two cap screws and nuts (C).
8. Remove two cap screws, washers, and nuts (E).
9. Remove F-N-R lever assembly.

A—F-N-R Linkage  
 B—Park Brake Linkage  
 C—Cap Screw and Nut (2 used)  
 D—F-N-R Lever Assembly  
 E—Cap Screw, Washer, and Nut (2 used)



LV1375 -UN-15SEP95




LV1376 -UN-15SEP95

Continued on next page

AG, OOU1085,83 -19-27JUN02-2/4

10. Disconnect turn signal connector (A) on back of instrument panel.
11. In tractors equipped with a tilt steering wheel, remove plastic covers (B) around tilt mechanism.
12. Disconnect instrument panel main harness connectors (C) on back of instrument panel and remove panel.

A—Turn Signal Connector  
B—Plastic Cover  
C—Main Harness Connector




LV2134 -UN-14MAY97

Continued on next page

AG,OUO1085,83 -19-27JUN02-3/4





A—Wiring Harness  
B—Instrument Cluster  
C—Gasket

D—Glass  
E—Instrument Panel  
F—Bulb Dust Cover (round)

G—Bulb (10 used)  
H—Bulb Dust Cover (rectangular)

I—Tach Switch  
J—Phillips Head Cap Screw (8 used)

13. Inspect and replace parts (A—J) as necessary.

**NOTE:** The tach switch (I) is located underneath the small rubber dust cap.

14. Make sure 2-position tach switch (I) is in the correct position for 3-cylinder or 4-cylinder engines.

- 3-Cylinder: Tab on tach switch must be in the UP position. (24 pulse/engine revolution)
- 4-Cylinder: Tab on tach switch must be in the DOWN position. (30 pulse/engine revolution)

15. Install instrument panel assembly.

16. Connect wiring connectors.

17. Install throttle lever knob.

18. Install light switch.

19. Install F-N-R lever assembly and connect linkage.

AG, OUC1085,83 -19-27JUN02-4/4

40  
10  
15


LV2124 -UN-28JUN02

## Replace Rear PTO Switch—Tractors Without Cab

**NOTE:** Left wheel, fender, and fuel line removed for illustration purposes only.

1. Disconnect wiring connector (A).
2. Replace rear PTO switch (B).
3. Connect wiring connector.

A—Wiring Connector  
B—Rear PTO Switch



LV524 -UN-09MAR92

AG,OUO1085,85 -19-08AUG00-1/1


## Replace Rear PTO Switch—Tractors With Cab

**NOTE:** Tractor without cab shown for illustration purposes only.

*If necessary remove cab seat, support, and left control console and panel.*

1. Remove seat and support plate. (See Remove and Install Seat and Support Plate—Tractors With Cab in Section 90, Group 05.)
2. Remove left control console and panel. (See Remove and Install Left-Side Control Console—Tractors With Cab in Section 90, Group 15.)
3. Disconnect wiring connector (A).
4. Replace rear PTO switch (B).
5. Connect wiring connector.
6. If removed, install console support plate, base plate, and seat.

A—Wiring Connector  
B—Rear PTO Switch



LV524 -UN-09MAR92


AG,OUO1085,86 -19-08AUG00-1/1

## Replace Neutral Start Switch

**NOTE:** Right fender removed for illustration purposes only.

*If equipped with PowrReverser™ transmission, neutral start switch is located on the PowrReverser™ control valve.*

1. Remove seat and support plate. (See Remove and Install Seat and Support—Tractors Without Cab or Remove and Install Seat and Support Plate—Tractors With Cab in Section 90, Group 05.)
2. Remove right control console. (See Remove and Install Right-Side Control Console and Panel—Tractors Without Cab in Section 90, Group 06 or Remove and Install Right-Side Control Console and Panel—Tractors With Cab in Section 90, Group 15.)
3. Disconnect wiring connector (B).
4. Replace neutral start switch and O-ring (A).
5. Connect wiring connector.
6. Install control console.
7. Install seat and support plate.



Right Side of Transmission Housing Shown

**A—Neutral Start Switch and O-Ring**  
**B—Wiring Connector**

LV521 -UN-09MAR92

40  
10  
17


AG,OUO1085,88 -19-27JUN02-1/1

## Replace Seat Switch

**NOTE:** Seat switch is located under seat cushion.

1. Disconnect wiring connector at seat switch.
2. Remove two screws (A) and remove switch assembly (B) from bottom of cushion.

**A—Screw (2 used)**  
**B—Seat Switch Assembly**



LV2326 -UN-16DEC97

Continued on next page

AG,OUO1085,89 -19-08AUG00-1/3

3. Remove switch plunger (A) and replace switch (B).

4. Install switch plunger (A).

A—Seat Switch Plunger  
B—Seat Switch




LV2327 -UN-26NOV97

AG,OUO1085,89 -19-08AUG00-2/3

5. Install seat switch assembly (B) and screws (A) in bottom of seat cushion.

6. Connect wiring connector.

A—Screw (2 used)  
B—Seat Switch Assembly



LV2326 -UN-16DEC97

AG,OUO1085,89 -19-08AUG00-3/3

## Replace Fuel Level Sender—Tractors Without Cab


1. Disconnect wiring lead (A and B).

2. Remove screws (C).

3. Replace fuel level sender and gasket (D).

4. Install screws.

5. Connect wiring leads.



LV2125 -UN-15MAY97

A—010 Black Wire Lead  
B—353 Orange Wire Lead  
C—Screw (5 used)  
D—Fuel Level Sender and Gasket

AG,OUO1085,90 -19-08AUG00-1/1


## Replace Fuel Level Sender—Tractors With Cab

1. Remove fuel tank retaining strap nut (B) and screw (A) on both sides of fuel tank.

**NOTE:** Rear of cab must be lifted upward approximately 25.4 mm (1.000 in.) for clearance to tilt fuel tank back.

2. Remove rear cab mounting nuts (C) on both sides of cab.


A—Screw  
B—Fuel Tank Retaining Strap Nuts  
C—Rear Cab Mounting Nut



AG,OUO1085,91 -19-08AUG00-1/4

3. Remove slow moving vehicle (SMV) emblem (A) and hydraulic oil dipstick (B) to aid during removal and installation of fuel level sender.
4. Lower lifting arms (C) and center link (D).
5. At location in front of right rear axle:
  - Disconnect fuel level sender wiring connector.
  - Cut all tie straps as necessary.

A—SMV Emblem  
B—Dipstick  
C—Lifting Arms  
D—Center Link



LV2263 -UN-20NOV97

Continued on next page

AG,OUO1085,91 -19-08AUG00-2/4



6. Using a hoist, raise rear of cab off rear cab mounts approximately 25.4 mm (1.000 in.). Tilt top of fuel tank back to access fuel level sender.

7. Disconnect wiring leads (A).


8. Remove retaining screws (B).

9. Replace fuel level sender and gasket (C).

10. Install screws.

**NOTE:** Connect orange wiring lead to the center terminal.

11. Connect wiring leads.



LV517 -UN-09MAR92

A—Wiring Leads  
B—Retaining Screws  
C—Fuel Level Sender and Gasket

AG,OUO1085,91 -19-08AUG00-3/4

12. Tilt fuel tank forward and lower cab.

13. Install fuel tank retaining strap nuts (B) and screws (A) on both sides of fuel tank. Tighten nuts (B) to specification.

**Specification**

Fuel Tank Retaining Strap Nut—  
Torque ..... 35 N•m (26 lb-ft)

14. Install rear cab mounting nuts (C). Tighten nuts to 203 N•m (150 lb-ft).

**Specification**


Rear Cab Mounting Nuts—  
Torque ..... 203 N•m (150 lb-ft)

15. Install hydraulic oil dipstick and SMV emblem.

16. At location in front of right rear axle:

- Connect fuel level sender wiring connector.
- Install tie straps as necessary.

A—Screws  
B—Fuel Tank Retaining Strap Nuts  
C—Rear Cab Mounting Nuts




LV2410 -UN-16DEC97

AG,OUO1085,91 -19-08AUG00-4/4

## Replace Wiper Control Switch

1. Disconnect battery negative (-) cable.
2. Loosen six screws (A) and remove air recirculating intake cover and filter (B).

A—Screw (6 used)  
B—Filter




LV1398 -UN-08AUG97

AG,OUO1085,92 -19-08AUG00-1/3

**NOTE:** Support control panel (B) using wire or rope to prevent weight of panel from pulling on wires during removal of wiper control switch.

3. Remove twelve screws (A) and control panel (B). Support weight of control panel using wire or rope.

A—Screw (12 used)  
B—Control Panel




LV1401 -UN-08AUG97


AG,OUO1085,92 -19-08AUG00-2/3

4. Remove knob (A) and nut (B).
5. Disconnect wiring leads (C—G).
6. Replace wiper control switch.
7. Connect wiring leads (C—G).
8. Install nut (B) and knob (A).
9. Install control panel and recirculating air intake cover and filter.
10. Connect battery negative (-) cable.

A—Knob  
B—Nut  
C—229 White Wire Lead  
D—262 Red Wire Lead  
E—238 Grey Wire Lead  
F—224 Yellow Wire Lead  
G—234 Yellow Wire Lead



LV1413 -UN-10NOV95




LV1414 -UN-05DEC95

AG,OUO1085,92 -19-08AUG00-3/3



## Replace Wiper Motor



A—Electrical Connector

B—Nut

C—Screw (3 used)

1. Remove cab roof. (See Remove and Install Cab Roof in Section 90, Group 15.)
2. Disconnect electrical connector (A) from motor.
3. Remove nut (B) from motor shaft.
4. Remove three screws (C) and lock washers.

*NOTE: Wiper motor is not repairable.*

5. Replace front wiper motor.
6. Install cab roof.


AG,OUO1085,93 -19-08AUG00-1/1

## Replace Blower Control Switch

1. Disconnect battery negative (–) cable.
2. Loosen six screws (A) and remove air recirculating intake cover and filter (B).

A—Screw (6 used)

B—Filter




Continued on next page

AG,OUO1085,94 -19-08AUG00-1/3

**NOTE:** Support control panel (B) using wire or rope to prevent weight of panel from pulling on wires during removal of blower control switch.

3. Remove twelve screws (A) and control panel (B). Support weight of control panel using wire or rope.

A—Screw (12 used)  
B—Control Panel




LV1401 -UN-08AUG97


AG,OUO1085,94 -19-08AUG00-2/3

4. Remove Knob (A) and nut (B).
5. Disconnect wiring connector (C).
6. Replace blower switch (D).
7. Install nut (B) and knob (A).
8. Connect wiring connector (C).
9. Install control panel, recirculating intake cover, and filter.
10. Connect battery negative (-) cable.

A—Knob  
B—Nut  
C—Wiring Connector  
D—Blower Switch



LV1411 -UN-12JAN96




LV1412 -UN-10NOV95

AG,OUO1085,94 -19-08AUG00-3/3

## Replace Air Conditioning Temperature Control Switch

1. Disconnect battery negative (-) cable.
2. Loosen six screws (A) and remove air recirculating intake cover and filter (B).

A—Screw (6 used)  
B—Filter



LV1398 -UN-08AUG97


Continued on next page

AG,OUO1085,95 -19-08AUG00-1/3

**NOTE:** Support control panel (B) using wire or rope to prevent weight of panel from pulling on wires during removal of control switch.

3. Remove twelve screws (A) and control panel (B). Support weight of control panel using wire or rope.

A—Screw (12 used)  
B—Control Panel




LV1401 -UN-08AUG97

AG,OUO1085,95 -19-08AUG00-2/3


4. Remove knob (A) and nut (B).
5. Remove control switch (C), from overhead panel.
6. Disconnect wiring leads (D and E).
7. Pull capillary sensing line (F) out of evaporator core.
8. Replace air conditioning control switch.

**IMPORTANT:** Insert end of capillary sensing line into the core of the evaporator, near the right side.

9. Connect wiring leads (D and E).
10. Install control switch (C) into panel.
11. Install nut (B) and knob (A).
12. Install control panel and recirculating intake cover and filter.
13. Connect battery negative (-) cable.



LV1415 -UN-05DEC95



LV1416 -UN-10NOV95


A—Knob  
B—Nut  
C—Control Switch  
D—228 Gray Wiring Lead  
E—227 Purple Wiring Lead  
F—Capillary Sensing Line

AG,OUO1085,95 -19-08AUG00-3/3


## Replace Dome Light

1. Disconnect battery negative (-) cable.
2. Remove dome light (A), from headliner.
3. Disconnect wiring leads (B—D)
4. Remove cover (E) and replace bulb (F).
5. Install cover (E) and connect wiring leads (B—D).
6. Install dome light (A).
7. Connect battery negative (-) cable.

A—Dome Light  
 B—262 Red Wiring Lead  
 C—255 Grn Wiring Lead  
 D—010 Blk Wiring Lead  
 E—Cover  
 F—Bulb



LV1417 -UN-10NOV95



LV1418 -UN-10NOV95


AG,OUO1085,96 -19-08AUG00-1/1

## Replace Dome Light Switch

**NOTE:** Dome light switches are located in upper front corner of cab door frame on both sides of cab.


1. Disconnect battery negative (–) cable.
2. Remove the side trim cover along cab door frame.
3. Remove nut (A).
4. Disconnect wiring leads (B and C).
5. Replace light switch (D).
6. Connect wiring leads to new light switch.
7. Install switch in cab door frame.
8. Install nut and side trim cover.
9. Connect battery negative (–) cable.

A—Nut  
B—Wiring Lead  
C—Wiring Lead  
D—Light Switch



LV1419 –UN–10NOV95

Right Side Light Switch Shown



LV1420 –UN–10NOV95

AG,OUO1085,97 –19–08AUG00–1/1

Special or Essential Tools


NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or in the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company.

DX,JDG155 –19–05JUN90–1/2

Electrical Repair Tool Kit. . . . . JDG155

For repair and installation of wires into electrical connectors.



TS446 –UN–22JUN89

DX,JDG155 –19–05JUN90–2/2

Service Equipment and Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.

SERVICEGARD is a trademark of Deere & Company

AG,OUO1085,263 –19–28AUG00–1/3

Extraction Tool . . . . . JDG364

Pulls wire from connector body.

AG,OUO1085,263 –19–28AUG00–2/3

Terminal Applicator . . . . . JDG783

Applies contact to terminal wire.

AG,OUO1085,263 –19–28AUG00–3/3



## Service Parts Kits

The following kits are available through your parts catalog:


- RE11154 Electrical Connector and Wire Service Kit.

DX,ECONN,AE -19-09AUG00-1/1

## Replace Connector Body—Blade Terminals

1. Use a small screwdriver to depress locking tang (A) on terminal. Slide connector body off.
2. Be sure to bend locking tang back to its original position (B) before installing connector body.

A—Locking Tang  
B—Locking Tang—Original Position



RW4218 -UN-23AUG88


AG,OUO1085,98 -19-09AUG00-1/1

## Replace WEATHER PACK™ Connector

**IMPORTANT:** Identify wire color locations with connector terminal letters.

1. Open connector body.
2. Insert JDG364 Extraction Tool over terminal contact in connector body.
3. Hold extractor tool fully seated and pull wire from connector body.

**NOTE:** If terminal cannot be removed, insert wire or nail through extractor tool handle and push terminal contact from connector.



TS0128 -UN-23AUG88

WEATHER PACK is a trademark of Packard Electric.


Continued on next page

DX,ECONN,R -19-04JUN90-1/2

**IMPORTANT:** Carefully spread contact lances to assure good seating on connector body.

*NOTE:* Connector bodies are “keyed” for proper contact mating. Be sure contacts are in proper alignment.

4. Push contact into new connector body until fully seated.
5. Pull on wire slightly to be certain contact is locked in place.
6. Transfer remaining wires to correct terminal in new connector.
7. Close connector body.



TS0130 -UN-23AUG88

DX,ECONN,R -19-04JUN90-2/2

40  
15  
3

### Install WEATHER PACK™ Contact

*NOTE:* Cable seals are color coded for three sizes of wire:

- Green - 18 to 20 gauge wire
- Gray - 14 to 16 gauge wire
- Blue - 10 to 12 gauge wire

1. Slip correct size cable seal on wire.
2. Strip insulation from wire to expose 6 mm (1/4 in.) and align cable seal with edge of insulation.



TS0136 -UN-23AUG88

WEATHER PACK is a trademark of Packard Electric.


Continued on next page

DX,ECONN,AD -19-04JUN90-1/3

**NOTE:** Contacts have numbered identification for two sizes of wire:

- #15 for 14 to 16 gauge wire
- #19 for 18 to 20 gauge wire


3. Put proper size contact on wire and crimp in place with a "W" type crimp, using JDG783 Terminal Applicator.
4. Fasten cable seal to contact as shown, using JDG783 Terminal Applicator.



DX,ECONN,AD -19-04JUN90-2/3

**IMPORTANT:** Proper contact installation for "sleeve" (A) and "pin" (B) is shown.


A—Sleeve  
B—Pin



DX,ECONN,AD -19-04JUN90-3/3



## Replace Front Wiring Harness—3 Cylinder



### FRONT WIRING HARNESS—3-CYLINDER

A—Engine Speed Sensor  
B—Left Headlight  
C—Right Headlight  
D—Air Filter Restriction Indicator

E—Horn (Optional)  
F—Ground  
G—Alternator/Regulator  
H—Manifold Heater


I—Manifold Heater Relay  
J—To Fuse Link Junction Box  
K—Coolant Temperature Sender

L—Rear Wiring Harness  
M—Starter  
N—Fuel Shut-Off Solenoid  
O—Oil Pressure Switch

1. Remove front grille panels and cooling fan finger guard.
2. Remove battery. (See Remove and Install Battery—Tractors Without Cab or Remove and Install Battery—Tractors With Cab in Group 05.)
3. Cut all tie straps.
4. Remove all hold-down clamps.
5. Disconnect wiring connectors and leads (A—O).
6. Replace wiring harness.
7. Connect wiring connectors and leads.
8. Install hold-down clamps.
9. Install tie straps as necessary.
10. Install battery.
11. Install fan finger guard and front grille panels.

LV2126 -UN-13JUN01

## Replace Front Wiring Harness—4 Cylinder



### FRONT WIRING HARNESS—4-CYLINDER

A—Engine Speed Sensor  
B—Left Headlight  
C—Right Headlight  
D—Air Filter Restriction Indicator

E—Horn (Optional)  
F—Ground  
G—Alternator/Regulator  
H—Manifold Heater Relay


I—Manifold Heater  
J—To Fuse Link Junction Box  
K—Rear Wiring Harness  
L—Starter

M—Fuel Shut-Off Solenoid  
N—Oil Pressure Switch  
O—Coolant Temperature Sender

1. Remove front grille panels and fan finger guard.
2. Remove battery. (See Remove and Install Battery—Tractors Without Cab or Remove and Install Battery—Tractors With Cab in Group 05.)
3. Cut all tie straps.
4. Remove all hold-down clamps.
5. Disconnect wiring connectors and leads (A—O).
6. Replace wiring harness.
7. Connect wiring connectors and leads.
8. Install hold-down clamps.
9. Install tie straps as necessary.
10. Install battery.
11. Install fan finger guard and front grille panels.



# Replace Rear Wiring Harness—Tractors Without Cab



Rear Wiring Harness—Tractors Without Cab

- |                             |                           |                           |                                |
|-----------------------------|---------------------------|---------------------------|--------------------------------|
| 1—Fuse Block                | 10—Start Relay            | 19—Neutral Start Switch   | 24—Rear Work Light             |
| 2—Starter Motor Battery     | 11—Light Switch           | (CollarShift/SyncShuttle™ | 25—Left Warn/Turn Light        |
| Terminal                    | 12—Key Switch             | Transmission)             | 26—Left Front Fender           |
| 3—To Fuse Link Junction Box | 13—Instrument Panel       | 20—Seat Switch            | Floodlight (Model 5510         |
| 4—To Front Wiring Harness   | 14—Optional Horn Switch   | 21—Fuel Level Sender      | Tractor Only)                  |
| 5—Diode Pack                | 15—Turn Signal Controller | 22—Right Front Fender     | 27—Neutral Start Switch        |
| 6—Ground                    | 16—Horn/Timer             | Floodlight (Model 5510    | (PowrReverser™                 |
| 7—Accessory Relay           | 17—Rear PTO Switch        | Tractor Only)             | Transmission)                  |
| 8—Bypass Start Relay #2     | 18—Ground                 | 23—Right Warn/Turn Light  | 28—Start Resistor (4-cyl only) |
| 9—Bypass Start Relay #1     |                           |                           |                                |

Continued on next page

AG,OUO1085,104 -19-27JUN02-1/2


**NOTE:** Model 5510 tractors are equipped with left and right fender mounted floodlights.

1. Remove instrument panel. (See Replace Instrument Panel—CollarShift/SyncShuttle™ Transmission or Replace Instrument Panel—PowrReverser™ Transmission in Group 10.)
2. Remove seat and support. (See Remove and Install Seat and Support—Tractors Without Cab in Section 90, Group 05.)
3. Cut all tie straps.
4. Remove fuse block (1) under instrument panel console.
5. Disconnect diode pack (5) and relay sockets (7—9) from support bracket.

6. Disconnect all wiring connectors and leads.
7. Remove wiring harness.
8. Install new harness and connect all wiring connectors and leads.
9. Install fuse block and relay sockets.
10. Install tie straps as necessary.
11. Install seat and support.
12. Install instrument panel and dash covers.

AG,OUO1085,104 -19-27JUN02-2/2

Replace Rear Wiring Harness—Tractors With Cab



Rear Wiring Harness—Tractors With Cab

LV2251 -UN-01JUL02

Continued on next page

AG,OUO1085,106 -19-27JUN02-1/2


1—To Trailer Connector	10—Bypass Starter Relay #1	17—Air Conditioning	21—Ground
2—To Left Rear Taillight	11—Bypass Starter Relay #2	Compressor	22—Fuse Block
3—Rear PTO Switch	12—Accessory Relay	18—To Fuse Link Junction	23—Neutral Start Switch
4—Key Switch	13—Diode Pack	Block	24—Seat Switch
5—Light Switch	14—Horn/Timer	19—To Cab Harness at Right	25—Ground
6—Instrument Panel	15—To Tractor Front Wiring	Hand Cab Post	26—Fuel Level Sender
7—Optional Horn Switch	Harness	20—High and Low Pressure	27—Start Resistor (4-cyl only)
8—Turn Signal Controller	16—To Cab Harness at Left	Switch at Receiver Dryer	
9—Start Relay	Cab Post		

1. Remove dash panels.
2. Remove instrument panel. (See Replace Instrument Panel—CollarShift/SyncShuttle™ Transmission or Replace Instrument Panel—PowrReverser™ Transmission in Group 10.)
3. Remove seat and support. (See Remove and Install Seat and Support Plate—Tractors With Cab in Section 90, Group 05.)
4. Remove fuse block (22) from instrument panel console.
5. Disconnect relay sockets (10, 11, 12, and 13) from support bracket.
6. Disconnect remaining wiring connectors and leads.
7. Cut all tie straps.
8. Remove wiring harness.
9. Install new harness and connect all wiring connectors and leads.
10. Install fuse block and relay sockets.
11. Install tie straps as necessary.
12. Install seat and support.
13. Install dash covers.
14. Install instrument panel.

AG,OUO1085,106 –19–27JUN02–2/2

40  
15  
11

## Replace Cab Wiring Harness—Lights



Cab Lights Wiring Harness

A—Right Rear Floodlight  
B—Ground  
C—Left Rear Floodlight  
D—Left Rear Flasher  
E—Rear Floodlight Power Jumper

F—Left Front Flasher  
G—Ground  
H—Left Taillight  
I—Rear Tractor Harness Connector  
K—Rear Tractor Harness Connector

J—Rear Tractor Harness Connector  
K—Rear Tractor Harness Connector

L—Right Taillight  
M—Taillight Power Jumper  
N—Cab Lights Wiring Harness

1. Disconnect battery negative (–) cable.

2. Remove cab roof and rear cab liner behind seat.

Continued on next page

AG,OUO1085,108 –19–27JUN02–1/2

## Wiring Harness


3. Remove both taillights from housings.
4. Cut all tie straps.
5. Remove all hold-down clamps.
6. Disconnect wiring connectors and leads (A—L).
7. Replace wiring harnesses (M and N) and connect all wiring connectors and leads.
8. Fasten wiring harnesses using hold-down clamps and tie straps.

AG,OUO1085,108 -19-27JUN02-2/2

40  
15  
13



Replace Cab Wiring Harness—Radio/Antenna



Radio/Antenna Wiring Harness

- |                                |                        |                           |                           |
|--------------------------------|------------------------|---------------------------|---------------------------|
| A—Radio/Speaker Wiring Harness | C—Radio Connector      | F—Radio/Antenna Connector | H—Antenna Connector       |
| B—Left Speaker Connector       | D—Junction Block Leads | G—Antenna Cable           | I—Right Speaker Connector |
| E—Ground                       |                        |                           |                           |

1. Disconnect battery negative (–) cable.

Continued on next page

AG,OUO1085,110 –19–27JUN02–1/2

2. Remove rear headliner. (See Remove and Install Rear Headliner in Section 90, Group 15.)

3. Remove foam filler panels around left and right speakers to access connectors.

4. Disconnect wiring connectors (B and I).

*NOTE: Support control panel using wire or rope to prevent weight of panel from pulling on wiring during disconnection of harness.*

5. Remove overhead control panel.

6. Disconnect wiring connector (C) and leads (D).

7. Remove wiring harness (A).

8. Install new wiring harness and connect all connectors and leads.

9. Remove cab roof and disconnect wiring connectors and leads (E, F, and H).

10. Remove antenna cable (G).

11. Install new wiring harness and antenna cable and connect all leads and connectors.

12. Install cab roof. (See Remove and Install Cab Roof in Section 90, Group 15.)

13. Install foam filler panels around speakers and install rear headliner.


14. Install overhead control panel.

15. Connect battery negative (–) cable.

AG,OUO1085,110 –19–27JUN02–2/2

40  
15  
15

Replace Cab Wiring Harness—Main



Main Cab Wiring Harness

Continued on next page

AG.OUO1085,113 -19-27JUN02-1/2

LV1487 -UN-16DEC97

1—Right Rear Flasher	11—Blower Switch Connector	19—Dome Light	27—Doorjamb Switch—Right Side
2—Ground	12—Flood Light Relay	20—Right Blower Motor	28—Ground
3—Rear Wiper	13—Ground	21—Front Floodlight—Left Side	29—Fuse Link Junction Box
4—Cab Fuse Block	14—Cab Junction Block (10-24 Stud)	22—Floodlight Relay Jumper	30—Tractor Rear Harness Connector
5—Air Conditioning Control Switch	15—Cab Junction Block (10-24 Stud)	23—Front Wiper Motor	31—Tractor Rear Harness Connector
6—Main Cab Relay	16—Cab Junction Block (1/4-20 Stud)	24—Front Floodlight—Right Side	32—Tractor Rear Harness Connector
7—Rear Wiper Switch	17—Left Blower Motor	25—Front Flasher—Right Side	
8—Front Wiper Switch	18—Doorjamb Switch—Left Side	26—Ground	
9—Front Wiper Switch			
10—Ground			

1. Disconnect battery negative (–) cable.
  2. Remove cab roof. (See Remove and Install Cab Roof in Section 90, Group 15.)
  3. Remove left and right cab post trim strips.
  4. Remove air circulating intake cover and filter.
- NOTE: Support cab control panel using wire or rope to prevent weight of panel from pulling on wiring during disconnection of harness.*
5. Remove cab control panel.
  6. Cut all tie straps.
  7. Remove all hold-down clamps.
  8. Disconnect wiring connectors and leads (1—30).
  9. Replace wiring harness.
  10. Connect all wiring connectors and leads.
  11. Install hold-down clamps.
  12. Install new tie straps as necessary.
  13. Install cab control panel and air recirculating intake cover and filter.
  14. Install left and right cab post trim strips.
  15. Install cab roof. (See Remove and Install Cab Roof in Section 90, Group 15.)
  16. Connect battery negative (–) cable.

AG,OUO1085,113 –19–27JUN02–2/2

40  
15  
18

# Section 50

## Power Train Repair

### Contents

	Page		Page
<b>Group 05—Clutch Housing</b>		Remove and Inspect Clutch Release	
Service Equipment and Tools . . . . .	50-05-1	Mechanism and Shafts . . . . .	50-11-11
Specifications . . . . .	50-05-1	Install Clutch Release Mechanism and	
Service Parts Kits . . . . .	50-05-2	Shafts . . . . .	50-11-14
Separate Engine from Clutch		Remove, Inspect, and Repair	
Housing—Tractors Without Cab. . . . .	50-05-2	Transmission Pump . . . . .	50-11-16
Install Engine to Clutch Housing—Tractors			
Without Cab. . . . .	50-05-8	<b>Group 12—PowrReverser™</b>	
Separate Engine from Clutch		Essential Tools . . . . .	50-12-1
Housing—Tractors With Cab . . . . .	50-05-13	Specifications . . . . .	50-12-1
Install Engine to Clutch Housing—Tractors		Remove and Install PowrReverser™	
With Cab . . . . .	50-05-19	Control Valve . . . . .	50-12-2
Replace Clutch Housing Seal . . . . .	50-05-25	Disassemble, Inspect, and Repair	
Inspect and Repair Clutch Pedal and		PowrReverser™ Control Valve . . . . .	50-12-3
Linkage—CollarShift/SyncShuttle™ . . . . .	50-05-27	Remove and Install PowrReverser™ . . . . .	50-12-13
Inspect and Repair Clutch Pedal and		Disassemble, Inspect, and Repair Reverse	
Linkage—PowrReverser™ . . . . .	50-05-29	Idle Gear . . . . .	50-12-17
		Disassemble, Inspect, and Repair Clutch	
<b>Group 10—Clutch Assembly—</b>		Gear . . . . .	50-12-18
<b>CollarShift/SyncShuttle™</b>		Disassemble, Inspect, and Repair Driven	
<b>Transmissions</b>		Shaft . . . . .	50-12-19
Essential Tools . . . . .	50-10-1	Disassemble, Inspect, and Repair	
Other Material . . . . .	50-10-2	PowrReverser™ . . . . .	50-12-20
Specifications . . . . .	50-10-3		
Service Parts Kits . . . . .	50-10-3	<b>Group 15—CollarShift/SyncShuttle™ Transmission</b>	
Remove and Install Clutch Assembly . . . . .	50-10-4	Service Equipment and Tools . . . . .	50-15-1
Disassemble and Inspect Clutch Assembly . . . . .	50-10-5	Other Material . . . . .	50-15-1
Assemble Clutch Assembly . . . . .	50-10-8	Specifications . . . . .	50-15-2
Traction Clutch Finger Adjustment . . . . .	50-10-11	Separate Clutch Housing from Transmission. . . . .	50-15-3
PTO Clutch Finger Adjustment . . . . .	50-10-12	Install Clutch Housing to Transmission . . . . .	50-15-7
Remove and Inspect Clutch Release		Inspect and Repair Gear Shift Lever . . . . .	50-15-11
Mechanism and Shafts . . . . .	50-10-13	Inspect and Repair Range Shift Lever. . . . .	50-15-13
Install Clutch Release Mechanism and		Remove Transmission. . . . .	50-15-15
Shafts . . . . .	50-10-17	Disassemble and Inspect Transmission. . . . .	50-15-19
		Assemble Transmission . . . . .	50-15-24
<b>Group 11—Clutch Assembly—PowrReverser™</b>		Install Transmission. . . . .	50-15-32
<b>Transmission</b>		Disassemble, Inspect and Assemble Gear	
Essential Tools . . . . .	50-11-1	Shift Shaft Assemblies. . . . .	50-15-40
Other Material . . . . .	50-11-1	Disassemble, Inspect, and Assemble	
Specifications . . . . .	50-11-2	Transmission Top Shaft—CollarShift	
Service Parts Kits . . . . .	50-11-2	Transmission . . . . .	50-15-42
Remove and Install Clutch Assembly . . . . .	50-11-3	Disassemble, Inspect, and Assemble	
Disassemble and Inspect Clutch Assembly . . . . .	50-11-3	Transmission Top Shaft—SyncShuttle™	
Assemble Clutch Assembly . . . . .	50-11-6	Transmission . . . . .	50-15-44
PTO Clutch Finger Adjustment . . . . .	50-11-10		

Continued on next page



	Page		Page
Disassemble, Inspect, and Assemble Range Reduction Shaft . . . . .	50-15-47	Service Parts Kits . . . . .	50-25-2
Disassemble, Inspect and Assemble Driven Shaft . . . . .	50-15-48	Remove and Install Differential Assembly . . . . .	50-25-3
Remove, Inspect, and Install MFWD and Range Gears . . . . .	50-15-50	Disassemble, Inspect, and Assemble Differential Assembly . . . . .	50-25-5
Remove, Inspect, and Install Reverse Idler Shaft . . . . .	50-15-51	Remove and Inspect Differential Drive Shaft . . . . .	50-25-6
<b>Group 16—PowrReverser™ Transmission</b>		Install Differential Drive Shaft . . . . .	50-25-8
Service Equipment and Tools . . . . .	50-16-1	Remove, Inspect, and Install Differential Lock Assembly . . . . .	50-25-11
Other Material . . . . .	50-16-1	Differential Cone Point Adjustment . . . . .	50-25-13
Specifications . . . . .	50-16-1	Differential Backlash Adjustment . . . . .	50-25-14
Separate Clutch Housing From Transmission . . . . .	50-16-2	<b>Group 30—Final Drives</b>	
Install Clutch Housing to Transmission . . . . .	50-16-7	Service Equipment and Tools . . . . .	50-30-1
Remove Transmission . . . . .	50-16-12	Other Material . . . . .	50-30-1
Disassemble and Inspect Transmission . . . . .	50-16-19	Specifications . . . . .	50-30-1
Assemble Transmission . . . . .	50-16-23	Remove and Install Final Drive Assembly . . . . .	50-30-2
Install Transmission . . . . .	50-16-30	Remove and Inspect Planetary Drive Assembly . . . . .	50-30-4
Disassemble, Inspect, and Assemble Gear Shift Shaft Assemblies . . . . .	50-16-44	Install Planetary Drive Assembly . . . . .	50-30-6
Disassemble, Inspect, and Assemble Transmission Bottom Shaft . . . . .	50-16-46	Remove, Inspect, and Install Axle Shaft Assembly . . . . .	50-30-8
Disassemble, Inspect, and Assemble Range Reduction Shaft . . . . .	50-16-49	<b>Group 35—Mechanical Front Wheel Drive</b>	
Disassemble, Inspect, and Assemble Top Shaft . . . . .	50-16-50	Essential Tools . . . . .	50-35-1
Remove, Inspect, Install MFWD and Range Gears . . . . .	50-16-52	Service Equipment and Tools . . . . .	50-35-1
Remove, Inspect and Replace Hydraulic Reverser Control Lever . . . . .	50-16-53	Other Material . . . . .	50-35-2
<b>Group 20—Rear PTO Drive Shaft</b>		Specifications . . . . .	50-35-3
Specifications . . . . .	50-20-1	Inspect and Repair MFWD Lever and Linkage . . . . .	50-35-5
Remove, Inspect and Install Rear PTO Lever and Linkage . . . . .	50-20-2	Remove and Install MFWD Drop Gearbox . . . . .	50-35-6
Inspect and Repair PTO 540/540E Shift Lever and Linkage . . . . .	50-20-4	Disassemble and Inspect MFWD Drop Gearbox . . . . .	50-35-7
Remove and Install Standard Rear PTO Drive Shaft Assembly . . . . .	50-20-5	MFWD Drop Gearbox Cross Section . . . . .	50-35-10
Disassemble, Inspect and Assemble Standard Rear PTO Drive Shaft Assembly . . . . .	50-20-6	Assemble MFWD Drop Gearbox . . . . .	50-35-11
Remove and Install 540/540E Rear PTO Drive Shaft Assembly . . . . .	50-20-9	Remove, Inspect and Install MFWD Drive Shaft . . . . .	50-35-15
Disassemble, Inspect, and Assemble Rear 540/540E PTO Drive Shaft Assembly . . . . .	50-20-10	Remove and Install MFWD Axle Housing Assembly . . . . .	50-35-16
<b>Group 25—Differential</b>		Remove, Inspect and Install MFWD Axle Supports . . . . .	50-35-18
Essential Tools . . . . .	50-25-1	Disassemble and Inspect MFWD Outer Drive . . . . .	50-35-19
Other Material . . . . .	50-25-1	Assemble MFWD Outer Drive . . . . .	50-35-22
Specifications . . . . .	50-25-2	Remove, Inspect, and Install MFWD Swivel Housing . . . . .	50-35-24
		Remove, Inspect, and Install MFWD Axle Shaft . . . . .	50-35-27
		Remove and Install MFWD Differential Carrier Assembly . . . . .	50-35-29
		Disassemble and Inspect MFWD Differential Carrier Assembly . . . . .	50-35-30

Continued on next page

	Page
Assemble MFWD Differential Carrier Assembly . . . . .	50-35-34
<b>Group 40—Creeper Assembly</b>	
Other Material . . . . .	50-40-1
Specifications . . . . .	50-40-1
Remove and Install Creeper Assembly . . . . .	50-40-2
Disassemble, Inspect, and Assemble Creeper Assembly . . . . .	50-40-5



Service Equipment and Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.

SERVICEGARD is a trademark of Deere & Company

OUC1043,0000E94 -19-28JUN02-1/4

Lifting Brackets . . . . . JDG19

Remove and install engine.

OUC1043,0000E94 -19-28JUN02-2/4

Lifting Brackets . . . . . JT01748

Remove and install engine.

OUC1043,0000E94 -19-28JUN02-3/4

Flywheel Turning Tool . . . . . JDE83

Rotates flywheel.

OUC1043,0000E94 -19-28JUN02-4/4

Specifications

Item	Measurement	Specification
Engine-to-Clutch Housing Cap Screws and Nuts—3 Cylinder Tractors without Cab	Torque	300 N•m (225 lb-ft)
Engine-to-Clutch Housing Cap Screws adn Nuts—4 Cylinder Tractors without Cab	Torque	350 N•m (255 lb-ft)
Engine-to-Clutch Housing Cap Screws and Nuts—Tractors with Cab	Torque	318 N•m (235 lb-ft)

OUC1043,0000EC0 -19-28JUN02-1/1

## Service Parts Kits

The following kits are available through your parts catalog:

- Clutch Housing Seal Kit

AG,OUO1085,116 -19-09AUG00-1/1

## Separate Engine from Clutch Housing— Tractors Without Cab

*NOTE: 4-cylinder engine shown, 3-cylinder engines are similar.*

1. Remove MFWD drive shaft, if equipped. (See Remove, Inspect and Install MFWD Drive Shaft in Group 35.)
2. Remove left and right grille panels.
3. Remove left and right dash panels.
4. Remove hood and disconnect battery negative (—) cable from battery.

Continued on next page

AG,OUO1085,117 -19-28JUN02-1/6

**NOTE:** Close all openings using caps and plugs.

5. Remove fuel filter/primer pump assembly. (See Remove and Install Fuel Filter/Primer Pump Assembly—5210 and 5310 or Remove and Install Fuel Filter/Primer Pump Assembly—5410 and 5510 in Section 30, Group 05.) Close all openings using caps and plugs.


6. Disconnect main wiring harness connectors (A) located at rear of engine.

7. Disconnect hydraulic lines (B and C) from hydraulic pump.

**NOTE:** Support suction line (D). Transmission/hydraulic oil will spill out of hose if line drops below transmission/reservoir oil level.

8. Disconnect suction line (D) and support line to prevent oil from spilling out.

9. Remove clamp under right step plate that retains lines (C and D).



Right Side Shown

A—Main Wiring Harness Connector  
B—Hydraulic Line  
C—Hydraulic Line  
D—Hydraulic Suction Line

Continued on next page

AG,OUO1085,117 -19-28JUN02-2/6

LV2328 -UN-16DEC97

50  
05  
3




**NOTE:** Remove high mount oil filter if equipped. See procedures below.

10. Remove four cap screws (A) and remove filter assembly and mounting bracket (B).

**NOTE:** During removal of oil tubes (C and D) a small amount of engine oil will spill out. Close all openings using caps and plugs.

11. Remove oil tubes (C and D). Close all openings using caps and plugs.

A—Cap Screw (4 used)  
B—Oil Filter Assembly and Bracket  
C—Oil Tube  
D—Oil Tube




Continued on next page


AG,OUO1085,117 -19-28JUN02-3/6

12. Disconnect red wire lead No. 002C from right post (A) of fuse link junction block.
13. Disconnect fuel return hose (B) from injection nozzles.
14. Cut all tie straps as necessary and move wire leads and fuel hoses away from engine.

A—Right Post  
B—Fuel Return Hose



LV2329 -UN-16DEC97



LV2330 -UN-16DEC97

Continued on next page

AG,OUO1085,117 -19-28JUN02-4/6


50  
05  
5

15. Remove throttle linkage rod (A). If equipped with 540/540E shifttable PTO, remove throttle cable bracket located on left side of engine block.
16. Remove cap screw and clamp (B) and nut and clamp (C).

**NOTE:** Close all openings using caps and plugs.

17. Disconnect hydraulic lines (D). If equipped with hydraulic oil cooler, disconnect lines (E). Close all openings using caps and plugs.

A—Throttle Linkage Rod  
 B—Cap Screw and Clamp  
 C—Nut and Clamp  
 D—Hydraulic Line (2 used)  
 E—Oil Cooler Line (2 used)



LV2331 -UN-16DEC97

Continued on next page


AG,OUO1085,117 -19-28JUN02-5/6

18. Remove exhaust pipe and muffler.
19. Install lifting brackets such as JDG19 or JT01748 Lifting Brackets to the rear section of the engine cylinder head.
20. Install lifting eye or bracket in location of removed fuel filter/primer pump and muffler.
21. Attach a hoist to engine.
22. Install a floor jack under clutch housing.
23. Install wood blocks between front axle pivot stops and frame.


**NOTE:** Ensure disconnected hydraulic lines do not entangle with engine components or electrical wiring during engine/clutch housing separation.

24. Remove cap screws (A) and two nuts and washers (B). Repeat this procedure for opposite side of tractor.
25. Roll front section (engine/front axle assembly) away from tractor rear section.
26. Install a support stand under the flywheel housing of engine.

**A—Cap Screw**  
**B—Nut and Washer (2 used)**



LV2333 -UN-16DEC97



LV2296 -UN-16DEC97



## Install Engine to Clutch Housing—Tractors Without Cab

1. Clean mating surfaces of clutch housing and engine.

**NOTE:** Ensure disconnected hydraulic lines do not entangle with engine components or electrical wiring during engine/clutch housing installation.

*It may be necessary to rotate the PTO shaft and/or engine flywheel so the clutch shafts mesh with the clutch discs. Rotate the PTO shaft by manually turning the PTO at rear of tractor.*

*Rotate the engine flywheel using Flywheel Turning Tool JDE83.*


2. Apply Moly High Temperature EP Grease to traction and PTO clutch shafts.
3. Install engine to clutch housing. Tighten cap screws and nuts to specifications.

### Specification


Engine-to-Clutch Housing Cap	
Screws and Nuts—3 Cylinder	
Tractors without Cab—Torque .....	300 N•m (225 lb-ft)
Engine-to-Clutch Housing Cap	
Screws and Nuts—4 Cylinder	
Tractors without Cab—Torque .....	350 N•m (255 lb-ft)

4. Remove wood blocks and floor jack.
5. Remove lifting brackets.

A—Cap Screw  
B—Nut



LV2296 -UN-16DEC97



LV2333 -UN-16DEC97


Continued on next page

AG,OUO1085,118 -19-28JUN02-1/5

**IMPORTANT:** Make sure all O-rings are in place and in good condition before making any hydraulic line connections. Damaged or missing O-rings and seals will leak.

6. Connect hydraulic line (D). If equipped with hydraulic oil cooler, connect lines (E).
7. Install nut and clamp (C).
8. Install cap screw and clamp (B).
9. Install throttle linkage rod (A). If equipped with 540/540E shifttable PTO, install throttle cable bracket on left side of engine block.

A—Throttle Linkage Rod  
B—Cap Screw and Clamp  
C—Nut and Clamp  
D—Hydraulic Line (2 used)  
E—Oil Cooler Line (2 used)



LV2331 -UN-16DEC97

Continued on next page



AG,OUO1085,118 -19-28JUN02-2/5

50  
05  
9



10. Connect red wiring lead at right post (A) of fuse link junction block.
11. Connect fuel hose (B).

A—Right Post  
B—Fuel Hose




Continued on next page

AG,OUO1085,118 -19-28JUN02-3/5

12. Install tubes (C and D).
13. Install filter assembly and bracket (B) using cap screws (A).

A—Cap Screw (4 used)  
B—Filter Assembly and Bracket  
C—Oil Tube  
D—Oil Tube



LV2332 -UN-16DEC97

Continued on next page

AG,OUO1085,118 -19-28JUN02-4/5

50  
05  
11

14. Connect hydraulic lines (B and C).
15. Connect suction line (D).
16. Install clamp under right step plate that supports and retains lines (C and D).
17. Connect wiring connectors (A).
18. Install tie straps as necessary.
19. Install fuel filter/primer pump assembly. (See Remove and Install Fuel Filter/Primer Pump Assembly—5210 and 5310 or Remove and Install Fuel Filter/Primer Pump Assembly—5410 and 5510 in Section 30, Group 05.)
20. Install muffler and exhaust pipe.
21. Connect battery negative (—) cable to battery.
22. Install hood.
23. Install left and right dash panels.
24. Install left and right grille panels.
25. Install MFWD drive shaft, if equipped. (See Remove, Inspect and Install MFWD Drive Shaft in Group 35.)
26. Adjust throttle control rod. (See Slow Idle Adjustment and Fast Idle Adjustment in Section 220, Group 15.)



Right Side Shown

A—Wiring Connector  
 B—Hydraulic Line  
 C—Hydraulic Line  
 D—Suction Line

LV2328 —UN—16DEC97

AG.OUO1085,118 —19—28JUN02—5/5

## Separate Engine from Clutch Housing— Tractors With Cab


1. Recover/recycle air conditioning refrigerant. (See Recover/Recycle Air Conditioning Refrigerant in Section 90, Group 20.)
2. Remove hood and side grille panels.
3. Disconnect battery, negative (—) cable first.
4. Remove fuel filter/primer pump assembly. (See Remove and Install Fuel Filter/Primer Pump Assembly—5210 and 5310 or Remove and Install Fuel Filter/Primer Pump Assembly—5410 and 5510 in Section 30, Group 05.)
5. Remove MFWD drive shaft, if equipped. (See Remove, Inspect and Install MFWD Drive Shaft in Group 35.)
6. Remove right crop guard.

**NOTE:** Close all openings using caps and plugs.

7. Disconnect air conditioning line (A) from receiver/dryer. Close all openings using caps and plugs.
8. Disconnect air conditioning line (B).
9. Disconnect two wiring connectors (C). Cut wire ties as necessary.



LV2443 -UN-16DEC97



LV2444 -UN-16DEC97

A—Air Conditioning Line  
B—Air Conditioning Line  
C—Wire Connector

Continued on next page

AG,OUO1085,119 -19-28JUN02-1/6

50  
05  
13




10. Remove trim strip from inside right cab post and disconnect three wire connectors (A).


*NOTE: Close all openings using caps and plugs.*

11. Disconnect three hydraulic lines (B). Close all openings using caps and plugs.
12. Remove two cap screws (C) and remove bracket (D) from engine block.


A—Wire Connector (3 used)  
 B—Hydraulic Line (3 used)  
 C—Cap Screw (2 used)  
 D—Bracket  
 E—Injection Pump Rod



LV2339 -UN-16DEC97



LV2454 -UN-16DEC97



LV2420 -UN-16DEC97

Continued on next page

AG.OUO1085,119 -19-28JUN02-2/6

13. Disconnect two coolant lines (A) from engine.

14. Disconnect hydraulic line (B).

15. Remove exhaust pipe.


*NOTE: Muffler removed for illustration purposes.*

16. Remove fuel return line (C).


A—Coolant Line (2 used)

B—Hydraulic Line

C—Fuel Return Line



LV2422 -UN-15DEC97



LV2455 -UN-16DEC97




Continued on next page

AG,OUO1085,119 -19-28JUN02-3/6

50  
05  
15

17. Disconnect red wires Nos. 002C and 002D/E from right post of fuse link (A).
18. Disconnect two main harness wiring connectors (B).
19. Disconnect hydraulic line (C).

A—Fuse Link  
B—Wire Connector (2 used)  
C—Hydraulic Line



Continued on next page

AG.OUO1085,119 -19-28JUN02-4/6




20. Disconnect hydraulic line (A) from hydraulic pump.

*NOTE: Support suction line (B). Transmission/hydraulic oil will spill out of hose if line drops below transmission/reservoir oil level.*

21. Disconnect suction line (B).

22. Disconnect battery positive (+) cable from starter terminal (C).

A—Hydraulic Line  
B—Suction Line  
C—Battery Positive Cable



LV2456 -UN-16DEC97

Continued on next page

AG,OUO1085,119 -19-28JUN02-5/6

50  
05  
17

23. Remove muffler if necessary.

24. Install lifting brackets such as JDG19 or JT01748 to engine in the areas where muffler and fuel filter primer pump were removed.

25. Attach a hoist to engine.

**NOTE:** If tractor is equipped with optional front weights, remove weights from weight bracket before removing any engine to clutch housing mounting hardware.


26. Install a floor jack under clutch housing.

27. Install wood blocks between front axle pivot stops and frame.

**NOTE:** Ensure disconnected hydraulic lines do not entangle with engine components or electrical wiring during engine/clutch housing separation.

28. Remove two cap screws (A) and four nuts (B). Roll front section (engine/front axle assembly) away from tractor rear section.

29. Install a support stand under the flywheel housing of engine.



A—Cap Screw (2 used)  
B—Nut (4 used)

AG,OUO1085,119 -19-28JUN02-6/6

## Install Engine to Clutch Housing—Tractors With Cab

1. Clean mating surfaces of clutch housing and engine.

**NOTE:** Ensure disconnected hydraulic lines do not entangle with engine components or electrical wiring during engine/clutch housing installation.

*It may be necessary to rotate the PTO shaft and/or engine flywheel so the clutch shafts mesh with the clutch discs. Rotate the PTO shaft by manually turning the PTO at rear of tractor.*

*Rotate the engine flywheel using Flywheel Turning Tool JDE83.*


2. Apply Moly High Temperature EP Grease to traction and PTO clutch shafts.
3. Install engine to clutch housing. Tighten cap screws (A) and nuts (B) to specification.

### Specification

Clutch Housing Cap Screws and Nuts—Tractors with Cab—Torque ..... 318 N•m (235 lb-ft)


4. Remove wood blocks and floor jack.
5. Remove lifting brackets.

A—Cap Screw  
B—Nut



LV525 -UN-03MAR92

50  
05  
19



LV2430 -UN-15DEC97

Continued on next page

AG,OUO1085,120 -19-28JUN02-1/6


6. Connect battery positive (+) cable to starter terminal (C).

7. Connect suction line (B).

**IMPORTANT: Replace all O-rings and seals. Used or damaged O-rings and seals will leak.**

8. Connect hydraulic line (A) to hydraulic pump.

A—Hydraulic Line  
B—Suction Line  
C—Battery Positive Cable



LV2456 -UN-16DEC97


Continued on next page

AG,OUO1085,120 -19-28JUN02-2/6




9. Connect hydraulic line (C).
10. Connect two main harness wiring connectors (B).
11. Connect red wires Nos. 002C and 002D/E to right post of fuse link (A).


A—Fuse Link  
B—Wiring Connector (2 used)  
C—Hydraulic Line



LV2426 -UN-15DEC97



LV2425 -UN-15DEC97




LV2329 -UN-16DEC97

Continued on next page


AG,OUO1085,120 -19-28JUN02-3/6

12. Connect fuel line (C).
13. Install exhaust pipe.
14. Connect hydraulic line (B).
15. Connect coolant supply and return lines (A) from engine.

A—Coolant Lines  
B—Hydraulic Line  
C—Fuel Line



LV2455 -UN-16DEC97




LV2422 -UN-15DEC97

Continued on next page


AG,OUO1085,120 -19-28JUN02-4/6

16. Connect hydraulic lines (B).
17. Install rod (E) to injection pump.
18. Install cap screws (C) through bracket (D) to engine.
19. Connect three wire connectors (A). Install trim strip inside right front cab post.


A—Wire Connector (3 used)  
 B—Hydraulic Line (2 used)  
 C—Cap Screw (2 used)  
 D—Bracket  
 E—Injection Pump Rod



LV2454 -UN-16DEC97



LV2420 -UN-15DEC97



LV2339 -UN-16DEC97

Continued on next page


AG,OUO1085,120 -19-28JUN02-5/6

50  
05  
23



20. Connect air conditioning line (B) and connect two wire connectors (C).
21. Connect air conditioning line (A) to receiver/dryer.
22. Install right crop guard.
23. Install MFWD drive shaft. (See Remove, Inspect and Install MFWD Drive Shaft in Group 35.)
24. Install fuel filter/primer pump assembly. (See Remove and Install Fuel Filter/Primer Pump Assembly—5210 and 5310 or Remove and Install Fuel Filter/Primer Pump Assembly—5410 and 5510 in Section 30, Group 05.)
25. Connect battery, positive (+) cable first.
26. Fill cooling system with proper coolant. Run engine to circulate coolant. Check coolant level and replenish as necessary.
27. Adjust fast idle. (See Fast Idle Adjustment in Section 220, Group 15.)
28. Flush, evacuate, and charge air conditioning system. (See Flush Air Conditioning System, Evacuate Air Conditioning System and Charge Air Conditioning System in Section 90, Group 20.)

**A—Air Conditioning Line**  
**B—Air Conditioning Line**  
**C—Wire Connector (2 used)**



LV2444 -UN-16DEC97



LV2443 -UN-16DEC97

AG.OUO1085,120 -19-28JUN02-6/6


## Replace Clutch Housing Seal

1. Separate clutch housing from transmission. (See Separate Clutch Housing from Transmission in Group 15 for CollarShift/SyncShuttle™ Transmission or Separate Clutch Housing from Transmission in Group 16 for PowrReverser™ Transmission.)

2. Remove PTO clutch shaft coupler (A).

**NOTE:** Traction clutch shaft will only pull out part way. When removing traction clutch shaft, the PTO clutch shaft may slide out with the traction clutch shaft.

3. Remove traction clutch shaft (B) using an inside puller and slide hammer.




LV315 -UN-03MAR92

A—PTO Clutch Shaft Coupler  
B—Traction Clutch Shaft

AG,OUO1085,121 -19-28JUN02-1/3

4. Pry out seal (A).

A—Clutch Housing Seal



LV316 -UN-03MAR92


Continued on next page

AG,OUO1085,121 -19-28JUN02-2/3

50  
05  
25

**IMPORTANT:** When installing clutch shafts, make sure splines on opposite end of shafts are in alignment with clutch disk splines before striking ends of shaft with a hammer. Damage to clutch disks and shaft splines can occur.

5. Install clutch shaft (B). Align opposite ends of each shaft with clutch disks. Rotate shaft in either direction if necessary. Tap on the end of each shaft using a brass drift and hammer to fully seat each shaft in its respective bore.
6. Apply multipurpose grease to the lips of new seal.
7. Install seal with lips facing away from clutch housing using a brass drift and hammer. Install seal until it stops.
8. Install PTO clutch shaft coupler (A).
9. Install clutch housing to transmission. (See Install Clutch Housing to Transmission in Group 15 for CollarShift/SyncShuttle™ Transmission or Install Clutch Housing to Transmission in Group 16 for PowrReverser™ Transmission.)






LV315 -UN-03MAR92

A—PTO Clutch Shaft Coupler  
B—Clutch Shaft

AG,OUO1085,121 -19-28JUN02-3/3

# Inspect and Repair Clutch Pedal and Linkage—CollarShift/SyncShuttle™



A—Clutch Pedal (Early)  
 B—Snap Ring (Early)  
 C—Bushings (2 used) (Early)  
 D—Cotter Pin (Early)  
 E—Extension Spring (Early)  
 F—Rod (Early)

G—Flange Nut (Early)  
 H—Yoke (Early)  
 I—Spring Locking Pin (Early)  
 J—Clutch Pedal (Cab Tractor Only)

K—Flange Nut (Later)  
 L—Snap Ring (Later)  
 M—Bushings (2 used) (Later)  
 N—Bushings (Later)  
 O—Clutch Pedal (Later)

P—Extension Spring (Later)  
 Q—Rod (Later)  
 R—Flange Nut (Later)  
 S—Yoke (Later)  
 T—Spring Locking Pin (Later)

Continued on next page

AG,OUO1085,122 -19-11NOV02-1/2

**NOTE:** If equipped with cab, lower front windows must be removed before removing dash covers. (See Remove and Install Lower Front Windows in Section 90, Group 15.)

*Early and later exploded view shown. Inspect and repair procedures are the same for both.*

1. Remove left and right dash panels.

**NOTE:** Cab tractors are equipped with clutch pedal (J) in place of clutch pedal (A or O).

2. Inspect all parts for wear or damage. Replace as necessary.

**NOTE:** Remove bushings only if replacement is necessary.

3. Inspect bushings (C or M) for wear or damage. Replace if necessary.

Replace bushings using a bearing, bushing, and seal driver set. Install bushings flush with pedal surface.

4. Apply Moly High Temperature EP Grease to I.D. of bushings.

5. Install left and right dash panels.

6. Adjust clutch pedal free-play. (See Clutch Pedal Free Play Adjustment in Section 250, Group 15.)

7. Adjust throttle control rod. (See Slow Idle Adjustment and Fast Idle Adjustment in Section 220, Group 15.)

AG,OUO1085,122 -19-11NOV02-2/2

## Inspect and Repair Clutch Pedal and Linkage—PowrReverser™

1. Remove left and right dash panels.

*NOTE: Cab tractors are equipped with clutch pedal (J) in place of clutch pedal (A).*

2. Inspect all parts for wear or damage. Replace as necessary.

*NOTE: Remove bushings (C) only if replacement is necessary.*


3. Inspect bushings (C) for wear or damage. Replace if necessary.

Replace bushings using a bearing, bushing, and seal driver set. Install bushings flush with pedal surface.

4. Apply Moly High Temperature EP Grease to I.D. of bushings.

5. Install left and right dash panels.

6. Adjust clutch pedal free-play. (See Clutch Pedal Linkage Adjustment in Section 250, Group 16.)



- A—Clutch Pedal
- B—Snap Ring
- C—Bushing (2)
- D—Cotter Pin
- E—Extension Spring
- F—Rod
- G—Flange Nut
- H—Yoke
- I—Pin
- J—Clutch Pedal (Cab Tractor)

LV1045AE -UN-09MAY02

50  
05  
29

50  
05  
30



# Clutch Assembly—CollarShift/SyncShuttle™ Transmissions Group 10

## Essential Tools

*NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).*

*SERVICEGARD is a trademark of Deere & Company*

OUC1043,0000E97 -19-28JUN02-1/5


Universal Clutch Alignment Tool. . . . . JDG689

Aligns PTO and traction clutch disks.

OUC1043,0000E97 -19-28JUN02-2/5

Traction Clutch Finger Height Gauge. . . . . JDG827

Measure traction clutch finger height on tractors without PowrReverser™. See Dealer Fabricated Tools in Section 299, Group 10 for dimensions.



*PowrReverser is a trademark of Deere & Company*

OUC1043,0000E97 -19-28JUN02-3/5

Traction Clutch Finger Height Adjustment Tool . . JDG828

Adjust traction clutch finger height on tractors without PowrReverser™. See Dealer Fabricated Tools in Section 299, Group 10 for dimensions.

JDG828 -UN-24FEB98



*PowrReverser is a trademark of Deere & Company*


Continued on next page

OUC1043,0000E97 -19-28JUN02-4/5

50  
10  
1

PTO Clutch Finger Height Gauge . . . . . JDG826

Measure PTO clutch finger height on tractors without PowrReverser™. See Dealer Fabricated Tools in Section 299, Group 10 for dimensions.



JDG826 -UN-01JUL97

PowrReverser is a trademark of Deere & Company

OUC1043,0000E97 -19-28JUN02-5/5

## Other Material

Number	Name	Use
TY6305 (U.S.) TY9485 (Canadian) 7649 (LOCTITE®)	Clean and Cure Primer	Cleans mating surfaces and reduces sealant curing time.
TY9370 (U.S.) TY9477 (Canadian) 242 (LOCTITE®)	Thread Lock and Sealer (Medium Strength)	Apply to PTO and traction clutch yoke-to-armshaft cap screw threads.

LOCTITE is a registered trademark of Loctite Corp.

OUC1043,0000E99 -19-28JUN02-1/1

## Specifications

Item	Measurement	Specification
Clutch Assembly Cap Screws	Torque	36 N•m (27 lb-ft)
Traction Clutch Disk	Minimum Thickness	6.50 mm (0.260 in.)
PTO Clutch Disk	Minimum Thickness	5.50 mm (0.220 in.)
PTO Clutch Front Pressure Plate	Minimum Thickness	17.30 mm (0.680 in.)
PTO Clutch Rear Pressure Plate	Minimum Thickness	18.80 mm (0.740 in.)
Traction Clutch Front Pressure Plate	Minimum Thickness	30.00 mm (1.181 in.)
Traction Clutch Rear Pressure Plate	Minimum Thickness	17.00 mm (0.669 in.)
Clutch Assembly Spring Washer	Height	13.3 mm (0.523 in.) minimum
Clutch Release Mechanism Cap Screws	Torque	65 N•m (48 lb-ft)

OUO1043,0000E9A -19-28JUN02-1/1

## Service Parts Kits

The following kits are available through your parts catalog:

Traction Clutch Shaft Seal Kit

PTO Clutch Lever Kit

Traction Clutch Lever Kit

AG,OUO1085,125 -19-11AUG00-1/1

## Remove and Install Clutch Assembly

**NOTE:** Clutch assembly can be removed and installed without any alignment or finger adjustment procedures.

*If clutch assembly has been disassembled for inspection or repair, see PTO Clutch Finger Adjustment and Traction Clutch Finger Adjustment in this group.*

1. Separate engine from clutch housing. (See Separate Engine from Clutch Housing—Tractors Without Cab or Separate Engine from Clutch Housing—Tractors With Cab in Group 05.)

**CAUTION:** Clutch assembly is heavy. Support clutch before removing cap screws to prevent personal injury.

2. Remove twelve cap screws (A) and clutch assembly.
3. Make repairs as necessary. (See Disassemble and Inspect Clutch Assembly in this group.)
4. Install clutch assembly and cap screws. Evenly tighten cap screws in a criss-cross pattern to specification.

### Specification

Clutch Assembly Cap Screws—  
Torque ..... 36 N•m (27 lb-ft)

5. Install engine to clutch housing. (See Install Engine to Clutch Housing—Tractors Without Cab or Install Engine to Clutch Housing—Tractors With Cab in Group 05.)



A—Cap Screw (12 used)

LV387 -UN-03MAR92

AG.OUO1085,126 -19-28JUN02-1/1

## Disassemble and Inspect Clutch Assembly

1. Put index marks (A) on pressure plates to aid in assembly.


A—Index Marks (4 used)



LV029 -UN-03MAR92

Continued on next page

AG,OUO1085,127 -19-28JUN02-1/5



Clutch Assembly

- |                                   |                              |                                   |                                        |
|-----------------------------------|------------------------------|-----------------------------------|----------------------------------------|
| A—Spring Pin (6 used)             | H—Spring (3 used)            | P—Pad (3 used)                    | V—Traction Clutch Front Pressure Plate |
| B—Adjuster Cap (3 used)           | I—Spring (3 used)            | Q—Spring (3 used)                 | W—Nut                                  |
| C—Bushing (6 used)                | J—PTO Clutch Finger (3 used) | R—PTO Clutch Front Pressure Plate | X—Adjuster Stud                        |
| D—Bushing (6 used)                | K—Adjuster (3 used)          | S—PTO Clutch Disk                 | Y—Traction Clutch Disk                 |
| E—Traction Clutch Finger (3 used) | L—Spacer (3 used)            | T—PTO Clutch Rear Pressure Plate  | Z—Traction Clutch Rear Pressure Plate  |
| F—Pin (6 used)                    | M—Spring (3 used)            | U—Spring Washer                   |                                        |
| G—Pin (6 used)                    | N—Conical Washer (3 used)    |                                   |                                        |
|                                   | O—Lock Nut (3 used)          |                                   |                                        |

**NOTE:** Spring pins (A) must be pulled from bore to remove.

PTO clutch and traction clutch finger assemblies are serviced as separate kits. Kits are available through the parts catalog.

- Disassemble parts (A—Z).
- Inspect all parts for wear or damage. Replace as necessary.
- Replace lock nuts (O).

Continued on next page

AG,OUO1085,127 -19-28JUN02-2/5

5. Clean any rust or oil from drive surfaces of plates (R, T, V, and Z). Inspect drive surfaces for distortion, checking cracks and heat damage.
6. Replace clutch disks if friction surfaces are contaminated with grease or oil or if thickness of disk is not within specifications.

#### Specification

Traction Clutch Disk—Minimum	
Thickness.....	6.50 mm (0.260 in.)
PTO Clutch Disk—Minimum	
Thickness.....	5.50 mm (0.220 in.)


AG,OUO1085,127 -19-28JUN02-3/5

7. Machine drive surfaces of pressure plates and cover, if necessary, until surface is free of scores, cracks, and heat discoloration.
8. Measure thickness of pressure plates at dimensions (A—D). Replace parts that are not within specifications.

#### Pressure Plates—Specification

PTO Clutch Front Pressure	
Plate—Minimum Thickness.....	17.30 mm (0.680 in.)
PTO Clutch Rear Pressure	
Plate—Minimum Thickness.....	18.80 mm (0.740 in.)
Traction Clutch Front Pressure	
Plate—Minimum Thickness .....	30.00 mm (1.181 in.)
Traction Clutch Rear Pressure	
Plate—Minimum Thickness.....	17.00 mm (0.669 in.)

- A—PTO Clutch Front Pressure Plate**  
**B—PTO Clutch Rear Pressure Plate**  
**C—Traction Clutch Front Pressure Plate**  
**D—Traction Clutch Rear Pressure Plate**




LV025AE -UN-03MAR92

AG,OUO1085,127 -19-28JUN02-4/5

9. Inspect pilot bearing (A) for wear or damage. Replace if necessary. (See procedure in CTM104 for 4-cylinder engines or CTM125 for 3-cylinder engines.)

- A—Pilot Bearing**



LV385 -UN-03MAR92

AG,OUO1085,127 -19-28JUN02-5/5



## Assemble Clutch Assembly

1. Install adjusters in PTO clutch fingers (B) and traction clutch fingers (C). Install pins (A) using a press. Adjusters should pivot freely.

A—Pin (2 used)  
B—PTO Clutch Finger  
C—Traction Clutch Finger



LV031 -UN-03MAR92


AG,OUO1085,128 -19-28JUN02-1/8

2. Install clutch finger assemblies in traction clutch rear pressure plate.

**NOTE:** PTO finger spring has shorter tang (B) than traction finger spring (D).

3. Install springs (B and D) and pins (C).
4. Install spring pins (A) until seated.

A—Spring Pin (6 used)  
B—PTO Clutch Finger Spring (3 used)  
C—Pin (6 used)  
D—Traction Clutch Finger Spring (3 used)



LV032 -UN-03MAR92

AG,OUO1085,128 -19-28JUN02-2/8

**IMPORTANT:** Wide edge (B) of pad must face clockwise direction.

5. Install traction clutch disk (A) in pressure plate with wide edge (B) of pads facing clockwise direction.

A—Traction Clutch Disk  
B—Wide Edge of Pad




LV033 -UN-03MAR92

Continued on next page

AG,OUO1085,128 -19-28JUN02-3/8

6. Install traction clutch front pressure plate with index marks (C) aligned.
7. Install adjuster studs (A) and lock nuts (B). Check that adjuster studs are seated in adjusters.

A—Adjuster Stud  
B—Lock Nut  
C—Index Mark (2)



AG,OUO1085,128 -19-28JUN02-4/8

LV034 -UN-03MAR92

8. Place spring washer (A) on a work bench or any flat surface and measure free height dimension (B). If less than specification, replace spring washer.


#### Specification

Clutch Assembly Spring

Washer—Height ..... 13.3 mm (0.523 in.) minimum

9. Install spring washer (A) with concave side toward traction clutch pressure plate. Center spring washer on traction clutch pressure plate.

A—Spring Washer  
B—Free Height Dimension



AG,OUO1085,128 -19-28JUN02-5/8


LV035 -UN-03MAR92

50  
10  
9

LV1611 -UN-07FEB96

10. Install PTO clutch rear pressure plate (A) with index marks aligned. Check that spring washer remains centered on traction clutch pressure plate and is seated in recess of PTO clutch rear pressure plate.

A—Rear Pressure Plate



Continued on next page


AG,OUO1085,128 -19-28JUN02-6/8

LV036 -UN-03MAR92

11. Install PTO clutch disk with short hub (A) facing out.
12. Install spacers (E) and springs (D) on adjusters.
13. Install pressure plate (H) with index marks aligned.
14. Install spring (F) and button (G) in pressure plate.

**NOTE:** Raise clutch assembly on blocks and pull PTO lever down to install special nuts.

15. Install washer (C) and new special nuts (B) loosely.
16. Align clutch discs using JDG689 Universal Clutch Alignment Tool.



LV037 -UN-03MAR92


- A—Short Hub of Clutch Disk
- B—Special Nut (3 used)
- C—Conical Washer (3 used)
- D—Spring (3 used)
- E—Spacer (3 used)
- F—Spring (3 used)
- G—Button (3 used)
- H—PTO Clutch Pressure Plate

AG,OUO1085,128 -19-28JUN02-7/8

**NOTE:** Conical washer must be seated in special nut before tightening.

17. Tighten special nut (A) while depressing button (B) until button is in channel.

- A—Special Nut
- B—Button




LV038 -UN-03MAR92

AG,OUO1085,128 -19-28JUN02-8/8


## Traction Clutch Finger Adjustment

1. Separate engine from clutch housing. (See Separate Engine from Clutch Housing—Tractors Without Cab or Separate Engine from Clutch Housing—Tractors With Cab in Group 05.)
2. Check finger height (E) from pressure plate (F) to traction clutch finger (B) using JDG827 Traction Clutch Finger Height Gauge (A).
3. Loosen jam nut (C). Turn adjuster (G) in or out until clutch finger touches gauge, using JDG828 Traction Clutch Finger Height Adjustment Tool (D).
4. Tighten jam nut.
5. Repeat procedures for two remaining fingers.

A—JDG827 Traction Clutch Finger Height Gauge  
 B—Traction Clutch Finger  
 C—Jam Nut  
 D—JDG828 Traction Clutch Finger Height Adjustment Tool  
 E—Distance  
 F—Pressure Plate  
 G—Adjuster



LV550 -UN-09JAN95




LV635AE -UN-09JAN95

AG,OUO1085,129 -19-11AUG00-1/1


## PTO Clutch Finger Adjustment

1. Separate engine from clutch housing. (See Separate Engine from Clutch Housing—Tractors Without Cab or Separate Engine from Clutch Housing—Tractors With Cab in Group 05.)
2. Check finger height (E) from pressure plate (D) to PTO clutch finger (B) using JDG826 PTO Clutch Finger Height Gauge (C).
3. Turn special nut (A) in or out until clutch finger touches gauge.
4. Using pliers, crimp the top of special nut to flats on finger adjusting rod.
5. Repeat procedure for two remaining fingers.

A—Special Nut  
B—PTO Clutch Finger  
C—JDG826 PTO Clutch Finger Height Gauge  
D—Pressure Plate  
E—Distance



LV386 -UN-03MAR92



LV636AE -UN-09JAN95

AG,OUO1085,130 -19-11AUG00-1/1




## Remove and Inspect Clutch Release Mechanism and Shafts

**NOTE:** Tractor without cab shown.

1. Separate engine from clutch housing. (See Separate Engine from Clutch Housing—Tractors Without Cab or Separate Engine from Clutch Housing—Tractors With Cab in Group 05.)
2. Disconnect traction clutch rod (A) and PTO clutch rod (B).

A—Traction Clutch Rod  
B—PTO Clutch Rod




LV319 -UN-03MAR92

AG,OUO1085,131 -19-16AUG00-1/5

3. Remove PTO clutch shaft (A).
4. Remove clutch release bearing assembly (B).

A—PTO Clutch Shaft  
B—Clutch Release Bearing Assembly



LV307 -UN-03MAR92

Continued on next page

AG,OUO1085,131 -19-16AUG00-2/5

50  
10  
13



5. Inspect parts (A—F) for wear or damage. Replace as necessary.

**NOTE:** Collars (A and C) and bearings (B and D) are press fit.

Remove collars and bearings only if replacement is necessary.


Disassemble parts (A—F) using a knife edged puller and a press.

Assemble parts using a press.

6. Tractors without cab: remove left platform.
7. Tractors with cab: remove battery. (See Remove and Install Battery—Tractors With Cab in Section 40, Group 05.)
8. Tractors with cab: remove battery box and crop guard.

**NOTE:** Tractors with cab: place a floor jack under left side of cab door to support cab during removal of left cab mounting bracket.

9. Install floor jack and remove left cab mounting bracket.




Clutch Release Bearing Assembly

- A—Traction Clutch Collar  
B—Bearing  
C—PTO Clutch Collar  
D—Bearing  
E—PTO Clutch Sleeve  
F—Traction Clutch Sleeve

LY354A -UN-03MAR92

Continued on next page

AG,OUO1085,131 -19-16AUG00-3/5



A—Traction Clutch Yoke  
B—Cap Screw (6 used)  
C—PTO Clutch Yoke  
D—Shoe (4 used)

E—Guide  
F—Cap Screw (3 used)  
G—Bearing  
H—Traction Clutch Shaft

I—Seal  
J—Bearing  
K—Snap Ring

L—Traction Clutch Armshaft  
M—PTO Clutch Armshaft  
N—Bushing (4 used)

10. Remove parts (A—M).

**NOTE:** Bearing (G) and bushings (N) are press fit.  
Remove only if replacement is necessary.  
Bearing (J) is slip fit.

Replace bearing (G) using a press.

Replace bushings (N) using a bushing, bearing, and seal driver set. Install bushings flush with clutch housing.

11. Inspect parts for wear or damage. Replace as necessary.

Continued on next page

AG,OUO1085,131 -19-16AUG00-4/5


**IMPORTANT: Replace all seals. Damaged or used seals will leak.**

stops, using a bushing, bearing, and seal driver set.

12. Pry out seal (I). Install seal into shaft bore with lips facing toward the rear of clutch housing, until it

AG,OUO1085,131 -19-16AUG00-5/5

## Install Clutch Release Mechanism and Shafts



A—Traction Clutch Yoke  
B—Cap Screw (6 used)  
C—PTO Clutch Yoke  
D—Shoe (4 used)

E—Guide  
F—Cap Screw (3 used)  
G—Bearing  
H—Traction Clutch Shaft

I—Seal  
J—Bearing  
K—Snap Ring

L—Traction Clutch Armshaft  
M—PTO Clutch Armshaft  
N—Bushing (4 used)

1. Apply multipurpose grease to inside lips of seal (I).
2. Apply Moly High Temperature EP Grease to armshafts (L and M), shoes (D), shaft end of guide (E), and splined ends of shaft (H).
3. Clean cap screws (B) and yoke threads (A and C) thoroughly with Clean and Cure Primer. Apply

thread lock and sealer (medium strength) to cap screw threads.

4. Install parts (A—N).

Continued on next page

AG,OUO1085,132 -19-28JUN02-1/4

5. Tighten cap screws (B) to specification.

6. Tractors without cab: install left platform.

# **Specification**

Clutch Release Mechanism

Cap Screws—Torque ..... 65 N•m (48 lb-ft)

AG,OUO1085,132 -19-28JUN02-2/4

7. Apply Moly High Temperature EP Grease to sliding surfaces of clutch release bearing assembly (B).

8. Install clutch release bearing assembly.


9. Install PTO clutch shaft; rotate shaft as necessary until splines align.

**NOTE:** *Opposite end of PTO shaft must align with a coupler.*


10. Apply Moly High Temperature EP Grease to splined ends of PTO and traction clutch shafts as shown in illustrations.

A—PTO Shaft

B—Clutch Release Bearing Assembly



LV307 -UN-03MAR92




**APPLY MOLY EP GREASE TO THE SHADED AREAS ONLY**

LV1188AE -19-25JAN95

Continued on next page

AG,OUO1085,132 -19-28JUN02-3/4

11. Connect PTO Clutch Rod (B) and traction clutch rod (A).
12. Install engine to clutch housing. (See Install Engine to Clutch Housing—Tractors Without Cab or Install Engine to Clutch Housing—Tractors With Cab in Group 05.)
13. Adjust clutch pedal free-play. (See Clutch Pedal Free Play Adjustment in Section 250, Group 15.)
14. Tractors with cab: install left cab mounting bracket, crop guard, battery box, and battery.



LV319 -UN-03MAR92

A—Traction Clutch Rod  
B—PTO Clutch Rod

AG,OUO1085,132 -19-28JUN02-4/4

50  
10  
19





Group 11

Clutch Assembly—PowrReverser™ Transmission

Essential Tools


NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUC1043,0000E9B -19-28JUN02-1/2

Clutch Finger Height Gauge . . . . . JDG919

Measures PTO clutch finger height. See Dealer Fabricated Tools in Section 299, Group 10 for dimensions.



JDG826 -UN-01JUL97

OUC1043,0000E9B -19-28JUN02-2/2

Other Material

Number	Name	Use
TY6305 (U.S.) TY9485 (Canadian) 7649 (LOCTITE®)	Clean and Cure Primer	Cleans parts and speeds cure of sealant.
TY9370 (U.S.) TY9477 (Canadian) 242 (LOCTITE®)	Thread Lock and Sealer (Medium Strength)	Apply to PTO clutch yoke-to-armshaft cap screw threads.

LOCTITE is a registered trademark of Loctite Corp.

OUC1043,0000E9D -19-28JUN02-1/1

## Specifications

Item	Measurement	Specification
Clutch Assembly Cap Screws	Torque	36 N•m (27 lb-ft)
PTO Clutch Disk	Thickness	5.50 mm (0.220 in.) Minimum
Front Pressure Plate Dimension	Thickness	17.00 mm (0.669 in.) Minimum
Rear Pressure Plate Dimension	Thickness	18.80 mm (0.740 in.) Minimum
Spring Washer	Height	13.3 mm (0.523 in.) Minimum
Clutch Release Mechanism Cap Screws	Torque	26 N•m (20 lb-ft)
Traction Clutch Shaft Cap Screws	Torque	65 N•m (48 lb-ft)
Transmission Pump Cap Screws	Torque	26 N•m (20 lb-ft)

OUO1020,000120C -19-18JUL02-1/1

## Service Parts Kits

The following kits are available through your parts catalog:

PTO Clutch Lever Kit

Traction Clutch Lever Kit

AG,OUO1085,134 -19-16AUG00-1/1

## Remove and Install Clutch Assembly

**NOTE:** Clutch assembly can be removed and installed without any alignment or finger adjustment procedures.

If clutch assembly has been disassembled for inspection or repair, see PTO Clutch Finger Adjustment in this group.

1. Separate engine from clutch housing. (See Separate Engine from Clutch Housing—Tractors Without Cab or Separate Engine from Clutch Housing—Tractors With Cab in Group 05.)




**CAUTION:** Clutch assembly is heavy. Support clutch before removing cap screws to prevent personal injury.

2. Remove twelve cap screws (A) and clutch assembly.
3. Make repairs as necessary. (See Disassemble and Inspect Clutch Assembly in this group.)
4. Install clutch assembly and cap screws. Evenly tighten cap screws in a criss-cross pattern to specification.

### Specification

Clutch Assembly Cap Screws—  
Torque ..... 36 N•m (27 lb-ft)

5. Install engine to clutch housing.



A—Cap Screw (12 used)

LV1044 -UN-15DEC94


50  
11  
3

AG,OUO1085,135 -19-16AUG00-1/1

## Disassemble and Inspect Clutch Assembly

1. Put index marks (A) on pressure plates to aid in assembly.


A—Index Mark (4 used)



LV1046 -UN-15DEC94

Continued on next page

AG,OUO1085,136 -19-28JUN02-1/5



Clutch Assembly

- |                       |                           |                                   |                                  |
|-----------------------|---------------------------|-----------------------------------|----------------------------------|
| A—Spring Pin (3 used) | G—Pin (3 used)            | M—Pad (3 used)                    | Q—PTO Clutch Rear Pressure Plate |
| B—Adjuster (3 used)   | H—Spring (3 used)         | N—Spring (3 used)                 | R—Spring Washer                  |
| C—Bushing (3 used)    | I—Washer (3 used)         | O—PTO Clutch Front Pressure Plate | S—Ring                           |
| D—Bushing (3 used)    | J—Spring (3 used)         | P—PTO Clutch Disk                 | T—Torsional Drive Plate          |
| E—PTO Clutch Finger   | K—Conical Washer (3 used) |                                   |                                  |
| F—Pin (3 used)        | L—Lock Nut (3 used)       |                                   |                                  |

**NOTE:** Spring pins (A) must be pulled from bore to remove.

PTO clutch finger assemblies are serviced as separate kits. Kits are available through the parts catalog.

2. Disassemble parts (A—T).

3. Inspect all parts for wear or damage. Replace as necessary.

4. Replace lock nuts (L).

5. Clean any rust or oil from drive surfaces of plates (O and Q). Inspect drive surfaces for distortion, checking cracks and heat damage.

Continued on next page

AG,OUO1085,136 —19-28JUN02-2/5

6. Replace clutch disk if friction surfaces are contaminated with grease or oil or if thickness of disk is not within specifications.

**Specification**

PTO Clutch Disk—Thickness ..... 5.50 mm (0.220 in.) Minimum

AG,OUO1085,136 -19-28JUN02-3/5

7. Machine drive surfaces of pressure plates if necessary, until surface is free of scores, cracks, and heat discoloration.

8. Measure thickness of pressure plates at dimensions (A and B). Replace parts that are not within specifications.

**Specification**

Front Pressure Plate


Dimension—Thickness ..... 17.00 mm (0.669 in.) Minimum

Rear Pressure Plate Dimension—

Thickness ..... 18.80 mm (0.740 in.) Minimum

**A—PTO Clutch Front Pressure Plate**

**B—PTO Clutch Rear Pressure Plate**



LV1225AE -UN-15DEC94


Continued on next page

AG,OUO1085,136 -19-28JUN02-4/5



9. Inspect pilot bearing (A) for wear or damage. Replace if necessary. (See procedure in CTM104 for 4 cylinder engines or CTM125 for 3 cylinder engines.)

A—Pilot Bearing




LV1047 -UN-15DEC94

AG,OUO1085,136 -19-28JUN02-5/5

## Assemble Clutch Assembly

1. Install adjusters in PTO clutch fingers (B). Install pin (A) using a press. Adjusters should pivot freely.

A—Pin  
B—PTO Clutch Finger




LV1048 -UN-15DEC94

AG,OUO1085,137 -19-28JUN02-1/7

2. Install clutch finger assemblies in PTO clutch rear pressure plate.
3. Install springs (A) and pins (B).
4. Install spring pins (C) until seated.

A—PTO Clutch Finger Spring (3 used)  
B—Pin (3 used)  
C—Spring Pin (3 used)



LV1049 -UN-15DEC94

Continued on next page

AG,OUO1085,137 -19-28JUN02-2/7


5. Place spring washer (A) on a work bench or any flat surface and measure free height dimension (B). If less than specification, replace spring washer.

**Specification**


Spring Washer—Height..... 13.3 mm (0.523 in.) Minimum

A—Spring Washer

B—Free Height Dimension



LV1612 -UN-02FEB96



LV1611 -UN-07FEB96

50  
11  
7

AG,OUO1085,137 -19-28JUN02-3/7


**IMPORTANT: Ensure that spacer ring (A) is installed and seated.**

6. Install spring washer (B) with concave side toward rear torsion plate (C).


A—Spacer Ring

B—Spring Washer

C—Rear Torsion Plate



LV1050 -UN-15DEC94



LV1051 -UN-15DEC94


Continued on next page

AG,OUO1085,137 -19-28JUN02-4/7

**NOTE:** Ensure that rear pressure plate is centered and seated on spring washer.

7. Install clutch rear pressure plate with index marks (A) aligned.
8. Install adjuster stud washer (B) and springs (C).

A—Index Mark (2 used)  
B—Adjuster Stud Washer  
C—Spring



LV1052 -UN-15DEC94


AG.OUO1085,137 -19-28JUN02-5/7

9. Install PTO clutch disk with long hub (A) facing out or to engine when clutch assembly is installed.
10. Install pressure plate (B) with index marks aligned.
11. Install spring (C) and button (D) in pressure plate.

**NOTE:** Raise clutch assembly on blocks and pull PTO fingers down to install special nuts.

12. Install washer (E) and new special nuts (F) loosely.

A—Long Hub of Clutch Disk  
B—PTO Clutch Pressure Plate  
C—Spring (3 used)  
D—Button (3 used)  
E—Conical Washer (3 used)  
F—Special Nut (3 used)



LV1053 -UN-15DEC94


Continued on next page

AG.OUO1085,137 -19-28JUN02-6/7

*NOTE: Conical washer must be sealed in special nut before tightening.*

13. Tighten special nut (A) while depressing button (B), until button is in channel.

A—Special Nut  
B—Button




LV038 -UN-03MAR92

AG,OUO1085,137 -19-28JUN02-7/7


## PTO Clutch Finger Adjustment

1. Separate engine from clutch housing. (See Separate Engine from Clutch Housing—Tractors Without Cab or Separate Engine from Clutch Housing—Tractors With Cab in Group 05.)
2. Check distance (height) (E) from pressure plate (D) to PTO clutch finger (B) using JDG919 Clutch Finger Height Gauge (C).
3. Turn special nut (A) in or out until clutch finger touches gauge.
4. Using pliers, crimp the top of special nut to flats on finger adjusting rod.
5. Repeat procedures for two remaining fingers.



LV1230 -UN-15DEC94

- A—Special Nut  
B—PTO Clutch Finger  
C—JDG919 Clutch Finger Height Gauge  
D—Pressure Plate  
E—Distance



LV1229AE -UN-15DEC94

AG,OUO1085,138 -19-16AUG00-1/1


## Remove and Inspect Clutch Release Mechanism and Shafts

**NOTE:** Floor plate removed for illustration purposes.

1. Separate engine from clutch housing. (See Separate Engine from Clutch Housing—Tractors Without Cab or Separate Engine from Clutch Housing—Tractors With Cab in Group 05.)
2. Disconnect PTO clutch rod (A) at both ends and remove.

**NOTE:** Tractor without cab shown.

3. Tractors without cab: remove left platform.




A—PTO Clutch Rod

AG,OUO1085,139 -19-16AUG00-1/5

4. Remove PTO clutch shaft (A).
5. Remove cap screw (B).
6. Remove clutch release bearing assembly (C).

A—PTO Clutch Shaft  
B—Cap Screw  
C—Clutch Release Bearing Assembly



AG,OUO1085,139 -19-16AUG00-2/5


7. Inspect parts (A—C) for wear or damage. Replace as necessary.

**NOTE:** Collars (A) and bearings (B) are press fit.

*Remove collar and bearing only if replacement is necessary.*

Disassemble parts (A—C) using a knife edged puller and a press.

Assemble parts using a press.




Clutch Release Bearing Assembly

A—PTO Clutch Collar  
B—Bearing  
C—PTO Clutch Sleeve

Continued on next page

AG,OUO1085,139 -19-16AUG00-3/5





A—PTO Clutch Armshaft  
B—Bushings (2 used)

C—Cap Screw (3 used)  
D—PTO Clutch Yoke

E—Shoe (2 used)  
F—Guide

G—Cap Screw (6 used)

8. Tractors with cab: remove battery. (See Remove and Install Battery—Tractors With Cab in Section 40, Group 05.)

9. Tractors with cab: remove battery box and crop guard.

**NOTE:** Tractors with cab: place a floor jack under left side of cab door to support cab during removal of left cab mounting bracket.

10. Tractors with cab: install floor jack and remove left cab mounting bracket.

11. Remove parts (A—G).

Continued on next page

AG,OUO1085,139 -19-16AUG00-4/5


*NOTE: Bushings (B) are press fit. Remove only if replacement is necessary.*

Replace bushings (B) using a bushing, bearing, and seal driver set. Install bushings flush with clutch housing.

12. Inspect parts for wear or damage. Replace as necessary.

AG,OUO1085,139 -19-16AUG00-5/5

## Install Clutch Release Mechanism and Shafts



A—PTO Clutch Armshaft  
B—Bushing (2 used)

C—Cap Screw (3 used)  
D—PTO Clutch Yoke

E—Shoe (2 used)  
F—Guide

G—Cap Screw (6 used)

1. Apply Moly High Temperature EP Grease to armshafts (A), shoes (E), and shaft end of guide (F).
2. Install parts (A—G). Tighten cap screws (G) to specification.

### Specification

Clutch Release Mechanism

Cap Screws—Torque ..... 26 N•m (20 lb-ft)

Continued on next page

AG,OUO1085,140 -19-28JUN02-1/3

3. Apply Moly High Temperature EP Grease to sliding surfaces of PTO clutch bearing assembly (C).
4. Install clutch release bearing assembly.
5. Clean cap screws (B) and yoke threads thoroughly with Clean and Cure Primer. Apply thread lock and sealer (medium strength) to cap screw threads.
6. Tighten cap screws (B) to specification.


**Specification**

Traction Clutch Shaft Cap  
Screws—Torque ..... 65 N•m (48 lb-ft)

7. Apply Moly High Temperature EP Grease to splined ends of PTO and traction clutch shafts (A).

**NOTE:** *Opposite end of clutch shaft must align with a coupler.*


8. Install PTO clutch shaft using a soft-faced hammer. Rotate shaft as necessary until fully seated.



**A—Traction Clutch Shaft**  
**B—Cap Screw**  
**C—PTO Clutch Release Bearing Assembly**

AG,OUO1085,140 -19-28JUN02-2/3


9. Connect PTO clutch rod (A).
10. Install engine to clutch housing. (See Install Engine to Clutch Housing—Tractors Without Cab or Install Engine to Clutch Housing—Tractors With Cab in Group 05.)
11. Adjust PTO clutch lever linkage. (See PTO Clutch Lever Adjustment in Section 250, Group 15.)
12. Tractors without cab: install left platform.
13. Tractors with cab: install left cab mounting bracket, crop guard, battery box, and battery.



**A—PTO Clutch Rod**

AG,OUO1085,140 -19-28JUN02-3/3

## Remove, Inspect, and Repair Transmission Pump



A—Cap Screw (2 used)  
B—Seal  
C—Pin (2 used)

D—Pump Cover  
E—Drive Gear

F—Pump Gear  
G—O-Ring

H—Pump Housing  
I—Gasket

1. Separate engine from clutch housing. (See Separate Engine from Clutch Housing—Tractors Without Cab or Separate Engine from Clutch Housing—Tractors With Cab in Group 05.)
2. Remove clutch release mechanism and shafts. (See Remove and Inspect Clutch Release Mechanism and Shafts in this group.)
3. Remove parts (A—I).
4. Inspect all parts for wear or damage. Replace as necessary.

Continued on next page

AG,OUO1085,141 -19-28JUN02-1/2

*NOTE: Remove seal (B) only if replacement is necessary.*

- 5. Inspect seal (B) for wear or damage. Replace if necessary.
- 6. Pry out seal (B).
- 7. Replace seal (B) using a bearing, bushing, and seal drive set. Install until seated.

**IMPORTANT: Always use new O-rings. Damaged or used O-rings will leak.**

*NOTE: Lubricate all internal parts with clean transmission/hydraulic oil during assembly.*

- 8. Install parts (A—I) and tighten cap screws (A) to specification.

Specification	
Transmission Pump Cap	
Screws—Torque .....	26 N•m (20 lb-ft)

- 9. Install clutch release mechanism and shafts.
- 10. Install engine to clutch housing. (See Install Engine to Clutch Housing—Tractors Without Cab or Install Engine to Clutch Housing—Tractors With Cab in Group 05.)

AG,OUO1085,141 –19–28JUN02–2/2





## Essential Tools

*NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).*

*SERVICEGARD is a trademark of Deere & Company*

OUO1043,0000E9F -19-28JUN02-1/2

Special Tool. . . . . JDT24B

Disassembles clutch piston.

OUO1043,0000E9F -19-28JUN02-2/2

## Specifications

Item	Measurement	Specification
Control Valve Cap Screws	Torque	26 N•m (20 lb-ft)
Detent Plug	Torque	19 N•m (14 lb-ft.)
Valve Spool Cover Screws	Torque	26 N•m (20 lb-ft.)
PowrReverser™ Control Valve Filter Plug	Torque	29 N•m (21 lb-ft.)
Valve Spool Retaining Plate Screws	Torque	26 N•m (19 lb-ft.)
Valve Body Screws	Torque	10 N•m (7 lb-in.)
PowrReverser™ Valve Plate Screws	Torque	10 N•m (7 lb-in.)
PowrReverser™ Clutch Pack Plate Cap Screw	Torque	26 N•m (20 lb-ft)
Outer Clutch Plate (21)	Thickness	5.85 mm (0.230 in.) Minimum
Clutch Disk (22)	Thickness	2.7 mm (0.106 in.) Minimum
Outer Clutch Plate (23)	Thickness	3.85 mm (0.151 in.) Minimum
PowrReverser™ Spring (No Load)	Length	58 mm (2.283 in.) Minimum

OUO1020,000120D -19-18JUL02-1/1

## Remove and Install PowrReverser™ Control Valve

**NOTE:** Tractor without cab shown.

*Left step removed for illustration purposes.*


1. Disconnect long PTO rod assembly (A) at both ends and remove.
2. Tractors without cab: remove left step.
3. Tractors with cab: remove floor plate covering clutch housing.
4. Remove cable clamp with shims (B) and clevis pin (C), and disconnect F-N-R cable.
5. Disconnect clutch pedal linkage (D).
6. Disconnect neutral safety wiring connector (E).
7. Remove cap screws (F) and control valve (G).
8. Make repairs as necessary. (See Disassemble, Inspect, and Repair PowrReverser™ Control Valve in this group.)
9. Clean mating surfaces of control valve and clutch housing.
10. Install new gasket.
11. Install control valve (G) and cap screws (F). Tighten cap screws to specification.

### Specification

Control Valve Cap Screws—

Torque ..... 26 N•m (20 lb-ft)

12. Connect neutral safety switch wiring connector.
13. Connect clutch pedal linkage and adjust. (See Clutch Pedal Linkage Adjustment in Section 250, Group 16.)
14. Connect F-N-R lever cable and make adjustments. (See Forward-Neutral-Reverse Control Cable Adjustment in Section 250, Group 16.)



A—Long PTO Rod Assembly  
B—F-N-R Cable Clamp with Shims  
C—Clevis Pin  
D—Traction Clutch Linkage  
E—Wire Connector  
F—Cap Screw (15 used)  
G—Control Valve

LV1056 -UN-08MAR95

Continued on next page

AG.OUO1085,142 -19-11NOV02-1/2


15. Install new tie straps as necessary.
16. Tractors without cab: install left step.
17. Tractors with cab: install clutch housing floor plate.
18. Install long PTO rod assembly and make adjustments.  
(See PTO Clutch Lever Adjustment in Section 250, Group 15 for adjustment procedures.)
19. Test control valve for proper function. (See PowrReverser™ Control Valve Tests in Section 250, Group 16.)

AG,OUO1085,142 -19-11NOV02-2/2

## Disassemble, Inspect, and Repair PowrReverser™ Control Valve

1. Remove PowrReverser™ valve. (See Remove and Install PowrReverser™ Control Valve in this group.)
2. Remove parts (A—F).

A—Clutch Lever  
 B—Neutral Safety Switch  
 C—F-N-R Lever  
 D—Spring Pin  
 E—Snap Ring  
 F—Washer



LV1226 -UN-06JAN95

Continued on next page

AG,OUO1085,143 -19-28JUN02-1/10


3. Remove socket head screws and sealing washers (A, B, and C).

**NOTE:** *Inspect sealing washers on screws for wear or damage. Replace if necessary.*

**A**—Screw and Sealing Washer 25 mm (0.984 in.) Long

**B**—Screw and Sealing Washer 45 mm (1.771 in.) Long

**C**—Screw and Sealing Washer 55 mm (2.165 in.) Long




LV1227 -UN-06/JAN95

Continued on next page

AG,OUO1085,143 -19-28JUN02-2/10





LV2130 -UN-08JUN97

Continued on next page

AG,OUO1085,143 -19-28JUN02-3/10

1—Plug  
2—Seal  
3—Filter Spring  
4—Filter  
5—Valve Body  
6—Gasket (2 used)  
7—Plate  
8—Bearing  
9—Valve Plate  
10—Pin  
11—Gasket  
12—Guide Pin  
13—Washer  
14—Spring  
15—Spring  
16—Spring Pin  
17—Piston

18—Plate  
19—Socket Head Screw (3 used)  
20—Spring  
21—Spool  
22—Spool  
23—Valve Body  
24—Socket Head Screw (3 used)  
25—Spool  
26—Seal  
27—Spring  
28—Socket Head Screw (3 used)  
29—Plate  
30—Spring

31—Spool  
32—Spool  
33—Spring  
34—Pin  
35—Clutch Arm  
36—Washer  
37—Seal  
38—Pin  
39—Shift Arm  
40—Seal  
41—Orifice  
42—Pin  
43—Snap Ring  
44—Valve Sleeve  
45—Seal  
46—Spring Pin

47—Spool  
48—Spring  
49—Spring  
50—Spring  
51—Spool  
52—Snap Ring  
53—Seal  
54—Socket Head Screw (4 used)  
55—Cover  
56—Seal  
57—Spool  
58—Spring  
59—Gasket  
60—Plug  
61—Ball

*NOTE: Clutch arm (35) is press fit in plate (9).*

4. Remove parts (35, 36, and 37) using a bushing, bearing, and seal driver set.
5. Separate back valve plate (9) from front valve body (5).
6. Remove gaskets (6) and plate (7).
7. Remove plug (60), gasket (59), springs (58), and balls (61).
8. Remove screws (24) and valve body (23).

**IMPORTANT: Replace all O-rings and seals. Used or damaged O-rings and seals will leak.**

9. Remove parts (11—34) from valve body (23). Inspect for wear or damage. Replace as necessary.
10. Disassemble piston (17) containing parts (12—16). Place piston assembly (17) in a soft-jawed vise. Place a socket or pipe over the head of pin (12) and compress washer (13) and springs (14 and 15). Remove pin (16) using a small punch and hammer.
11. Remove parts (12—15) from piston (17). Inspect all parts for wear or damage. Replace as necessary.

*NOTE: Bearing (8) is press fit in plate (9). Inspect for wear or damage. Replace only if necessary.*

12. Replace bearing (8) using a bushing, bearing, and seal driver set. Install new bearing until centered in bore.
13. Remove shift arm (39) and seal (40) using a punch and soft-faced hammer.
14. Remove orifice (41). Inspect for debris or damage in orifice hole. Clean or replace if necessary.
15. Remove plug (1), seal (2), spring (3), and filter (4). Inspect parts for wear or damage. Replace as necessary.
16. Remove screws (54), cover (55), and seals (53 and 56).
17. Remove spool (57).
18. Remove sleeve (44) containing parts (43 and 45—53) from front valve body (5).

*NOTE: Spring pin (46) is press fit in spool (47). Remove spring pin only if replacement of spool is necessary.*

19. Disassemble sleeve (44) by compressing spool (51) and remove snap ring (52).



20. Remove spool (51) and springs (48, 49, and 50).


21. Remove spring pin (46), snap ring (43), and spool (47).

AG,OUO1085,143 -19-28JUN02-5/10

22. Inspect all parts for wear or damage. Replace as necessary.

44—Valve Sleeve

46—Spring Pin




LV1631 -UN-02APR96

Continued on next page

AG,OUO1085,143 -19-28JUN02-6/10





Continued on next page

AG,OUO1085,143 -19-28JUN02-7/10

LV2130 -UN-08JUN97

1—Plug  
2—Seal  
3—Filter Spring  
4—Filter  
5—Valve Body  
6—Gasket (2 used)  
7—Plate  
8—Bearing  
9—Valve Plate  
10—Pin  
11—Gasket  
12—Guide Pin  
13—Washer  
14—Spring  
15—Spring  
16—Spring Pin  
17—Piston

18—Plate  
19—Socket Head Screw (3 used)  
20—Spring  
21—Spool  
22—Spool  
23—Valve Body  
24—Socket Head Screw (3 used)  
25—Spool  
26—Seal  
27—Spring  
28—Socket Head Screw (3 used)  
29—Plate  
30—Spring

31—Spool  
32—Spool  
33—Spring  
34—Pin  
35—Clutch Arm  
36—Washer  
37—Seal  
38—Pin  
39—Shift Arm  
40—Seal  
41—Orifice  
42—Pin  
43—Snap Ring  
44—Valve Sleeve  
45—Seal  
46—Spring Pin

47—Spool  
48—Spring  
49—Spring  
50—Spring  
51—Spool  
52—Snap Ring  
53—Seal  
54—Socket Head Screw (4 used)  
55—Cover  
56—Seal  
57—Spool  
58—Spring  
59—Gasket  
60—Plug  
61—Ball

**IMPORTANT:** Replace all O-rings and seals. Used or damaged O-rings and seals will leak.

*NOTE: Lubricate all internal parts with clean transmission/hydraulic oil during assembly.*

23. Assemble parts (43—53).

24. Install parts (38—61). Tighten detent plug (60) and valve spool cover screws (54) to specification.

**Specification**

Detent Plug—Torque ..... 19 N•m (14 lb-ft.)  
Valve Spool Cover Screws—  
Torque..... 26 N•m (20 lb-ft.)

25. Install filter (4), spring (3), seal (2), and plug (1). Tighten socket head plug (1) to specification.

**Specification**

PowrReverser™ Control Valve  
Filter Plug—Torque..... 29 N•m (21 lb-ft.)

26. Reassemble parts (12—17). Install pin (16) until centered.

27. Install parts (12—22) and parts (25—34) on valve body (23). Tighten screws (19 and 28) to specification.

**Specification**

Valve Spool Retaining Plate  
Screws—Torque ..... 26 N•m (19 lb-ft.)

28. Install gasket (11), valve body (23), and screws (24). Tighten screws to specification.

**Specification**

Valve Body Screws—Torque..... 10 N•m (7 lb-in.)

29. Install valve case (5), gaskets (6), plate (7), and valve plate (9).

Continued on next page


AG,OUO1085,143 -19-28JUN02-8/10



## Remove and Install PowrReverser™

1. Separate clutch housing from transmission. (See Separate Clutch Housing from Transmission in Group 16.)
2. Remove cap screws (A) and clutch pack plate (B).
3. Disassemble and inspect plate (B). Replace parts as necessary. (See Disassemble, Inspect, and Repair Reverse Idle Gear in this group.)

A—Cap Screw  
B—Plate




LV1069 -UN-15DEC94

AG,OUO1085,144 -19-28JUN02-1/8

4. Remove splined coupling (A).
5. Remove clutch gear (B).
6. Disassemble and inspect clutch gear (B). Replace parts as necessary. (See Disassemble, Inspect, and Repair Clutch Gear in this group.)

A—Splined Coupling  
B—Clutch Gear



LV1070 -UN-15DEC94



LV1071 -UN-15DEC94

Continued on next page

AG,OUO1085,144 -19-28JUN02-2/8


50  
12  
13




**NOTE:** Place a mark on the end of driven shaft (B) to aid during installation.

7. Slide PowrReverser™ (A) and driven shaft (B) rearward until driven shaft (B) can be removed.
8. Disassemble and inspect driven shaft (B). Replace parts as necessary. (See Disassemble, Inspect, and Repair Driven Shaft in this group.)

**A—PowrReverser™**  
**B—Driven Shaft**



LV1072 -UN-15DEC94



LV1073 -UN-15DEC94

Continued on next page


AG,OUO1085,144 -19-28JUN02-3/8



**CAUTION:** Approximate weight of PowrReverser™ (B) is 20 kg (45 lbs).

9. Remove PTO shaft (A).
10. Remove hydraulic reverser (B).
11. Disassemble and inspect PowrReverser™ (B). Replace parts as necessary. (See Disassemble, Inspect, and Repair PowrReverser™ in this group.)

A—PTO Shaft  
B—Hydraulic Reverser



LV1074 -UN-15DEC94



LV1075 -UN-15DEC94


50  
12  
15

AG,OUO1085,144 -19-28JUN02-4/8

**NOTE:** Lubricate all internal parts with clean transmission/hydraulic oil during assembly.

**IMPORTANT:** Use new seals and O-rings during assembly. Damaged or used seals or O-rings will leak.

12. Apply Moly High Temperature EP Grease to splined ends of PTO and clutch shafts.
13. Install PowrReverser™ (B) and PTO shaft (A). It may be necessary to rotate PowrReverser™ during installation.



LV1074 -UN-15DEC94

A—PTO Shaft  
B—PowrReverser™


Continued on next page

AG,OUO1085,144 -19-28JUN02-5/8

**NOTE:** To aid in installation of driven shaft (B), do not seat PowrReverser™ (A) completely into case bore.

14. Install driven shaft (B) and fully seat both shafts (A and B) into case bore.

A—PowrReverser™  
B—Driven Shaft




LV1072 -UN-15DEC94

AG.OUO1085,144 -19-28JUN02-6/8

**NOTE:** During installation of clutch gear (B), rotate clutch gear to align disks onto splined ends of clutch gear. Make sure clutch gear (B) is completely seated inside PowrReverser™.

15. Install clutch gear (B) until large seal on clutch gear is completely under plate (C).
16. Apply Moly High Temperature EP Grease to inside splines of coupling (A).
17. Install splined coupling (A).



LV1368 -UN-15SEP95

A—Splined Coupling  
B—Clutch Gear  
C—Plate


AG.OUO1085,144 -19-28JUN02-7/8

18. Install clutch pack plate (B) and cap screws (A). Tighten cap screws to specification.

#### Specification

PowrReverser™ Clutch Pack  
Plate Cap Screw—Torque..... 26 N•m (20 lb-ft)

A—Cap Screw  
B—Clutch Pack Plate



LV1069 -UN-15DEC94

AG.OUO1085,144 -19-28JUN02-8/8


## Disassemble, Inspect, and Repair Reverse Idle Gear

1. Remove retaining ring (A and B).
2. Remove retaining ring (C).

**NOTE:** Reverse idle gear (D) is press fit. Remove reverse idle gear (D) using a bushing, bearing, and seal driver set.

3. Remove idle gear (D) and bearing (E).

A—Retaining Ring (2 used)  
 B—Retaining Ring  
 C—Retaining Ring  
 D—Reverse Idle Gear  
 E—Bearing



LV1076 -UN-15DEC94

50  
12  
17

AG,OUO1085,145 -19-16AUG00-1/2


**NOTE:** Bearing (A) is press fit on shaft (B). Remove bearing only if replacement is necessary.

Remove bearing (A) using a knife-edged puller and press. Install new bearing until seated.

4. Inspect all parts for wear or damage. Replace as necessary.

**NOTE:** Lubricate all bearings with clean transmission/hydraulic oil during assembly.

5. Install all parts.



A—Bearing  
 B—Shaft

LV1077 -UN-15DEC94

AG,OUO1085,145 -19-16AUG00-2/2

## Disassemble, Inspect, and Repair Clutch Gear

**NOTE:** Bearings (C and E) are press fit on clutch gear (B).

1. Remove bearings (C and E) using a knife-edged puller and a press.


**IMPORTANT:** Replace seal. Damaged or used seal will leak.

2. Remove all parts.
3. Inspect all parts for wear or damage. Replace as necessary.

**NOTE:** Lubricate all parts with clean transmission/hydraulic oil during assembly.

4. Install all parts.

Install bearings (C and E) using a bearing, bushing, and seal drive set and a press.



A—Seal  
B—Clutch Gear  
C—Ball Bearing  
D—Collar  
E—Bearing

LV1220A -UN-15DEC94

LV1078 -UN-15DEC94

AG,OUO1085,146 -19-16AUG00-1/1

## Disassemble, Inspect, and Repair Driven Shaft

**NOTE:** Bearings (A and H) are press fit on shaft (E).


1. Remove bearings (A and H) using a knife-edged puller and a press.
2. Remove all parts.
3. Inspect all parts for wear or damage. Replace as necessary.

**NOTE:** Lubricate all parts with clean transmission/hydraulic oil during assembly.

4. Install all parts.

Install bearings (A and H) using a bearing, bushing, and seal driver set and a press.

- A—Ball Bearing
- B—Snap Ring
- C—Drive Gear
- D—Snap Ring
- E—Driven Shaft
- F—Snap Ring
- G—Drive Gear
- H—Ball Bearing



LV1222A -UN-15DEC94




LV1221 -UN-15DEC94

AG,OUO1085,147 -19-16AUG00-1/1



## Disassemble, Inspect, and Repair PowrReverser™



1—Ring Seal (4 used)  
 2—Shaft  
 3—Key  
 4—Key  
 5—Ball (4 used)  
 6—Washer (2 used)  
 7—Seal

8—Bearing  
 9—Snap Ring  
 10—Ball Bearing  
 11—Snap Ring (3 used)  
 12—Bearing (2 used)  
 13—Snap Ring  
 14—Clutch Gear

15—Washer  
 16—Seal  
 17—Snap Ring (2 used)  
 18—Support (2 used)  
 19—Spring (2 used)  
 20—Retaining Ring (2 used)  
 21—Plate (2 used)

22—Disk (8 used)  
 23—Plate (8 used)  
 24—Piston (2 used)  
 25—Seal (2 used)  
 26—Clutch Cylinder  
 27—Ball Bearing

**IMPORTANT:** Replace all seals and O-rings.  
 Damaged or used seals and O-rings  
 will leak.

1. Remove seals (1) and key (3).

Continued on next page

AG,OUO1085,148 -19-28JUN02-1/5

**NOTE:** Bearing (27) is press fit on shaft (2).

2. Remove bearing (27) using a knife-edged puller.
3. Remove retaining ring (20) and parts (21—23) on both sides of clutch cylinder (26).
4. Inspect disks (22) and plates (21 and 23) for cracks or damage. Replace if necessary. Measure disk and plate thickness. Replace if less than specifications.

#### Specification

Outer Clutch Plate (21)—	
Thickness.....	5.85 mm (0.230 in.) Minimum
Clutch Disk (22)—Thickness .....	2.7 mm (0.106 in.) Minimum
Outer Clutch Plate (23)—	
Thickness.....	3.85 mm (0.151 in.) Minimum

5. Remove snap ring (11) from transmission end of shaft (2).
6. Remove clutch cylinder (26) containing parts (17—19), piston (24), and seal (25).

AG,OUO1085,148 -19-28JUN02-2/5

**NOTE:** Dealers with JDT24A need only purchase new center tee JDT24-3 to make special tool JDT24B.


7. Disassemble clutch piston by placing clutch cylinder (A) and special tool JDT24B (B) on a press or flat-jawed vise.
8. Compress spring (C) and support (D). Remove snap ring (E).
9. Slowly release pressure of special tool and remove parts (B—E) and piston (F).
10. Measure spring (C) under no load. Replace spring if not within specification.

#### Specification

PowrReverser™ Spring (No Load)—Length.....	58 mm (2.283 in.) Minimum
--------------------------------------------	---------------------------

11. Repeat procedure for other side of clutch cylinder.


A—Clutch Cylinder  
B—Special Tool JDT24B  
C—Spring  
D—Support  
E—Snap Ring  
F—Piston



LV1228 -UN-09JAN95

Continued on next page

AG,OUO1085,148 -19-28JUN02-3/5



1—Ring Seal (4 used)  
2—Shaft  
3—Key  
4—Key  
5—Ball (4 used)  
6—Washer (2 used)  
7—Seal

8—Bearing  
9—Snap Ring  
10—Ball Bearing  
11—Snap Ring (3 used)  
12—Bearing (2 used)  
13—Snap Ring  
14—Clutch Gear  
21—Plate (2 used)

15—Washer  
16—Seal  
17—Snap Ring (2 used)  
18—Support (2 used)  
19—Spring (2 used)  
20—Retaining Ring (2 used)  
22—Disk (8 used)  
23—Plate (8 used)  
24—Piston (2 used)  
25—Seal (2 used)  
26—Clutch Cylinder  
27—Ball Bearing

**IMPORTANT: Replace all seals and O-rings. Damaged or used seals and O-rings will leak.**

12. Remove seals (25) from piston (24).

13. Remove parts (11—16) and key (4) from shaft (2).

Continued on next page

AG,OUO1085,148 -19-28JUN02-4/5

*NOTE: Bearing (10) is press fit on shaft (2). Inspect bearing (10) for wear or damage. Replace only if necessary.*

14. Remove bearing (10) from charge pump end of shaft (2) using a knife-edged puller and a press.

*NOTE: Seal (7) is press fit inside shaft (2). Inspect seal (7) for wear or damage. Replace only if necessary.*

15. Remove snap ring (9), bearing (8), and washer (6).

16. Pry out seal (7) and remove washer (6) behind seal.

*NOTE: Balls (5) are press fit and are not replaceable.*

17. Inspect shaft (2) for wear or damage. Replace if necessary.

18. Inspect all parts for wear or damage. Replace as necessary.

*NOTE: Lubricate all parts with clean transmission/hydraulic oil during assembly.*

19. Install washer (6) inside transmission end of shaft (2).

20. Install seal (7) using a bushing, bearing, and seal driver set and a press.

21. Install washer (6), bearing (8), and snap ring (9).

22. Install snap ring (11).

23. Install bearing (10) from the PTO clutch end of shaft (2) using a bushing, bearing, and seal driver set. Install bearing (10) until seated against snap ring (11).

24. Install parts (12—16) on shaft (2).

25. Reassemble parts (17, 18, 19, 24, and 25) on both sides of clutch cylinder (26) using special tool JDT24A.

26. Install key (4).

*NOTE: Make sure the radius on plate (21) is toward the large retaining ring (20).*

27. Install parts (21—23) on clutch gear (14).

*NOTE: When installing large retaining rings (20), make sure open end of retaining ring aligns with solid wall of clutch cylinder (26).*

28. Install clutch cylinder (26) and back retaining ring (20).

*NOTE: Make sure the radius on plate (21) is toward the large retaining ring (20).*

29. Install parts (21—23) and front retaining ring (20).

*NOTE: When installing large retaining rings (20), make sure open end of retaining ring aligns with solid wall of clutch cylinder (26).*

30. Install snap ring (11) and seals (1).

31. Install bearing (27) using a bushing, bearing, and seal driver set.

32. Install key (3) in shaft (2).

33. Install clutch housing to transmission. (See Install Clutch Housing to Transmission in Group 16.)

34. Test function of PowrReverser™. (See PowrReverser™ Control Valve Tests in Section 250, Group 16.)

AG,OUO1085,148 -19-28JUN02-5/5

50  
12  
24

### Service Equipment and Tools

*NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.*

*SERVICEGARD is a trademark of Deere & Company*

OUC1043,0000EA4 -19-28JUN02-1/2

Flywheel Turning Tool . . . . . JDE83

Rotates flywheel.

OUC1043,0000EA4 -19-28JUN02-2/2

### Other Material

Number	Name	Use
TY15130 (U.S.)	John Deere Sealer	Seals shift lever housings.
TY6305 (U.S.) TY9485 (Canadian) 7649 (LOCTITE®)	Clean and Cure Primer	Cleans mating surfaces and reduces sealant curing time.
TY9370 (U.S.) TY9477 (Canadian) 242 (LOCTITE®)	Thread Lock and Sealer (Medium Strength)	Apply to PTO and traction clutch yoke-to-armshaft cap screw threads. Apply to shift fork-to-shaft cap screw threads.

*LOCTITE is a registered trademark of Loctite Corp.*

OUC1043,0000EA5 -19-28JUN02-1/1

50  
15  
1

Specifications

Item	Measurement	Specification
Clutch Housing-to-Transmission Cap Screws	Torque	118—147 N•m (87—108 lb-ft)
Wheel Cap Screws	Torque	175 N•m (130 lb-ft)
Transmission-to-Differential Case Cap Screws	Torque	140 N•m (105 lb-ft)
Reverse Idler Shaft	Torque	132 N•m (97 lb-ft)

OUO1043.0000EA6 -19-28JUN02-1/1



## Separate Clutch Housing from Transmission

**NOTE:** The approximate capacity of transmission is 38 L (10 U.S. gal).

1. Drain transmission.


**NOTE:** Remove cab and floor plate if equipped. (See Cab Remove and Install and Cab Floor Plates Remove and Install—Early Model Tractors or Cab Floor Plate Remove and Install—Later Model Tractors in Section 90, Group 15.)

2. Remove seat and support. (See Remove and Install Seat and Support—Tractors Without Cab or Remove and Install Seat and Support Plate—Tractors With Cab in Section 90, Group 05.)
3. Remove clamp (A).
4. Disconnect wiring leads (B).
5. Disconnect ground wire lead (D), located on transmission cover.
6. Disconnect wiring connectors (C).

A—Clamp  
B—Fuel Level Sender Wiring Leads  
C—Wiring Connector  
D—Ground Wiring Lead



LV2440 -UN-16DEC97




LV2441 -UN-18DEC97

50  
15  
3

AG,OUO1085,150 -19-17AUG00-1/6

7. Tractors without cab: remove right step plate.
8. Disconnect turn signal wiring connector (A).
9. Disconnect neutral safety switch wiring connector (B).

A—Turn Signal Wiring Connector  
B—Neutral Safety Switch Wiring Connector



LV516 -UN-03MAR92


Continued on next page

AG,OUO1085,150 -19-17AUG00-2/6

**NOTE:** Close all openings using caps and plugs.

10. Remove suction line (E).
11. Remove cap screw (C).
12. Disconnect hydraulic lines (A and D).
13. Disconnect brake line (B).

A—Brake Valve Return Line  
 B—Brake Pressure Line  
 C—Cap Screw  
 D—Hydraulic Pump-to-Inlet Housing Supply Line  
 E—Suction Line




Right Side Shown

LV515 -UN-03MAR92

AG,OUO1085,150 -19-17AUG00-3/6

14. Tractors without cab: remove left step plate.
15. Disconnect brake line (A).
16. Remove cap screw (B).
17. Remove PTO clutch linkage rod (C).

A—Brake Line  
 B—Cap Screw  
 C—Linkage Rod



Left Side Shown

LV518 -UN-03MAR92

Continued on next page

AG,OUO1085,150 -19-17AUG00-4/6

**NOTE:** Fuel tank capacity for 5210, 5310, and 5410 tractors is 68 L (18.0 U.S. gal).

Fuel tank capacity for 5510 and tractors with cab is 83 L (22.0 U.S. gal).

18. Drain fuel tank.


**NOTE:** Fuel lines are located on left side of tractor by axle final drive housing.

19. Disconnect fuel lines (A). Cut tie straps as necessary.

20. Disconnect hydraulic line (B).

21. Remove wire harness from rear of tractor. Cut tie straps as necessary.

A—Fuel Line (2 used)  
B—Hydraulic Line



LV2442 -UN-16DEC97

Continued on next page


AG,OUO1085,150 -19-17AUG00-5/6

50  
15  
5

22. Remove MFWD drive shaft, if equipped. (See Remove, Inspect and Install MFWD Drive Shaft in Group 35.)
23. Install wood blocks between the front axle pivot stops and tractor frame. Check front and back of rear wheels.
24. Position a floor jack under the transmission and a support stand under end of drawbar.
25. Attach a hoist and lifting chains or strap around clutch housing.
26. Place range shift lever in neutral and move gear shift lever fully left to neutral position between 2nd and reverse gears. Use wire or rope to hold gear shift lever in this position.

**NOTE:** When separating, the main outer shaft, gear fork shaft, and driven shaft assemblies must remain in transmission case.

27. Remove ten cap screws. Roll front section of tractor (clutch housing) away from rear section (transmission).
28. Install a support stand under clutch housing.



LV522 -UN-03MAR92

AG,OUO1085,150 -19-17AUG00-6/6

## Install Clutch Housing to Transmission

1. Clean mating surfaces of transmission and clutch housings. Install new gasket.
2. Place range shift lever in neutral and gear shift lever in reverse.

**NOTE:** *It may be necessary to rotate the clutch shafts and reverse gears during installation so that the clutch and transmission shafts mesh.*

*Rotate the PTO shaft by manually turning the PTO at rear of tractor.*

*Rotate the traction shaft by turning the flywheel using JDE83 Flywheel Turning Tool.*

*Verify that the two bearings and two fork shafts enter holes of clutch housing at the same time.*


*Verify that the two pins enter the holes in transmission housing.*

3. Install clutch housing to transmission. Tighten cap screws to specification.

### Specification

Clutch Housing-to-Transmission  
Cap Screws—Torque ..... 118—147 N•m (87—108 lb-ft)

4. Install MFWD drive shaft, if equipped. (See Remove, Inspect and Install MFWD Drive Shaft in Group 35.)



LV522 -UN-03MAR92

50  
15  
7


Continued on next page

AG\_OUO1085,151 -19-28JUN02-1/6



5. Connect hydraulic line (B).
6. Connect fuel hoses (A).


A—Fuel Hose (2 used)  
B—Hydraulic Line



AG,OUO1085,151 -19-28JUN02-2/6

7. Install PTO clutch linkage rod (C).
8. Install cap screw (B).
9. Connect brake line (A).
10. Install left step plate if removed.

A—Brake Line  
B—Cap Screw  
C—Clutch Linkage Rod




Left Side Shown

Continued on next page

AG,OUO1085,151 -19-28JUN02-3/6

11. Connect brake line (B).
12. Connect hydraulic lines (A and D).
13. Install cap screw (C).
14. Install suction line (E).

**A—Brake Valve Return Line**  
**B—Brake Pressure Line**  
**C—Cap Screw**  
**D—Hydraulic Pump-to-Inlet Housing Supply Line**  
**E—Suction Line**




Right Side Shown

AG,OUO1085,151 -19-28JUN02-4/6

15. Connect wiring connector to neutral safety switch (B).
16. Connect wiring connector (A). Install new tie straps as necessary.
17. Install right step plate if removed.
18. Install cab and floor plates if equipped. (See Cab Remove and Install and Cab Floor Plates Remove and Install—Early Model Tractors or Cab Floor Plate Remove and Install—Later Model Tractors in Section 90, Group 15.)

**A—Wiring Connector**  
**B—Neutral Safety Switch**



Right Side Shown


Continued on next page

AG,OUO1085,151 -19-28JUN02-5/6




19. Connect wiring connectors (C).
20. Connect wire lead (D).
21. Connect wiring leads (B).
22. Install clamp (A).
23. Fill fuel tank with proper fuel. (See Diesel Fuel Specifications in Section 10, Group 20.)
24. Install seal and support. (See Remove and Install Seat and Support—Tractors Without Cab or Remove and Install Seat and Support Plate—Tractors With Cab in Section 90, Group 05.)
25. Fill transmission with clean transmission/hydraulic oil. (See Transmission and Hydraulic Oil in Section 10, Group 20.)
26. Bleed brake system. (See Bleed Brake System in Section 260, Group 15.)

A—Clamp  
B—Fuel Level Sender Wiring Lead  
C—Wiring Connectors  
D—Ground Wire Lead



AG,OUO1085,151 -19-28JUN02-6/6

## Inspect and Repair Gear Shift Lever



Gear Shift Lever

A—Knob Cover  
B—Screw  
C—Washer  
D—Knob  
E—Gear Shift Lever  
F—Clamp

G—Boot  
H—Clamp  
I—Retaining Ring  
J—Spring  
K—Retaining Ring  
L—Ring

M—Pin  
N—Ball  
O—Case  
P—Plug  
Q—Plug  
R—Spring Pin

S—Spring Pin  
T—Arm  
U—Case Cover  
V—Screw  
W—Plate

**NOTE:** Tractor without cab shown. Tractor with cab is similar.

Remove and Install Seat and Support Plate—Tractors With Cab in Section 90, Group 05.)

1. Remove seat and support. (See Remove and Install Seat and Support—Tractors Without Cab or

Continued on next page

AG,OUO1085,152 -19-28JUN02-1/2

2. Remove right control console and panel. See Remove and Install Right-Side Control Console and Panel—Tractors With Cab in Section 90, Group 15 or Remove and Install Right-Side Control Console and Panel—Tractors Without Cab in Section 90, Group 06.)
3. Tractors without cab: remove right rear wheel and fender.
4. Remove case cover (U) and plate (W).
5. Remove plugs (P and Q).
6. Remove spring pins (R and S).
7. Remove parts (A—N).


8. Inspect all parts for wear or damage. Replace as necessary.
9. Apply multipurpose grease to ball (N).
10. Install all parts.
11. Install right control console and panel.
12. Install seat and support.
13. Tractors without cab: install fender and wheel. Tighten wheel cap screws to specification.

**Specification**

Wheel Cap Screws—Torque ..... 175 N•m (130 lb-ft)

AG,OUO1085,152 –19–28JUN02–2/2

## Inspect and Repair Range Shift Lever



Range Shift Lever

A—Knob Cover  
B—Screw  
C—Washer  
D—Knob  
E—Range Shift Lever  
F—Clamp

G—Boot  
H—Clamp  
I—Retaining Ring  
J—Spring  
K—Retaining Ring  
L—Ring

M—Spring Pin  
N—Ball  
O—Spring Pin  
P—Spring Pin  
Q—Arm  
R—Cover

S—Screw  
T—Plug  
U—Park Brake Cable Bracket  
V—Shiftable PTO Cable Bracket

**NOTE:** Tractor without cab shown. Tractor with cab is similar.

Remove and Install Seat and Support Plate—Tractors With Cab in Section 90, Group 05.)

1. Remove seat and support. (See Remove and Install Seat and Support—Tractors Without Cab or

Continued on next page

AG,OUO1085,153 -19-28JUN02-1/2

2. Remove left control console and panel. (See Remove and Install Left-Side Control Console—Tractors With Cab in Section 90, Group 15 or Remove and Install Left-Side Control Console and Panel—Tractors Without Cab in Section 90, Group 06.)
3. Tractors without cab: remove left rear wheel and fender.
4. Remove screws (S) and bracket (U or V) if equipped.
5. Remove cover (R) and plugs (T) on both sides of range shift housing.
6. Remove spring pin (O and P).
7. Remove parts (A—Q).

8. Inspect all parts for wear or damage. Replace as necessary.
9. Apply multipurpose grease to ball (O).
10. Install all parts.
11. Install seat and support.
12. Install control console.
13. Tractors without cab: install fender and wheel. Tighten wheel cap screws to specification.

**Specification**

Wheel Cap Screws—Torque ..... 175 N•m (130 lb-ft)

AG,OUO1085,153 -19-28JUN02-2/2


## Remove Transmission

**NOTE:** Tractor without cab shown. Tractor with cab is similar.

1. Separate clutch housing from transmission. (See Separate Clutch Housing from Transmission in this group.)
2. In tractor with cab, remove both control consoles and support plate. (See Remove and Install Right-Side Control Console and Panel—Tractors With Cab and Remove and Install Left-Side Control Console—Tractors With Cab in Section 90, Group 15.)
3. Raise and support rear axles.
4. In tractor without cab, remove rear wheels and fenders.
5. Remove rockshaft control levers.
6. Remove right control console. (See Remove and Install Right-Side Control Console and Panel—Tractors Without Cab in Section 90, Group 06.)
7. Remove SCV joystick and cable assembly, if equipped. (See Inspect and Repair Joystick and Linkage—Without Cab or Inspect and Repair Joystick and Linkage—With Cab in Section 70, Group 15.)

**NOTE:** Close all openings using caps and plugs.

8. Remove right brake line. Close all openings using caps and plugs.




Continued on next page

AG.OUO1085,154 -19-17AUG00-1/4

LV526 -UN-03MAR92

50  
15  
15

9. Remove MFWD lever and linkage, if equipped. (See Inspect and Repair MFWD Lever and Linkage in Group 35.)
10. Remove PTO lever and linkage. (See Remove, Inspect and Install Rear PTO Lever and Linkage in Group 20.)
11. Remove left control console.
12. Remove gear shift lever and range shift lever. (See Inspect and Repair Gear Shift Lever and Inspect and Repair Range Shift Lever in this group.)
13. Remove 8 cap screws (B) and nuts (C) to remove cover and shifter housings (A). Repair if necessary. (See Disassemble and Inspect Transmission in this group.)




Left Side Shown

- A—Shifter Housing  
 B—Cap Screw (8 used)  
 C—Nut (8 used)

Continued on next page

AG,OUO1085,154 -19-17AUG00-2/4





Range Shift Shaft Assembly


- |                                  |                                   |                   |             |
|----------------------------------|-----------------------------------|-------------------|-------------|
| A—Cap Screw (2 used)             | E—A Range and Creeper Shift Shaft | H—Ball (2 used)   | L—Cap Screw |
| B—Lock Washer (2 used)           | F—B and C Range Shift Shaft       | I—Spring (2 used) | M—Plate     |
| C—B and C Range Shift Fork       | G—Sleeve                          | J—Bushings        | N—Pin       |
| D—A Range and Creeper Shift Fork |                                   | K—Cap Screw       | O—Ball      |

14. Remove parts (H—O).
15. Remove cap screws (A) and lock washers (B). Slide shift shafts (F and E) forward into transmission housing to obtain necessary clearance to remove shift forks.
16. Remove shift fork (C).
17. Remove shift fork (D).
18. Install bushing (J) and cap screw (K) to aid in disassembly.

Continued on next page

AG.OUO1085,154 -19-17AUG00-3/4

19. Remove hydraulic oil filter assembly. (See Remove and Install Hydraulic Filter/Manifold—Early Model or Remove and Install Hydraulic Filter/Manifold—Later Model in Section 70, Group 05.)
20. Remove side cover or creeper assembly, if equipped. (See Remove and Install Creeper Assembly in Group 40.)
21. Remove lower cover or MFWD drop gearbox, if equipped. (See Remove and Install MFWD Drop Gearbox in Group 35.)
22. Position a jackstand under drawbar assembly.
23. Attach hoist and chains to transmission housing.




**IMPORTANT:** Before separating the transmission from rear differential housing, rotate park pawl until it rests against the inside of transmission housing. If park pawl is not rotated, damage to gears may result when transmission is separated from the rear differential housing.

*NOTE: Differential drive shaft and gear cluster assembly will stay with the differential during transmission removal.*

24. Remove ten cap screws. Remove transmission.
25. Make repairs as necessary. (See Disassemble and Inspect Transmission in this group.)

AG,OUO1085,154 -19-17AUG00-4/4

## Disassemble and Inspect Transmission



A—Cap Screw	F—Bushing (2 used)	K—Spring Pin	P—Gear Shift Arm
B—Range Shift Lever Housing	G—Gear Shift Lever Housing	L—Spring Pin	Q—Range Shift Arm
C—Bushing (2 used)	H—Pin	M—Spring	R—Pin
D—Cap Screw (6 used)	I—Cover	N—Spring	S—Cap Screw
E—Plug	J—Gear Shift Shaft	O—Ball	

1. Remove cap screws (A, D, and S).
2. Remove range shift lever housing (B) and gear shift lever housing (G).
3. Remove plug (E) and remove pins (K and L) through plug hole.
4. Remove gear shift arm (J), being careful not to lose detent ball (O) and springs (M and N).
5. Remove range shift arm (Q).
6. Inspect parts for wear or damage. Replace as necessary.

Continued on next page

AG,OUO1023,510 -19-28JAN00-1/9

**NOTE:** Bushings (C and F) are a press fit in case (I) and housing (B and G). Remove bushings only if replacement is necessary.

7. Replace bushings (C and F) using a bushing, bearing, and seal driver set.


AG,OUO1023,510 -19-28JAN00-2/9

8. Remove range shift shafts (A and B).

9. Remove PTO shaft (D), washer (E), and bearing (C).


10. Inspect parts for wear or damage. Replace if necessary.

A—B and C Range Shift Shaft  
B—A Range and Creeper Shift Shaft  
C—Bearing  
D—PTO Shaft  
E—Washer



Continued on next page

AG,OUO1023,510 -19-28JAN00-3/9



Park Pawl Assembly


- |                      |                               |                      |             |
|----------------------|-------------------------------|----------------------|-------------|
| A—Cap Screw (5 used) | G—Bushings                    | L—Thrust Bearing     | Q—Cap Screw |
| B—Shaft              | H—Washer (2 used)             | M—Bearing Race       | R—Cam       |
| C—Guide              | I—Spring Locking Pin (2 used) | N—Shim (as required) | S—Pawl      |
| D—Spring             | J—Spring                      | O—O-Ring             | T—Shaft     |
| E—Arm                | K—Bearing Race                | P—Cover Plate        | U—Spring    |
| F—Link               |                               |                      |             |

11. Remove parts (A—U).

12. Inspect parts for wear or damage. Replace as necessary.

Continued on next page

AG,OUO1023,510 -19-28JAN00-4/9



LV464A -UN-03MAR92

A—Cap Screw (2 used)  
B—Bushing (2 used)  
C—Arm

D—Ball (2 used)  
E—Spring (2 used)  
F—Pin

G—Plate  
H—Cap Screw  
I—Cap Screw

J—Bushing  
K—Ball

13. Remove parts (A—K).

**NOTE:** Reinstall bushing (J) and cap screw (I) to ease removal of gear shift/shaft assembly.

14. Install bushing (J) and cap screw (I).

15. Inspect parts for wear or damage. Replace as necessary.


Continued on next page

AG,OUO1023,510 -19-28JAN00-5/9

**NOTE:** To aid in removal, secure shifter shafts to transmission top shaft with wire.

16. Remove transmission top shaft (A) with reverse and 2nd gear shift shaft assembly (B) and 1st and 3rd gear shift shaft assembly (C).
17. Disassemble and inspect parts as necessary. (See Disassemble, Inspect, and Assemble Transmission Top Shaft—CollarShift Transmission or Disassemble, Inspect, and Assemble Transmission Top Shaft—SyncShuttle™ Transmission in this group.)

**A—Transmission Top Shaft**  
**B—Reverse and 2nd Gear Shift Shaft Assembly**  
**C—1st and 3rd Gear Shift Shaft Assembly**



LV467 -UN-03MAR92




LV468 -UN-03MAR92

AG,OUO1023,510 -19-28JAN00-6/9

18. Mark support (A) and transmission case to aid in installation.
19. Remove cap screws and bushings (B), and support (A).
20. Inspect parts for wear or damage. Replace as necessary.

**A—Support**  
**B—Bushing**



LV470 -UN-03MAR92


Continued on next page

AG,OUO1023,510 -19-28JAN00-7/9



21. Remove range reduction shaft (A).
22. Disassemble and inspect parts as necessary. (See Disassemble, Inspect, and Assemble Range Reduction Shaft in this group.)

A—Range Reduction Shaft




LV471 -UN-03MAR92

AG,OUO1023,510 -19-28JAN00-8/9

23. Remove driven shaft (A).
24. Disassemble and inspect parts as necessary. (See Disassemble, Inspect and Assemble Driven Shaft in this group.)
25. Inspect transmission case for cracks or damage. Replace if necessary.

A—Driven Shaft



LV473 -UN-03MAR92

AG,OUO1023,510 -19-28JAN00-9/9


## Assemble Transmission

**NOTE:** Lubricate all internal parts with clean transmission/hydraulic oil during assembly.

**IMPORTANT:** Use new seals and O-rings during assembly. Damaged or used seals or O-rings will leak.

1. Install driven shaft (A). Tap on end of shaft with a soft-faced hammer to fully seat shaft in case bore.

A—Driven Shaft




LV473 -UN-03MAR92

Continued on next page

AG,OUO1085,155 -19-17AUG00-1/10

2. Install range reduction shaft (A).

**A—Range Reduction Shaft**




LV471 -UN-03MAR92

AG,OUO1085,155 -19-17AUG00-2/10

3. Align support (A) with transmission case with marks inside during disassembly.
4. Install bushings and cap screws (B).

**A—Support**  
**B—Cap Screw**



LV470 -UN-03MAR92

Continued on next page

AG,OUO1085,155 -19-17AUG00-3/10

50  
15  
25

**NOTE:** To aid in installation, secure shifter shafts to transmission top shaft with wire.


5. Install transmission top shaft (A) with reverse and 2nd gear shaft assembly (B) and 1st and 3rd gear shaft assembly (C).

**A—Transmission Top Shaft**  
**B—Reverse and 2nd Gear Shift Shaft Assembly**  
**C—1st and 3rd Gear Shift Shaft Assembly**



CollarShift Shown


LV468 -UN-03MAR92



LV467 -UN-03MAR92

Continued on next page

AG,OUO1085,155 -19-17AUG00-4/10



A—Cap Screw (2 used)  
B—Bushing (2 used)  
C—Arm

D—Ball (2 used)  
E—Spring (2 used)  
F—Pin

G—Plate  
H—Cap Screw  
I—Cap Screw

J—Bushing  
K—Ball

6. Remove cap screw (I).


8. Install cap screw (I).

7. Install parts (A—H and K).

AG,OUO1085,155 -19-17AUG00-5/10


9. Assemble parts (A, B, E, F, and H). Spring tangs (C and D) and stop peg (G) should be positioned as shown.

A—Shaft  
B—Cap Screw  
C—Spring Tang  
D—Spring Tang  
E—Guide  
F—Arm  
G—Stop Peg  
H—Spring



Continued on next page

AG,OUO1085,155 -19-17AUG00-6/10



Park Pawl Assembly



- |                      |                               |                      |             |
|----------------------|-------------------------------|----------------------|-------------|
| A—Cap Screw (5 used) | G—Bushings                    | L—Thrust Bearing     | Q—Cap Screw |
| B—Shaft              | H—Washer (2 used)             | M—Bearing Race       | R—Cam       |
| C—Guide              | I—Spring Locking Pin (2 used) | N—Shim (as required) | S—Pawl      |
| D—Spring             | J—Spring                      | O—O-Ring             | T—Shaft     |
| E—Arm                | K—Bearing Race                | P—Cover Plate        | U—Spring    |
| F—Link               |                               |                      |             |

NOTE: Parts (K—Q) will be installed later.

10. Install parts (A—J) and (R—U).


Continued on next page

AG,OUO1085,155 —19–17AUG00–7/10



11. Install park cam (A) into bore with pin (B) positioned as shown in photo.
12. Install park pawl (D) and spring (C) on park shaft (E).
13. Install park shaft (E) in shaft bore. Make sure spring (C) loops around and engages casting and park pawl as shown.

A—Park Cam  
B—Pin  
C—Spring  
D—Park Pawl  
E—Park Shaft




Continued on next page

AG,OUO1085,155 -19-17AUG00-8/10




14. Install washer (E) and PTO shaft (D) with bearing (C).
15. Apply Moly High Temperature EP Grease to splines on both ends of PTO shaft.
16. Install range shift shafts (A and B), with holes (F) and notches (G) positioned as shown.

A—B and C Range Shift Shaft  
 B—A Range and Creeper Shift Shaft  
 C—Bearing  
 D—PTO Shaft  
 E—Washer  
 F—Shift Fork Hole  
 G—Detent Notch



LV466 -UN-03MAR92




LV625 -UN-17JUN94

Continued on next page

AG,OUO1085,155 -19-17AUG00-9/10





Top Cover

- |                             |                            |              |                   |
|-----------------------------|----------------------------|--------------|-------------------|
| A—Cap Screw                 | F—Bushing (2 used)         | K—Spring Pin | P—Gear Shift Arm  |
| B—Range Shift Lever Housing | G—Gear Shift Lever Housing | L—Spring Pin | Q—Range Shift Arm |
| C—Bushing (2 used)          | H—Pin                      | M—Spring     | R—Pin             |
| D—Cap Screw (6 used)        | I—Cover                    | N—Spring     | S—Cap Screw       |
| E—Plug                      | J—Gear Shift Shaft         | O—Ball       |                   |

17. Install range shift arm (Q).
18. Install gear shift shaft (J) into cover (I). Use a punch through plug hole to depress detent ball (O) against springs (M and N). Slide shaft through, making sure detent ball stays under shaft.
19. Install pins (L and K) through shift arm (P) and into shaft (J).
20. Install plug (E) into cover (I).
21. Clean mating surfaces of cover (I) and lever housings (B and G).
22. Apply John Deere TY15130 or equivalent sealer to shift lever housings (B and G) and install housings to cover (I). Be sure that alignment pins (H and R) are in place.

## Install Transmission


**NOTE:** Tractor without cab shown. Tractor with cab is similar.

1. Clean mating surfaces of differential and transmission housings.
2. Install new gasket.
3. Position transmission approximately 127 mm (5 in.) from the differential case so bearing (C) is just past sliding gear (H).
4. Insert PTO shaft (D) into coupler (G).
5. Insert washer (B) into differential case.

**NOTE:** It may be necessary to rotate the transmission shafts during installation of transmission.

6. Install transmission. Ensure park pawl shaft (A) aligns with bore in differential case. Push park pawl (F) inward after clearing gear (E).

A—Park Pawl Shaft  
B—Washer  
C—Bearing  
D—PTO Shaft  
E—B Range Driven Gear  
F—Park Pawl  
G—PTO Shaft Coupler  
H—A Range and Creeper Shift Sliding Gear



LV533 -UN-03MAR92



LV534 -UN-03MAR92


AG,OUO1085,156 -19-28JUN02-1/11

7. Install ten cap screws (A). Tighten to specification.

### Specification

Transmission-to-Differential Case



Cap Screws—Torque ..... 140 N•m (105 lb-ft)



LV530 -UN-03MAR92



Continued on next page

AG,OUO1085,156 -19-28JUN02-2/11



8. Position gear shift lever in park.
9. Make sure machined surface (C) is clean to achieve proper measurement.
10. Position shim gauge (D) over camshaft (B) with pin (A) inserted in center hole of camshaft.
11. Hold shim gauge (D) in position and apply inward force in center of shim gauge, using a tool with a flat or blunt end, as shown in photo.
12. Make sure park pawl (F) is fully engaged in gear (G) by rotating the "A" range gear (E).
13. While applying inward force, slide outer collar (H) of shim gauge forward until seated against machined surface (C) of transmission housing.
14. Remove fingers from shim gauge (D). Slowly and evenly remove the inward force applied to center of shim gauge by the tool with flat or blunt end.

**A—Pin**  
**B—Camshaft**  
**C—Machined Surface**  
**D—Shim Gauge (RE188114)**  
**E—A Range Gear**  
**F—Park Pawl**  
**G—Gear**  
**H—Outer Collar**



Continued on next page


AG,OUO1085,156 -19-28JUN02-3/11

15. Carefully remove shim gauge from cam shaft. Make sure not to move the shim gauge during removal; this could affect the shim gauge setting.

AG,OUO1085,156 -19-28JUN02-4/11

16. Install shims (B) one at a time, as necessary, between tab (C) and collar flange (A) on shim gauge. Do not force shims in gauge. Retain shims for installation into park cam cover.

A—Collar Flange  
B—Shims (as required)  
C—Tab




LV7056 -JUN-13MAY02


Continued on next page

AG,OUO1085,156 -19-28JUN02-5/11





LV7002 -UN-15MAY02



LV7003 -UN-15MAY02


17. Install shims (A) from shim gauge setting in park cam cover (B).

18. Install one thrust washer (C) on top of shims.

19. Apply multi-purpose grease to both sides of needle bearing (D).

20. Install needle bearing (D) on top of thrust washer.

21. Install remaining thrust washer (C) on top of bearing.



LV7004 -UN-15MAY02

**IMPORTANT: Always use new O-rings. Damaged or used O-rings will leak.**


22. Apply multi-purpose grease to O-ring groove.

23. Install O-ring (F) in park cam cover (B).

24. Place a mark (E) on side edge of cover (B) closest to O-ring as, shown in photo, to aid during installation.


25. Position gear shift lever in neutral.

26. Install park cam cover (B) with mark (E) made earlier facing rear of tractor. Make sure O-ring stays in position during installation.



LV7005 -UN-15MAY02

- A—Shim (as required)
- B—Park Cam Cover
- C—Thrust Washer (2 used)
- D—Needle Bearing
- E—Mark
- F—O-Ring
- G—Cap Screw (2 used)



LV7057 -UN-15MAY02

Continued on next page

AG,OUO1085,156 -19-28JUN02-6/11

27. Install cap screws (G). Tighten cap screws to specification.

**Specification**

Park Cam Cover Cap Screws—

Torque ..... 27 N•m (20 lb-ft)

28. Install MFWD drop gearbox, if equipped. (See Remove and Install MFWD Drop Gearbox in Group 35.)


29. Install side cover, or, if equipped, the creeper assembly. (See Remove and Install Creeper Assembly in Group 40.)

30. Install hydraulic oil filter assembly. See Remove and Install Hydraulic Filter/Manifold—Early Model or Remove and Install Hydraulic Filter/Manifold—Later Model in Section 70, Group 05.)

50  
15  
36

Continued on next page

AG,OUO1085,156 -19-28JUN02-7/11



Range Shift Shaft Assembly

- |                                  |                                   |                   |             |
|----------------------------------|-----------------------------------|-------------------|-------------|
| A—Cap Screw (2 used)             | E—A Range and Creeper Shift Shaft | H—Ball (2 used)   | L—Cap Screw |
| B—Lock Washer (2 used)           | F—B and C Range Shift Shaft       | I—Spring (2 used) | M—Plate     |
| C—B and C Range Shift Fork       | G—Sleeve                          | J—Bushings        | N—Pin       |
| D—A Range and Creeper Shift Fork |                                   | K—Cap Screw       | O—Ball      |

31. Remove cap screw (K), if installed.
32. Install shift fork (D).
33. Install sleeve (G) and shift fork (C).
34. Slide shift shafts (F and E) into position.
35. Clean cap screws (A) with Clean and Cure Primer. Apply thread lock and sealer (medium strength) to threads of cap screws. Install lock washers (B) and cap screws (A).
36. Install parts (H—O).

Continued on next page

AG,OUO1085,156 -19-28JUN02-8/11


50  
15  
37

LV2451 -JUN-19DEC97



37. Install cover and shifter housings (A). Install eight cap screws (B) and nuts (C).
38. Install gear shift and range shift levers in housings. (See Inspect and Repair Gear Shift Lever and Inspect and Repair Range Shift Lever in his group.)


A—Shifter Housing  
B—Cap Screw (8 used)  
C—Nut (8 used)



AG.OUO1085,156 -19-28JUN02-9/11

39. Tractors without cab: install left control console (A).
40. Install PTO lever and linkage. (See Remove, Inspect and Install Rear PTO Lever and Linkage in Group 20.)
41. Install MFWD lever and linkage, if equipped. (See Inspect and Repair MFWD Lever and Linkage in Group 35.)

A—Left Control Console




Left Side Shown

Continued on next page

AG.OUO1085,156 -19-28JUN02-10/11

42. Install right brake line.
43. Tractors with cab: install left and right control consoles and support plate. (See Remove and Install Right-Side Control Console and Panel—Tractors With Cab and Remove and Install Left-Side Control Console—Tractors With Cab in Section 90, Group 15.)
44. Install SCV joystick and cable assembly if equipped. (See Inspect and Repair Joystick and Linkage—Without Cab or Inspect and Repair Joystick and Linkage—With Cab in Section 70, Group 15.)
45. Tractors without cab: install right control console. (See Remove and Install Right-Side Control Console and Panel—Tractors Without Cab in Section 90, Group 06.)
46. Install rockshaft control lever (A).
47. Install cab if equipped. (See Cab Remove and Install in Section 90, Group 15.)
48. Install fenders and rear wheels.
49. Install clutch housing to transmission. (See Install Clutch Housing to Transmission in this group.)



AG,OUO1085,156 -19-28JUN02-11/11

## Disassemble, Inspect and Assemble Gear Shift Shaft Assemblies


1. Remove shift shaft assemblies (B and C) from transmission top shaft (A).

A—Transmission Top Shaft  
B—Shift Shaft Assembly  
C—Shift Shaft Assembly



CollarShift

LV468 -UN-03MAR92




SyncShuttle™

LV626 -UN-17JUN94

Continued on next page

AG,OUO1085,158 -19-18AUG00-1/2



A—Small Spring Pin (4 used)

B—Large Spring Pin (4 used)

C—Reverse and 2nd Gear Shift Fork (CollarShift)

D—1st and 3rd Gear Shift Fork (CollarShift)

E—1st and 3rd Gear Shift Shaft

F—Reverse and 2nd Gear Shift Shaft

G—Reverse and 2nd Gear Shift Yoke

H—1st and 3rd Gear Shift Yoke

I—Reverse and 2nd Gear Shift Fork SyncShuttle™ (SS)

J—1st and 3rd Gear Shift Fork SyncShuttle™ (SS)

**NOTE:** The SyncShuttle™ transmission is equipped with forks (I and J) in place of forks (C and D).

**NOTE:** Lubricate all parts with clean transmission/hydraulic oil during assembly.

2. Mark position and location of yokes (G and H) and forks (C and D) or (I and J) on shafts to aid in assembly.

**IMPORTANT:** Install pins (A) inside pins (B) with splits facing 180° from each other.

3. Drive out spring pins (A and B).

6. Assemble all parts.

4. Disassemble parts.

7. Install shift shaft assemblies to transmission top shaft.

5. Inspect parts for wear or damage. Replace as necessary.

## Disassemble, Inspect, and Assemble Transmission Top Shaft—CollarShift Transmission

1. Remove reverse and 2nd gear shift shaft assembly (B) and 1st and 3rd gear shift shaft assembly (C) from transmission top shaft (A).


A—Transmission Top Shaft  
B—Reverse and 2nd Gear Shift Shaft Assembly  
C—1st and 3rd Gear Shift Shaft Assembly



LV468 -UN-03MAR92

Continued on next page

AG,OUO1085,159 -19-18AUG00-1/3



- |                                     |                          |                                 |                        |
|-------------------------------------|--------------------------|---------------------------------|------------------------|
| A—Bearing                           | G—Collar                 | M—1st Speed Drive Gear          | Q—Washer               |
| B—Washer                            | H—Snap Ring              | N—Snap Ring                     | R—Snap Ring            |
| C—Reverse Drive Gear                | I—2nd Speed Drive Gear   | O—Collar                        | S—3rd Speed Drive Gear |
| D—Snap Ring                         | J—Transmission Top Shaft | P—1st and 3rd Gear Shift Collar | T—Washer               |
| E—Washer                            | K—Spring Pin             |                                 | U—Bearing              |
| F—Reverse and 2nd Gear Shift Collar | L—Spacer (2 used)        |                                 |                        |

**NOTE:** Bearings (A and U) are press fit on shaft (J).

- Remove bearing (A) using a knife-edged puller and a press.

Continued on next page

AG,OUO1085,159 -19-18AUG00-2/3

50  
15  
43  
LV476A -UN-03MAR92

3. Remove parts (B—I).
4. Remove bearing (U) using a knife-edged puller and a press.
5. Remove parts (K—T).
6. Inspect all parts for wear or damage. Replace as necessary.

**NOTE:** Lubricate all parts with clean transmission/hydraulic oil during assembly.

7. Apply Moly High Temperature EP Grease to ID of gears (C, I, M, and S).

**IMPORTANT:** Install washers (B and T) with grooves toward gears.

8. Install all parts.

Install bearings (U and A) using a bearing, bushing, and seal driver set and a press.

9. Install shift shaft assemblies to transmission top shaft.




LV475 -UN-03MAR92

AG,OUO1085,159 -19-18AUG00-3/3

## Disassemble, Inspect, and Assemble Transmission Top Shaft—SyncShuttle™ Transmission

1. Remove reverse and 2nd gear shift shaft assembly (B) and 1st and 3rd gear shift shaft assembly (C) from transmission top shaft (A).

A—Transmission Top Shaft  
B—Reverse and 2nd Gear Shift Shaft Assembly  
C—1st and 3rd Gear Shift Shaft Assembly




LV626 -UN-17JUN94

Continued on next page

AG,OUO1085,160 -19-28JUN02-1/4





- |                              |                       |                             |                               |
|------------------------------|-----------------------|-----------------------------|-------------------------------|
| 1—Front Bearing (Non-Sealed) | 9—Snap Ring           | 17—2nd Speed Drive Gear     | 25—Stop Ring and Pin Assembly |
| 2—Grooved Washer             | 10—Washer             | 18—Transmission Top Shaft   | 26—Washer                     |
| 3—Reverse Drive Gear         | 11—Hub                | 19—Spring Pin               | 27—Snap Ring                  |
| 4—Splined Coupler (2 used)   | 12—Spring (3 used)    | 20—Spacer (2 used)          | 28—3rd Speed Drive Gear       |
| 5—Disk (8 used)              | 13—Detent (3 used)    | 21—1st Speed Drive Gear     | 29—Grooved Washer             |
| 6—Snap Ring (2 used)         | 14—Insert (3 used)    | 22—Snap Ring                | 30—Rear Bearing (Sealed)      |
| 7—Separator Plate (6 used)   | 15—Shift Collar       | 23—Outer Stop Ring (2 used) |                               |
| 8—Drum (2 used)              | 16—Snap Ring (2 used) | 24—Splined Coupler          |                               |

Continued on next page

AG,OUO1085,160 -19-28JUN02-2/4

**NOTE:** Bearings (1 and 30) are press fit on shaft (18).  
Use a knife-edged puller and a press to remove bearings.

To aid in assembly, keep parts together and in proper sequence as the gear cluster is disassembled.

2. Remove parts (1—30).

AG,OUO1085,160 -19-28JUN02-3/4

3. Inspect all parts for wear or damage. Replace as necessary.

**IMPORTANT:** Washers (2 and 29) must be installed with grooves toward adjacent gears.

**Lubricate all parts with clean transmission/hydraulic oil during assembly.**



LV627 -UN-17JUN94

4. Install all parts using the following instructions:

- Insert spring pin (19) into shaft (18) until a maximum of 5 mm (0.20 in.) extends from shaft surface. Install spring pin with the slit facing 90° away from (perpendicular to) the length of the shaft.
- Apply Moly High Temperature EP Grease to ID of gears (3, 17, 21, and 28).
- Install the two splined couplers (4) with the smooth side toward gears (3 and 17).
- Install splined coupler (24) with grooved side toward gear (21).
- Install washer (2) with grooved side toward gear (3).
- Install washer (29) with grooved side toward gear (28).

**NOTE:** Ensure that sealed bearing is installed to the rear and non-sealed bearing is installed at the front.

- Install bearings (1 and 30) using a press.

5. Install shift shaft assemblies to the transmission top shaft.

AG,OUO1085,160 -19-28JUN02-4/4

## Disassemble, Inspect, and Assemble Range Reduction Shaft

**NOTE:** Bearings (A and G) are press fit on shaft.


1. Remove bearings (A and G) using a knife-edged puller and a press.
2. Remove all parts.
3. Inspect all parts for wear or damage. Replace as necessary.

**NOTE:** Lubricate all parts with clean transmission/hydraulic oil during assembly.

4. Install all parts.

Install bearings (A and G) using a bearing, bushing, and seal driver set and a press.

- A—Bearing
- B—Range Reduction Drive Gear
- C—Collar
- D—B Range Drive Gear
- E—Collar
- F—Range Reduction Shaft
- G—Bearing




LV478A -UN-03MAR92



LV477 -UN-03MAR92

AG,OUO1085,161 -19-18AUG00-1/1

## Disassemble, Inspect and Assemble Driven Shaft



**NOTE:** Bearings (A and I) are press fit on shaft (J).

1. Remove bearing (A) using a knife-edged puller and a press.
2. Remove parts (B—H).
3. Remove parts (L, M, and K).

- A—Bearing
- B—Reverse Driven Gear
- C—Collar (2 used)
- D—2nd Speed Driven Gear
- E—1st Speed Driven Gear
- F—3rd Speed Driven Gear
- G—Snap Ring
- H—Spacer
- I—Bearing
- J—Driven Shaft
- K—C Range Driven Gear
- L—Washer
- M—Snap Ring



LV482A —UN-18APR96

LV481 —UN-03MAR92

Continued on next page

AG.OUO1085,162 —19-18AUG00-1/2

4. Remove bearing (I) using a knife-edged puller and a press.

5. Inspect all parts for wear or damage. Replace as necessary.

*NOTE: Lubricate all parts with clean transmission/hydraulic oil during assembly.*

6. Install bearing (I) using a piece of pipe and a press.


7. Install all parts.

Install bearing (A) using a bearing, bushing, and seal driver set and a press.

AG.OUO1085,162 -19-18AUG00-2/2

50  
15  
49

## Remove, Inspect, and Install MFWD and Range Gears



**NOTE:** If it is necessary to remove the entire shaft, see *Remove and Inspect Differential Drive Shaft in Group 25.*

1. Remove transmission. (See Remove Transmission in this group.)
2. Remove parts (A—N).
3. Inspect all parts for wear or damage. Replace as necessary.

**NOTE:** Lubricate all parts with clean transmission/hydraulic oil during assembly.

4. Apply Moly High Temperature EP Grease to ID of gear (G).
5. Install all parts.
6. Install transmission.




- A—Snap Ring
- B—Washer (2 used)
- C—Bearing
- D—Snap Ring
- E—Collar
- F—B and C Range Shift Collar
- G—B Range Driven Gear (Later Models)
- H—Bearing (Later Models)
- I—Bearing (Later Models)
- J—Snap Ring (2 used)
- K—MFWD Gear
- L—A Range and Creeper Shift Sliding Gear
- M—B Range Driven Gear (Early Models)
- N—Washer (Early Models)

## Remove, Inspect, and Install Reverse Idler Shaft

**NOTE:** Reverse idler shaft is mounted to rear of clutch housing.

1. Separate clutch housing from transmission. (See Separate Clutch Housing from Transmission in this group.)
2. Remove snap ring (A) and washer (C).
3. Remove reverse idler gear assembly (B).



A—Snap Ring  
B—Reverse Idler Gear Assembly  
C—Washer

AG,OUO1085,164 -19-28JUN02-1/2

4. Remove threaded shaft (A).

**NOTE:** Bearings (B and F) are press fit in gear (D).

5. Remove bearings (B and F) using a bearing, bushing, and seal driver set and a press.
6. Inspect all parts for wear or damage. Replace as necessary.


**NOTE:** Lubricate all parts with clean transmission/hydraulic oil during assembly.

7. Assembly parts (B—F). Install bearings using a bearing, bushing, and seal driver set and a press.
8. Apply thread lock and sealer (medium strength) to threads of shaft (A).
9. Install shaft and tighten to specification.

### Specification

Reverse Idler Shaft—Torque..... 132 N•m (97 lb-ft)

10. Install idler gear assembly, washer (G), and snap ring (H).
11. Install clutch housing to transmission. (See Install Clutch Housing to Transmission in this group.)



A—Reverse Idler Shaft  
B—Bearing  
C—Spacer  
D—Reverse Idler Gear  
E—Snap Ring  
F—Bearing  
G—Washer  
H—Snap Ring

AG,OUO1085,164 -19-28JUN02-2/2





Service Equipment and Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.

SERVICEGARD is a trademark of Deere & Company

OUC1043,0000EA8 –19–28JUN02–1/2

Flywheel Turning Tool . . . . . JDE83

Rotates flywheel.

OUC1043,0000EA8 –19–28JUN02–2/2

Other Material

Number	Name	Use
TY15130 (U.S.)	John Deere Sealer	Apply to shift lever housings.
TY6305 (U.S.) TY9485 (Canadian) 7649 (LOCTITE®)	Clean and Cure Primer	Cleans mating surfaces and reduces sealant curing time.
TY9370 (U.S.) TY9477 (Canadian) 242 (LOCTITE®)	Thread Lock and Sealer (Medium Strength)	Apply to PTO and traction clutch yoke-to-armshaft cap screw threads.

LOCTITE is a registered trademark of Loctite Corp.

OUC1043,0000EAA –19–28JUN02–1/1

Specifications

Item	Measurement	Specification
Clutch Housing-to-Transmission Cap Screws	Torque	118—147 N•m (87—108 lb-ft)
Transmission Cap Screws	Torque	140 N•m (105 lb-ft)

OUC1043,0000EAA –19–28JUN02–1/1

## Separate Clutch Housing From Transmission

**NOTE:** The approximate capacity of transmission is 42.5 L (11 U.S. gal).

1. Drain transmission.

**NOTE:** Remove cab and floor plates if equipped. (See *Cab Remove and Install* and *Cab Floor Plates Remove and Install—Early Model Tractors* or *Cab Floor Plate Remove and Install—Later Model Tractors* in Section 90, Group 15.)

2. Remove seat and support. (See *Remove and Install Seat and Support—Tractors Without Cab* or *Remove and Install Seat and Support Plate—Tractors With Cab* in Section 90, Group 05.)

3. Remove clamp.

4. Disconnect wiring leads (B).

5. Disconnect wiring lead (D).


6. Disconnect wiring connectors (C).

7. Disconnect turn signal wiring connector. Cut all wire tie straps as necessary.

8. Disconnect park pawl cable.



LV2440 —UN-16DEC97



LV2441 —UN-18DEC97

A—Clamp  
B—Fuel Level Sender Wiring Lead  
C—Wiring Connector  
D—Ground Wiring Lead


Continued on next page

AG,OUO1085,166 —19-18AUG00-1/5

*NOTE: Close all openings using caps and plugs.*

9. Tractors without cab: remove right step plate and fender.
10. Remove suction line (F).
11. Remove cap screw (C).
12. Disconnect hydraulic lines (A and E).
13. Disconnect brake line (B).
14. Disconnect hydraulic supply line (D).

**A—Brake Valve Return Line**  
**B—Brake Pressure Line**  
**C—Cap Screw**  
**D—PowrReverser™ Supply Line**  
**E—Hydraulic Pump-to-Inlet Housing Supply Line**  
**F—Hydraulic Suction Line**



*Right Side Shown*

LV1065 -UN-15DEC94


Continued on next page

AG,OUO1085,166 -19-18AUG00-2/5

50  
16  
3

15. Disconnect long PTO rod assembly at both ends and remove.
16. Tractors without cab: remove left step.
17. Remove left dash panel.
18. Remove spring clip (B) and disconnect park brake linkage (A). Cut all tie straps as necessary.
19. Disconnect brake line (C).
20. Disconnect safety neutral switch wiring connector (D).
21. Disconnect clutch pedal linkage (E).

A—Park Brake Linkage  
B—Spring Clip  
C—Hydraulic Brake Line  
D—Wiring Connector  
E—Clutch Pedal Linkage



Left Side Shown

LV1066 -UN-05JAN98

Continued on next page

AG,OUO1085,166 -19-18AUG00-3/5

**NOTE:** Fuel tank capacity for 5210, 5310, and 5410 tractors is 68 L (18.0 U.S. gal).

Fuel tank capacity for 5510 and tractors with cab is 83 L (22.0 U.S. gal).

22. Drain fuel tank.


**NOTE:** Fuel lines are located on left side of tractor by axle final drive housing.

23. Disconnect fuel lines (A). Cut tie straps as necessary.

24. Disconnect hydraulic line (B).

25. Remove wire harness from rear of tractor. Cut tie straps as necessary.

A—Fuel Line (2 used)  
B—Hydraulic Line




LV2442 -UN-16DEC97

Continued on next page

AG,OUO1085,166 -19-18AUG00-4/5

50  
16  
5

26. Remove MFWD drive shaft, if equipped. (See Remove, Inspect and Install MFWD Drive Shaft in Group 35.)
27. Install wood blocks between the front axle pivot stops and tractor frame. Chock front and back of rear wheels.
28. Position a floor jack under the transmission and a support stand under end of drawbar.
29. Attach a hoist and lifting chains or strap around clutch housing.
30. Place range shift lever in neutral and move gear shift lever fully left to neutral position between 1st and 2nd gears. Use wire or rope to hold gear shift lever in this position.



*NOTE: When separating, the main outer shaft, gear fork shaft, and driven shaft assemblies must remain in transmission case.*

31. Remove ten cap screws. Roll front section of tractor (clutch housing) away from rear section (transmission).
32. Install a support stand under clutch housing.

AG,OUO1085,166 -19-18AUG00-5/5



## Install Clutch Housing to Transmission

1. Clean mating surfaces of transmission and clutch housings. Install new gasket.
2. Place range shift lever in neutral and gear shift lever in 2nd gear.

**NOTE:** *It may be necessary to rotate the clutch shafts and reverse gears during installation so that the clutch and transmission shafts mesh.*

*Rotate the PTO shaft by manually turning the PTO at rear of tractor.*

*Rotate the traction shaft by turning the flywheel using JDE83 Flywheel Turning Tool.*

*Verify that the two bearings and two fork shafts enter holes of clutch housing at the same time.*


*Verify that the two pins enter the holes in transmission housing.*

3. Install clutch housing to transmission. Tighten cap screws to specification.

### Specification

Clutch Housing-to-Transmission  
Cap Screws—Torque ..... 118—147 N•m (87—108 lb-ft)

4. Install MFWD drive shaft, if equipped. (See Remove, Inspect and Install MFWD Drive Shaft in Group 35.)




Continued on next page

AG\_OUO1085,167 -19-28JUN02-1/5

50  
16  
7

5. Connect hydraulic line (B).
6. Connect fuel hoses (A).

A—Fuel Hose (2 used)  
B—Hydraulic Line



LV2442 -UN-16DEC97


50  
16  
8

Continued on next page

AG,OUO1085,167 -19-28JUN02-2/5

7. Connect clutch pedal linkage (E).
8. Connect neutral safety switch wiring connector (D).
9. Connect brake line (C).
10. Connect park brake linkage (A) and install spring clip (B).
11. Adjust park brake cable. (See Park Brake Cable Adjustment in Section 250, Group 16.)
12. Install new tie straps as necessary.
13. Install dash panel.
14. Tractors without cab: install left step.
15. Install long PTO rod assembly. (See PTO Clutch Lever Adjustment in Section 250, Group 15 for adjustment procedures.)

A—Park Brake Linkage  
 B—Spring Clip  
 C—Hydraulic Brake Line  
 D—Wiring Connector  
 E—Clutch Pedal Linkage



Left Side Shown

Continued on next page


AG,OUO1085,167 -19-28JUN02-3/5

LV1066 -UN-05JAN98

50  
16  
9

16. Connect brake line (B).
17. Connect hydraulic lines (A and E).
18. Install cap screw (C).
19. Install suction line (F).
20. Connect hydraulic supply line (D).
21. Tractors without cab: install right step and fender.

A—Brake Valve Return Line  
B—Brake Pressure Line  
C—Cap Screw  
D—PowrReverser™ Supply Line  
E—Hydraulic Pump-to-Inlet Housing Supply Line  
F—Suction Line



Right Side Shown

Continued on next page


AG,OUO1085,167 -19-28JUN02-4/5

22. Connect wiring connectors (C).
23. Connect ground wiring lead (D).
24. Connect turn signal wiring connector.
25. Install cab if equipped. (See Cab Remove and Install in Section 90, Group 15.)
26. Connect wiring leads (B).
27. Install clamp (A).
28. Connect park pawl cable.
29. Fill fuel tank with proper fuel. (See Diesel Fuel Specifications in Section 10, Group 20.)
30. Install seat and support. (See Remove and Install Seat and Support—Tractors Without Cab or Remove and Install Seat and Support Plate—Tractors With Cab in Section 90, Group 05.)
31. Fill transmission with clean transmission/hydraulic oil. (See Transmission and Hydraulic Oil in Section 10, Group 20.)
32. Bleed brake system. (See Bleed Brake System in Section 260, Group 15.)

**A—Clamp**  
**B—Fuel Level Sender Wiring Leads**  
**C—Wiring Connectors**  
**D—Ground Wiring Lead**



LV2440 -UN-16DEC97



LV2441 -UN-18DEC97

AG\_OUO1085,167 -19-28JUN02-5/5

50  
16  
11

## Remove Transmission

**NOTE:** Tractor without cab shown, tractor with cab is similar.

1. Separate clutch housing from transmission. (See Separate Clutch Housing from Transmission in this group.)
2. Tractor with cab: remove both control consoles and support plate. (See Remove and Install Right-Side Control Console and Panel—Tractors With Cab and Remove and Install Left-Side Control Console—Tractors With Cab in Section 90, Group 15.)
3. Raise and support rear axles.
4. Tractors without cab: remove rear wheels and fenders.



Continued on next page

LV,5016HA,B22 -19-21NOV02-1/10




5. Remove rockshaft control levers (A).
6. Tractors without cab: remove right-hand control console (B).
7. Remove SCV joystick and cable assembly (C), if equipped. (See Inspect and Repair Joystick and Linkage—Without Cab or Inspect and Repair Joystick and Linkage—With Cab in Section 70, Group 15.)

*NOTE: Close all openings using caps and plugs.*

8. Remove brake line (D).
9. Remove MFWD lever and linkage, if equipped. (See Inspect and Repair MFWD Lever and Linkage in Group 35.)
10. Remove PTO lever and linkage. (See Remove, Inspect and Install Rear PTO Lever and Linkage in Group 20.)

**A—Rockshaft Levers**  
**B—Right-Hand Control Console**  
**C—SCV Joystick and Cable Assembly**  
**D—Brake Line**



Right-Hand Side

LV527 -UN-03MAR92

Continued on next page


LV,5016HA,B22 -19-21NOV02-2/10

50  
16  
13



11. Tractors without cab: remove left-hand control console (A).

A—Left-Hand Control Console




Left-Hand Side

LV528 -UN-03MAR92

LV,5016HA,B22 -19-21NOV02-3/10

12. Remove bulkhead nuts (C).  
13. Remove spring locking pin (A).  
14. Remove park brake cable (B).

A—Spring Locking Pin  
B—Park Brake Cable  
C—Bulkhead Nut (2 used)




LV7326 -UN-09MAY02

Continued on next page

LV,5016HA,B22 -19-21NOV02-4/10

15. Remove eight cap screws (C) and nuts (B) to remove transmission top cover (A).
16. Remove hydraulic filter and manifold. (See Remove and Install Hydraulic Filter/Manifold—Early Model or Remove and Install Hydraulic Filter/Manifold—Later Model in Section 70, Group 05.)
17. Remove creeper assembly. (See Remove and Install Creeper Assembly in Group 40.)

A—Transmission Top Cover  
B—Nut  
C—Cap Screw




LV7920 -UN-09MAY02

LV,5016HA,B22 -19-21NOV02-5/10

18. Remove cap screws (A), cover (B), shims (C), washers and bearing (D).
19. Remove spring clip (F) and washer (E).
20. Disconnect tension spring (H) and remove bushing (I).
21. Disconnect arm (G) from cam.

A—Cap Screw (2 used)  
B—Cover  
C—Shims  
D—Washer (2 used) and Bearing  
E—Washer  
F—Spring Clip  
G—Arm  
H—Tension Spring  
I—Bushing



LV6589 -UN-09MAY02


Continued on next page

LV,5016HA,B22 -19-21NOV02-6/10

50  
16  
15

22. Remove four cap screws (C).
23. Remove washer (H), collar (G) and link plate (A).
24. Remove park guide assembly (B).
25. Remove screws (D), plate (E) and cap screws (F).


A—Link Plate  
B—Park Guide Assembly  
C—Cap Screw (4 used)  
D—Cap Screw (2 used)  
E—Plate  
F—Cap Screw (2 used)  
G—Collar  
H—Washer




LV6829 -UN-09MAY02

Continued on next page

LV,5016HA,B22 -19-21NOV02-7/10




LV6888 -UN-09MAY02



LV6889 -UN-09MAY02

26. Remove two springs (A) and dowel pin (B).
27. Remove two small detent balls (C) and one large detent ball (D) using a pen magnet.
28. Slide outer shift shaft (I) forward into transmission housing until spacer (G) can be removed. Remove spacer (G).
29. Remove outer shift shaft (I).
30. Slide inner shift shaft (E) forward into transmission housing and remove shift shaft.
31. Remove outer shift fork (H) first, then remove inner shift fork (F).
32. Inspect all parts for wear or damage. Replace as necessary.



LV6983 -UN-09MAY02

- A—Spring (2 used)
- B—Dowel Pin
- C—Small Detent Ball (2 used)
- D—Large Detent Ball
- E—Inner Shift Shaft
- F—Inner Shift Fork
- G—Spacer
- H—Outer Shift Fork
- I—Outer Shift Shaft

Continued on next page


LV,5016HA,B22 -19-21NOV02-8/10

50  
16  
17



33. Remove cap screws (A) and hydraulic reverser supply line (B).
34. Remove lower cover or MFWD drop gearbox, if equipped. (See Remove and Install MFWD Drop Gearbox in Group 35.)

**IMPORTANT:** Before separating the transmission from rear differential housing, rotate park pawl until it rests against the park arm inside of transmission housing. If park pawl is not rotated, damage to gears may result when transmission is separated from the rear differential housing.



A—Cap Screw  
B—Hydraulic Reverser Supply Line

35. Rotate park pawl fully outward to side of transmission case.
36. Position a jackstand under drawbar assembly.
37. Attach hoist and chains to transmission housing.

LV,5016HA,B22 -19-21NOV02-9/10


38. Remove PTO shaft (A)

**NOTE:** Differential drive shaft and gear cluster assembly will stay with the differential during transmission removal.

**IMPORTANT:** Early model tractors use 8.8 grade transmission mounting cap screws (B). Replace the 8.8 grade with 10.9 grade (see your parts catalog).


39. Remove ten cap screws (B).
40. Remove transmission and make repairs as necessary. (See Disassemble and Inspect Transmission in this group.)

A—PTO Shaft  
B—Cap Screw



LV,5016HA,B22 -19-21NOV02-10/10

## Disassemble and Inspect Transmission



Top Cover

A—Cap Screw	F—Bushings (2 used)	K—Spring Pin	P—Gear Shift Arm
B—Range Shift Lever Housing	G—Gear Shift Lever Housing	L—Spring Pin	Q—Range Shift Arm
C—Bushings (2 used)	H—Pin	M—Spring	R—Pin
D—Cap Screw (6 used)	I—Cover	N—Spring	S—Cap Screw
E—Plug	J—Gear Shift Shaft	O—Ball	

1. Remove cap screws (A, D, and S).
2. Remove range shift lever housing (B) and gear shift lever housing (G).
3. Remove plug (E) and remove pins (K and L) through plug hole.
4. Remove gear shift arm (J), being careful not to lose detent ball (O) and springs (M and N).
5. Remove range shift arm (Q).
6. Inspect parts for wear or damage. Replace as necessary.

Continued on next page

AG,OUO1085,170 -19-21AUG00-1/8

**NOTE:** Bushings (C and F) are a press fit in case (I) and housing (B and G). Remove bushings only if replacement is necessary.


7. Replace bushings (C and F) using a bushing, bearing, and seal driver set.

AG,OUO1085,170 -19-21AUG00-2/8

8. Remove washer (B) and bearing (A) from differential housing.

9. Inspect parts for wear or damage. Replace if necessary.

A—Bearing  
B—Washer




LV1250 -UN-21DEC94

Continued on next page

AG,OUO1085,170 -19-21AUG00-3/8





LV1238A -UN-21DEC94

A—Cap Screw  
B—Cap Screw

C—Bushings  
D—Ball

E—Ball (2 used)  
F—Spring (2 used)

G—Pin  
H—Plate

10. Remove parts (A—H).

*NOTE: Reinstall bushing (C) and cap screw (B) to ease removal of gear shift shaft assembly.*

11. Install bushing (C) and cap screw (B).


12. Inspect parts for wear or damage. Replace as necessary.

Continued on next page

AG,OUO1085,170 -19-21AUG00-4/8

13. Remove transmission bottom shaft (A) with 1st and 2nd gear shift shaft assembly (B) and 3rd and 4th gear shift shaft assembly (C).
14. Disassemble and inspect parts as necessary. (See Disassemble, Inspect, and Assemble Transmission Bottom Shaft in this group.)

**A—Transmission Bottom Shaft**  
**B—1st and 2nd Gear Shift Shaft Assembly**  
**C—3rd and 4th Gear Shift Shaft Assembly**



LV1247 -UN-21DEC94




LV1248 -UN-21DEC94

AG,OUO1085,170 -19-21AUG00-5/8

15. Mark support (A) and transmission case to aid in installation.
16. Remove cap screws and bushings (B) and support (A).
17. Inspect parts for wear or damage. Replace as necessary.

**A—Support**  
**B—Cap Screw and Bushing (2 used)**




LV470 -UN-03MAR92

Continued on next page

AG,OUO1085,170 -19-21AUG00-6/8

18. Remove range reduction shaft (A).
19. Disassemble and inspect parts as necessary. (See Disassemble, Inspect, and Assemble Range Reduction Shaft in this group.)

A—Range Reduction Shaft




LV471 -UN-03MAR92

AG,OUO1085,170 -19-21AUG00-7/8

20. Remove driven shaft (A).
21. Disassemble and inspect parts as necessary. (See Disassemble, Inspect, and Repair Driven Shaft in Group 12.)
22. Inspect transmission case for cracks or damage. Replace if necessary.

A—Driven Shaft



LV1249 -UN-21DEC94

AG,OUO1085,170 -19-21AUG00-8/8


## Assemble Transmission

**NOTE:** Lubricate all internal parts with clean transmission/hydraulic oil during assembly.

**IMPORTANT:** Use new seals and O-rings during assembly. Damaged or used seals or O-rings will leak.

1. Install driven shaft (A). Tap on end of shaft with a soft-faced hammer to fully seat shaft in case bore.

A—Driven Shaft




LV1249 -UN-21DEC94

Continued on next page

AG,OUO1085,171 -19-21AUG00-1/8

2. Install range reduction shaft (A).

A—Range Reduction Shaft



LV471 -UN-03MAR92


AG,OUO1085,171 -19-21AUG00-2/8

*NOTE: Support plate (A) installed to support transmission bottom shaft during installation.*

3. Align support plate (A) with transmission case with marks made during disassembly.
4. Install bushings and cap screws (B).

A—Support Plate

B—Bushing and Cap Screw (2 used)



LV470 -UN-03MAR92

Continued on next page


AG,OUO1085,171 -19-21AUG00-3/8

5. Install transmission bottom shaft (A) with 1st and 2nd gear shift shaft assembly (B) and 3rd and 4th gear shift shaft assembly (C).

A—Transmission Bottom Shaft  
B—1st and 2nd Gear Shift Shaft Assembly  
C—3rd and 4th Gear Shift Shaft Assembly



LV1248 -UN-21DEC94




LV1247 -UN-21DEC94

Continued on next page

AG,OUO1085,171 -19-21AUG00-4/8

50  
16  
25



LV1238A -UN-21DEC94

A—Cap Screw  
B—Cap Screw

C—Bushing  
D—Ball

E—Ball (2 used)  
F—Spring (2 used)

G—Pin  
H—Plate

6. Remove cap screw (B).


8. Install cap screw (B).

7. Install parts (A and C—H).


Continued on next page

AG,OUO1085,171 -19-21AUG00-5/8





LV7921 -UN-10MAY02




LV6636 -UN-10MAY02

**NOTE:** Apply clean transmission/hydraulic oil to all internal transmission parts before installing.

9. Install park cam (A) into bore with pin (B) positioned as shown in photo.
10. Install park pawl (D) and spring (C) on park shaft (E).
11. Install park shaft (E) in shaft bore. Make sure spring (C) loops around and engages casting and park pawl as shown.

A—Park Cam  
B—Pin  
C—Spring  
D—Park Pawl  
E—Park Shaft



LV7922 -UN-10MAY02

Continued on next page


AG.OUO1085,171 -19-21AUG00-6/8

50  
16  
27




12. Install bearing (A) and washer (B) into differential housing.

A—Bearing  
B—Washer



Continued on next page

AG,OUO1085,171 -19-21AUG00-7/8



Top Cover

- |                             |                            |              |                   |
|-----------------------------|----------------------------|--------------|-------------------|
| A—Cap Screw                 | F—Bushings (2 used)        | K—Spring Pin | P—Gear Shift Arm  |
| B—Range Shift Lever Housing | G—Gear Shift Lever Housing | L—Spring Pin | Q—Range Shift Arm |
| C—Bushings (2 used)         | H—Pin                      | M—Spring     | R—Pin             |
| D—Cap Screw (6 used)        | I—Cover                    | N—Spring     | S—Cap Screw       |
| E—Plug                      | J—Gear Shift Shaft         | O—Ball       |                   |

13. Install range shift arm (Q).
14. Install gear shift shaft (J) into cover (I). Use a punch through plug hole to depress detent ball (O) against springs (M and N). Slide shaft through, making sure detent ball stays under shaft.
15. Install pins (L and K) through shift arm (P) and into shaft (J).
16. Install plug (E) into cover (I).
17. Clean mating surfaces of cover (I) and lever housings (B and G).
18. Apply John Deere TY15130 or equivalent sealer to shift lever housings (B and G) and install housings to cover (I). Be sure that alignment pins (H and R) are in place.

## Install Transmission

1. Install new transmission-to-differential case gasket (C).


**IMPORTANT:** If bearing (B) and oil deflector (A) were removed or fell from bore during transmission separation, make sure bearing (B) and oil deflector (A) are installed as shown in photo.

2. Install bearing (B) and oil deflector (A), if removed as shown.


A—Oil Deflector

B—Bearing

C—Transmission-to-Differential Case Gasket



LV6987 -UN-10MAY02



LV6988 -UN-10MAY02

Continued on next page

LV,5016HA,A53 -19-21NOV02-1/18

**NOTE:** Make sure the transmission and differential housings are level and square when joining both sections to aid during assembly.


**IMPORTANT:** Do not force alignment or join both sections by tightening cap screw. Damage to components will result if force is used. If encountering difficulty during alignment, separate and check the level of transmission and differential housings.

3. Position transmission approximately 127 mm (5 in.) from the differential case so bearing (A) is just past sliding gear (B).


**NOTE:** It may be necessary to rotate the transmission shafts during installation of transmission.

4. Install transmission. Make sure park pawl shaft (C) aligns with bore in differential case. Push park pawl (D) inward after clearing gear (E).

A—Bearing  
B—A Range and Creeper Shift Sliding Gear  
C—Park Pawl Shaft  
D—Park Pawl  
E—



LV1252 -UN-21DEC94



LV1251 -UN-21DEC94

Continued on next page

LV,5016HA,A53 -19-21NOV02-2/18

50  
16  
31

**IMPORTANT:** Early model tractors use 8.8 grade transmission mounting cap screws. Replace the 8.8 grade with 10.9 grade (see your parts catalog).

5. Install ten cap screws (B) and tighten to specification.

**Specification**


Transmission Cap Screws—

Torque ..... 140 N•m (105 lb-ft)

6. Install PTO shaft (A).

**A—PTO Shaft**


**B—Cap Screw (10 used)**



LV1246 -UN-21DEC94

Continued on next page

LV,5016HA,A53 -19-21NOV02-3/18



Range Shift Shaft Assembly

A—Cap Screw (2 used)  
B—Lock Washer (2 used)  
C—2nd and 3rd Range Shift Fork  
D—1st Range and Creeper Shift Fork

E—1st Range and Creeper Shift Shaft  
F—2nd and 3rd Range Shift Shaft  
G—Sleeve

H—Ball (2 used)  
I—Spring (2 used)  
J—Bushing  
K—Cap Screw

L—Cap Screw  
M—Plate  
N—Pin  
O—Ball

7. Install shift fork (C and D).
8. Install sleeve (G) and slide shift shafts (E and F) into position.
9. Clean cap screws (A) with Clean and Cure Primer. Apply thread lock and sealer (medium strength) to threads of cap screws. Install lock washers (B) and cap screws (A). Tighten cap screws (A) to specification.

**Specification**

Shift Fork Cap Screws—Torque..... 27 N•m (20 lb-ft)

10. Install parts (H—O). Tighten cap screw (K and L) to specification.


**Specification**

Range Shift shaft Detent Plate  
Cap Screws—Torque ..... 27 N•m (20 lb-ft)


Continued on next page

LV,5016HA,A53 -19-21NOV02-4/18






LV7327 -UN-10MAY02



LV6994 -UN-10MAY02



LV6995 -UN-10MAY02

**NOTE:** Only one arm of tension spring (C) has an offset (D). This arm with the offset (D) must be connected to the pin on new cam inside transmission and the straight arm on tension spring (C) connected to pin (B) on park guide assembly (A).


11. Install arm (E) and bushing (F).
12. Install tension spring (C) with offset (D) on opposite end of bushing (F) as shown in photo.
13. Install washer (H) and spring pin (G).

A—Park Guide Assembly  
B—Pin  
C—Tension Spring  
D—Offset  
E—Arm  
F—Bushing  
G—Spring Pin  
H—Washer


Continued on next page

LV,5016HA,A53 -19-21NOV02-5/18





LV7923 -UN-10MAY02




LV6996 -UN-10MAY02

14. Install park guide assembly (C).
15. Install collar (E), link plate (B) and washer (A).
16. Install cap screws (D). Tighten cap screws to specification

**Specification**

Park Guide Cap Screws—Torque..... 27 N•m (20 lb-ft)

17. Push inward on cam (H) and connect arm (F) to pin (I).
18. Install bushing (J) on pin (I). Install tension spring (G) on bushing.
19. Install washer (L) and spring pin (K). Make sure spring pin (K) is hooked, as shown in photo.



LV6997 -UN-10MAY02

- A—Washer
- B—Link Plate
- C—Park Guide Assembly
- D—Cap Screw (4 used)
- E—Collar
- F—Arm
- G—Tension Spring
- H—Cam
- I—Pin
- J—Bushing
- K—Spring Pin
- L—Washer

Continued on next page

LV,5016HA,A53 -19-21NOV02-6/18

50  
16  
35


**NOTE:** Make sure shift forks (B and C) are in neutral position as shown in photo.

20. Install new gasket (A).
21. Position the range and gear shift levers in neutral to aid during alignment of transmission top cover (D).
22. Install transmission top cover (D) using cap screws (E) and nuts (F). Do not tighten mounting at this time.
23. Move range and gear shift levers in all positions to check for smooth and correct operation. If range and gear shift levers do not operate correctly, remove transmission top cover and realign shift levers into shift forks.
24. Install cap screws (E) and nuts (F), if removed. Tighten cap screws and nuts to specification.


#### Specification

Transmission Top Cover  
Mounting Hardware—Torque ..... 27 N•m (20 lb-ft)

- A—Gasket
- B—Shift Fork
- C—Shift Fork
- D—Transmission Top Cover
- E—Cap Screw (7 used)
- F—Nut (2 used)



LV7924 -UN-13MAY02




LV7067 -UN-13MAY02

LV,5016HA,A53 -19-21NOV02-7/18

25. Position and hold the park brake engagement lever (A) against the internal stop (toward the left side of tractor) using a length of rope or wire (B)

- A—Park Brake Engagement Lever
- B—Length of Rope or Wire




LV6511 -UN-15MAY02


Park Brake Engagement Lever

Continued on next page

LV,5016HA,A53 -19-21NOV02-8/18




LV7052 -UN-15MAY02




LV7053 -UN-15MAY02

26. Make sure machined surface (C) is clean to achieve proper measurement.
27. Position shim gauge (D) over camshaft (B) with pin (A) inserted in center hole of camshaft.
28. Hold shim gauge (D) in position and apply inward force in center of shim gauge, using a tool with a flat or blunt end, as shown in photo.
29. Make sure park pawl (F) is fully engaged in gear (G) by rotating the "A" range gear (E).
30. While applying inward force, slide outer collar (H) of shim gauge forward until seated against machined surface (C) of transmission housing.
31. Remove fingers from shim gauge (D). Slowly and evenly remove the inward force applied to center of shim gauge by the tool with flat or blunt end.
32. Carefully remove shim gauge from cam shaft. Make sure not to move the shim gauge during removal; this could affect the shim gauge setting.

A—Pin  
 B—Camshaft  
 C—Machined Surface  
 D—Shim Gauge  
 E—A Range Gear  
 F—Park Pawl  
 G—Gear  
 H—Outer Collar



LV7054 -UN-15MAY02



LV7055 -UN-15MAY02


Continued on next page

LV,5016HA,A53 -19-21NOV02-9/18




33. Install shims (B) one at a time, as necessary, between tab (C) and collar flange (A) on shim gauge. Do not force shims in gauge. Retain shims for installation into park cam cover.

A—Collar Flange  
B—Shims (as required)  
C—Tab




Continued on next page

LV,5016HA,A53 -19-21NOV02-10/18



LV7002 -UN-15MAY02



LV7003 -UN-15MAY02


34. Install shims (A) from shim gauge setting in park cam cover (B).

35. Install one thrust washer (C) on top of shims.

36. Apply multi-purpose grease to both sides of needle bearing (D).

37. Install needle bearing (D) on top of thrust washer.

38. Install remaining thrust washer (C) on top of bearing.



LV7004 -UN-15MAY02

**IMPORTANT: Always use new O-rings. Damaged or used O-rings will leak.**


39. Apply multi-purpose grease to O-ring groove.

40. Install O-ring (F) in park cam cover (B).

41. Place a mark (E) on side edge of cover (B) closest to O-ring as, shown in photo, to aid during installation.


42. Remove rope or wire used to hold the park brake engagement lever in position.

43. Install park cam cover (B) with mark (E) made earlier facing rear of tractor. Make sure O-ring stays in position during installation.



LV7005 -UN-15MAY02

- A—Shim (as required)
- B—Park Cam Cover
- C—Thrust Washer (2 used)
- D—Needle Bearing
- E—Mark
- F—O-Ring
- G—Cap Screw (2 used)



LV7057 -UN-15MAY02

Continued on next page

LV,5016HA,A53 -19-21NOV02-11/18

44. Install cap screws (G). Tighten cap screws to specification.

**Specification**

Park Cam Cover Cap Screws—

Torque ..... 27 N•m (20 lb-ft)


45. Install clutch housing to transmission. (See Install Clutch Housing to Transmission in this group.)

LV,5016HA,A53 -19-21NOV02-12/18


46. Position park cable (B) in rear mounting bracket (A), located behind range shift lever housing.

47. Center bulkhead nuts (C) on threaded end of cable. Tighten two bulkhead nuts (C) on both sides of bracket (A) securely.

A—Bracket  
B—Park Cable  
C—Bulkhead Nut (2 used)



LV6583 -UN-15MAY02



LV7324 -UN-15MAY02

Continued on next page


LV,5016HA,A53 -19-21NOV02-13/18

48. Position and hold the control lever (A) in the bottom of park slot using a screwdriver as a wedge.
49. Position and hold park engagement lever (G) fully engaged to the left side of tractor using a vice grip (F).
50. Pull park cable (D) toward park engagement lever (G) to remove any slack in cable.
51. Turn yoke (E) on park brake cable (D) until hole in yoke aligns with hole in park engagement lever (G). Shorten cable by turning yoke (E) four full turns clockwise.
52. Remove vice grip from park engagement lever and screwdriver from control lever.
53. Position control lever in neutral.
54. Install spring locking pin (B).
55. Tighten jam nut (C) against back of yoke (E).

**A—Control Lever**  
**B—Spring Locking Pin**  
**C—Jam Nut**  
**D—Park Cable**  
**E—Yoke**  
**F—Vice Grip**  
**G—Park Engagement Lever**



LV7325 -UN-15MAY02



LV6590 -UN-15MAY02

Continued on next page

LV,5016HA,A53 -19-21NOV02-14/18

50  
16  
41




56. Move control lever from neutral to park position six or seven times. Leave control lever in park position and verify the following items

- Make sure park pawl (C) has movement by pushing inward on park pawl (C). If park pawl has no movement, recheck shimming process with shim gauge.
- If park pawl still has no movement after rechecking shimming process, remove park cam cover (B) and remove one shim from cover.
- Install park cam cover and tighten cap screws (A) to specification. Recheck park pawl for movement by pushing inward on park pawl (C).

#### Specification

Park Cam Cover Cap Screws—


Torque ..... 27 N•m (20 lb-ft)



LV7925 -UN-15MAY02

57. Shift control lever to neutral and check spring pin (D) remains installed, as shown in photo

- A—Cap Screw (2 used)  
B—Park Cam Cover  
C—Park Pawl  
D—Spring Pin




LV7926 -UN-15MAY02

Continued on next page

LV.5016HA,A53 -19-21NOV02-15/18

58. Install hydraulic reverser supply line (B) and cap screws (A).
59. Install MFWD drop gearbox, if equipped. (See Remove and Install MFWD Drop Gearbox in Group 35.)
60. Install side cover or, if equipped, the creeper assembly. (See Remove and Install Creeper Assembly in Group 40.)
61. Install hydraulic oil filter assembly. (See Remove and Install Hydraulic Filter/Manifold—Early Model or Remove and Install Hydraulic Filter/Manifold—Later Model in Section 70, Group 05.)



A—Cap Screw (2 used)  
B—Hydraulic Reverser Supply Line


LV,5016HA,A53 -19-21NOV02-16/18

62. Tractors without cab: install left-hand control console (A).

*NOTE: Long PTO rod assembly is installed after left-hand step.*

63. Install PTO lever and linkage. (See Remove, Inspect and Install Rear PTO Lever and Linkage in group 20.)
64. Install MFWD lever and linkage, if equipped. (See Inspect and Repair MFWD Lever and Linkage in Group 35.)
65. Tractors with cab: install left and right control consoles and support plate. (See Remove and Install Right-Side Control Console and Panel—Tractors With Cab and Remove and Install Left-Side Control Console—Tractors With Cab in Section 90, Group 15.)

A—Left-Hand Control Console



Left-Hand Side


Continued on next page

LV,5016HA,A53 -19-21NOV02-17/18

50  
16  
43

66. Install brake line (D).
67. Install SCV joystick and cable assembly (C) if equipped. (See Inspect and Repair Joystick and Linkage—Without Cab or Inspect and Repair Joystick and Linkage—With Cab in Section 70, Group 15.)
68. Tractors without cab: install right-hand control console (B).
69. Install rockshaft control lever (A).
70. Install cab if equipped. (See Cab Remove and Install in Section 90, Group 15.)
71. Tractors without cab: install fenders and rear wheels.

A—Rockshaft Levers  
 B—Right-Hand Control Console  
 C—SCV Joystick and Cable Assembly  
 D—Brake Line



Right-Hand Side

LV527 -UN-03MAR92

LV,5016HA,A53 -19-21NOV02-18/18

## Disassemble, Inspect, and Assemble Gear Shift Shaft Assemblies

1. Remove shift shaft assemblies (B and C) from transmission bottom shaft (A).

A—Transmission Bottom Shaft  
 B—Shift Shaft Assembly  
 C—Shift Shaft Assembly




Bottom Shaft Synchronized

LV1248 -UN-21DEC94

Continued on next page

AG,OUO1085,173 -19-21AUG00-1/2



A—Small Spring Pin (4 used)  
B—Large Spring Pin (4 used)  
C—1st and 2nd Gear Shift Fork

D—3rd and 4th Gear Shift Fork  
E—3rd and 4th Gear Shift Shaft

F—1st and 2nd Gear Shift Shaft  
G—1st and 2nd Gear Shift Yoke

H—3rd and 4th Gear Shift Yoke

2. Mark position and location of yokes (G and H) and forks (C and D) on shafts to aid in assembly.
3. Drive out spring pins (A and B).
4. Disassemble parts.
5. Inspect parts for wear or damage. Replace as necessary.

**IMPORTANT:** Install pins (A) inside pins (B) with splits facing 180° from each other.

6. Assemble all parts.
7. Install shift shaft assemblies to transmission bottom shaft.

**NOTE:** Lubricate all parts with clean transmission/hydraulic oil during assembly.

AG,OUO1085,173 -19-21AUG00-2/2

## Disassemble, Inspect, and Assemble Transmission Bottom Shaft

1. Remove 1st and 2nd gear shift shaft assembly (B) and 3rd and 4th gear shift shaft assembly (C) from transmission bottom shaft (A).


A—Transmission Bottom Shaft  
B—1st and 2nd Gear Shift Shaft Assembly  
C—3rd and 4th Gear Shift Shaft Assembly



LV1248 -UN-21DEC94

Continued on next page

AG,OUO1085,174 -19-28JUN02-1/4



A—Bearing  
B—Spacer  
C—Bearing (8 used)  
D—Snap Ring (8 used)

E—2nd Speed Driven Gear  
F—Snap Ring (6 used)  
G—Cup  
H—Synchronizer

I—Spline Collar  
J—1st Speed Driven Gear  
K—4th Speed Driven Gear  
L—3rd Speed Driven Gear

M—Collar  
N—Bearing  
O—Driven Shaft

Continued on next page

AG,OUO1085,174 -19-28JUN02-2/4



**NOTE:** Bearings (A and N) are press fit on shaft (O).  
Use a knife-edged puller and a press to remove bearings.

To aid in assembly, keep parts together and in proper sequence as the gear cluster is disassembled.

2. Remove parts (B—M).

AG,OUO1085,174 -19-28JUN02-3/4

3. Inspect all parts for wear or damage. Replace as necessary.

**NOTE:** Lubricate all parts with clean transmission/hydraulic oil during assembly.

4. Apply Moly High Temperature EP Grease to ID of gears (E, J, K, and L).

5. Install all parts.

6. Install bearings (A and N) using a bushing, bearing, and seal driver set and a press.

7. Install shift shaft assemblies to the transmission bottom shaft.



LV1254 -UN-21DEC94

AG,OUO1085,174 -19-28JUN02-4/4

## Disassemble, Inspect, and Assemble Range Reduction Shaft

**NOTE:** Bearings (A and G) are press fit on shaft.


1. Remove bearings (A and G) using a knife-edged puller and a press.
2. Remove all parts.
3. Inspect all parts for wear or damage. Replace as necessary.

**NOTE:** Lubricate all parts with clean transmission/hydraulic oil during assembly.

4. Install all parts.

Install bearings (A and G) using a bearing, bushing, and seal driver set and a press.

- A—Bearing
- B—Range Reduction Drive Gear
- C—Collar
- D—2nd Range Drive Gear
- E—Collar
- F—Range Reduction Shaft
- G—Bearing




LV478A -UN-03MAR92



LV477 -UN-03MAR92

AG,OUO1085,176 -19-21AUG00-1/1

## Disassemble, Inspect, and Assemble Top Shaft



**NOTE:** Bearings (A and I) are press fit on shaft (H).

1. Remove bearing (A) using a knife-edged puller and a press.
2. Remove parts (B—G).
3. Remove bearing (I) using a knife-edged puller and a press.
4. Inspect all parts for wear or damage. Replace as necessary.

**NOTE:** Lubricate all parts with clean transmission/hydraulic oil during assembly.

5. Install bearing (I) using a bushing, bearing, and seal driver set and a press.
6. Install all parts.



- A—Bearing
- B—Washer
- C—2nd Speed Drive Gear
- D—Snap Ring (4 used)
- E—1st Speed Drive Gear
- F—4th Speed Drive Gear
- G—3rd Speed Drive Gear
- H—Shaft
- I—Bearing

LV1241A -UN-21DEC94

LV1255 -UN-21DEC94


Continued on next page

AG.OUO1085,177 -19-21AUG00-1/2

Install bearing (A) using a bearing, bushing, and seal driver set and a press.

AG,OUO1085,177 -19-21AUG00-2/2

## Remove, Inspect, Install MFWD and Range Gears



**NOTE:** If it is necessary to remove the entire shaft, see *Remove and Inspect Differential Drive Shaft in Group 25.*

1. Remove transmission. (See Remove Transmission in this group.)
2. Remove parts (A—N).
3. Inspect all parts for wear or damage. Replace as necessary.

**NOTE:** Lubricate all parts with clean transmission/hydraulic oil during assembly.

4. Apply Moly High Temperature EP Grease to ID of gear (G).
5. Install all parts.
6. Install transmission.




- A—Snap Ring
- B—Washer (2 used)
- C—Bearing
- D—Snap Ring
- E—Collar
- F—B and C Range Shift Collar
- G—B Range Driven Gear (Later Models)
- H—Bearing (Later Models)
- I—Bearing (Later Models)
- J—Snap Ring (2 used)
- K—MFWD Gear
- L—A Range and Creeper Shift Sliding Gear
- M—B Range Driven Gear (Early Models)
- N—Washer (Early Models)

## Remove, Inspect and Replace Hydraulic Reverser Control Lever


**NOTE:** Tractor without cab show. Tractors with cab are similar.

1. Remove knob (A), screws (C) and shift guide cover (B).
2. Remove screws (D) and shift guide plate (E).
3. Remove left-side control console and panel. (See Remove and Install Left-Side Control Console—Tractors With Cab in Section 90, Group 15 or Remove and Install Left-Side Control Console and Panel—Tractors Without Cab in Section 90, Group 06.)

A—Knob  
B—Shift Guide Cover  
C—Screw (2 used)  
D—Screw (2 used)  
E—Shift Guide Plate



LV7320 UN-15MAY02



LV6522 UN-15MAY02

Continued on next page


OUO1020,0001211 -19-14NOV02-1/4

50  
16  
53




4. Disconnect park cable (B) and F-N-R cable (A) from control lever.
5. Remove cap screws, nuts and washers (C, D and E).
6. Remove control lever assembly. Inspect for wear or damage, replace if necessary.

A—F-N-R Cable  
 B—Park Cable  
 C—Cap Screw and Nut (2 used)  
 D—Cap Screw and Nut (2 used)  
 E—Washers



LV6584 —UN-15MAY02



LV6574 —UN-15MAY02

Continued on next page

OUC1020,0001211 —19-14NOV02-2/4


7. Install control lever assembly using cap screws, nuts and washers (C, D and E). Tighten cap screws and nuts to specification.

#### Specification


Hydraulic Reverser Control  
Lever—Torque..... 17 N•m (12 lb-ft)

8. Connect park cable (B) and F-N-R cable (A) to control lever.

A—F-N-R Cable  
B—Park Cable  
C—Cap Screw and Nut (2 used)  
D—Cap Screw and Nut (2 used)  
E—Washers



LV6584 -UN-15MAY02



LV6574 -UN-15MAY02

Continued on next page

OUC1020,0001211 -19-14NOV02-3/4


9. Install shift guide plate (E) and screws (D). Tighten screws to specification.

**Specification**


Shift Guide Plate—Torque ..... 17 N•m (12 lb-ft)

10. Install shift guide cover and screws (C).
11. Install dash panel.
12. Adjust park brake cable. (See Park Brake Cable Adjustment in Section 250, Group 16.)
13. Adjust F-N-R cable. (See Forward-Neutral-Reverse Control Cable Adjustment in Section 250, Group 16.)

A—Knob  
B—Shift Guide Cover  
C—Screw (2 used)  
D—Screw (2 used)  
E—Shift Guide Plate



LV7320 —UN-15MAY02



LV6522 —UN-15MAY02


OUO1020,0001211 —19-14NOV02-4/4

## Specifications

Item	Measurement	Specification
Wheel Cap Screws	Torque	175 N•m (130 lb-ft)
Rear PTO Drive Shaft Assembly Cap Screws	Torque	65 N•m (48 lb-ft)

OUO1043,0000EAE -19-28JUN02-1/1

# Remove, Inspect and Install Rear PTO Lever and Linkage



Rear PTO Lever and Linkage

- |                      |                    |                           |                        |
|----------------------|--------------------|---------------------------|------------------------|
| A—Knob               | H—Nut              | O—Cap Screw               | V—Yoke (2 used)        |
| B—Rear PTO Lever     | I—Hub              | P—Retaining Ring (3 used) | W—Locking Pin (2 used) |
| C—Shoulder Bolt      | J—Extension Spring | Q—Pin (2 used)            | X—Nut                  |
| D—Bushing (2 used)   | K—Shoulder Bolt    | R—Yoke                    | Y—Rod                  |
| E—Washer             | L—Washer           | S—Bushing (2 used)        | Z—Rod (used with       |
| F—Compression Spring | M—Pin              | T—Bellcrank               | PowrReverser™ only)    |
| G—Cap Screw          | N—Nut              | U—Shoulder Bolt           |                        |

1. Tractors without cab: remove left rear wheel and fender.

Continued on next page

AG,OUO1023,521 -19-28JUN02-1/2

2. Tractors with cab: remove left control console and panel. (See Remove and Install Left-Side Control Console—Tractors With Cab in Section 90, Group 15.)

*NOTE: Bushings (D and S) are press fit. Remove bushings only if replacement is necessary.*

3. Replace bushing (D or S) using a bearing, bushing, and seal driver set.
4. Inspect all parts for wear or damage. Replace as necessary.
5. Apply Moly High Temperature EP Grease to shaft of bolts (C and U).

6. Tractors without cab: install left fender and wheel.
7. Tractors with cab: install control console and support plate.
8. Tighten wheel cap screws to specification.

**Specification**


Wheel Cap Screws—Torque ..... 175 N•m (130 lb-ft)

9. Adjust PTO clutch lever. (See PTO Clutch Lever Adjustment in Section 250, Group 15.)
10. Adjust clutch pedal free play. (See Clutch Pedal Free Play Adjustment in Section 250, Group 15.)

AG,OUO1023,521 -19-28JUN02-2/2



## Inspect and Repair PTO 540/540E Shift Lever and Linkage



1—Adjusting Nut  
2—Jam Nut (2 used)  
3—Knob  
4—Yoke  
5—Rod

6—Spring Pin  
7—Arm  
8—Locking Pin  
9—Nut

10—Lever  
11—Washer  
12—Shoulder Bolt  
13—Retainer Clip

14—Bracket  
15—Bracket  
16—Cable  
17—Nut

1. Remove right rear wheel and fender.
2. Tractors with cab: remove left control console and panel. (See Remove and Install Left-Side Control Console—Tractors With Cab in Section 90, Group 15.)
3. Tractors without cab: remove right step plate.
4. Inspect all parts for wear or damage. Replace as necessary.
5. Apply Moly High Temperature EP Grease to shaft of shoulder bolt (12).
6. Tractors without cab: install right step plate.
7. Tractors with cab: install left control console and panel.
8. Install right rear wheel and fender.

Continued on next page

AG,OUO1085,181 -19-28JUN02-1/2

9. Tighten wheel cap screws to specification.

10. Adjust linkage. (See PTO 540/540E Lever and Linkage Adjustment in Section 250, Group 16.)

**Specification**

Wheel Cap Screws—Torque ..... 176 N•m (130 lb-ft)

AG,OUO1085,181 -19-28JUN02-2/2

**Remove and Install Standard Rear PTO Drive Shaft Assembly**

*NOTE: The approximate capacity of transmission/differential is 38 L (10 U.S. gal).*

1. Drain transmission/differential.
2. Remove PTO shield.
3. Remove drawbar pin (B) and drawbar.
4. Remove ten cap screws (A), rear PTO drive shaft assembly, and gasket.

*NOTE: Parts (D and C) may remove with rear PTO drive shaft assembly.*


*Rockshaft is removed for illustration purposes.*

5. Make repairs as necessary. (See Disassemble, Inspect and Assemble Standard Rear PTO Drive Shaft Assembly in this group.)
6. Apply Moly High Temperature EP Grease to splined ends of intermediate shaft PTO pinion shaft (top shaft).
7. Install intermediate shaft and coupler.
8. Install rear PTO drive shaft assembly and new gasket. Tighten cap screws to specification.


**Specification**

Rear PTO Drive Shaft Assembly  
Cap Screws—Torque ..... 65 N•m (48 lb-ft)

9. Install drawbar and pin.
10. Install PTO shield.
11. Fill transmission/differential with proper oil. (See Transmission and Hydraulic Oil in Section 10, Group 20.)



LV308 -UN-03MAR92



LV488 -UN-03MAR92

A—Cap Screw (10 used)  
B—Drawbar Pin  
C—Intermediate Shaft  
D—Coupler


AG,OUO1085,182 -19-28JUN02-1/1

## Disassemble, Inspect and Assemble Standard Rear PTO Drive Shaft Assembly

*NOTE: Shaft assemblies are slip fit in cover.*

1. Remove PTO output shaft assembly (B) from cover using a soft-faced hammer.
2. Remove PTO pinion shaft assembly (A).


A—PTO Pinion Shaft Assembly  
B—PTO Output Shaft Assembly



LV309 -UN-03MAR92

Continued on next page

AG,OUO1085,183 -19-14NOV02-1/3



A—Snubber  
B—Coupler  
C—Intermediate Shaft  
D—Coupler

E—Bearing  
F—Pinion Shaft  
G—Bearing  
H—Bearing

I—Output Shaft  
J—Snap Ring  
K—Drive Gear

L—Bearing  
M—Seal  
N—Cover

**NOTE:** Snubber (A) is mounted to differential housing. Coupler (B) is held in place by snubber. If replacement is necessary, remove rockshaft. (See Remove and Install Rockshaft Case in Section 70, Group 10.)

**IMPORTANT:** Replace seal. Damaged or used seal will leak.

3. Remove seal (M) using a screwdriver. Install seal into cover bore until it stops, using a bushing, bearing, and seal driver set.

**NOTE:** Bearing (L) is press fit on shaft.

4. Remove gear (K) and bearing (L) using a press.
5. Inspect parts (C—N) for wear or damage. Replace as necessary.

**NOTE:** Bearings (E, G, and H) are press fit. Remove bearings only if replacement is necessary.

6. Remove bearings (E, G, and H) using a knife-edged puller and a press.

7. Install new bearings (G and H) using a press.

**NOTE:** Install bearing (E) with flanged side toward pinion gear.

8. Install bearing (E) using a piece of pipe and a press.

9. Apply multipurpose grease to lips of seal.

10. Lubricate all parts with clean transmission/hydraulic oil.

Continued on next page

AG,OUO1085,183 -19-14NOV02-2/3

*Rear PTO Drive Shaft*

11. Assemble all parts.

AG,OUO1085,183 -19-14NOV02-3/3

## Remove and Install 540/540E Rear PTO Drive Shaft Assembly

**NOTE:** The approximate capacity of transmission/differential is 38 L (10 U.S. gal).

1. Drain transmission/differential.
2. Remove PTO shield.
3. Remove drawbar pin (B) and drawbar.
4. Remove ten cap screws (A), rear PTO drive shaft assembly, and gasket.

**NOTE:** Parts (D and C) may come away with rear PTO drive shaft assembly.


*Rockshaft is removed for illustration purposes.*

5. Make repairs as necessary. (See Disassemble, Inspect, and Assemble Rear 540/540E PTO Drive Shaft Assembly in this group.)
6. Apply Moly High Temperature EP Grease to splined ends of intermediate shaft and PTO pinion shaft (top shaft).
7. Install intermediate shaft and coupler.
8. Install rear PTO drive shaft assembly and new gasket. Tighten cap screws to specification.


### Specification

Rear PTO Drive Shaft Assembly  
Cap Screws—Torque ..... 65 N•m (48 lb-ft)

9. Install drawbar and pin.
10. Install PTO shield.
11. Fill transmission/differential with proper oil. (See Transmission and Hydraulic Oil in Section 10, Group 20.)



LV308 -UN-03MAF92



LV488 -UN-03MAF92

A—Cap Screw (10 used)  
B—Drawbar Pin  
C—Intermediate Shaft  
D—Coupler

50  
20  
9




## Disassemble, Inspect, and Assemble Rear 540/540E PTO Drive Shaft Assembly

*NOTE: Shaft assemblies are slip fit in cover.*

1. Remove shift fork assembly (A).
2. Remove PTO output shaft assembly (B) from cover using a soft-faced hammer.
3. Remove PTO pinion shaft assembly (C).


A—Shift Fork Assembly  
B—PTO Output Shaft Assembly  
C—PTO Pinion Shaft Assembly



LV980 -UN-21SEP94

Continued on next page

AG,OUO1085,185 -19-21AUG00-1/3



- 1—Cap Screw
- 2—Nut
- 3—Snubber
- 4—Coupler
- 5—Ring
- 6—Intermediate Shaft
- 7—Shaft
- 8—Fork
- 9—Ball
- 10—Spring

- 11—Gasket
- 12—Pin
- 13—Cover
- 14—Seal
- 15—Plate
- 16—Screw with Washer
- 17—Cap Screw
- 18—Ball Bearing
- 19—Washer

- 20—Gear
- 21—Bushing
- 22—Shaft
- 23—Shift Collar
- 24—Shifter
- 25—Bushing
- 26—Gear
- 27—Washer
- 28—Ring

- 29—Ball Bearing
- 30—Ball Bearing
- 31—Gear
- 32—Ball Bearing
- 33—Arm
- 34—Seal
- 35—Washer
- 36—Plate
- 37—Cap Screw

Continued on next page

AG,OUO1085,185 -19-21AUG00-2/3

**NOTE:** *Snubber (3) is mounted to differential housing. Coupler (4) is held in place by snubber. If replacement is necessary, remove rockshaft. (See Remove and Install Rockshaft Case in Section 70, Group 10.)*

**IMPORTANT:** **Replace seal. Damaged or used seal will leak.**

4. Remove screws (16) and plate (15).

5. Remove seal (14) using a screwdriver. Install seal into cover bore until it stops, using a bushing, bearing, and seal driver set.

**NOTE:** *Bearing (18) is press fit on shaft.*

6. Remove gear (20) and bearing (18) using a press.

7. Inspect parts (6—37) for wear or damage. Replace as necessary.

**NOTE:** *Bearings (29, 30, and 32) are press fit. Remove bearings only if replacement is necessary.*

8. Remove bearings (29, 30, and 32) using a knife-edged puller and a press.

9. Install bearings (29 and 30) using a press.

**NOTE:** *Install bearing (32) with flanged side toward pinion gear.*

10. Install bearing (32) using a piece of pipe and a press.

11. Apply multipurpose grease to lips of seal.

12. Lubricate all parts with clean transmission/hydraulic oil.

13. Assemble all parts.

AG,OUO1085,185 -19-21AUG00-3/3

## Essential Tools

*NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).*


*SERVICEGARD is a trademark of Deere & Company*

OUO1023,0000015 -19-07APR04-1/4

Pinion Shaft Holding Fixture . . . . . JDG1164

Holds differential drive shaft when removing or torquing nut.

JDG486 -UN-03MAR92




OUO1023,0000015 -19-07APR04-2/4

Special Socket . . . . . JDG735

Removes and torques differential drive shaft nut.

JT0735 -UN-03MAR92



OUO1023,0000015 -19-07APR04-3/4

Spring Scale . . . . . JDT42

Measures differential drive shaft rolling drag torque.

JDT42 -UN-03MAR92



OUO1023,0000015 -19-07APR04-4/4

## Other Material

Number	Name	Use
TY9370 (U.S.) TY9477 (Canadian) 242 (LOCTITE®)	Thread Lock and Sealer (Medium Strength)	Apply to the differential housing cap screw threads. Apply to the differential lock shaft-to-fork lock pin threads.

*LOCTITE is a registered trademark of Loctite Corp.*

OUO1043,0000EB1 -19-28JUN02-1/1

50  
25  
1

## Specifications

Item	Measurement	Specification
Differential Cap Screws	Torque	58 N•m (43 lb-ft)
Differential Housing with Locking Pawl Cap Screw	Torque	95 N•m (70 lb-ft)
Differential Housing Cap Screw	Torque	78 N•m (58 lb-ft)
Differential Drive Shaft Spacer and Shims	Thickness	0.25—0.75 mm (0.010—0.030 in.) nominal
Differential Drive Shaft Nut	Torque	269 N•m (198 lb-ft)
Differential Drive Shaft	Force	10—30 N (2—7 lb-force)
Differential Drive Shaft Quil Cap Screw	Torque	52 N•m (38 lb-ft)
Cone Point	Dimension (A)	17.5 ± 0.05 mm (0.688 ± 0.002 in.)
Differential	Backlash	0.18—0.25 mm (0.007—0.010 in.)
Differential Quill	Angle	30°

OUO1043,0000EB2 —19—28JUN02—1/1

## Service Parts Kits

The following kits are available through your parts catalog:

Shim Kit—Differential Drive Shaft Bearing Preload

Shim Kit—Differential Drive Shaft Cone Point


Shim Kit—Differential Backlash

AG,OUO1085,188 —19—21AUG00—1/1

## Remove and Install Differential Assembly

1. Remove differential lock assembly. (See Remove, Inspect, and Install Differential Lock Assembly in this group.)
2. Remove brake assemblies. (See Remove and Inspect Brakes in Section 60, Group 10.)
3. Remove rear PTO drive shaft assembly. (See Remove and Install Standard Rear PTO Drive Shaft Assembly or Remove and Install 540/540E Rear PTO Drive Shaft Assembly in Group 20.)

**NOTE:** Remove cab if equipped. (See Cab Remove and Install in Section 90, Group 15.)



Right Side Shown

A—Differential Quill  
B—Shim (6 used)  
C—Cap Screw (6 used)

4. Remove six cap screws (C) and shims (B). Turn differential quill (A) 30° and install cap screws in the two threaded holes. Use cap screws to draw out the quill.
5. Remove differential assembly.
6. Make repairs as necessary. (See Disassemble, Inspect, and Assemble Differential Assembly in this group.)
7. Install differential assembly.
8. Install differential quill, cap screws, and shims. Tighten cap screws to specification.

### Specification

Differential Cap Screws—Torque..... 58 N•m (43 lb-ft)

**NOTE:** Adjustment of backlash is not necessary unless the ring gear or differential drive shaft were replaced or cone point adjustment was made.

9. Adjust differential backlash. (See Differential Backlash Adjustment in this group.)
10. Install brake assemblies.
11. Install rear PTO drive gear shaft assembly.
12. Install differential lock assembly.

Continued on next page


AG,OUO1085,189 -19-28JUN02-1/2



13. Install cab if equipped.

AG,OUO1085,189 –19–28JUN02–2/2

## Disassemble, Inspect, and Assemble Differential Assembly



A—Bearing  
B—Cap Screw (8 used)  
C—Housing with Locking Pawl  
D—Thrust Washer (2 used)  
E—Bevel Gear (2 used)  
F—Bevel Pinion (4 used)

G—Thrust Washer (4 used)  
H—Pinion Shaft (2 used)  
I—Ring Gear

J—Housing  
K—Cap Screw (12 used)  
L—Bearing

1. Disassemble parts (B—K).

**NOTE:** Bearings (A and L) are press fit. Remove bearings only if replacement is necessary.

2. Remove bearings (A and L) using a knife-edged puller and a press.
3. Inspect parts for wear or damage. Replace if necessary.
4. Apply thread lock and sealer (medium strength) to threads of cap screws (B and K). Tighten cap

screws to specification.

### Specification

Differential Housing with Locking Pawl Cap Screw—Torque.....	95 N•m (70 lb-ft)
Differential Housing Cap Screw—Torque.....	78 N•m (58 lb-ft)


5. Apply clean transmission/hydraulic oil to all parts during assembly.
6. Assemble all parts.

## Remove and Inspect Differential Drive Shaft

1. Remove MFWD and range gears. (See Remove, Inspect, and Install MFWD and Range Gears in Group 15 for CollarShift/SyncShuttle™ Transmission or Remove, Inspect, and Install MFWD and Range Gears in Group 16 for PowrReverser™ Transmission.)
2. Remove six cap screws (A).

**IMPORTANT:** When prying around quill flange, take care not damage shim packs.

3. Pry around quill flange (B) using a screwdriver. Remove differential drive shaft quill and shims.



A—Cap Screw (6 used)  
B—Quill Flange

OUO1023,0000016 —19-07APR04-1/4

4. Straighten locking tabs (A) on collar of nut using a small punch.


A—Locking Tab



OUO1023,0000016 —19-07APR04-2/4

5. Place JDG1164 Pinion Shaft Holding Fixture (B) onto end of shaft.
6. Place assembly in a vise as shown.
7. Use JDG735 Special Socket (A) to remove nut.

A—JDG735 Special Socket  
B—JDG1164 Pinion Shaft Holding Fixture



Continued on next page

OUO1023,0000016 —19-07APR04-3/4

**NOTE:** Bearing cones (B and H) are press fit on shaft.

8. Remove shaft (I) from quill (D) using a knife-edged puller and a press.

9. Remove parts (B, E, F, and H).


10. Inspect all parts for wear or damage. Replace as necessary.

**NOTE:** Bearing cups (C and G) are press fit in quill (D).  
Remove cups only if replacement is necessary.

11. Remove bearing cups using a small punch and hammer.

**IMPORTANT:** Differential drive shaft and differential ring gear are a matched set. If shaft was replaced, ring gear must be replaced also.

- A—Nut
- B—Bearing Cone
- C—Bearing Cup
- D—Quill
- E—Shim (number as required)
- F—Spacer
- G—Bearing Cup
- H—Bearing Cone
- I—Differential Drive Shaft



LV485A -UN-03MAR92

50  
25  
7

OUC1023,0000016 -19-07APR04-4/4

## Install Differential Drive Shaft

**NOTE:** Lubricate all parts with clean transmission/hydraulic oil during assembly.

1. Install bearing cup (C), if removed, into quill (D), using a bearing, bushing, and seal driver set and a press.
2. Install bearing cup (G), cone (H), and shaft (I) into quill (D), using a press.

**NOTE:** Shims are available in three thicknesses: 0.10, 0.15, and 0.20 mm (0.004, 0.006, and 0.008 in.).

3. Turn quill and shaft assembly around and install spacer (F) and shims (E) as necessary to obtain specified thickness.


### Specification

Differential Drive Shaft Spacer  
and Shims—Thickness..... 0.25—0.75 mm (0.010—0.030 in.)  
nominal

4. Install bearing cone (B) using a piece of pipe and a press.

**IMPORTANT:** Always use a new nut when assembling shaft.

5. Install new nut (A) and tighten by hand.



A—Nut  
B—Bearing Cone  
C—Bearing Cup  
D—Quill  
E—Shim (number as required)  
F—Spacer  
G—Bearing Cup  
H—Bearing Cone  
I—Differential Drive Shaft

LV485A -UN-03MAR92


Continued on next page

AG.OUO1085,192 -19-28JUN02-1/5

6. Place JDG1164 Pinion Shaft Holding Fixture (B) onto end of shaft.

7. Place assembly in a vise as shown.

8. Use JDG735 Special Socket (A) to tighten nut to specification.



LV483 -UN-03MAR92

**Specification**

Differential Drive Shaft Nut—

Torque ..... 269 N•m (198 lb-ft)

A—JDG735 Special Socket

B—JDG1164 Pinion Shaft Holding Fixture

AG,OUO1085,192 -19-28JUN02-2/5

9. Wrap a string (A) (approximately 1 m (3 ft) long) around differential drive shaft.

10. Attach a JDT42 Spring Scale (B) or its equivalent to the end of the string.

11. Pull spring scale away from differential drive shaft, noting the force (rolling drag) required to turn the differential drive shaft while holding the quill stationary. Repeat several times for an accurate reading. Rolling drag should be within specification. If rolling drag is high, add shims. If rolling drag is low, remove shims. Check and adjust until rolling drag is within specification.



RW2050 -UN-06MAR90

**Specification**

Differential Drive Shaft—Rolling

Drag ..... 10—30 N (2—7 lb-force)

A—String


B—JDT42 Spring Scale

Continued on next page

AG,OUO1085,192 -19-28JUN02-3/5

12. Deform collar of nut (A) into splines of shaft at three places around nut, using a small punch.

A—Collar of Nut




LV484 -UN-03MAR92

AG,OUO1085,192 -19-28JUN02-4/5

**IMPORTANT:** Adjust differential cone points only if ring gear and shaft were replaced. If gear and shaft were not replaced, use same shim pack or same thickness of original shims removed.

13. Install differential drive shaft quill (B) using a rubber mallet.
14. Install six cap screws (A) and original shim pack. Tighten cap screws to specifications.



LV474 -UN-03MAR92

#### Specification

Differential Drive Shaft Quill Cap  
Screw—Torque..... 52 N•m (38 lb-ft)

A—Cap Screw (6 used)  
B—Differential Drive Shaft Quill

15. Install MFWD and range gears. (See Remove, Inspect, and Install MFWD and Range Gears in Group 15 for CollarShift/SyncShuttle™ Transmission or Remove, Inspect, and Install MFWD and Range Gears in Group 16 for PowrReverser™ Transmission.)


**NOTE:** To adjust cone point, rockshaft case must be removed. (See Remove and Install Rockshaft Case in Section 70, Group 10.)

16. Adjust cone point, if necessary. (See Differential Cone Point Adjustment in this group.)

AG,OUO1085,192 -19-28JUN02-5/5



## Remove, Inspect, and Install Differential Lock Assembly



Differential Lock Assembly

A—Bushings	H—End Plate	O—Snap Ring	V—Lever Extension (Cab Tractors Only)
B—Differential Lock Pedal (Without Cab)	I—Seal	P—End Cap	W—Cap Screw (Cab Tractors Only) (2 used)
C—Shoulder Bolt	J—Spring Pin	Q—Threaded Locking Pin	X—Nut (Cab Tractors Only) (2 used)
D—Cap Screw	K—Differential Lock Shaft	R—Lock Washer	Y—Lever (Cab Tractors Only)
E—Roller	L—Spring	S—Lock Collar	
F—Washer	M—Fork	T—Pin (Cab Tractors Only)	
G—Cap Screw (2 used)	N—Washer	U—Pedal (Cab Tractors Only)	

1. Remove rockshaft case. (See Remove and Install Rockshaft Case in Section 70, Group 10.)
2. Remove parts (B—F).
3. Tractors with cab: remove parts (T—Y).

**NOTE:** Bushings (A) are press fit. Remove bushings only if replacement is necessary.

4. Replace bushings (A) using a bearing, bushing, and seal driver set.

Continued on next page

AG,OUO1085,193 -19-28JUN02-1/2

5. Pry between differential housing and fork (M) to remove pin (Q) and washer (R).

**Replace locking pin (Q). Always use a new pin when assembling shaft and fork.**

6. Remove parts (G—P).

*NOTE: To service lock collar (S), remove left brake assembly. (See Remove and Inspect Brakes in Section 60, Group 10.)*

7. Inspect all parts for wear or damage. Replace as necessary.

**IMPORTANT: Replace seal (I). Damaged or used seals will leak.**

8. Apply multipurpose grease to inside lips of seal (I) and to shoulder bolt (C).

9. Apply thread lock and sealer (medium strength) to threads of locking pin (Q).

10. Install all parts.

11. Install rockshaft case.

AG,OUO1085,193 -19-28JUN02-2/2

## Differential Cone Point Adjustment

**NOTE:** Gears are removed from differential drive shaft for illustration purposes.

1. Remove rockshaft case. (See Remove and Install Rockshaft Case in Section 70, Group 10.)
2. Measure cone point with a spacer of known dimension and feeler gauges. Measure spacer (drill bits work well) and add feeler gauges to equal specification. Insert spacer and feeler gauge to determine cone point dimension (A). Add shims to increase cone point; remove shims to decrease.


**NOTE:** Shims are available in three thicknesses: 0.1, 0.3 and 0.5 mm (0.004, 0.012 and 0.020 in.).

3. After adding or removing shims, tighten cap screws to specification and recheck cone point.
4. Check differential backlash. (See Differential Backlash Adjustment in this group.)


### Specification

Cone Point—Dimension (A) .....	17.5 ± 0.05 mm (0.688 ± 0.002 in.)
Differential Drive Shaft Quil Cap	
Screw—Torque.....	52 N•m (38 lb-ft)

**A—Cone Point Dimension**



LV1617 -UN-12FEB96



LV463 -UN-03MAR92


AG.OUO1085,194 -19-22AUG00-1/1

50  
25  
13

## Differential Backlash Adjustment

**IMPORTANT:** Always check and adjust backlash after cone point adjustment has been made.

1. While slowly rotating differential carrier, lightly tap carrier with a soft-faced mallet to make sure bearing on other side of ring gear is seated.
2. Attach a dial indicator to housing, as shown, with contact point positioned on ring gear splines.
3. While holding input shaft, move carrier and ring gear to determine backlash. Backlash should be within specification.



LV314 -UN-15DEC00

### Specification

Differential—Backlash ..... 0.18—0.25 mm (0.007—0.010 in.)

AG,OUO1023,530 -19-28JUN02-1/2

4. To adjust backlash, remove six cap screws (C). Turn differential quill (A) 30° and install cap screws in the two threaded holes. Use cap screws to draw out the quill.

### Specification

Differential Quill—Angle ..... 30°


5. Remove shims (B) to decrease backlash, and add shims to increase.
6. Recheck backlash after removing or adding shims.

**NOTE:** Ring gear carrier is not preloaded and will have normal side-to-side movement.

7. Tighten cap screws to specification.

### Specification

Differential Cap Screws—Torque..... 58 N•m (43 lb-ft)



LV312 -UN-15DEC00

A—Differential Quill  
B—Shim  
C—Cap Screw (6 used)

AG,OUO1023,530 -19-28JUN02-2/2

## Service Equipment and Tools

*NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.*

SERVICEGARD is a trademark of Deere & Company

OUC1043,0000EB4 -19-28JUN02-1/2

Final Drive Turning Tool . . . . . DFLV1A

Turns final drive housing to set rolling torque.

OUC1043,0000EB4 -19-28JUN02-2/2

## Other Material

Number	Name	Use
TY6305 (U.S.) TY9485 (Canadian) 7649 (LOCTITE®)	Clean and Cure Primer	Cleans mating surfaces and reduces sealant curing time.
TY6304 (U.S.) TY9484 (Canadian) 518 (LOCTITE®)	Flexible Sealant	Seals differential carrier housing to axle housing.

LOCTITE is a registered trademark of Loctite Corp.

OUC1043,0000EB5 -19-28JUN02-1/1

## Specifications

Item	Measurement	Specification
Final Drive Assembly Cap Screws	Torque	100 N•m (74 lb-ft)
Final Drive Housing	Rolling Drag Torque	9 N•m (80 lb-in.) increase above base line

OUC1043,0000EB6 -19-28JUN02-1/1

## Remove and Install Final Drive Assembly

**NOTE:** Remove cab if equipped. (See Cab Remove and Install in Section 90, Group 15.)

1. Tractors without cab: remove ROLL-GARD™. (See Remove and Install ROLL-GARD™ in Section 90, Group 10.)

**NOTE:** The approximate capacity of transmission/differential is 38 L (10 U.S. gal).

2. Drain transmission/differential.

**NOTE:** Close all openings using caps and plugs.

Hydraulic line (B) is on left side only.

3. Disconnect lines (A and B).

**NOTE:** Disconnect draft link sway linkage from final drive housing.

4. Attach lifting chains or strap to final drive housing.

5. Remove twelve cap screws (C).

6. Remove final drive assembly.

**NOTE:** To inspect or replace final drive pinion shaft, brakes must be removed. (See Remove and Inspect Brakes in Section 60, Group 10.)


7. Make repairs as necessary. (See Remove and Inspect Planetary Drive Assembly and Remove, Inspect, and Install Axle Shaft Assembly in this group.)

8. Clean mating surfaces of final drive and differential casings using Clean and Cure Primer. Apply a coat of Flexible Sealant or an equivalent to mating surfaces.

9. Install final drive assembly. Tighten cap screws to specification.

### Specification

Final Drive Assembly Cap  
Screws—Torque..... 100 N•m (74 lb-ft)



Left Side Shown

A—Hydraulic Line  
B—Hydraulic Line  
C—Cap Screw (12 used)

LV511 -UN-03MAR92

**IMPORTANT: Always use new O-rings. Damaged or used O-rings will leak.**

10. Install new O-rings and connect hydraulic lines (B and A). Connect draft link sway linkage.
11. Fill transmission with specified transmission/hydraulic oil. (See Transmission and Hydraulic Oil in Section 10, Group 20.)
12. Bleed brakes. (See Bleed Brake System in Section 260, Group 10.)
13. Install ROLL-GARD™.
14. Install cab if equipped. (See Cab Remove and Install in Section 90, Group 15.)

*ROLL-GARD is a trademark of Deere & Company*

AG,OUO1085,197 -19-28JUN02-2/2




## Remove and Inspect Planetary Drive Assembly

**CAUTION:** Gears may turn. Keep fingers away from planetary gears.

1. Remove lock plate (B).
2. Remove cap screw (A).
3. Remove planetary carrier assembly (C).

A—Cap Screw  
B—Lock Plate  
C—Planetary Carrier Assembly



T6639GK -UN-19OCT88



LV102 -UN-03MAR92


Continued on next page

AG,OUO1085,198 -19-22AUG00-1/3

**NOTE:** Planetary gears are press fit on carrier studs.

4. Remove snap ring (C).
5. Remove planetary gear (B) using a two-jaw puller.
6. Remove spacer (A).

A—Spacer  
B—Planetary Gear  
C—Snap Ring




LV555 -UN-03MAR92

AG,OUO1085,198 -19-22AUG00-2/3

7. Disassemble parts (A—D) on 5210, 5310, and 5410 series tractors.
8. Disassemble parts (A—E) on 5510 series tractors.
9. Inspect all parts for wear or damage. Replace as necessary.

A—Retaining Ring (2 used)  
B—Roller (17 used)  
C—Bearing Race  
D—Planetary Gear  
E—Thrust Washer (2 used on 5510 series tractor only)



LV100AE -UN-18APR96

AG,OUO1085,198 -19-22AUG00-3/3


50  
30  
5

## Install Planetary Drive Assembly

**NOTE:** Lubricate all internal parts with clean transmission/hydraulic oil during assembly.

1. Assemble parts (A—D) and thrust washers (E), if equipped.

A—Retaining Ring (2 used)  
 B—Roller (17 used)  
 C—Bearing Race  
 D—Planetary Gear  
 E—Thrust Washer (2 used on 5510 series tractor only)




LV100AE -UN-18APR96

AG,OUO1085,199 -19-28JUN02-1/3

2. Install spacer (A).
3. Install planetary gears with bevel (B) facing carrier using a bushing, bearing, and seal driver set and a press.
4. Install snap ring (C).

A—Spacer  
 B—Bevel  
 C—Snap Ring



LV556 -UN-03MAR92

Continued on next page

AG,OUO1085,199 -19-28JUN02-2/3

**IMPORTANT:** Before assembling and adjusting final drives, rear axle should be bolted to a tractor wheel.

5. Attach final drive housing to a rear tractor wheel.
6. Install planetary carrier assembly (C) onto the axle shaft. Do not install cap screw (A).

*NOTE: See DFLV1A—Final Drive Turning Tool in Section 299 for instructions to make turning tool.*

7. Rotate final drive housing through three complete revolutions in each direction using DFLV1A Final Drive Turning Tool (D) to ensure proper seating of bearing rollers.
8. Rotate final drive housing a minimum of ten revolutions using a torque wrench and Turning Tool to determine rolling drag torque. This is the base line rolling drag torque.
9. Install a new cap screw (A). Tighten cap screw until the rolling drag torque increases 9 N•m (80 lb-in.) above the base line.

#### Specification


Final Drive Housing—Rolling  
Drag Torque ..... 9 N•m (80 lb-in.) increase above  
base line

10. Install lock plate (B).

A—Special Cap Screw  
B—Lock Plate  
C—Planetary Carrier Assembly  
D—DFLV1A Final Drive Turning Tool




LV102 -UN-03MAR92



LV101 -UN-03MAR92

## Remove, Inspect, and Install Axle Shaft Assembly



A—Axle Shaft  
B—Seal  
C—Backup Ring  
D—Bearing Cone

E—Bearing Cup  
F—Grease Fitting  
G—Plug (2 used)  
H—Cap

I—Brake Bleeder  
J—Final Drive Housing  
K—Seal

L—Bearing Cup  
M—Bearing Cone  
N—Retaining Ring

1. Remove planetary drive assembly. (See Remove and Inspect Planetary Drive Assembly in this group.)
2. Remove retaining ring (N).
3. Remove axle (A) using a lead hammer on splined end of shaft.

**NOTE:** Bearing cone (D) is press fit on axle shaft. Bearing cups (E and L) are press fit in final drive housing.

Remove bearing cups only if replacement is necessary.

4. Remove bearing (D) using a knife-edged puller and a press.
5. Remove backup ring (C) and seal (B).
6. Pry out seal (K).
7. Inspect all parts for wear or damage. Replace as necessary.
8. Remove cups (E and L), if necessary, using a two-jaw inside puller and a slide hammer.

Continued on next page


AG,OUO1020,3454 -19-22AUG00-1/3

9. Install bearing cups (A) in both ends of housing until seated, using a bushing, bearing, and seal driver set.

**IMPORTANT: Replace all seals. Damaged or used seals will leak.**

10. Install seal (B) with lips facing planetary drive end of housing.
11. Apply multipurpose grease to lips of seal.

A—Bearing Cup  
B—Seal



Continued on next page


AG,OUO1020,3454 -19-22AUG00-2/3

12. Install seal (A) and back-up ring (B) on axle shaft until seated.

**CAUTION:** DO NOT heat oil over 182°C (360°F). Oil fumes or oil can ignite above 193°C (380°F). Use a thermometer. DO NOT allow a flame or heating element to come in direct contact with the oil. Heat the oil in a well-ventilated area.

13. Heat bearing cones (C and D) to 150°C (300°F), immersed in oil.
14. Install bearing cone (C) on axle shaft.
15. Install axle shaft in housing.
16. Install bearing cone (D) on axle shaft until seated.
17. Install new retaining ring (E).
18. Apply multipurpose grease to hub and axle shaft bearing at grease fitting.
19. Install planetary drive assembly. (See Install Planetary Drive Assembly in this group.)


A—Seal  
B—Backup Ring  
C—Bearing Cone  
D—Bearing Cone  
E—Retaining Ring



T81191 -UN-23FEB89



LV105 -UN-03MAR92



LV106 -UN-03MAR92

AG,OUO1020,3454 -19-22AUG00-3/3



Essential Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).


SERVICEGARD is a trademark of Deere & Company

OUC1023,0000013    –19–07APR04–1/2

Spanner Wrench . . . . . JDG736

To remove and install MFWD pinion shaft nut.

JDG736    –UN–17JUN94



OUC1023,0000013    –19–07APR04–2/2

Service Equipment and Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.


SERVICEGARD is a trademark of Deere & Company

OUC1043,0000EB8    –19–28JUN02–1/2

Pinion Shaft Holding Fixture . . . . . JDG486

Holds differential drive shaft when removing or torquing nut.

JDG486    –UN–03MAR92



OUC1043,0000EB8    –19–28JUN02–2/2

**Other Material**

Number	Name	Use
TY9370 (U.S.) TY9477 (Canadian) 242 (LOCTITE®)	Thread Lock and Sealer (Medium Strength)	Apply to the outer drive cap screws. Apply to the wheel mounting studs. Apply to the bevel gear cap screws.
T43515 (U.S.) TY9479 (Canadian) 635 (LOCTITE®)	Retaining Compound	Apply to outer drive thrust pad and differential carrier cover OD
TY6305 (U.S.) TY9485 (Canadian) 7649 (LOCTITE®)	Clean and Cure Primer	Cleans mating surfaces and reduces sealant curing time.
TY6304 (U.S.) TY9484 (Canadian) 518 (LOCTITE®)	Flexible Sealant	Seals differential carrier housing to axle housing.

LOCTITE is a registered trademark of Loctite Corp.

OUC1043,0000EB9 -19-28JUN02-1/1

**Specifications**

Item	Measurement	Specification
Wheel Cap Screws	Torque	175 N•m (130 lb-ft)
MFWD Drop Gearbox Cap Screw	Torque	132 N•m (97 lb-ft)
MFWD Drop Gearbox Shift Lever Bolt	Torque	26 N•m (230 lb-in.)
Drop Gearbox Drive Shaft Cover Cap Screws	Torque	26 N•m (230 lb-in.)
MFWD Drop Gearbox Top Shaft Nut	Torque	60 N•m (44 lb-ft)
Drive Shaft Guard Cap Screws	Torque	15 N•m (11 lb-ft)
Axle-to-Frame Cap Screws	Torque	650 N•m (479 lb-ft)
Front Wheel Nuts	Torque	300 N•m (220 lb-ft)
MFWD Outer Drive Cap Screws	Torque	78 N•m (58 lb-ft)
MFWD Outer Drive Studs	Torque	70 N•m (50 lb-ft)
Planet Pinion Carrier Socket Screws	Torque	25 N•m (18.5 lb-ft)
Planet Pinion Carrier Fill/Drain Plug	Torque	80 N•m (59 lb-ft)
Front Wheel Nuts	Torque	300 N•m (220 lb-ft)
MFWD Swivel Housing Cap Screw	Torque	120 N•m (89 lb-ft)
Tie Rod End Nut	Torque	165 N•m (122 lb-ft)
Planet Pinion Carrier Socket Screws	Torque	25 N•m (18.5 lb-ft)
Planet Pinion Carrier Fill/Drain Plug	Torque	80 N•m (59 lb-ft)
Front Wheel Nuts	Torque	300 N•m (220 lb-ft)
Differential Carrier-to-Axle Housing Cap Screws	Torque	169 N•m (125 lb-ft)
Axle Housing Fill Plug	Torque	70 N•m (50 lb-ft)
Friction Plate	Minimum Thickness New Thickness	1.30 mm (0.051 in.) 1.60 mm (0.063 in.)

Continued on next page

OUO1020,0001212 -19-14NOV02-1/2

## Mechanical Front Wheel Drive

Item	Measurement	Specification
Drive Plate	Minimum Thickness	1.47 mm (0.058 in.)
	New Thickness	1.53 mm (0.060 in.)
Inner Thrust Plate	Minimum Thickness	2.73 mm (0.107 in.)
	New Thickness	2.83 mm (0.110 in.)
Differential Carrier Assembly Cap Screws	Torque	266 N•m (196 lb-ft)
Pinion Shaft	Rolling Drag	105—157 N (24—35 lb force)
Bevel Gear Cap Screw	Torque	78 N•m (58 lb-ft)
Differential Ring Gear-to-Pinion Gear	Backlash	0.16—0.21 mm (0.006—0.008 in.)
Pinion Shaft Plus Differential	Rolling Drag	142—213 N (32—48 lb force)
End Cap Screws	Torque	266 N•m (196 lb-ft)

OUO1020,0001212 -19-14NOV02-2/2

## Inspect and Repair MFWD Lever and Linkage

1. Tractors without cab: remove left rear wheel and fender.
2. Tractors with cab: remove left rear wheel, seat, support, and base plate. (Remove and Install Seat and Support Plate—Tractors With Cab in Section 90, Group 05.)


**NOTE:** Bushings (C) are press fit. Remove bushings only if replacement is necessary.

3. Replace bushing (C) using a bearing, bushing, and seal driver set.
4. Inspect all parts for wear or damage. Replace as necessary.
5. Apply Moly High Temperature EP Grease to shaft of bolt (H).
6. Install all parts.
7. Tractors without cab: install left fender and wheel.
8. Tighten wheel cap screws to specification.

### Specification

Wheel Cap Screws—Torque..... 175 N•m (130 lb-ft)

9. Tractors with cab: install seat, support, and base plate.



- A—Knob
- B—MFWD Lever
- C—Bushings (2 used)
- D—Cotter Pin (2 used)
- E—Spring Pin
- F—Arm
- G—Rod
- H—Shoulder Bolt

LV456AE -UN-03MAR92

50  
35  
5

AG\_OUO1085.201 -19-28JUN02-1/1

## Remove and Install MFWD Drop Gearbox

**NOTE:** The approximate capacity of transmission is 38 L (10 U.S. gal).

1. Remove plug (B) and drain transmission/hydraulic oil.
2. Remove MFWD drive shaft. (See Remove, Inspect and Install MFWD Drive Shaft in this group.)
3. Disconnect link (C).

**CAUTION:** Approximate weight of drop gearbox is 20 kg (45 lbs).

4. Remove four cap screws and washers (A) to remove drop gearbox.
5. Make repairs as necessary. (See Disassemble and Inspect MFWD Drop Gearbox in this group.)


**IMPORTANT:** Always use new O-rings. Damaged or used O-rings will leak.

6. Install gearbox and new O-ring. Tighten cap screws to specification.

### Specification

MFWD Drop Gearbox Cap  
Screw—Torque..... 132 N•m (97 lb-ft)

7. Connect shift link.
8. Install drive shaft.
9. Install plug and new O-ring. Fill transmission with proper oil. (See Transmission and Hydraulic Oil in Section 10, Group 20.)



A—Cap Screw and Washer (4 used)  
B—Plug  
C—Link


LV494 -UN-03MAR92

AG,OUO1085,202 -19-28JUN02-1/1

## Disassemble and Inspect MFWD Drop Gearbox

1. Remove cotter pin (K), nut (J), and washer (I).
2. Remove spring pins (A and B) using a punch and hammer.
3. Remove shaft (C), using a brass drift and hammer.
4. Remove bearing cones (D), bearing cups (E), spacer (H), and gears (F). Remove snap ring (G) only if necessary.

A—Large Spring Pin  
 B—Small Spring Pin  
 C—Top Shaft  
 D—Bearing Cone (2 used)  
 E—Bearing Cup (2 used)  
 F—Driven Gears  
 G—Snap Ring  
 H—Spacer  
 I—Washer  
 J—Nut  
 K—Cotter Pin




LV495A -UN-20SEP96

Continued on next page

AG,OUO1008,220 -19-06OCT99-1/3

50  
35  
7





A—Cap Screw (4 used)  
B—Cover  
C—O-Ring  
D—Seal  
E—Bearing  
F—Output Shaft

G—Spring  
H—Ball (2 used)  
I—Shift Collar  
J—O-Ring  
K—Shift Lever

L—Shift Block  
M—Idler Gear  
N—Washer  
O—Snap Ring  
P—Bearing

Q—Lock Plate  
R—Lock Washer  
S—Bolt  
T—Shift Arm  
U—Spring Pin

5. Remove parts (A—D).
6. Remove parts (Q, R, and S).
7. Pull arm (T) toward gearbox.
8. Remove parts (E—I) and (M—P) as an assembly.
9. Remove parts (U and T) and (J—L).

**NOTE:** Bearings (E and P) are press fit on shaft (H). Remove bearing (E) only if replacement is necessary.

10. Remove bearing (P) using a knife-edged puller and a press.

**CAUTION:** Balls (H) and spring (G) will shoot out of shaft when removing collar (I). Use care when removing collar.

11. Remove parts (O—M) and (I, H, and G).
12. Inspect all parts for wear or damage. Replace as necessary.

Continued on next page

AG,OUO1008,220 -19-06OCT99-2/3


**IMPORTANT: Replace all seals. Damaged or used seals will leak.**

cover bore until it stops, using a bearing, bushing, and seal driver set.

13. Remove seal (D) using a screwdriver. Install new seal, with lips facing toward shaft assembly, into

AG,OUO1008,220 -19-06OCT99-3/3

# MFWD Drop Gearbox Cross Section



A—Output Shaft  
B—Seal  
C—Bearing  
D—Shift Collar  
E—Dual Spring Pins  
F—Top Shaft  
G—Bearing Assembly

H—Snap Ring  
I—Driven Gears  
J—Spacer  
K—Washer  
L—Nut  
M—Cotter Pin  
N—O-Ring

O—Bearing  
P—MFWD Drop Gearbox  
Q—Snap Ring  
R—Washer  
S—O-Ring  
T—Drain Plug

U—Idler Gear  
V—Ball (2 used)  
W—Spring  
X—O-Ring  
Y—Cap Screw (4 used)  
Z—Cover


LV497AE -JUN-07NOV96

## Assemble MFWD Drop Gearbox

**IMPORTANT:** Use new seals and O-rings during assembly. Damaged or used seals and O-rings will leak.

**NOTE:** Lubricate all internal parts with clean transmission/hydraulic oil during assembly.

1. Install bearing (A), if removed, using a piece of pipe and a press.
2. Apply multipurpose grease to balls (D) and spring (C).
3. Install balls and spring in hole in shaft.
4. Install collar (B) over balls with shoulder of collar facing bearing (A).



A—Bearing  
B—Shift Collar  
C—Spring  
D—Ball (2 used)

LV560 -UN-09MAR92

50  
35  
11


AG,OUO1085,206 -19-28JUN02-1/6

**IMPORTANT:** Small splines on gear (A) must face shift collar.


**Grooves in washer (B) must face gear (A).**

5. Install gear (A), washer (B), and snap ring (C).
6. Press bearing (D) tight against shoulder of shaft.

A—Idler Gear  
B—Washer  
C—Snap Ring  
D—Bearing



LV561 -UN-09MAR92



LV562 -UN-09MAR92

Continued on next page


AG,OUO1085,206 -19-28JUN02-2/6

7. Apply multipurpose grease to shift lever shaft (C), new O-ring (B), and shift block (A).

8. Install shift block on lever.

9. Install lever in gearbox. Pull lever tight against gearbox and install O-ring.

A—Shift Block  
B—O-Ring  
C—Shift Lever Shaft



LV563 -UN-09MAR92

AG.OUO1085,206 -19-28JUN02-3/6

10. Install shaft assembly (A).

11. Position shift block on lever (C) between shoulders of shift collar. Push lever into gearbox.

12. Install plate (B) in groove of lever and install bolt (D). Tighten bolt to specification.


#### Specification

MFWD Drop Gearbox Shift Lever

Bolt—Torque..... 26 N•m (230 lb-in.)

13. Install shift arm with long end pointing in opposite direction of output shaft.

A—Output Shaft Assembly  
B—Lock Plate  
C—Shift Lever  
D—Bolt



LV564 -UN-09MAR92

Continued on next page

AG.OUO1085,206 -19-28JUN02-4/6


14. Apply multipurpose grease to inside lips of cover seal.
15. Install new O-ring and cover (A).
16. Install four cap screws (B) and tighten to specification.

**Specification**

Drop Gearbox Drive Shaft Cover  
 Cap Screws—Torque ..... 26 N•m (230 lb-in.)

17. Install new O-ring and plug (C).

A—O-Ring and Cover  
 B—Cap Screw (4 used)  
 C—O-Ring and Plug




LV565 -UN-09MAR92

Continued on next page

AG,OUO1085,206 -19-28JUN02-5/6

18. Install snap ring (G) if removed.
19. Install spacer (H) and bearing cups (E) into gear (F).

**CAUTION:** DO NOT heat oil over 182°C (360°F). Oil fumes or oil can ignite above 193°C (380°F). Use a thermometer. DO NOT allow a flame or heating element to come in direct contact with the oil. Heat the oil in a well-ventilated area.



20. Heat bearing cones (D) to 149°C (300°F).
21. Assemble bearing cones (D) to gear (F).

**NOTE:** Align hole in shaft with hole in gearbox when installing shaft.

22. Position gear and bearings between ears of gearbox and install shaft (C) using a brass drift and hammer. Shoulder on shaft must be flush with bearing cone.

**NOTE:** Install spring pin (B) inside spring pin (A) with splits facing 180° (opposite) from each other.


23. Install spring pins (A and B).
24. Install washer (I) and nut (J). Tighten nut to specification.

#### Specification

MFWD Drop Gearbox Top Shaft  
Nut—Torque ..... 60 N•m (44 lb-ft)

25. Install cotter pin (K).

- A—Large Spring Pin
- B—Small Spring Pin
- C—Top Shaft
- D—Bearing Cone (2 used)
- E—Bearing Cup (2 used)
- F—Driven Gears
- G—Snap Ring
- H—Spacer
- I—Washer
- J—Nut
- K—Cotter Pin




T81191 -UN-23FEB89

LV495A -UN-20SEP96



## Remove, Inspect and Install MFWD Drive Shaft



1

A—Drive Shaft Guard (inner)  
B—Drive Shaft Guard (outer)  
C—Cap Screw (6 used)  
D—Cotter Pin (2 used)

E—Coupler (2 used)

F—Drive Shaft

1. Remove cap screws (C).
2. Slide guards (A and B) together.
3. Remove cotter pins (D).
4. Slide couplers (E) toward drive shaft (F) and remove drive shaft assembly.
5. Inspect parts for wear or damage. Check drive shaft for straightness. Replace parts as necessary.

6. Apply Moly High Temperature EP Grease to ID of couplers (E).
7. Install drive shaft assembly.
8. Install drive shaft guard cap screws (C). Tighten to specification.

### Specification

Drive Shaft Guard Cap  
Screws—Torque ..... 15 N•m (11 lb-ft)


AG,OUO1085,207 -19-28JUN02-1/1

50  
35  
15  
LV280AE -UN-17JUN94

## Remove and Install MFWD Axle Housing Assembly

1. Remove drive shaft. (See Remove, Inspect and Install MFWD Drive Shaft in this group.)
2. Raise front of tractor. Securely support tractor below the engine/transmission junction.

**CAUTION:** Axle will pivot to one side when one wheel is removed. Install wooden blocks between the axle stops and frame to prevent axle from tipping.



LV282 -UN-03MAR92

3. Install wooden blocks between axle and frame.
4. Remove front wheels.
5. Position a transmission jack or floor jack under center of axle as shown. Ensure axle will be stable on the floor jack when cap screws (B) are removed.

**NOTE:** Close all openings using caps and plugs.

6. Disconnect hydraulic hoses (A). Close all openings using caps and plugs.
7. Remove cap screws (B) and lower axle.
8. Make repairs as necessary. (See procedures in this group.)
9. Raise axle into position and install cap screws. Tighten cap screws to specifications.

### Specification

Axle-to-Frame Cap Screws—  
Torque ..... 650 N•m (479 lb-ft)

10. Connect hydraulic hoses.
11. Install front wheels. Tighten wheel nuts to specification.

### Specification

Front Wheel Nuts—Torque ..... 300 N•m (220 lb-ft)

12. Remove all supports and lower tractor.

A—Hydraulic Hose (2 used)  
B—Cap Screw (4 used)


Continued on next page

AG,OUO1085,208 -19-28JUN02-1/2

13. Install drive shaft.

AG,OUO1085,208 -19-28JUN02-2/2

## Remove, Inspect and Install MFWD Axle Supports



MFWD Axle Supports

- |                             |                            |                       |                                |
|-----------------------------|----------------------------|-----------------------|--------------------------------|
| A—Rear Support              | D—Support Bushing (2 used) | G—Front Support       | J—Locating Bolt                |
| B—O-Ring                    | E—Thrust Washer (2 used)   | H—Bushing (4 used)    | K—Lubrication Fitting Assembly |
| C—Trunnion Bushing (2 used) | F—Axle Trunnion            | I—Lubrication Fitting |                                |

1. Remove MFWD axle. (See Remove and Install MFWD Axle Housing Assembly in this group.)
2. Remove supports (A and G).
3. Remove O-ring (B).
4. Clean supports and axle trunnions. Do not remove bushings (C and D).
5. Install supports on axle trunnions (F). Rock supports from side to side. Replace bushings (C and D) if excessive play is noted.

6. Inspect all parts for wear or damage. Replace as necessary.

**NOTE:** The inner and outer bushings (C and D) are a matched set. Always replace both if replacement is necessary.

*Bushings (D) are press fit inside supports (A and G). Bushings (C) are press fit on trunnions (F). Remove bushings only if replacement is necessary.*

7. Remove parts (I—K).

Continued on next page

AG.OUO1008,364 -19-22AUG00-1/2

8. Cut bushings to remove.
9. Install bushings using a press or a brass drift and hammer.
10. Install parts (I—K).
11. Apply multipurpose grease to all bushings.
12. Install new O-ring (B) in support (A). Install supports on axle trunnions.
13. Install MFWD axle. (See Remove and Install MFWD Axle Housing Assembly in this group.)
14. Apply multipurpose grease to fittings (I and K).

AG,OUO1008,364 -19-22AUG00-2/2


## Disassemble and Inspect MFWD Outer Drive

**NOTE:** Outer drive assembly can be serviced without removing axle.

1. Raise and support MFWD axle.
2. Remove front wheel.
3. Turn outer drive until filler/drain plug (C) is at the lowest position.

**NOTE:** Approximate capacity of wheel hub is 0.6 L (0.63 U.S. qt).

4. Remove plug (C) to drain wheel hub.
5. Remove two socket head screws (A).
6. Remove planet pinion carrier (B).



A—Socket Head Screw (2 used)  
B—Planet Pinion Carrier  
C—Filler/Drain Plug

LV284 -UN-09MAR92

50  
35  
19

Continued on next page

AG,OUO1008,365 -19-28JUN02-1/3


**IMPORTANT: Keep each planet gear assembly together as a set.**

7. Remove parts (A—E) from planet pinion carrier (I).

*NOTE: Pad (G) is held with adhesive to carrier (I).  
Replace only if necessary.*

*Shaft (F) and carrier (I) are interference fit and are a matched set. If shafts or carrier are worn or damaged, replace as one unit.*

8. Inspect all parts for wear or damage. Replace as necessary.




- A—Snap Ring (3 used)
- B—Pinion Plate
- C—Planet Pinion (3 used)
- D—Needle Bearings (30 per gear)
- E—Thrust Washer (3 used)
- F—Pinion Shaft (3 used)
- G—Thrust Pad
- H—Socket Head Screw (2 used)
- I—Planet Pinion Carrier
- J—O-Ring
- K—Filler/Drain Plug

LV567AE -UN-09MAR92

Continued on next page

AG,OUO1008,365 -19-28JUN02-2/3



A—Seal  
B—Bearing (2 used)  
C—Hub  
D—Stud (8 used)

E—O-Ring  
F—Retaining Ring  
G—Ring Gear Plate

H—Thrust Washer  
I—Spacer  
J—Cap Screw (6 used)

K—Ring Gear  
L—Snap Ring  
M—Bushing (6 used)

9. Remove snap ring (L) and washers (H and I).

10. Remove cap screws (J).

11. Install two of the 10 mm cap screws (J) in the threaded jacking holes located in plate (G). Tighten cap screws evenly to remove ring gear assembly.

*NOTE: Bushings (M) are press fit. Remove only if replacement is necessary.*

12. Remove retaining ring (F) to separate plate (G) from ring gear (K).

**IMPORTANT: The cone and cup of bearings (B) are matched sets. Tag bearing cones**

**to identify each cone with its respective bearing cup to aid in assembly.**

**Replace all seals. Damaged or used seals will leak.**

*NOTE: Bearing cups are press fit in hub (C). Remove cups only if replacing bearings.*

*Remove studs (D) only if replacement is necessary.*

13. Remove parts (A—E).

14. Inspect all parts for wear or damage. Replace as necessary.


AG,OUO1008,365 -19-28JUN02-3/3

LV2128 -UN-09JUN97

50  
35  
21



# Assemble MFWD Outer Drive



A—Seal  
B—Bearing (2 used)  
C—Hub  
D—Stud (8 used)

E—O-Ring  
F—Retaining Ring  
G—Ring Gear Plate

H—Thrust Washer  
I—Spacer  
J—Cap Screw (4 used)

K—Ring Gear  
L—Snap Ring  
M—Bushing (4 used)

**IMPORTANT:** Use new O-rings during assembly. Damaged or used O-rings will leak.

**Lubricate all internal parts with clean oil during assembly.**

1. Apply multipurpose grease to lips of seal (A).
2. Install bearing cone (B) on swivel housing.
3. Install hub (C), remaining bearing cone, and new O-ring (E).
4. Assemble parts (F, G and K).
5. Press bushings (M) into bores of plate (G).
6. Apply thread lock and sealer (medium strength) to threads of cap screws (J).

7. Install ring gear assembly and cap screws. Tighten cap screws to specification.

## Specification

MFWD Outer Drive Cap  
Screws—Torque ..... 78 N•m (58 lb-ft)

8. Install washers (H and I) and snap ring (L).

9. If studs (D) were removed:

- Apply thread lock and sealer (medium strength) to threads of studs.
- Install studs and tighten to specifications.

## Specification

MFWD Outer Drive Studs—  
Torque..... 70 N•m (50 lb-ft)

Continued on next page

AG,OUO1008,366 -19-28JUN02-1/2

## 10. If thrust pad (G) was removed:

- Clean thrust pad and surface of carrier housing (where pad contacts housing) with solvent. Allow to air dry.
- Apply retaining compound to pad.
- Install pad in carrier housing.

## 11. Install parts (A—E) into carrier (I). Install needle bearings (D) using grease to hold the individual bearings in position.

## 12. Install carrier assembly to hub.

## 13. Install two socket head screws (H). Tighten to specifications.

**Specification**

Planet Pinion Carrier Socket  
Screws—Torque ..... 25 N•m (18.5 lb-ft)

## 14. Rotate outer drive until filler/drain plug hole is approximately at the 3:00 o'clock position and oil level line is horizontal. Fill to level line with specified gear oil. (See MFWD Gear Oil in Section 10, Group 20.)

## 15. Install O-ring (J) and plug (K). Tighten plug to specifications.


**Specification**

Planet Pinion Carrier Fill/Drain  
Plug—Torque..... 80 N•m (59 lb-ft)

## 16. Install wheel. Tighten wheel nuts to specifications.

**Specification**

Front Wheel Nuts—Torque ..... 300 N•m (220 lb-ft)



- A—Snap Ring (3 used)  
B—Pinion Plate  
C—Planet Pinion (3 used)  
D—Needle Bearing (30 per gear)  
E—Thrust Washer (3 used)  
F—Pinion Shaft (3 used)  
G—Thrust Pad  
H—Socket Screw (2 used)  
I—Planet Pinion Carrier  
J—O-Ring  
K—Filler/Drain Plug

LV567AE -UN-09MAR92


50  
35  
23

## Remove, Inspect, and Install MFWD Swivel Housing

1. Raise and support MFWD axle.
2. Remove front wheel.
3. Turn outer drive so that filler/drain plug (C) is at the lowest position.

**NOTE:** Approximate capacity of wheel hub is 0.6 L (0.63 U.S. qt).

4. Remove plug (C) to drain wheel hub.
5. Remove two socket head screws (A).
6. Remove planet pinion carrier (B).




A—Socket Head Screw (2 used)  
B—Planet Pinion Carrier  
C—Filler/Drain Plug

LV284 -UN-09MAR92

AG,OOU1008,383 -19-28JUN02-1/5

7. Attach lifting chain or sling around swivel housing.
8. Disconnect tie rod end (A).
9. Remove snap ring and washers (B) from axle shaft.


A—Tie Rod End  
B—Washer



LV286 -UN-09MAR92

Continued on next page

AG,OOU1008,383 -19-28JUN02-2/5



A—Belleville Washer  
B—Spacer  
C—Bushing  
D—Seal

E—Bushing  
F—Lubrication Fitting (2 used)  
G—Cap Screw (8 used)

H—Upper Swivel Pin  
I—Swivel Housing  
J—Lower Swivel Pin

K—Bearing Cone  
L—Bearing Cup  
M—Belleville Washer

**NOTE:** When removing swivel housing (I), keep axle shaft with axle housing. Hold shaft in position while pulling swivel housing away from axle housing.

10. Remove parts (G—J).

**NOTE:** All bushings and bearings are press fit. Remove only if replacement is necessary.

*If replacing bearing cone (K), it may be necessary to heat the axle housing and chill the bearing cone to aid in installation.*

11. Inspect all parts for wear or damage. Replace as necessary.

**IMPORTANT:** Replace all seals. Damaged or used seals will leak.

**Remove burrs from mating surfaces of parts (H, I, and J). Raised**

**imperfections on these surfaces will affect swivel pin bearing preload.**

12. Install all parts using the following instructions:

- Install seals using a bearing, bushing, and seal driver set. Install seal (D) with lips toward swivel housing.
- Apply multipurpose grease to inside lips of seals.
- Apply Moly High Temperature EP Grease to shaft of pins (H and J).
- Belleville washers (A and M) are used to preload the swivel pin bearings. No adjustment is necessary.
- Tighten cap screws (G) to specification.

#### Specification

MFWD Swivel Housing Cap  
Screw—Torque ..... 120 N•m (89 lb-ft)

Continued on next page

AG,OUO1008,383 -19-28JUN02-3/5

**NOTE:** Washer with tangs on its outer edge goes against ring gear plate.

13. Install washers and snap ring (B).


14. Connect tie rod end (A) to swivel housing. Tighten nut to specification.

**Specification**

Tie Rod End Nut—Torque..... 165 N•m (122 lb-ft)

A—Tie Rod End

B—Snap Ring



LV286 -UN-09MAR92

AG,OUO1008,383 -19-28JUN02-4/5

**IMPORTANT:** Replace all O-rings. Damaged or used O-rings will leak.

15. Install planet pinion carrier (B) with new O-ring.

16. Install two socket head screws (A). Tighten to specifications.

**Specification**

Planet Pinion Carrier Socket

Screws—Torque..... 25 N•m (18.5 lb-ft)

17. Turn outer drive until filler/drain plug hole is approximately at the 3:00 o'clock position and oil level line is horizontal (parallel to ground). Fill with specified gear oil. (See MFWD Gear Oil in Section 10, Group 20.)

18. Install plug (C) with new O-ring. Tighten plug to specifications.

**Specification**

Planet Pinion Carrier Fill/Drain

Plug—Torque..... 80 N•m (59 lb-ft)

19. Install wheel. Tighten wheel nuts to specifications.

**Specification**

Front Wheel Nuts—Torque ..... 300 N•m (220 lb-ft)



A—Socket Head Screw (2 used)

B—Planet Pinion Carrier

C—Plug


LV284 -UN-09MAR92

AG,OUO1008,383 -19-28JUN02-5/5

## Remove, Inspect, and Install MFWD Axle Shaft

1. Remove swivel housing. (See Remove, Inspect, and Install MFWD Swivel Housing in this group.)
2. Remove axle shaft assembly (A). Support shaft as it is removed from housing so as not to damage axle housing oil seal.


**A—Axle Shaft Assembly**



LV288 -UN-09MAF92

Continued on next page

AG.OUO1008,384 -19-22AUG00-1/2



A—Long Axle Shaft  
B—Cross and Bearing  
Assembly (2 used)

C—Center Yoke  
D—Retaining Ring (8 used)

E—Short Axle Shaft  
F—Seal

G—Bushing

**NOTE:** Bushing (G) is press fit in MFWD axle housing. Remove bushing only if replacement is necessary.

3. Inspect parts (A—G) for wear or damage. Replace as necessary.

**IMPORTANT:** Replace all seals. Damaged or used seals will leak.

4. Pry seal (F) out of axle housing. Install new seal with lips facing bushing (G), using a bearing,

bushing, and seal driver set. Install seal into axle bore until tight against shoulder in bore.

5. Apply multipurpose grease to lips of seal.

6. Install axle shaft assembly.

7. Install swivel housing. (See Remove, Inspect, and Install MFWD Swivel Housing in this group.)

AG,OUO1008,384 -19-22AUG00-2/2

LV289AE -JUN-09MAR92



## Remove and Install MFWD Differential Carrier Assembly

1. Remove steering cylinder. (See Remove and Install Steering Cylinder—MFWD Axle in Section 60, Group 05.)
2. Remove axle supports. (See Remove, Inspect and Install MFWD Axle Supports in this group.)
3. Remove MFWD axle shafts. (See Remove, Inspect, and Install MFWD Axle Shaft in this group.)


**NOTE:** Approximate capacity of axle housing is 5 L (5.3 U.S. qt).

4. Drain axle housing.
5. Remove ten cap screws (A) to remove carrier housing.
6. Make repairs as necessary. (See Disassemble and Inspect MFWD Differential Carrier Assembly in this group.)
7. Clean mating surfaces of housing using Clean and Cure Primer. Apply John Deere Flexible Sealant to mating surfaces of housings.
8. Install differential carrier housing.
9. Install cap screws and tighten to specifications.

### Specification

Differential Carrier-to-Axle  
Housing Cap Screws—Torque..... 169 N•m (125 lb-ft)

10. Install steering cylinder. (See Remove and Install Steering Cylinder—MFWD Axle in Section 60, Group 05.)
11. Install MFWD axle shafts. (See Remove, Inspect, and Install MFWD Axle Shaft in this group.)
12. Install MFWD axle and supports. (See Remove, Inspect and Install MFWD Axle Supports and Remove and Install MFWD Axle Housing Assembly in this group.)



A—Cap Screw (10 used)

LV291 -UN-09MAF92

50  
35  
29

Continued on next page

AG,OUO1008,385 -19-28JUN02-1/2

13. Fill axle housing with specified gear oil. (See MFWD Gear Oil in Section 10, Group 20.)

14. Tighten axle housing fill plug to specification.

**Specification**

Axle Housing Fill Plug—Torque ..... 70 N•m (50 lb-ft)

AG,OUO1008,385 -19-28JUN02-2/2

## Disassemble and Inspect MFWD Differential Carrier Assembly

1. Remove MFWD differential carrier assembly. (See Remove and Install MFWD Differential Carrier Assembly in this group.)

2. Remove cover (A) using a puller.

A—Cover



LV294 -UN-09MAR92


AG,OUO1008,386 -19-28JUN02-1/6

3. Straighten locking tabs on collar of nut using a small punch.

4. Wedge a brass drift (B) or piece of hard wood between ring gear and pinion shaft.

5. Loosen pinion nut using JDG736 Spanner Wrench (A).

A—Spanner Wrench  
B—Brass Drift



LV295 -UN-09MAR92


Continued on next page

AG,OUO1008,386 -19-28JUN02-2/6

**IMPORTANT:** Ring nut (B), end cap (C), and the related bearing boss on each side of carrier housing are matched sets. Do not interchange parts.

6. Mark each end cap (C) and related bearing boss to identify for assembly purposes.
7. Mark position of each ring nut (B) in respect to the end cap and related bearing boss to aid in assembly.
8. Remove parts (A—D).
9. Remove differential and ring gear assembly from carrier housing.

A—Lock Plate (2 used)  
B—Ring Nut (2 used)  
C—Bearing End Cap (2 used)  
D—Cap Screw (4 used)




LV296 -UN-09MAR92

Continued on next page

AG,OUO1008,386 -19-28JUN02-3/6

50  
35  
31



A—Cap Screw (12 used)  
B—Bevel Gear  
C—Roller Bearing  
D—Differential Housing (2 halves used)

E—Drive Plate (10 used)  
F—Friction Plate (8 used)  
G—Inner Thrust Plate (2 used)

H—Bevel Gear (2 used)  
I—Spring Pin  
J—Thrust Washer (2 used)

K—Bevel Pinion (2 used)  
L—Pinion Shaft  
M—Roller Bearing

**IMPORTANT:** Keep plates (E—G) together and in sequence removed to aid in assembly.

**Keep cup and cone of each bearing (C and M) together as a set.**

10. Disassemble parts (A—M). Remove bearing cones of bearings (C and M) only if replacement is necessary.

11. Inspect all parts for wear or damage. Replace as necessary.

12. Measure thickness of plates (E—G). Replace if not to specification.

#### Specification

Friction Plate—Minimum	
Thickness.....	1.30 mm (0.051 in.)
New Thickness .....	1.60 mm (0.063 in.)
Drive Plate—Minimum	
Thickness.....	1.47 mm (0.058 in.)
New Thickness .....	1.53 mm (0.060 in.)
Inner Thrust Plate—Minimum	
Thickness.....	2.73 mm (0.107 in.)
New Thickness .....	2.83 mm (0.110 in.)

Continued on next page

AG,OUO1008,386 -19-28JUN02-4/6

**IMPORTANT:** If either ring gear or pinion shaft is worn or damaged, both components must be replaced as a matched set.

AG,OUO1008,386 -19-28JUN02-5/6


**IMPORTANT:** Replace all seals. Damaged or used seals will leak.

**DO NOT** use old collapsible spacer (F) and pinion nut (J). If removed, always install new spacer and nut.

*NOTE: Bearing cone (C) and bearing cups (D and G) are press fit. Remove only if replacement is necessary.*

13. Remove parts (A—K). Remove bearing cone (C) and shim (B) using a knife-edged puller and a press.
14. Inspect all parts for wear or damage. Replace as necessary.

A—Pinion Shaft  
B—Shim  
C—Bearing Cone  
D—Bearing Cup  
E—Washer (2 used)  
F—Collapsible Spacer  
G—Bearing Cup  
H—Bearing Cone  
I—Washer  
J—Nut  
K—Seal  
L—Cover



LV551AE -UN-09MAR92

AG,OUO1008,386 -19-28JUN02-6/6

50  
35  
33

## Assemble MFWD Differential Carrier Assembly

**IMPORTANT:** If the ring gear and pinion assembly, pinion bearings, or the differential carrier housing have been replaced, it will be necessary to calculate for thickness of shim (B) to adjust cone point.

1. If either the ring gear and pinion assembly, pinion bearings, or carrier housing are replaced, cone point will require adjusting. Continue to step 2.

If all the components are reused, no adjustment is required. Go to step 10. Use original shim value.



2. Install the differential side bearing end caps and cap screws. Tighten cap screws to specification.

### Specification

Differential Carrier Assembly Cap  
Screws—Torque..... 266 N•m (196 lb-ft)

3. Measure the side bearing bore using an internal micrometer or vernier gauge. Record the reading obtained.
4. Remove end caps.

- A—Pinion Shaft
- B—Shim
- C—Bearing Cone
- D—Bearing Cup
- E—Washer (2 used)
- F—Collapsible Spacer
- G—Bearing Cup
- H—Bearing Cone
- I—Washer
- J—Pinion Nut
- K—Seal
- L—Cover



LV551AE -UN-09MAR92

LV301A -UN-09MAR92

Continued on next page

OUC1023.0000014 -19-07APR04-1/10

5. If pinion bearing cups were removed, install new cups in carrier housing with large ID of taper facing outward from housing. Press cups tight against shoulder in housing bore.

6. Install and clamp bearing cones (G) into carrier housing using an M12 x 110 mm cap screw, nut, and washers (F).

Tighten the cap screw so that bearing cones can just be turned by hand. DO NOT overtighten.

7. Lay a 25 x 228 mm (0.984 x 8.976 in.) circular bar (E) across the inside surface of the two side bearing bores. Measure for dimension (B) using a depth gauge (D).

8. Calculate:

Dimension (A) = dimension (B) minus diameter of bar (E) [25 mm (0.984 in.)] plus [1/2 diameter of bore (C)] recorded in step 3.

**NOTE:** Dimension (H) is etched on the head of the pinion gear.

Actual shim thickness = dimension (A) minus dimension (H).



EXAMPLE (calculated in metric):

Dimension (A) =  $104.1 - 25 + [1/2 (90) = 45] = 124.1$

Etched on the head of the pinion is 121.0

$124.1 - 121.0 = 3.1$  mm (shim thickness)

9. Remove items (E—G).



- A—Dimension (bore center to bearing)
- B—Dimension (rod to bearing)
- C—Bore Diameter (from step 3)
- D—Depth Gauge
- E—Circular Bar
- F—M12 Cap Screw, Nut, and Washers
- G—Bearing (2 used)
- H—Pinion Dimension
- I—Ring Gear/Pinion Mating Number

Continued on next page

OUO1023,0000014 -19-07APR04-2/10

LV302A -UN-09MAR92

LV303A -UN-09MAR92

50  
35  
35




**IMPORTANT: DO NOT** use old collapsible spacer (F) and pinion nut (J). Always install new spacer and nut.

To prevent damaging bearing (C), apply force only to inner race of bearing cone during installation.

Lubricate all internal parts with clean gear oil during assembly.

10. Install parts (A—J) using the following instructions:

- Install shim (B) with the chamfer adjacent to the pinion gear.
- Install bearing cone (C) with large OD of taper toward pinion gear. Install bearing tight against shoulder of pinion shaft using a piece of pipe and a press.
- Tighten nut (J) by hand using JDG736 Spanner Wrench.  
Apply only enough force needed to just remove free play from bearings.
- DO NOT install seal (K) at this time.



- A—Pinion Shaft
- B—Shim
- C—Bearing Cone
- D—Bearing Cup
- E—Washer (2 used)
- F—Collapsible Spacer
- G—Bearing Cup
- H—Bearing Cone
- I—Washer
- J—Pinion Nut
- K—Seal
- L—Cover

LV551AE -UN-09MAR92


Continued on next page

OUC1023.0000014 -19-07APR04-3/10

11. Measure and adjust pinion bearing preload using the following method:

- Wrap a length of string (C) evenly (do not overlap) around the exposed pinion shaft (A).
- Attach a spring scale (B) to string. Pull scale firmly and evenly to measure the force required to rotate the pinion shaft.
- Read scale during rotation of the pinion shaft. Do not read scale at the point where rotation starts.
- Record the reading (rolling drag) obtained.

A—Pinion Shaft  
B—Spring Scale  
C—String



LV304A -UN-22NOV94

OUO1023.0000014 -19-07APR04-4/10

12. Attach JDG1164 Pinion Shaft Holding Fixture to pinion gear and install assembly in a vise.


**IMPORTANT: Over-tightening the pinion nut may damage the collapsible spacer.**

13. Tighten or loosen the pinion nut using JDG736 Spanner Wrench (A) until rolling drag is within specification.

**Specification**

Pinion Shaft—Rolling Drag..... 105—157 N (24—35 lb force)

14. Lock the pinion nut to the shaft by peening collar of nut into the slot on pinion shaft.




A—JDG736 Spanner Wrench

LV281 -UN-09MAR92

Continued on next page

OUO1023.0000014 -19-07APR04-5/10

50  
35  
37



A—Cap Screw (12 used)  
B—Bevel Gear  
C—Roller Bearing  
D—Differential housing (2  
halves used)

E—Drive Plate (10 used)  
F—Friction Plate (8 used)  
G—Inner Thrust Plate (2 used)

H—Bevel Gear (2 used)  
I—Spring Pin  
J—Thrust Washer (2 used)

K—Bevel Pinion (2 used)  
L—Pinion Shaft  
M—Roller Bearing

15. Assemble parts (A—M). Apply thread lock and sealer (medium strength) to threads of cap screws (A) and tighten cap screws to specification.

#### Specification

Bevel Gear Cap Screw—  
Torque..... 78 N•m (58 lb-ft)

Continued on next page

OUC1023.0000014 -19-07APR04-6/10

LV292AE -UN-09MAR92


**NOTE:** When the differential and bevel gear assembly is properly installed in the carrier housing, the bevel gear will be to the left of the pinion gear when viewed from the input shaft side of carrier housing and the carrier housing drain hole is at bottom.

16. Install differential and bevel gear assembly in the carrier housing.

17. Install end caps (C) and ring nuts (B).

**IMPORTANT:** When tightening cap screws (D), be careful not to force the bevel gear against the pinion gear. This could seriously damage the gear set.

18. Install cap screws (D) and tighten cap screws until the end caps just hold ring nuts and bearing cups in position. At the same time, carefully adjust the ring nuts to ensure the bevel gear is not forced against the pinion gear.



A—Lock Plate (2 used)  
B—Ring Nut (2 used)  
C—End Cap (2 used)  
D—Cap Screw (4 used)


LV296 -UN-09MAR92

Continued on next page

OUC1023,0000014 -19-07APR04-7/10

50  
35  
39

19. Adjust both ring nuts (C) to remove all side bearing free play.
20. Move bevel gear (B) inward toward the pinion gear by turning the left ring nut (bevel gear side) clockwise while turning the right ring nut the same amount counterclockwise. Continue moving bevel gear inward until the bevel gear fully meshes with the pinion gear (do not force the ring nuts). At the same time, keep bearings aligned by lightly hitting the end caps with a soft-faced hammer.
21. Install a dial indicator (A) with its stylus in contact with and 90° to a tooth on the bevel gear.
22. Adjust the ring nuts equally, moving the bevel gear towards or away from the pinion gear until specified backlash reading is achieved.



A—Dial Indicator  
B—Bevel Gear  
C—Ring Nut (2 used)

#### Specification

Differential Ring Gear-to-Pinion  
Gear—Backlash..... 0.16—0.21 mm (0.006—0.008 in.)

23. Tap each end cap with a soft-faced hammer to make sure end caps and bearings remain correctly positioned during the procedure.
24. Repeat steps 21—23 at two or more locations on bevel gear that are an equal distance from each other.

LV300A -UN-09MAR92


Continued on next page

OUO1023.0000014 -19-07APR04-8/10

**NOTE:** Before adjusting differential side bearing preload, the pinion bearing preload and pinion-to-bevel gear backlash must be to specification.

25. Measure differential side bearing preload using the following method:

- Wrap a length of string (C) evenly (do not overlap) around the exposed input shaft (A).
- Attach a spring scale (B) to string. Pull scale firmly and evenly to measure the force required to rotate the pinion shaft.
- Read scale during rotation of the pinion. DO NOT read scale at the point where rotation starts.
- Record the reading (rolling drag) obtained.



A—Input Shaft  
B—Spring Scale  
C—String

**NOTE:** The differential side bearing preload specification (rolling drag) is the sum of the pinion shaft rolling drag specification and the differential rolling drag.

26. Tighten both ring nuts equally to retain the backlash adjustment until specified rolling drag is achieved.

#### Specification

Pinion Shaft Plus Differential—  
Rolling Drag..... 142—213 N (32—48 lb force)

27. Tighten the end cap screws to specification.

#### Specification

End Cap Screws—Torque..... 266 N•m (196 lb-ft)

28. Recheck the backlash.

29. Install ring nut locking tabs. If nearest slot in the ring nut does not align with tab, tighten ring nut until slot aligns.

30. Recheck rolling drag.

Continued on next page

OUO1023,0000014 -19-07APR04-9/10

LV312A -UN-09MAR92

50  
35  
41

**NOTE:** *Lips of seal (A) must face toward differential when cover is installed.*

31. Install oil seal into cover (A). Apply multipurpose grease to lips of seal.
32. Apply retaining compound to OD of cover (A) to hold cover in position.
33. Install cover using a brass drift and hammer.
34. Install differential carrier. (See Remove and Install MFWD Differential Carrier Assembly in this group.)

**A—Seal and Cover**



LY294 -UN-09MAR92

OUO1023.0000014 -19-07APR04-10/10



Other Material

Number	Name	Use
TY6305 (U.S.) TY9485 (Canadian) 7649 (LOCTITE®)	Clean and Cure Primer	Cleans mating surfaces and reduces sealant curing time.
TY6304 (U.S.) TY9484 (Canadian) 518 (LOCTITE®)	Flexible Sealant	Seals creeper assembly to transmission case.

LOCTITE is a registered trademark of Loctite Corp.

OUC1043,0000EBE –19–28JUN02–1/1

Specifications

Item	Measurement	Specification
Creeper Assembly Cap Screws	Torque	50 N•m (37 lb-ft)
Rear Wheel Bolt	Torque	175 N•m (130 lb-ft)

OUC1043,0000EBF –19–28JUN02–1/1

50  
40  
1

## Remove and Install Creeper Assembly

**NOTE:** Tractor is equipped with dual selective control valve (SCV) only. Removal of creeper assembly is similar on tractors equipped with single (third) SCV option.

1. Tractors without cab: remove right rear wheel and fender.
2. Tractors with cab: remove rear cab liner behind seat.
3. Drain approximately 7.5 L (2 U.S. gal) of oil from transmission.
4. If equipped with dual SCV: remove cap screws (B) and lock pins (A) to disconnect cable assembly (C). Position cable assembly out of the way.


5. Remove shoulder bolt (F) and pedal (E).

**NOTE:** Remove suction line (H) hold-down bracket, located between pump and filter, to allow movement of suction line and line (D).

6. Remove suction line (H) hold-down bracket.

**NOTE:** Close all openings using caps and plugs.

7. Remove hose elbow (G).
8. Disconnect hydraulic line (D) located on top of SCV.




A—Clevis Lock Pins  
B—Cap Screw (2 used)  
C—Cable Assembly  
D—Inlet Housing Hydraulic Line  
E—Differential Lock Pedal  
F—Shoulder Bolt  
G—Hose Elbow  
H—Suction Line

LY194 -UN-03MAR92

Continued on next page

AG.OUO1085,210 -19-28JUN02-1/3

- 9. Remove six cap screws (A).
- 10. Separate creeper assembly (B) from transmission case. Remove creeper assembly.
- 11. Make repairs as necessary. (See Disassemble, Inspect, and Assemble Creeper Assembly in this group.)
- 12. Clean mating surface of creeper assembly and transmission case using Clean and Cure Primer. Apply a coat of Flexible Sealant to mating surfaces.
- 13. Install creeper assembly and cap screws. Tighten cap screws to specification.



LV195 -UN-03MAR92

A—Cap Screw (6 used)  
B—Creeper Assembly

**Specification**

Creeper Assembly Cap Screws—  
Torque ..... 50 N•m (37 lb-ft)

Continued on next page

AG,OUO1085,210 -19-28JUN02-2/3

14. Connect hydraulic line (D).
15. Install hose elbow (G).
16. Install suction line (H) hold-down bracket.


**IMPORTANT:** If installing an optional creeper kit assembly on a tractor that did not have one previously installed from the factory or dealer, remove stop screw (F) and replace it with a M10 x 30 mm cap screw supplied with kit. Also cut tab off range shift plate.

17. Install pedal (E) and shoulder bolt (F).
18. If equipped with dual SCV: install cable assembly (C) by installing clevis lock pins (A) and cap screws (B).
19. Tractors without cab: install fender and wheel. Tighten rear wheel bolts to specification.

#### Specification

Rear Wheel Bolt—Torque ..... 175 N•m (130 lb-ft)


20. Install rear cab liner if removed.
21. Fill transmission with specified transmission/hydraulic oil. (See Transmission and Hydraulic Oil in Section 10, Group 20)



- A—Clevis Lock Pins
- B—Cap Screw (2 used)
- C—Cable Assembly
- D—Inlet Housing Hydraulic Line
- E—Differential Lock Pedal
- F—Shoulder Bolt
- G—Hose Elbow
- H—Suction Line

AG,OUO1085,210 -19-28JUN02-3/3

## Disassemble, Inspect, and Assemble Creeper Assembly



Creeper Assembly

A—Snap Ring	F—Bearing	K—Lock Washer	P—Needle Bearing
B—Washer	G—Shaft	L—Screw	Q—Gear
C—Bearing	H—Housing	M—Washer	R—Gear
D—Drive Gear	I—Cap Screw	N—Snap Ring	S—Washer
E—Spacer	J—Washer	O—Gear	T—Shaft

**NOTE:** Bearings (C and F) are press fit on shaft (G).

1. Remove snap ring (A) and washer (B).
2. Remove shaft (G) using a brass drift and hammer on end of shaft that snap ring was removed from.
3. Remove parts (C—E) and (I, J, and F).
4. Remove screw (L) and lock washer (K). Remove shaft (T).
5. Remove parts (M—S).
6. Remove snap ring (N) and remove gear (O) from gear (Q).
7. Inspect all parts for wear or damage. Replace as necessary.
8. Lubricate all parts with clean transmission/hydraulic oil during assembly.
9. Assemble all parts.



# Section 60

## Steering and Brake Repair

### Contents

	Page
<b>Group 05—Steering Repair</b>	
Other Material . . . . .	60-05-1
Specifications . . . . .	60-05-1
Service Parts Kits . . . . .	60-05-2
Remove and Install Steering Column and Valve . . . . .	60-05-3
Disassemble and Inspect Steering Valve. . . . .	60-05-4
Assemble Steering Valve . . . . .	60-05-7
Remove and Install Steering Cylinder—2WD Axle . . . . .	60-05-11
Disassemble, Inspect, and Assemble Steering Cylinder—2WD Axle . . . . .	60-05-12
Remove and Install Steering Cylinder—MFWD Axle . . . . .	60-05-13
Disassemble, Inspect, and Assemble Steering Cylinder—MFWD Axle . . . . .	60-05-15
Remove, Inspect and Install Tie Rod Assembly—2WD Axle . . . . .	60-05-16
Remove, Inspect and Install Tie Rod Assembly—MFWD Axle. . . . .	60-05-17
Inspect and Replace Steering Hydraulic Lines—Without Oil Cooler . . . . .	60-05-18
Inspect and Replace Steering Hydraulic Lines—With Oil Cooler. . . . .	60-05-20
<b>Group 10—Brake Repair</b>	
Other Material . . . . .	60-10-1
Specifications . . . . .	60-10-1
Remove and Install Brake Valve and Pedals. . . . .	60-10-2
Disassemble and Inspect Brake Valve . . . . .	60-10-4
Brake Valve Cross Section . . . . .	60-10-7
Assemble Brake Valve . . . . .	60-10-8
Remove and Inspect Brakes . . . . .	60-10-10
Install Brakes . . . . .	60-10-12
Inspect and Replace Brake Hydraulic Lines . . . . .	60-10-15





## Other Material

Number	Name	Use
T43512 (U.S.) TY9473 (Canadian) 242 (LOCTITE®)	Thread Lock and Sealer (Medium Strength)	2WD Steering Cylinder Mounting Cap Screws
TY6333 (U.S.) TY6347 (U.S.)	Moly High Temperature EP Grease	Apply to mating surfaces of steering cylinder and differential case

LOCTITE is a trademark of Loctite Corp.

OUO1080,0000279 -19-03JUL02-1/1

## Specifications

Item	Measurement	Specification
Steering Column-to-Support Cap Screws	Torque	71 N•m (52 lb-ft)
Steering Wheel Nut	Torque	68 N•m (50 lb-ft)
Steering Valve Cover-to-Steering Valve Cap Screws	Torque	30 N•m (22 lb-ft)
Steering Cylinder Cap Screws (2WD)	Torque	200 N•m (147 lb-ft)
Steering Cylinder Cap Screws (MFWD)	Torque	94 N•m (69 lb-ft)
Ball Joint-to-Piston Rod	Torque	300 N•m (221 lb-ft)
Tie Rod-to-Inner Sleeve Cap Screws	Torque	90 N•m (66 lb-ft)
Tie Rod Lock Nut	Torque	165 N•m (122 lb-ft)
Ball Joint Jam Nut	Torque	120 N•m (89 lb-ft)

OUO1080,000024D -19-26JUN02-1/1

60  
05  
1

## **Service Parts Kits**

The following kits are available through your parts catalog:

Steering Valve Seal Kit

Steering Cylinder Seal Kit

AG,OUO1023,367 -19-25AUG00-1/1

## Remove and Install Steering Column and Valve

1. Remove steering wheel.

**NOTE:** Straight steering column is shown. Removal and installation of tilt steering column is the same.

Wiring harness and relay blocks are removed for clarity of photograph.

2. Remove instrument panel and dash panels. See Replace Instrument Panel—CollarShift/SyncShuttle™ Transmission or Replace Instrument Panel—PowrReverser™ Transmission in Section 40, Group 10.
3. Disconnect hydraulic lines (C).

**IMPORTANT:** Support steering valve before removing mounting cap screws. When cap screws are removed, steering column and valve are separated.

4. Remove four cap screws (B), steering column (A), and valve and O-ring (D).

**NOTE:** Straight steering column is non-serviceable.


5. Inspect steering column for wear or damage. Replace if necessary.
6. Make repairs as necessary to steering valve. (See Disassemble and Inspect Steering Valve in this group.)

**IMPORTANT:** Always use new O-rings. Damaged or used O-rings will leak.

7. Install steering valve with new O-ring, steering column, and cap screws. Do not tighten cap screws at this time.
8. Connect hydraulic lines.
9. Tighten cap screws (B) to specification.

### Specification

Steering Column-to-Support Cap  
Screws—Torque ..... 71 N•m (52 lb-ft)



A—Steering Column  
B—Cap Screw (4 used)  
C—Hydraulic Line  
D—Steering Valve and O-Ring

LV361 -UN-09MAR92

60  
05  
3

Continued on next page

AG,OUO1085,219 -19-25AUG00-1/2

10. Install dash panels and instrument panel.
11. Install steering wheel. Tighten steering wheel nut to specification.

**Specification**

Steering Wheel Nut—Torque ..... 68 N•m (50 lb-ft)

AG,OUO1085,219 -19-25AUG00-2/2


**Disassemble and Inspect Steering Valve**

*NOTE: Special cap screw (B) is identified by the raised center of hex head.*

1. Remove six cap screws and washers (A) and special cap screw and washer (B).


A—Cap Screw (6 used)

B—Special Cap Screw and Washer



LV000 -UN-09MAR92

AG,OUO1085,220 -19-25AUG00-1/8



LV2218 -UN-01JUL97

A—Cover  
B—O-Ring

C—Gerotor Set  
D—Drive Shaft

E—Distributing Plate

F—O-Ring


2. Remove parts (A—F).

Continued on next page

AG,OUO1085,220 -19-25AUG00-2/8

3. Remove threaded bushing (A) and ball (B).

A—Threaded Bushing  
B—Ball



AG.OUO1085,220 -19-25AUG00-3/8

LV008 -UN-09MAR92

**IMPORTANT:** If spool and sleeve assembly must be removed from valve body for cleaning, handle parts with care. Tolerances on these parts are very close. When replacement is necessary, the spool, sleeve, and valve body must be replaced as a set.

Use care so not to drop or lose parts when removing sleeve and spool assembly. Keep cross pin in assembly horizontal.

4. Push and turn sleeve and spool assembly (A) to remove from valve body.

*NOTE: Thin bearing race may remain in valve body.*

5. Remove parts (B—D).



A—Spool and Sleeve Assembly  
B—Thick Bearing Race  
C—Needle Bearing  
D—Thin Bearing Race

Continued on next page

AG.OUO1085,220 -19-25AUG00-4/8

LV009 -UN-09MAR92

60  
05  
5


6. Remove cross pin (A) and ring (B).

7. Carefully slide spool (C) from sleeve (D).

**NOTE:** Spring set consists of two flat and four curved leafs.

8. Push spring set (E) from spool.

A—Cross Pin  
B—Ring  
C—Spool  
D—Sleeve  
E—Spring




LV010 -UN-09MAR92

AG,OUO1085,220 -19-25AUG00-5/8

9. Remove dust seal (A), kin-ring (B), and O-ring (C).

A—Dust Seal  
B—Kin-Ring  
C—O-Ring



LV011 -UN-09MAR92


AG,OUO1085,220 -19-25AUG00-6/8

**IMPORTANT:** If relief valve is removed, steering relief valve pressure must be checked and adjusted.

Relief valve seat in valve body is not serviceable. Valve body, spool, and sleeve must be replaced as a set if relief valve seat is damaged.

**NOTE:** Count the number of turns needed to remove plug (B). This will help to initially set relief valve pressure at assembly.

10. Remove parts (A—D) to inspect and clean relief valve. Be sure orifice in piston (D) is free of obstruction.



A—Plug and O-Ring  
B—Adjustable Plug  
C—Spring  
D—Piston

LV012 -UN-09MAR92


Continued on next page

AG,OUO1085,220 -19-25AUG00-7/8



11. Remove hydraulic fitting from inlet port to inspect check valve (A). Remove any obstructions from check valve. If check valve is worn or damaged, valve body, spool, and sleeve must be replaced as a set.
12. Install and tighten hydraulic fitting.
13. Inspect all parts for scoring, wear, or damage. Replace as necessary.

A—Check Valve



LV013 -UN-09MAR92

AG.OUO1085,220 -19-25AUG00-8/8


## Assemble Steering Valve

**NOTE:** Apply clean transmission/hydraulic oil to all internal parts.

**IMPORTANT:** Always replace all O-rings and seals. Damaged or used parts will leak.

1. Install parts (A—D). Install plug (B) the same number of turns as needed to remove the plug.

A—Plug and O-Ring  
B—Adjustable Plug  
C—Spring  
D—Piston




LV012 -UN-09MAR92

AG.OUO1085,221 -19-25AUG00-1/7

2. Install dust seal (A) with seal lip away from valve body and to bottom of bore.

A—Dust Seal




LV014 -UN-09MAR92

Continued on next page


AG.OUO1085,221 -19-25AUG00-2/7

3. Install two flat leaves of spring set (E) in slot of spool (C). Install curved leaves so their centers touch and curved leaves fit between the flat leaves.
4. Slide spool and springs into sleeve (D). Squeeze spring ends together so springs fit into slot of sleeve. Make sure leaf ends are aligned and centered.
5. Install ring (B) with rounded end away from sleeve. Ring must rotate freely on sleeve.
6. Install pin (A).



LV010 -UN-09MAR92

A—Cross Pin  
B—Ring  
C—Spool  
D—Sleeve  
E—Spring Set




LV015 -UN-09MAR92

LV016AE -UN-13MAR92


AG,OUO1085,221 -19-25AUG00-3/7

7. Install parts (B—D) on spool and sleeve assembly (A). Inner chamfer of thick bearing race (B) must be towards spool.
8. Put O-ring (E) on kin-ring (F). Install O-ring and kin-ring on spool just past spool chamfer.
9. Put spool and sleeve assembly in valve body using a turning motion. Position the cross pin so it is parallel to surface of valve body with hose connections. Push assembly into body until end of assembly is even with machined surface of valve body.



LV017 -UN-09MAR92

A—Spool and Sleeve Assembly  
B—Thick Bearing Race  
C—Needle Bearing Race  
D—Thin Bearing Race  
E—O-Ring  
F—Kin-Ring




LV018AE -UN-09MAR92

Continued on next page

AG,OUO1085,221 -19-25AUG00-4/7


10. Install ball (B) and threaded bushing (A). Top of bushing must be below surface of valve body.

A—Threaded Bushing  
B—Ball



LV008 -UN-09MAR92

AG,OUO1085,221 -19-25AUG00-5/7



LV2218 -UN-01JUL97

A—Cover  
B—O-Ring (2 used)

C—Gerotor Set  
D—Drive Shaft

E—Distributing Plate

F—O-Ring

11. Install parts (B—F).

**IMPORTANT: Violent steering wheel oscillation can occur if gerotor is not timed correctly.**

12. Make sure gerotor is timed. Install inner rotor of gerotor so that the center of a valley of the rotor is

aligned with the center line of the cross pin. Turn outer gear of gerotor until holes are aligned.

13. Install cover (A).

Continued on next page

AG,OUO1085,221 -19-25AUG00-6/7

14. Install six washers and cap screws (A) and washer and special cap screw (B). Tighten cap screws in crisscross sequence as indicated to specification.

**Specification**



Steering Valve Cover-to-Steering

Valve Cap Screws—Torque ..... 30 N•m (22 lb-ft)

15. If relief valve was removed, relief valve pressure must be checked and adjusted after installing steering valve on tractor. (See Steering Valve Relief Test in Section 260, Group 15.)

A—Cap Screw (6 used)

B—Special Cap Screw



LV000 -JUN-09MAR92

M53502 -JUN-20NOV89

AG,OUO1085,221 -19-25AUG00-7/7

## Remove and Install Steering Cylinder—2WD Axle


1. Remove tie rod ends (C). (See Remove, Inspect and Install Tie Rod Assembly—2WD Axle in this group.)
2. Disconnect hoses (A). Close all openings using caps and plugs.
3. Remove cap screws and lock washers (B) from both ends of cylinder. Remove cylinder.
4. Make repairs as necessary. (See Disassemble, Inspect, and Assemble Steering Cylinder—2WD Axle in this group.)
5. Apply thread lock and sealer (medium strength) to threads of cap screws (B).
6. Install steering cylinder, lock washers, and cap screws. Tighten cap screws to specification.

### Specification

Steering Cylinder Cap Screws  
(2WD)—Torque ..... 200 N•m (147 lb-ft)

**IMPORTANT: Always replace all O-rings. Damaged or used O-rings will leak.**

7. Install new O-rings and connect hydraulic hoses.
8. Install tie rod ends.
9. Start engine. Operate steering and check for hydraulic leaks.




Right-Hand Side Shown

A—Hose  
B—Cap Screw and Lock Washer  
C—Tie Rod End

AG.OUO1085,222 -19-25AUG00-1/1

60  
05  
11

## Disassemble, Inspect, and Assemble Steering Cylinder—2WD Axle



A—Rod Guide (2 used)

B—Cylinder Barrel

C—Rod and Piston Assembly

D—Wiper Seal (2 used)

E—Split Wear Ring (4 used)

F—Backup Ring (2 used)

G—Seal (2 used)

H—Ring Seal (2 used)

I—O-Ring

J—Split Wear Ring

K—Piston Seal

**NOTE:** Ball joints must be removed from steering cylinder rod for cylinder disassembly.

1. Pull rod guides (A) from cylinder barrel (B) and remove from rod and piston assembly (C).
2. Pull rod and piston assembly from barrel.
3. Remove two wear rings (E), seal (G), backup ring (F), wiper seal (D), and ring seal (H) from each guide.
4. Remove piston seal (K), wear ring (J), and O-ring (I).

5. Inspect rod and barrel for scoring, wear, or damage. Replace cylinder if necessary.

6. Install new seals and wear rings.
7. Apply clean transmission/hydraulic oil to all internal parts during assembly.
8. Install rod and piston assembly into barrel.
9. Carefully install rod guides on rod and in barrel so as not to damage seals.

AG,OUO1085,223 -19-25AUG00-1/1


LV002AE -UN-09MAR92

## Remove and Install Steering Cylinder—MFWD Axle


1. Turn the front wheels all the way to the right. This will allow room for removal of steering assembly.
2. Loosen cap screws (B) by two turns each.
3. Turn the steering wheel to left. This will unseat the end cap and cylinder from the differential casing.
4. Disconnect hoses (A). Close all openings using caps and plugs.
5. Remove tie rod ends (C). (See Remove, Inspect and Install Tie Rod Assembly—MFWD Axle in this group.)
6. Remove hydraulic fitting on right-hand side of cylinder.
7. Remove cap screws.

**IMPORTANT:** Steering cylinder may be seized to differential case. Do not strike cylinder end near edges (D and E). Striking at these points can distort wiper seal area or cause distortion of outer edge, preventing removal of cylinder. Use a brass drift and hammer to remove cylinder.

8. Remove steering cylinder assembly using a brass drift and hammer, if necessary.
9. Make repairs as necessary. (See Disassemble, Inspect, and Assemble Steering Cylinder—MFWD Axle in this group.)
10. Apply Moly High Temperature EP Grease to mating surfaces of steering cylinder and differential case. Install cylinder with hydraulic fitting port (F) facing front of machine.
11. Install the steering cylinder assembly.



LV297 -UN-09MAR92



LV631 -UN-17JUN94

- A—Steering Hose  
 B—Cap Screw (4 used)  
 C—Tie Rod End  
 D—Cylinder Inner Edge  
 E—Cylinder Outer Edge  
 F—Hydraulic Fitting Port

Continued on next page

AG,OUO1085,224 -19-25AUG00-1/2



12. Install cap screws and tighten to specification.

**Specification**

Steering Cylinder Cap Screws  
(MFWD)—Torque ..... 94 N•m (69 lb-ft)

**IMPORTANT: Always replace all O-rings. Damaged or used O-rings will leak.**

13. Install new O-ring and hydraulic fitting.


14. Install new tie rod ends.

15. Install new O-rings and connect hydraulic hoses.

16. Start engine. Operate steering and check for hydraulic leaks.

AG,OUO1085,224 -19-25AUG00-2/2

## Disassemble, Inspect, and Assemble Steering Cylinder—MFWD Axle



A—Wiper Seal (2 used)  
B—O-Ring  
C—Wear Ring (2 used)

D—Piston Seal  
E—O-Ring

F—Rod and Piston Assembly  
G—Oil Seal (2 used)

H—Cylinder Barrel  
I—End Plate

1. Remove parts (A—I).
2. Inspect rod and barrel for wear or damage. Replace as necessary.
3. Install new seals and wear rings.
4. Apply clean transmission/hydraulic oil to all parts during assembly.

**NOTE:** Allow the center piston seal to contract naturally on top of the O-ring before installing the piston and rod assembly into the cylinder barrel.


5. Install all parts.

AG,OUO1085,225 -19-25AUG00-1/1

LV299A -UN-09MAR92

60  
05  
15

## Remove, Inspect and Install Tie Rod Assembly—2WD Axle



LV001AE -UN-08JUL02

A—Lock Nut (2 used)  
B—Right Tie Rod End

C—Cap Screw (4 used)  
D—Inner Sleeve (2 used)

E—Rod (2 used)  
F—Ball Joint (2 used)

G—Left Tie Rod End  
H—Lock Nut (4 used)

**NOTE:** Tie rod end is a tapered bore fit. Use a ball joint fork or puller to ease removal.

1. Remove lock nut (A). Remove tie rod end from spindle arm.
2. Inspect parts (A—H) for wear or damage.

**NOTE:** To replace ball joints (F), use a standard 46-mm wrench on flats on both ball joints. Turn one side while holding the other.

3. Remove parts (B—H) as necessary for replacement.
4. Apply a small amount of Moly High Temperature EP Grease to outer surface of rod (E) and inner sleeve (D).
5. Install parts (B—H). Tighten ball joint (F) to specification.

**Specification**

Ball Joint-to-Piston Rod—  
Torque..... 300 N•m (221 lb-ft)

6. Adjust length of tie rod (E) assembly by positioning inner sleeve (D) so wheel is approximately straight forward when steering cylinder is centered and tie rod end fits into arm of spindle. Tighten cap screws (C) to specification.

**Specification**

Tie Rod-to-Inner Sleeve Cap  
Screws—Torque ..... 90 N•m (66 lb-ft)

7. Tighten lock nuts (H) securely.
8. Install and tighten lock nut (A) to specification.

**Specification**

Tie Rod Lock Nut—Torque..... 165 N•m (122 lb-ft)


Continued on next page

AG.OUO1085,226 -19-25AUG00-1/2

9. Adjust front axle toe-in. (See Toe-In Check and Adjustment—Standard Axle in Section 260, Group 15.)

AG,OUO1085,226 -19-25AUG00-2/2

Remove, Inspect and Install Tie Rod Assembly—MFWD Axle



A—Left Tie Rod End  
B—Nut (2 used)

C—Ball Joint (2 used)  
D—Right Tie Rod End

E—Boot

F—Lock Nut (2 used)

1. Remove lock nut (F). Remove tie rod from spindle arm.
2. Inspect parts (A—E) for wear or damage.

*NOTE: To remove ball joint (C), place wrench on flats of both ball joints. Turn one side while holding the other.*

3. Remove parts (A—E) as necessary for replacement.
4. Install parts (A—F). Tighten ball joint (C) to specification.

Specification

Ball Joint-to-Piston Rod—  
Torque..... 300 N•m (221 lb-ft)

5. Adjust length of tie rod assembly by turning tie rod end (A or D) so wheel is approximately straight forward when steering cylinder is centered and tie rod end fits into arm spindle. Tighten nut (B) to specification.

Specification

Ball Joint Jam Nut—Torque ..... 120 N•m (89 lb-ft)

6. Install and tighten lock nut (F) to specification.


Specification

Tie Rod Lock Nut—Torque..... 165 N•m (122 lb-ft)

7. Adjust front axle toe-in. (See Toe-In Check and Adjustment—MFWD in Section 260, Group 15.)

AG,OUO1085,227 -19-25AUG00-1/1

## Inspect and Replace Steering Hydraulic Lines—Without Oil Cooler



A—Pressure Line-to-Steering Cylinder

B—Hydraulic Pump-to-Steering Valve Supply Line

C—Pressure Line-to-Steering Cylinder

D—Stud (2 used)

E—Clamp (4 used)

F—Bracket (2 used)

G—Steering Valve-to-Cylinder Hose (2 used)

H—O-Ring (5 used)

I—Connector

J—O-Ring (3 used)

K—Fitting (2 used)

L—Clamp (2 used)

M—Steering Valve Return/Transmission Lube Line

N—O-Ring

O—Fitting

**NOTE:** If equipped with cab, lower front cab windows must be removed before removing dash panels. (See Remove and Install Lower Front Windows in Section 90, Group 15.)

1. Remove left and right dash panels and front grille panels.

**NOTE:** Remove brake pedals to replace hydraulic lines (B and M).

Remove fuel filter and disconnect brake lines to replace hydraulic line (B).

2. Inspect hydraulic lines and hoses for wear or damage. Replace as necessary.

**IMPORTANT:** Replace all O-rings. Damaged or used O-rings will leak.


3. Install side dash and grille panels.

4. Adjust hydraulic oil level to full mark with proper oil. (See Transmission and Hydraulic Oil in Section 10, Group 20.)

LV458AE -JUN-03MAY01



# Inspect and Replace Steering Hydraulic Lines—With Oil Cooler



Steering Hydraulic Lines (With Oil Cooler)

Continued on next page

AG.OUO1085,320 -19-29AUG00-1/2



1—Steering Valve Supply Line	10—Oil Cooler Inlet Line	18—Steering Cylinder Pressure Line	25—Steering Valve-to-Steering Pressure Line
2—Steering Valve Return Line	11—Oil Cooler Outlet Line	19—Steering Valve-to-Steering Pressure Line	26—Transmission Return Lube Line
3—Pressure Line-to-Steering Cylinder	12—Nut (2 used)	20—Bracket	27—Cap Screw
4—Pressure Line-to-Steering Cylinder	13—Hydraulic Oil Cooler	21—Nut (2 used)	28—Clamp
5—O-Ring (11 used)	14—Oil Cooler Return/Transmission Lube Line	22—Washer	29—O-Ring
6—Steering Valve-to-Hydraulic Oil Cooler	15—O-Ring (4 used)	23—Stud	30—Hydraulic Pump-to-Steering Valve Supply Line
7—Clamp (4 used)	16—Elbow Connector	24—Oil Cooler Outlet-to-Transmission Return Line	31—O-Ring
8—Cap Screw	17—Steering Cylinder Pressure Line		
9—Steering Valve-to-Oil Cooler Inlet			

*NOTE: If equipped with cab, lower front cab windows must be removed before removing dash panels. (See Remove and Install Lower Front Windows in Section 90, Group 15.)*

1. Remove left and right dash and front grille panels.

*NOTE: Remove brake pedals to replace hydraulic lines (1 and 2). Remove fuel filter and disconnect brake lines to replace hydraulic line (30).*

2. Inspect hydraulic lines and hoses for wear or damage. Replace as necessary.

**IMPORTANT: Replace all O-rings. Damaged or used O-rings will leak.**

3. Install side dash and grille panels.
4. Adjust hydraulic oil level to full mark with proper oil. (See Transmission and Hydraulic Oil in Section 10, Group 20.)

60  
05  
22

Other Material

Number	Name	Use
TY9371 (U.S.) TY9478 (Canadian) 271 (LOCTITE®)	Thread Lock and Sealer (High Strength)	Apply to threads of brake return compression spring assemblies.

LOCTITE is a registered trademark of Loctite Corp.

OUO1080,0000250 –19–26JUN02–1/1

Specifications

Item	Measurement	Specification
Brake Valve Mounting Cap Screws	Torque	70 N•m (52 lb-ft)
Brake Valve Outlet Fittings	Torque	11 N•m (97 lb-in.)
Brake Valve Inlet Check Valve Seat	Torque	73 N•m (54 lb-ft)
Brake Valve Plug	Torque	37 N•m (27 lb-ft)
Brake Valve Spring Seat	Torque	92 N•m (68 lb-ft)
Brake Retractor Spring	Torque	15 N•m (133 lb-in.)
Mating Surface of Final Drive Housing to Face of Piston	Distance	12.40—12.80 mm (0.488—0.503 in.)

60101

OUO1080,0000251 –19–26JUN02–1/1

## Remove and Install Brake Valve and Pedals


1. Tractors without cab: remove left and right dash panels.

*NOTE: Close all openings with caps and plugs.*

2. Disconnect return and supply hoses (B and C).
3. Disconnect brake lines (D).

*NOTE: Outlet fittings are removed to allow clearance for brake valve removal.*

*Use care during valve removal to prevent loss of check balls and springs from outlet fitting ports.*



LV362 -UN-09MAR92

A—Outlet Fittings  
B—Return Hose  
C—Supply Hose  
D—Brake Lines

4. Remove outlet fittings (A).
5. Remove four cap screws and brake valve.
6. Make repairs as necessary. (See Disassemble and Inspect Brake Valve in this group.)
7. Install brake valve. Tighten cap screws to specification.

### Specification

Brake Valve Mounting Cap  
Screws—Torque..... 70 N•m (52 lb-ft)

**IMPORTANT: Replace O-rings. Damaged or used O-rings will leak.**

8. Install outlet fittings (A) with new O-rings. Tighten fittings to specification.

### Specification

Brake Valve Outlet Fittings—  
Torque ..... 11 N•m (97 lb-in.)

9. Connect hoses and lines.
10. Install dash panels if removed.
11. Start engine. Run at idle speed for several minutes to fill brake valve with transmission/hydraulic oil. Shut off engine.



Continued on next page

AG,OUO1085,321 -19-30AUG00-1/2

12. Apply pressure to both brake pedals and loosen brake lines (D) slightly, to bleed air from brake valve and lines.
13. Repeat as necessary.
14. Check and adjust transmission/hydraulic oil level.

AG,OUO1085,321 -19-30AUG00-2/2

## Disassemble and Inspect Brake Valve



A—Left Brake Pedal  
B—Bushings (2 used)  
C—Cotter Pin

D—Pivot Shaft  
E—Right Brake Pedal  
F—Lock Plate

G—Left Brake Pedal (cab tractors only)

H—Right Brake Pedal (cab tractors only)

1. Remove left and right dash panels.

**NOTE:** Cab tractors are equipped with brake pedals (G and H) in place of brake pedals (A and E).

2. Disengage lock plate (F).

3. Remove cotter pin (C) to remove shaft (D) and pedals (A and E).


**NOTE:** Bushings (B) are press fit in pedals. Remove bushings only if replacement is necessary.

4. Inspect parts for wear or damage. Replace as necessary.

Continued on next page

AG, OOU1085,322 -19-30AUG00-1/3

LV568AE -JUN-07FEB96



Brake Valve

A—Plug  
 B—Cap Screw (2 used)  
 C—Nut (2 used)  
 D—Bracket  
 E—Cap Screw (4 used)  
 F—Elbow Fitting (2 used)  
 G—O-Ring (2 used)  
 H—Inlet Check Valve Seat (2 used)

I—O-Ring (2 used)  
 J—Inlet Check Valve (2 used)  
 K—Spring (2 used)  
 L—O-Ring (2 used)  
 M—Spring Seat (2 used)  
 N—Outlet Check Ball (2 used)  
 O—Spring (2 used)

P—O-Ring (2 used)  
 Q—Outlet Fitting (2 used)  
 R—Pressure Equalizing Ball (2 used)  
 S—Spring (2 used)  
 T—O-Ring (2 used)  
 U—Plug (2 used)

V—Outlet Check Valve (2 used)  
 W—Spring (2 used)  
 X—Brake Piston (2 used)  
 Y—O-Ring (2 used)  
 Z—Seal (2 used)

5. Remove parts (E—K).

6. Remove parts (R—U).

Continued on next page

AG,OUO1085,322 -19-30AUG00-2/3



*NOTE: Parts (D, E, P, and Q) were removed during brake valve removal.*



**CAUTION: Spring seats (M) are under spring pressure. Hold seat firmly while removing.**

7. Remove parts (L—O) and (V—Y).


**IMPORTANT: Replace all seals. Damaged or used seals will leak.**

8. Pry out seals (Z). Install new seal with lips facing away from valve using a bearing, bushing, and seal driver set.

9. Inspect all parts for wear or damage. Replace as necessary.

AG,OUO1085,322 -19-30AUG00-3/3

# Brake Valve Cross Section



A—Spring (2 used)  
 B—Outlet Check Valve (2 used)  
 C—Spring (2 used)  
 D—O-Ring (2 used)  
 E—Inlet Check Valve (2 used)

F—Inlet Check Valve Seat (2 used)  
 G—Plug  
 H—Seal (2 used)  
 I—Spring (2 used)  
 J—Brake Piston (2 used)

K—O-Ring (2 used)  
 L—Pressure Equalizing Ball (2 used)  
 M—Spring (2 used)  
 N—O-Ring (2 used)  
 O—Plug (2 used)

P—Outlet Check Ball (2 used)  
 Q—O-Ring (2 used)  
 R—Spring Seat (2 used)  
 S—O-Ring (2 used)  
 T—Fitting (2 used)

60  
10  
7

LV570AE -UN-09MAR92

## Assemble Brake Valve

**NOTE:** Lubricate all internal parts with clean transmission/hydraulic oil during assembly.

**IMPORTANT:** Replace all O-rings. Damaged or used O-rings will leak.


**Inlet check valves must be installed before brake pistons to ensure proper position of check valve in relation to piston.**

1. Install new O-rings (B and D).
2. Install spring (F), check valve (E), and valve seat (C). Tighten seat to specification.

### Specification

Brake Valve Inlet Check Valve  
Seat—Torque ..... 73 N•m (54 lb-ft)

3. Install fitting (A).



A—Elbow Fitting (2 used)  
B—O-Ring (2 used)  
C—Inlet Check Valve Seat (2 used)  
D—O-Ring (2 used)  
E—Inlet Check Valve (2 used)  
F—Spring (2 used)

LV019 -UN-09MAR92


AG,OUO1085,324 -19-30AUG00-1/4

4. Install new O-ring (B).
5. Install ball (D), spring (C), and plug (A). Tighten plug to specification.

### Specification

Brake Valve Plug—Torque..... 37 N•m (27 lb-ft)

A—Plug (2 used)  
B—O-Ring (2 used)  
C—Spring (2 used)  
D—Pressure Equalizing Ball (2 used)




LV020 -UN-09MAR92

Continued on next page

AG,OUO1085,324 -19-30AUG00-2/4

6. Install new O-rings (A).
7. Apply multipurpose grease to lips of seals (B).

A—O-Ring  
B—Seal



LV022 -UN-09MAR92

AG.OUO1085,324 -19-30AUG00-3/4

8. Install new O-ring (B).
9. Install parts (C—H). Tighten spring seat (C) to specification.


**Specification**

Brake Valve Spring Seat—Torque ..... 92 N•m (68 lb-ft)

*NOTE: Install fittings (A) loosely. Fittings are removed for brake valve installation.*

10. Install new O-ring and fitting (A). Tighten fitting finger tight.
11. Install brake pedals, pivot shaft, and cotter pin.
12. Adjust brake pedals. (See Brake Pedal Adjustment in Section 260, Group 15.)

A—Outlet Fitting (2 used)  
B—O-Ring (2 used)  
C—Spring Seat (2 used)  
D—Spring (2 used)  
E—Outlet Check Ball (2 used)  
F—Outlet Check Valve (2 used)  
G—Spring (2 used)  
H—Brake Piston (2 used)



60  
10  
9

LV021 -UN-09MAR92

AG.OUO1085,324 -19-30AUG00-4/4

## Remove and Inspect Brakes

1. Remove final drive assembly. (See Remove and Install Final Drive Assembly in Section 50, Group 30.)


2. Remove back plate (A) and friction disc (B).

*NOTE: Piston assembly is press fit into final drive housing. Remove only if necessary.*

3. Remove piston assembly (C) using a pry bar. Pry at three retractor locations (D) evenly until piston assembly is removed.


4. Inspect piston ring and piston ring bore in axle housing for scoring or damage.

- A—Back Plate
- B—Friction Disc
- C—Piston Assembly
- D—Retractor (3 used)



LV2402 —UN-16DEC97


Left-Hand Side Shown



LV2403 —UN-16DEC97

Continued on next page

AG,OUO1085,325 —19-30AUG00-1/2



A—Outer O-Ring  
B—Inner O-Ring

C—Retractor Spring (3 used)  
D—Piston

E—Friction Disc

F—Back Plate

**IMPORTANT:** Always use new O-rings. Damaged or used O-rings will leak.

5. Replace the inner and outer O-rings (A and B).

*NOTE:* Retractor springs (C) are threaded into piston (D).

6. Remove retractor spring (C).


7. Inspect parts (A—F) for wear or damage. Check piston (D) and plate (F) for warpage. Replace parts as necessary.

AG,OUO1085,325 -19-30AUG00-2/2

LV2396 -UN-16DEC97

60  
10  
11

## Install Brakes



A—Outer O-Ring  
B—Inner O-Ring

C—Retractor Spring (3 used)  
D—Piston

E—Friction Disc

F—Back Plate

1. Apply thread lock and sealer (high strength) to threads of return retractor spring (C).
2. Install retractor spring (C) into piston (D). Tighten to specification.

3. Install new O-rings (A and B). Apply hydraulic oil to inside and outside diameter of piston (D).

### Specification

Brake Retractor Spring—  
Torque..... 15 N•m (133 lb-in.)

Continued on next page

AG,OUO1085,326 -19-30AUG00-1/3

LV2396 -UN-16DEC97



4. Install piston (A) into final drive housing using a cross beam (B) from a bushing, bearing, and seal driver set or equivalent type set-up, to drive retractors and piston into final drive housing.

5. Remove cross beam set-up (B).

**IMPORTANT: Seat retractors and piston to specification (E) as shown. If not seated to specification damage will occur.**

6. Place a deep socket on each retractor and hit evenly using a soft-faced hammer, until retractors and piston are seated in final drive housing. Seat to specification.

**Specification**


Mating Surface of Final Drive

Housing to Face of Piston—


Distance..... 12.40—12.80 mm (0.488—0.503 in.)

7. Using a depth gauge, measure the distance from the mating surface of final drive housing (C) to face of piston (D). When properly seated, measurement (E) will be 12.40 mm (0.488 in.) to 12.80 mm (0.503 in.).

A—Piston  
B—Cross Beam  
C—Mating Surface of Final Drive Housing  
D—Piston Face  
E—Measurement Specification



LV2404 -UN-16DEC97



LV2405 -UN-16DEC97

Continued on next page


AG.OUO1085,326 -19-30AUG00-2/3

60  
10  
13

**IMPORTANT:** Back plate (A) is machined on one side only. Plates must be installed so that machined side of plate (A) is facing friction disc (B).

8. Install friction disc (B) and back plate (A) with machined side facing friction disc.
9. Install final drive assembly. (See Remove and Install Final Drive Assembly in Section 50, Group 30.)


A—Back Plate  
B—Friction Disc



LV2402 -UN-16DEC97

AG,OUO1085,326 -19-30AUG00-3/3

# Inspect and Replace Brake Hydraulic Lines



A—Hose Clamp (4 used)  
B—Steering Valve  
C—Brake Valve Return Hose  
D—Line Clamp (4 used)  
E—Pressure Line from Brake Valve

F—O-Rings (4 used)  
G—Pressure Line-to-Left-Hand Brakes  
H—Pressure Line from Brake Valve

I—Bushing  
J—Line Clamp  
K—Pressure Line-to-Right-Hand Brake  
L—Fitting (2 used)

M—O-Ring (2 used)  
N—Brake Valve Return Line  
O—O-Ring  
P—Fitting  
Q—O-Ring

**NOTE:** 5210 and 5310 tractor shown. 5410 and 5510 tractors are similar.

*If equipped with cab, lower front cab windows must be removed before removing dash panels. (See Remove and Install Lower Front Windows in Section 90, Group 15.)*

1. Remove right and left dash panels.
2. Inspect hydraulic lines and hoses for wear or damage. Replace as necessary.

**IMPORTANT:** Replace all O-rings. Damaged or used O-rings will leak.

3. Install dash panels.
4. Bleed brakes. (See Bleed Brake System in Section 260, Group 15.)
5. Install lower front cab windows, if removed.
6. Check transmission/hydraulic oil level, add fluid if necessary. (See Transmission and Hydraulic Oil in Section 10, Group 20.)

LV2131 -UN-09JUN97

60  
10  
15



# Section 70

## Hydraulic Repair

### Contents

	Page		Page
<b>Group 05—Hydraulic Pump and Filter</b>			
Specifications . . . . .	70-05-1	Replace Rockshaft Surge Relief Valve . . . . .	70-10-11
Service Parts Kits . . . . .	70-05-1	Remove, Inspect and Install Rate-of-Drop Valve . . . . .	70-10-11
Remove, Inspect and Install Hydraulic Oil Pick-Up Screen . . . . .	70-05-2	Replace Rockshaft Control Valve . . . . .	70-10-13
Remove and Install Hydraulic Pump—5210 and 5310 . . . . .	70-05-3	Remove and Install Rockshaft Case . . . . .	70-10-15
Remove Hydraulic Pump External Components—5210 and 5310 . . . . .	70-05-4	Remove, Inspect and Install Rockshaft Lift Arms . . . . .	70-10-17
Disassemble and Inspect Hydraulic Pump—5210 and 5310 . . . . .	70-05-5	Remove, Inspect and Install Rockshaft Piston and Cylinder . . . . .	70-10-18
Assemble Hydraulic Pump—5210 and 5310 . . . . .	70-05-7	<b>Group 15—Dual Selective Control Valve</b>	
Install Hydraulic Pump External Components—5210 and 5310 . . . . .	70-05-8	Other Material . . . . .	70-15-1
Remove and Install Hydraulic Pump—5410 and 5510 . . . . .	70-05-9	Specifications . . . . .	70-15-1
Remove Hydraulic Pump External Components—5410 and 5510 . . . . .	70-05-10	Service Parts Kits . . . . .	70-15-2
Disassemble and Inspect Hydraulic Pump—5410 and 5510 . . . . .	70-05-11	Inspect and Repair Joystick and Linkage—Without Cab . . . . .	70-15-3
Assemble Hydraulic Pump—5410 and 5510 . . . . .	70-05-13	Inspect and Repair Joystick and Linkage—With Cab . . . . .	70-15-5
Install Hydraulic Pump External Components—5410 and 5510 . . . . .	70-05-14	Remove and Install Dual Selective Control Valve (SCV) . . . . .	70-15-9
Remove and Install Hydraulic Filter/Manifold—Early Model . . . . .	70-05-15	Disassemble, Inspect, and Assemble Dual Selective Control Valve (SCV) . . . . .	70-15-11
Remove and Install Hydraulic Filter/Manifold—Later Model . . . . .	70-05-16	Inspect and Replace Hydraulic Hoses—Dual Selective Control Valve (SCV) . . . . .	70-15-14
Inspect and Replace Hydraulic Supply/Return Line . . . . .	70-05-17	<b>Group 16—Single (Third) Selective Control Valve</b>	
<b>Group 06—Hydraulic Oil Cooler</b>			
Remove, Inspect, and Install Hydraulic Oil Cooler . . . . .	70-06-1	Other Material . . . . .	70-16-1
<b>Group 10—Rockshaft</b>			
Other Material . . . . .	70-10-1	Specifications . . . . .	70-16-1
Specifications . . . . .	70-10-2	Service Parts Kits . . . . .	70-16-1
Service Parts Kits . . . . .	70-10-2	Inspect and Repair Single (Third) SCV Lever and Linkage . . . . .	70-16-2
Inspect and Repair Rockshaft Control Lever Assembly . . . . .	70-10-3	Remove and Install Single (Third) Selective Control Valve (SCV) . . . . .	70-16-3
Inspect and Repair Rockshaft Control Linkage . . . . .	70-10-6	Disassemble, Inspect and Assemble Single (Third) Selective Control Valve (SCV) . . . . .	70-16-5
Inspect and Repair Draft Sensing Support Assembly . . . . .	70-10-9	Inspect and Replace Hydraulic Hoses—Single (Third) Selective Control Valve (SCV) . . . . .	70-16-7
Replace Main Relief Valve . . . . .	70-10-10	<b>Group 20—Hydraulic Mid Mount Coupler</b>	
		Inspect and Replace Hydraulic Hoses—Mid Mount Coupler Without Cab . . . . .	70-20-2

Continued on next page

	Page
Inspect and Replace Hydraulic Hoses— Mid Mount Coupler With Cab. . . . .	70-20-4
<b>Group 25—Hydraulic Power Beyond</b>	
Specifications . . . . .	70-25-1
Inspect and Replace Power Beyond Hydraulic Lines and Fittings. . . . .	70-25-2
Inspect Power Beyond Motor Control Lines and Fittings . . . . .	70-25-7

## Specifications

Item	Measurement	Specification
Pick-Up Screen Cover Cap Screws	Torque	23 N•m (17 lb-ft)
Hydraulic Pump-to-Engine Cap Screws (5210—5310)	Torque	50 N•m (37 lb-ft)
Hydraulic Pump-to-Engine Cap Screws (5410—5510)	Torque	50 N•m (37 lb-ft)
Hydraulic Pump Assembly Cap Screws (5210—5310)	Torque	50 N•m (37 lb-ft)
Hydraulic Pump Assembly Cap Screws (5410—5510)	Torque	50 N•m (37 lb-ft)
Steering Pump Outlet Fitting	Torque	28 N•m (21 lb-ft)
Main Hydraulic Pump Outlet Fitting	Torque	46 N•m (34 lb-ft)
Pump Shaft Nut	Torque	55 N•m (41 lb-ft)
Pump Bracket-to-Pump Nuts	Torque	50 N•m (37 lb-ft)
Hydraulic Filter/Manifold Cap Screws	Torque	70 N•m (52 lb-ft)
Wheel Cap Screws	Torque	175 N•m (130 lb-ft)

OUO1089,000024F -19-18JUL02-1/1

## Service Parts Kits

The following kit is available through your parts catalog:

Hydraulic Pump Seal Kit


LV,7005HA,A1A -19-07MAY96-1/1



## Remove, Inspect and Install Hydraulic Oil Pick-Up Screen

**NOTE:** The approximate capacity of CollarShift/SyncShuttle™ transmission is 37.9 L (10 U.S. gal), and 43.5 L (11.5 U.S. gal) for PowrReverser™ transmissions.

1. Drain transmission/hydraulic oil.
2. Remove cap screws (A) and cover (B).
3. Remove screen and inspect for damage. Replace if necessary.
4. Clean undamaged pick-up screen in solvent and blow dry with compressed air.
5. Install pick-up screen into differential case.
6. Install cover (B) and cap screws (A). Tighten cap screws to specification.



A—Cap Screw  
B—Cover

### Specification

Pick-Up Screen Cover Cap  
Screws—Torque..... 23 N•m (17 lb-ft)

7. Fill transmission with proper oil. (See Transmission and Hydraulic Oil in Section 10, Group 20.)

M46986 —UN—31JAN92

AG,OUO1085,338 —19—30AUG00—1/1

## Remove and Install Hydraulic Pump—5210 and 5310

1. Disconnect negative (—) cable at battery.

**NOTE:** Close all openings with caps and plugs.

2. Disconnect lines (A) and hose (B).
3. Remove one cap screw (C) and two cap screws (D).
4. Remove hydraulic pump and O-ring.
5. Make repairs as necessary. (See Remove Hydraulic Pump External Components—5210 and 5310 and Disassemble and Inspect Hydraulic Pump—5210 and 5310 in this group.)


**IMPORTANT:** Always use new O-rings. Damaged or used O-rings will leak.

6. Place new O-ring on pump flange. Install pump on engine.
7. Install cap screws. Tighten to specifications.
8. Connect hydraulic lines and hose.
9. Connect negative (—) cable to battery.
10. Start engine and operate machine hydraulics. Check and adjust transmission/hydraulic oil level.


### Specification

Hydraulic Pump-to-Engine Cap  
Screws (5210—5310)—Torque..... 50 N•m (37 lb-ft)

A—Outlet Line  
B—Suction Hose  
C—Bracket-to-Engine Cap Screw  
D—Mounting Cap Screw




LV2135 -UN-14MAY97



LV2136 -UN-14MAY97

70  
05  
3

## Remove Hydraulic Pump External Components—5210 and 5310



A—Nut (2 used)  
B—Lock Washer (2 used)  
C—Bracket  
D—O-Ring  
E—Rear Fitting  
F—O-Ring

G—O-Ring  
H—Front Fitting  
I—O-Ring  
J—O-Ring  
K—Woodruff Key

L—Gear  
M—Tab Washer  
N—Nut  
O—Lock Washer (2 used)  
P—Socket Head Cap Screw

Q—Socket Head Cap Screw  
R—Manifold  
S—O-Ring  
T—Tube  
U—O-Ring

**NOTE:** O-ring (U) was removed during pump removal.


1. Remove parts (A—C).
2. Remove manifold (R) and tube (T). Remove O-rings (J and S).
3. Flatten tabs of washer (M) with hammer and punch.

4. Remove nut (N) and tab washer.
5. Remove gear (L) using a two-jaw puller.
6. Remove woodruff key (K).
7. Remove fittings (E and H) and O-rings (D, F, G, and I).

AG,OUO1085,340 -19-23JUL02-1/1

LV371AE -UN-05MAR03

## Disassemble and Inspect Hydraulic Pump—5210 and 5310



Rear Pump Section

A—Coupling  
B—Plate  
C—Body Seal  
D—Packing Ring

E—O-Ring Seal  
F—Bushing  
G—Driven Gear  
H—Dowel (2 used)

I—Housing  
J—Bushing  
K—Packing Ring  
L—Lock Washer (4 used)

M—Cap Screw (2 used)  
N—Bolt (2 used)  
O—End Plate  
P—Drive Gear


**NOTE:** Hydraulic pump components are not serviceable. Replace complete pump if any part, other than seals, is worn or damaged.

1. Thoroughly clean and dry outside of pump.
  2. Mark or number pump sections to aid during assembly.
- IMPORTANT:** Separate pump sections carefully. Do not allow parts to fall out. Keep individual pump components together as matched sets.
3. Mount pump in a vise and remove cap screws and bolts (M and N).

4. Remove end plate (O) and parts (C, D, E, and K).
5. Mark teeth of pump gears (G and P) to aid during assembly.
6. Remove remaining parts of rear pump. If bushings (F and J) do not come out easily, push on shaft of drive gear (P).
7. Clean and dry parts. Inspect parts for wear or damage. Replace complete pump if necessary.

Continued on next page

AG,OUO1085,341 -19-30AUG00-1/2



Front Pump Section

A—Oil Seal  
B—Oil Seal  
C—Mounting Flange  
D—Body Seal

E—Packing Ring  
F—O-Ring Seal  
G—Bushing

H—Driven Gear  
I—Dowel (2 used)  
J—Housing

K—Bushing  
L—Packing Ring  
M—Drive Gear

8. Separate mounting flange (C) from housing (J).
9. Remove parts (D, E, F, and L).
10. Mark teeth of pump gears (H and M) to aid during assembly.
11. Remove remaining parts of front pump. If bushings (G and K) do not come out easily, push on shaft of drive gear (M).

**NOTE:** Install seals with lips facing away from each other.


12. Pry out seals (A and B). Install seals using a bearing, bushing, and seal driver set. Install seal (B) with lips toward pump gears. Install seal (A) with lips away from pump gears.
13. Clean and dry parts. Inspect parts for wear or damage. Replace complete pump if necessary.

**IMPORTANT:** Always replace seals. Damaged or used seals will leak.

AG,OUO1085,341 -19-30AUG00-2/2

LV372A -UN-09MAR92

## Assemble Hydraulic Pump—5210 and 5310



A—Coupling  
B—Plate  
C—Body Seal  
D—Packing Ring  
E—O-Ring Seal  
F—Bushing

G—Driven Gear  
H—Dowel (4 used)  
I—Housing  
J—Bushing  
K—Packing Ring  
L—End Plate

M—Lock Washer (4 used)  
N—Cap Screw (2 used)  
O—Bolt (2 used)  
P—Drive Gear  
Q—Oil Seals  
R—Mounting Flange

S—Bushing  
T—Driven Gear  
U—Housing  
V—Bushing  
W—Drive Gear

**IMPORTANT:** Always use new seals and O-rings. Damaged or used seals and O-rings will leak.

Apply clean hydraulic oil to all internal parts before assembly. Premature pump failure can result if pump is assembled dry.

1. Apply multipurpose grease to inside lips of seals (Q).
2. Assemble pump sections with new seals and O-rings, aligning all marks made during disassembly.

**IMPORTANT:** Make sure that pump shaft can be turned with a pair of 6 in. pliers when tightening bolts. A seized shaft indicates misaligned components. Disassemble pump to determine cause.


3. Tighten cap screws (N) and bolts (O) to specification.

## Specification

Hydraulic Pump Assembly Cap  
Screws and Bolts (5210—  
5310)—Torque..... 50 N•m (37 lb-ft)



## Install Hydraulic Pump External Components—5210 and 5310



A—Nut (2 used)  
B—Lock Washer (2 used)  
C—Bracket  
D—O-Ring  
E—Rear Fitting  
F—O-Ring

G—O-Ring  
H—Front Fitting  
I—O-Ring  
J—O-Ring  
K—Woodruff Key

L—Gear  
M—Tab Washer  
N—Nut  
O—Lock Washer (2 used)  
P—Socket Head Cap Screw

Q—Socket Head Cap Screw  
R—Manifold  
S—O-Ring (2 used)  
T—Tube  
U—O-Ring

**IMPORTANT: Always use new O-rings. Damaged or used O-rings will leak.**

1. Install new O-rings (D, F, G, and I).
2. Install fittings (E and H). Tighten fittings to specifications.
3. Install parts (L—N). Tighten nut to specifications. Bend tabs of washer up against nut.

**NOTE:** O-ring (U) is installed during pump installation.

4. Install new O-rings (S) and tube (T).

5. Install new O-ring (J) and manifold (R).

6. Install parts (A—C). Tighten nuts (A) to specifications after pump is installed on engine.

#### Specification

Steering Pump Outlet Fitting—	
Torque.....	28 N•m (21 lb-ft)
Main Hydraulic Pump Outlet	
Fitting—Torque .....	46 N•m (34 lb-ft)
Pump Shaft Nut—Torque .....	55 N•m (41 lb-ft)
Pump Bracket-to-Pump Nuts—	
Torque.....	50 N•m (37 lb-ft)

LV371AE -UN-05MAR03



## Remove and Install Hydraulic Pump—5410 and 5510

1. Disconnect negative (—) cable at battery.

*NOTE: Close all openings with caps and plugs.*

2. Disconnect hydraulic lines (A) and suction hose (B).

*NOTE: Provide adequate support when removing pump mounting screws. Pump weighs approximately 12.7 kg (28 lb).*

3. Remove two cap screws (C).
4. Remove hydraulic pump and O-ring.
5. Make repairs as necessary. (See Remove Hydraulic Pump External Components—5410 and 5510 and Disassemble and Inspect Hydraulic Pump—5410 and 5510 in this group.)


**IMPORTANT: Always use new O-rings. Damaged or used O-rings will leak.**

6. Place new O-ring on pump flange. Install pump on engine.
7. Install cap screws (C) and tighten to specification.

### Specification

Hydraulic Pump-to-Engine Cap  
Screws (5410—5510)—Torque..... 50 N•m (37 lb-ft)

8. Connect hydraulic lines (A) and hose (B).
9. Connect negative (—) cable to battery.
10. Start engine and operate machine hydraulics. Check for leaks and adjust transmission/hydraulic oil level.




A—Outlet Line  
B—Suction Hose  
C—Cap Screw (2 used)

LV2137 -UN-14MAY97

70  
05  
9

## Remove Hydraulic Pump External Components—5410 and 5510



A—O-Ring  
B—Rear Fitting  
C—O-Ring  
D—O-Ring  
E—Front Fitting

F—O-Ring  
G—O-Ring  
H—Woodruff Key  
I—Gear

J—Tab Washer  
K—Nut  
L—Lock Washer (2 used)  
M—Socket Head Cap Screw


N—Socket Head Cap Screw  
O—Manifold  
P—O-Ring (2 used)  
Q—Tube

1. Remove manifold (O) and tube (Q). Remove O-rings (G and P).
2. Flatten tabs of washer (J) with hammer and punch.
3. Remove nut (K) and tab washer.
4. Remove gear (I) using a two-jaw puller.
5. Remove woodruff key (H).
6. Remove fittings (B and E) and O-rings (A, C, D, and F).

LV2138 -JUN-09JUN97

AG,OUO1085,345 -19-30AUG00-1/1

## Disassemble and Inspect Hydraulic Pump—5410 and 5510



Rear Pump Section

A—Coupling  
B—O-Ring  
C—Plate  
D—Body Seal  
E—Packing Ring

F—O-Ring Seal  
G—Bushing  
H—Drive Gear  
I—Housing

J—Bushing  
K—O-Ring Seal  
L—Packing Ring  
M—Body Seal

N—End Plate  
O—Lock Washer (4 used)  
P—Cap Screw (2 used)  
Q—Driven Gear

**NOTE:** Hydraulic pump components are not serviceable. Replace complete pump if any part, other than seals, is worn or damaged.

1. Thoroughly clean and dry outside of pump.
2. Mark or number pump sections to aid during assembly.


**IMPORTANT:** Separate pump sections carefully. Do not allow parts to fall out. Keep individual pump components together as matched sets.

3. Mount pump in a vise and remove cap screws (P).

4. Remove end plate (N) and parts (M, E, L, K, F, D, and B).
5. Mark teeth of pump gears (H and Q) to aid during assembly.
6. Remove remaining parts of rear pump. If bushings (G and J) do not come out easily, push on shaft of drive gear (H).
7. Clean and dry parts. Inspect parts for wear or damage. Replace complete pump if necessary.

Continued on next page

AG,OUO1085,347 -19-30AUG00-1/2



Front Pump Section

A—Oil Seal  
B—Oil Seal  
C—Mounting Flange  
D—Body Seal

E—Packing Ring  
F—O-Ring Seal  
G—Bushing  
H—Woodruff Key

I—Drive Gear  
J—Housing  
K—Bushing

L—Packing Ring  
M—Adapter Plate  
N—Drive Gear

8. Separate mounting flange (C) from housing (J).

9. Remove parts (D, E, F, and L).

10. Mark teeth of pump gears (I and N) to aid during assembly.

11. Remove remaining parts of front pump. If bushings (G and K) do not come out easily, push on shaft of drive gear (N).

**NOTE:** Install seals with lips facing away from each other.

12. Pry out seals (A and B). Install seals using a bushing, bearing, and seal driver set. Install seal (B) with lips toward pump gears. Install seal (A) with lips away from pump gears.


13. Clean and dry parts. Inspect parts for wear or damage. Replace complete pump if necessary.

**IMPORTANT:** Always replace seals. Damaged or used seals will leak.

AG,OUO1085,347 -19-30AUG00-2/2

LV1379AE -UN-20NOV95

# Assemble Hydraulic Pump—5410 and 5510



A—Cap Screw (4 used)  
 B—Lock Washer (4 used)  
 C—End Plate  
 D—Body Seal  
 E—Packing Ring  
 F—O-Ring Seal  
 G—Bushing

H—Housing  
 I—Drive Gear  
 J—Bushing  
 K—Packing Ring  
 L—Plate  
 M—O-Ring

N—Coupling  
 O—Oil Seals  
 P—Mounting Flange  
 Q—Driven Gear  
 R—Bushing  
 S—Drive Gear

T—Bushing  
 U—Woodruff Key  
 V—Driven Gear  
 W—Housing  
 X—Body Seal  
 Y—Adapter Plate

**IMPORTANT:** Always use new seals and O-rings. Damaged or used seals and O-rings will leak.

Apply clean hydraulic oil to all internal parts before assembly. Premature pump failure can result if pump is assembled dry.

1. Apply multipurpose grease to inside lips of seals (O).
2. Assemble pump sections with new seals and O-rings, aligning all marks made during disassembly.

**IMPORTANT:** Make sure that pump shaft can be turned with a pair of 6 in. pliers when tightening bolts. A seized shaft indicates misaligned components. Disassemble pump to determine cause.

3. Tighten cap screws (A) to specification.


## Specification

Hydraulic Pump Assembly Cap  
 Screws (5410—5510)—Torque ..... 50 N•m (37 lb-ft)

LV1360AE -UN-17APR98

70  
05  
13

## Install Hydraulic Pump External Components—5410 and 5510



A—O-Ring  
B—Steering Pump Outlet Fitting  
C—O-Ring  
D—O-Ring

E—Main Hydraulic Pump Outlet Fitting  
F—O-Ring  
G—O-Ring  
H—Woodruff Key

I—Gear  
J—Tab Washer  
K—Nut  
L—Lock Washer (2 used)  
M—Socket Head Cap Screw

N—Socket Head Cap Screw  
O—Manifold  
P—O-Ring (2 used)  
Q—Tube

**IMPORTANT: Always use new O-rings. Damaged or used O-rings will leak.**

1. Install new O-rings (A, C, D, and F).
2. Install steering and main pump outlet fittings (B and E). Tighten fittings to specifications.
3. Install parts (I—K). Tighten nut (K) to specifications. Bend tabs of washer up against nut.

4. Install new O-rings (P) and tube (Q).
5. Install new O-ring (G) and manifold (O).

#### Specification

Steering Pump Outlet Fitting—Torque.....	28 N•m (21 lb-ft)
Main Hydraulic Pump Outlet Fitting—Torque .....	46 N•m (34 lb-ft)
Pump Shaft Nut—Torque .....	55 N•m (41 lb-ft)

OUO1085,000015E -19-31AUG00-1/1

LV2138 -JUN-09JUN97

## Remove and Install Hydraulic Filter/Manifold—Early Model

**NOTE:** The approximate capacity of CollarShift/SyncShuttle™ transmission is 37.9 L (10 U.S. gal), and 43.5 L (11.5 U.S. gal) for PowrReverser™ transmissions.

1. Drain transmission/hydraulic oil.

**NOTE:** Close all openings using caps and plugs.

2. Remove hose elbow (C).
3. Remove three cap screws (B) to remove hydraulic oil filter assembly (A).


**IMPORTANT:** Replace all O-rings. Damaged or used O-rings will leak.

4. Install new O-ring and oil filter assembly. Tighten cap screws to specification.

### Specification

Hydraulic Filter/Manifold Cap  
Screws—Torque ..... 70 N•m (52 lb-ft)

5. Install hose elbow.
6. Fill transmission with proper oil. (See Transmission and Hydraulic Oil in Section 10, Group 20.)



LV513 -UN-28FEB92

Filter/Manifold (Early Model Tractors)

A—Hydraulic Oil Filter Assembly  
B—Cap Screw (3 used)  
C—Hose Elbow

OUO1085,000015F -19-31AUG00-1/1

70  
05  
15



## Remove and Install Hydraulic Filter/Manifold—Later Model

**NOTE:** The approximate capacity of CollarShift/SyncShuttle™ transmission is 37.9 L (10 U.S. gal), and 43.5 L (11.5 U.S. gal) for PowrReverser™ transmissions.

1. Drain transmission/hydraulic oil.

**NOTE:** Close all openings using caps and plugs.

2. Remove three cap screws (B).
3. Remove hydraulic oil filter assembly (A) by sliding rearward of suction line (C).

**IMPORTANT: Replace all O-rings. Damaged or used O-rings will leak.**

4. Install new O-ring and oil filter assembly. Tighten cap screws to specification.

### Specification

Hydraulic Filter/Manifold Cap  
Screws—Torque..... 70 N•m (52 lb-ft)


5. Fill transmission with proper oil. (See Transmission and Hydraulic Oil in Section 10, Group 20.)



A—Hydraulic Oil Filter Assembly  
B—Cap Screw (3 used)  
C—Suction Line

LV7955 —UN-01JUL02

## Inspect and Replace Hydraulic Supply/Return Line



A—Pump-to-Inlet Housing  
Supply Line

B—Bracket

C—O-Ring

D—Clamp (4 used)

E—Suction Line-to-Pump Hose

F—Filter Manifold-to-Pump  
Suction Line

G—Clamp (2 used)

H—Spacer

I—Pump-to-Inlet Housing  
Pressure Line

J—O-Ring

K—Fitting

L—O-Ring

M—Filter Manifold-to-Suction  
Line Hose

1. Remove right-hand rear wheel and fender.

**IMPORTANT:** Replace all O-rings. Damaged or used O-rings will leak.

*NOTE:* To remove fitting (K) on tractors without cab it is necessary to remove fuel tank. (See *Remove, Inspect and Install Fuel Tank—Without Cab* in Section 30, Group 05.)

*To remove fitting (K) on tractors with cab it is necessary to remove right-side control console and panel. (See *Remove and Install Right-Side Control Console and Panel—Tractors With Cab* in Section 90, Group 15.)*

*NOTE:* If replacement of lines or hoses is necessary, drain transmission/hydraulic oil.

2. Inspect hydraulic lines and hoses for wear or damage. Replace as necessary.
3. Install fender and wheel. Tighten wheel cap screws to specification.

### Specification

Wheel Cap Screws—Torque ..... 175 N•m (130 lb-ft)

4. Adjust transmission/hydraulic oil level to full mark with proper oil. (See *Transmission and Hydraulic Oil* in Section 10, Group 20.)



## Remove, Inspect, and Install Hydraulic Oil Cooler

1. Remove left- and right-side front grille panels.

**NOTE:** On tractors equipped with air conditioning, remove A/C condenser. (See *Remove, Inspect, and Install Air Conditioning Condenser* in Section 90, Group 20.)

2. Disconnect negative (—) battery cable.

**NOTE:** Hydraulic oil cooler can be inspected without removing oil cooler.

*Front grille-to-radiator brace removed for clarity of photo only.*


3. Remove nut (B) on both sides of oil cooler and tilt cooler (D) forward.
4. Inspect oil cooler for bent fins, cracks, and damaged seams. Repair as necessary.
5. Disconnect two hydraulic lines (A).
6. Remove two cap screws and nuts (C). Remove oil cooler.




**CAUTION:** Reduce compressed air to less than 210 kPa (2 bar) (30 psi) when using for cleaning purposes. Clear area of bystanders, guard against flying chips or debris and wear personal protection equipment including eye protection.

7. Check oil cooler for debris lodged in fins. Clean cooler using compressed air or pressure washer.
8. Install oil cooler using two cap screws and nuts (C).
9. Install two nuts (B) and connect hydraulic lines (A).

A—Hydraulic Line  
B—Nut (2 used)  
C—Cap Screw and Nut (2 used)  
D—Hydraulic Oil Cooler



LV2254 -UN-16DEC97



LV2288 -UN-16DEC97

70  
06  
1

*NOTE: Tractors equipped with cab, install A/C condenser.  
(See Remove, Inspect, and Install Air Conditioning  
Condenser in Section 90, Group 20.)*

10. Connect negative (—) battery cable.
11. Start engine and operate tractor hydraulics system.  
Check for leaks. Check and adjust  
transmission/hydraulic oil level.
12. Install right- and left-side grille panels.

OUO1085,0000161 -19-31AUG00-2/2

## Other Material

Number	Name	Use
TY9375 (U.S.) TY9480 (Canadian) 592 (LOCTITE®)	Pipe Sealant	Apply to threads of rockshaft control lever support socket head cap screws.
TY9370 (U.S.) TY9477 (Canadian) 242 (LOCTITE®)	Thread Lock and Sealer (Medium Strength)	Apply to the following: rockshaft control valve-to-inlet housing socket head cap screws, inlet housing-to-rockshaft case cap screws.
TY6305 (U.S.) TY9477 (Canadian) 7649 (LOCTITE®)	Clean and Cure Primer	Cleans mating surfaces and reduces sealant curing time.
TY6304 (U.S.) TY9484 (Canadian) 518 (LOCTITE®)	Flexible Sealant	Seals the following: inlet housing to rockshaft case, rockshaft case to differential housing.
TY9370 (U.S.) TY9477 (Canadian) 242 (LOCTITE®)	Thread Lock and Sealer (Medium Strength)	Apply to the following: rockshaft control valve-to-inlet housing socket head cap screws, inlet housing-to-rockshaft case cap screws.
TY6305 (U.S.) TY9477 (Canadian) 7649 (LOCTITE®)	Clean and Cure Primer	Cleans mating surfaces and reduces sealant curing time.
TY6304 (U.S.) TY9484 (Canadian) 518 (LOCTITE®)	Flexible Sealant	Seals the following: inlet housing to rockshaft case, rockshaft case to differential housing.

LOCTITE is a trademark of Loctite Corp.  
LOCTITE is a registered trademark of Loctite Corp.

OUC1023,000040A -19-23JUL02-1/1

70  
10  
1

Specifications

Item	Measurement	Specification
Draft Sensing Support Assembly Socket Head Cap Screws	Torque	375 N•m (277 lb-ft)
Main Relief Valve	Torque	51 N•m (38 lb-ft)
Surge Relief Valve	Torque	34 N•m (25 lb-ft)
Rate-of-Drop Valve	Torque	50 N•m (37 lb-ft)
Rockshaft Control Valve Socket Head Cap Screws	Torque	13.6 N•m (120 lb-in.)
Inlet Housing Mounting Cap Screws	Torque	35 N•m (26 lb-ft)
Rockshaft Case Cap Screws	Torque	125 N•m (92 lb-ft)
Hydraulic Pump Outlet Line Fitting	Torque	60 N•m (45 lb-ft)
Bushing Outer Edge to Edge of Bore	Distance (Minimum)	7 mm (0.283 in.)

OUO1089,0000258 –19–18JUL02–1/1

Service Parts Kits

The following kits are available through your parts catalog:

- Inlet Housing Seal Kit
- Rockshaft Cylinder Seal Kit


OUO1085,0000163 –19–31AUG00–1/1



## Inspect and Repair Rockshaft Control Lever Assembly

1. Remove rockshaft case. (See Remove and Install Rockshaft Case in this group.)
2. Remove levers (A and B).
3. Loosen nuts (H).
4. Remove parts (C—H).

A—Position Sensing Lever  
 B—Draft Sensing Lever  
 C—Alignment Plate  
 D—Cap Screw (2 used)  
 E—Spring Washer (4 used)  
 F—Washer  
 G—Spacer  
 H—Jam Nut (2 used)



LV491 -UN-28FEB92


OUO1085,0000164 -19-31AUG00-1/5

5. Remove inlet housing. (See Replace Rockshaft Control Valve in this group.)


**NOTE:** To access links inside rockshaft case, rockshaft case must be placed upside down.

6. Turn rockshaft case upside down.
7. Remove E-clips (B). Disconnect links from levers (A).
8. Rotate levers and remove socket head cap screws (C).

A—Lever  
 B—E-Clip  
 C—Socket Head Cap Screw




LV209 -UN-28FEB92



LV210 -UN-28FEB92

Continued on next page

OUO1085,0000164 -19-31AUG00-2/5



A—Cap Screw (2 used)  
 B—Washer (2 used)  
 C—Alignment Plate  
 D—Position Control Shaft  
 E—O-Ring  
 F—Friction Disk (2 used)

G—Alignment Plate  
 H—Bushing  
 I—Draft Control Shaft  
 J—Spacer  
 K—Washer  
 L—O-Ring

M—Support  
 N—Socket Head Cap Screw (2 used)  
 O—O-Ring  
 P—Key

Q—Draft Control Actuating Lever  
 R—Position Control Actuating Lever  
 S—Woodruff Key

**NOTE:** Levers (Q and R) are keyed to shafts (I) and (D), respectively, inside rockshaft case. Levers and keys (P and S) will drop into case when lever assembly is removed.

9. Remove parts (A—S).

**IMPORTANT:** Always use new O-rings during assembly. Damaged or used O-rings will leak.

**NOTE:** Bushing (H) is press fit inside shaft (I).

10. Inspect all parts for wear or damage. Replace as necessary.

11. Install new O-rings (E, L, and O).

12. Apply multipurpose grease to shafts (D and I).

13. Apply thread sealant to threads of cap screws (N).

14. Install all parts.


Continued on next page

OUC1085,0000164 —19—31AUG00—3/5


LV2139 —UN—09JUN97

15. Install and tighten socket head cap screws (C).
16. Connect links to levers (A) and install E-clips (B).
17. Install inlet housing. (See Replace Rockshaft Control Valve in this group.)

A—Lever  
B—E-Clip  
C—Socket Head Cap Screw



LV209 -UN-28FEB92




LV210 -UN-28FEB92

OUC1085,0000164 -19-31AUG00-4/5

**IMPORTANT:** Each pair of spring washers (E) must be installed with concave sides facing each other.

18. Install parts (C—H).
19. Install levers (A and B).
20. Install rockshaft case. (See Remove and Install Rockshaft Case in this group.)
21. Adjust rockshaft control lever friction. (See Rockshaft Control Lever Friction Adjustment in Section 270, Group 19.)

A—Position Sensing Lever  
B—Draft Sensing Lever  
C—Alignment Plate  
D—Cap Screw (2 used)  
E—Spring Washer (4 used)  
F—Washer  
G—Spacer  
H—Jam Nut (2 used)



LV491 -UN-28FEB92


OUC1085,0000164 -19-31AUG00-5/5

## Inspect and Repair Rockshaft Control Linkage

1. Remove rockshaft case. (See Remove and Install Rockshaft Case in this group.)
2. Remove inlet housing. (See Replace Rockshaft Control Valve in this group.)

*NOTE: To access links inside rockshaft case, rockshaft case must be placed upside down.*

3. Turn rockshaft case upside down.
4. Remove E-clips (B). Disconnect links from levers (A).




A—Lever  
B—E-Clip

LV209 -UN-28FEB92

Continued on next page

OUO1085,0000165 -19-31AUG00-1/4



Rockshaft Control Linkage

- |                                 |                          |                          |                          |
|---------------------------------|--------------------------|--------------------------|--------------------------|
| 1—Bracket                       | 9—Bushing                | 17—Bushing               | 24—Link (2 used)         |
| 2—Clevis                        | 10—Nut                   | 18—Shaft                 | 25—E-Clips               |
| 3—Draft Sensing Rod             | 11—Bracket               | 19—Spring Pin            | 26—Lever                 |
| 4—Pin                           | 12—Lever                 | 20—Washer (as required)  | 27—Socket Head Cap Screw |
| 5—Compression Spring            | 13—Square Key            | 21—O-Ring                | 28—Shaft                 |
| 6—Cotter Pin                    | 14—Nut                   | 22—Lever                 | 29—Washer                |
| 7—E-Clip (2 used)               | 15—Woodruff Key (3 used) | 23—Socket Head Cap Screw | 30—Snap Ring             |
| 8—Position Sensing Feedback Rod | 16—Lever                 |                          |                          |

Continued on next page

OUC1085,0000165 -19-31AUG00-2/4

5. Remove parts (1—11).
6. Remove socket head cap screws (23 and 27).
7. Remove E-clips (25).
8. Remove and inspect parts for wear or damage.  
Replace as necessary.


**IMPORTANT:** Always use new O-rings during assembly. Damaged or used O-rings will leak.

*NOTE: Bushing (17) is press fit inside lever (16).*

9. Apply multipurpose grease to shafts (18 and 28) and bushing (17).
10. Install all parts.
11. Tighten nut (14) until shaft stops. Then back off 1/2 turn.

OUO1085,0000165 -19-31AUG00-3/4

12. Connect links to levers (A).
13. Install E-clips (B).
14. Install inlet housing. (See Replace Rockshaft Control Valve in this group.)
15. Install rockshaft case. (See Remove and Install Rockshaft Case in this group.)
16. Adjust rockshaft position and draft sensing feedback linkages. (See Rockshaft Position-Sensing Feedback Linkage Adjustment and Rockshaft Draft-Sensing Feedback Linkage Adjustment in Section 270, Group 15.)



A—Lever  
B—E-Clip

LV209 -UN-28FEB92

OUO1085,0000165 -19-31AUG00-4/4




## Inspect and Repair Draft Sensing Support Assembly

1. Open rate-of-drop valve and lower rockshaft arms completely.
2. Move draft sensing control lever full forward.
3. Remove center link and bracket (B).
4. Remove bracket (A), if equipped.
5. Remove bracket (D) from support assembly.
6. Remove four socket head cap screws (C) and support assembly.
7. Inspect support assembly for wear or damage. Replace if necessary.
8. Install support assembly. Tighten four socket head cap screws (C) to specification.

### Specification

Draft Sensing Support Assembly  
 Socket Head Cap Screws—  
 Torque ..... 375 N•m (277 lb-ft)

9. Install draft-sensing rod bracket.
10. Install SCV outlet bracket, if equipped.
11. Install center link bracket and center link.
12. Adjust draft-sensing feedback linkage. (See Rockshaft Draft-Sensing Feedback Linkage Adjustment in Section 270, Group 15.)



Dual SCV Shown

A—SCV Outlet Bracket  
 B—Center Link Bracket  
 C—Socket Head Cap Screw (4 used)  
 D—Draft-Sensing Rod Bracket

LV395 -UN-28FEB92

70  
10  
9

OUO1085,0000166 -19-31AUG00-1/1




## Replace Main Relief Valve

**NOTE:** Right-hand control console removed to show valve location.

1. Lower rockshaft arms completely.

**NOTE:** Main relief valve can be accessed from rear or underneath tractor, between right rear fender and rockshaft housing.


2. Remove main relief valve (A) from inlet housing end plate or dual SCV, if equipped.



Dual SCV Shown

**IMPORTANT:** Always use new O-rings. Damaged or used O-rings will leak.

3. Install O-rings (D and G) and backup rings (E and F).
4. Install main relief valve. Tighten to specification.



### Specification

Main Relief Valve—Torque ..... 51 N•m (38 lb-ft)

5. Operate machine hydraulics. Check and adjust transmission/hydraulic oil level.

- A—Main Relief Valve
- B—Inlet Housing
- C—Rate-of-Drop Valve
- D—O-Ring
- E—Backup Ring
- F—Backup Ring
- G—O-Ring

OUO1085,0000167 -19-31AUG00-1/1

## Replace Rockshaft Surge Relief Valve

1. Remove rockshaft case. (See Remove and Install Rockshaft Case in this group.)
2. Remove surge relief valve (A).

**IMPORTANT:** Always use new O-rings. Damaged or used O-rings will leak.


3. Install new O-rings (B and C).
4. Install surge relief valve. Tighten relief valve to specification.

### Specification


Surge Relief Valve—Torque ..... 34 N•m (25 lb-ft)

5. Install rockshaft case.

A—Surge Relief Valve  
B—O-Ring  
C—O-Ring



LV350 -UN-28FEB92




LV357 -UN-28FEB92

OUO1085,0000168 -19-31AUG00-1/1

## Remove, Inspect and Install Rate-of-Drop Valve

**NOTE:** Rate-of-drop valve is mounted to inlet housing (A), located on right-hand side of rockshaft case.

1. Open rate-of-drop valve and lower rockshaft arms completely.
2. Operate all SCV levers, if equipped, to relieve any possible hydraulic pressure in the system.
3. Tractors equipped with cab: remove rear cab liner and right-side control console and panel. (See Remove and Install Right-Side Control Console and Panel—Tractors With Cab in Section 90, Group 15.)
4. Disconnect hydraulic line (B) if necessary.
5. Loosen set screw to remove knob (C).
6. Remove rate-of-drop valve (D) using a crow's foot wrench.



LV346 -UN-17JUN94

A—Inlet Housing  
B—Hydraulic Line  
C—Knob  
D—Rate-of-Drop Valve

Continued on next page

OUO1085,0000169 -19-31AUG00-1/2


*NOTE: Turn valve stem (A) clockwise to remove from fitting (C).*

- 7. Disassemble parts (A—D).
  - 8. Inspect valve face (F) for wear or damage. Replace parts as necessary.
- IMPORTANT: Always use new O-rings and backup rings. Damaged or used parts will leak.**
- 9. Apply multipurpose grease to O-rings, backup ring, and valve stem shaft.
  - 10. Assemble all parts.
  - 11. Install rate-of-drop valve. Tighten valve to specification.

**Specification**

Rate-of-Drop Valve—Torque..... 50 N•m (37 lb-ft)

- 12. Install knob.
- 13. Connect hydraulic line if removed.
- 14. Tractors with cab: install right side control and panel. (See Remove and Install Right-Side Control Console and Panel—Tractors With Cab in Section 90, Group 15.)
- 15. Tractors with cab: install rear cab upholstery liner.




A—Valve Stem  
B—O-Ring  
C—Valve Fitting  
D—Backup Ring  
E—O-Ring  
F—Valve Face

## Replace Rockshaft Control Valve

1. Open rate-of-drop valve and lower rockshaft arms completely.
2. Move SCV joystick or lever through all positions, if equipped.

**NOTE:** *If equipped with cab, remove fuel tank. (See Remove, Inspect and Install Fuel Tank—With Cab in Section 30, Group 05.) Also remove seat and support. (See Remove and Install Seat and Support Plate—Tractors With Cab in Section 90.)*



LV355 -UN-28FEB92

**A—Inlet Housing**  
**B—Hydraulic Line**

3. Tractors without cab: remove right-hand fender.
4. Remove right-side control console and panel on tractors with and without cab. (See Remove and Install Right-Side Control Console and Panel—Tractors Without Cab in Section 90, Group 06 or Remove and Install Right-Side Control Console and Panel—Tractors With Cab in Section 90, Group 15.)

5. Tractors without cab: disconnect right-hand fuel tank strap.

**NOTE:** *If equipped with SCVs, it is not necessary to disconnect hydraulic hoses. Disconnect SCV linkages and control cables as necessary to remove SCVs. Move SCVs away from inlet housing.*

6. Remove SCVs, if equipped. (See Remove and Install Dual Selective Control Valve (SCV) and/or Remove and Install Single (Third) Selective Control Valve (SCV) in Groups 15 or 16.)
7. Disconnect hydraulic line (B).

**NOTE:** *Tractors without cab: move fuel tank as necessary to allow clearance for inlet housing removal.*

8. Remove six cap screws and inlet housing (A).

Continued on next page

OUC1085,000016A -19-31AUG00-1/2

9. Remove three socket head cap screws (A) and control valve (B).

**IMPORTANT: Use new O-rings during assembly. Damaged or used O-rings will leak.**

10. Install new O-rings (C and D) and control valve.

11. Apply thread lock and sealer (medium strength) to threads of socket head cap screws.

12. Install socket head cap screws. Tighten to specifications.

13. Clean mating surfaces of rockshaft case and inlet housing Clean and Cure Primer. Apply a coat of Flexible Sealant to mating surfaces.

14. Apply thread lock and sealer (medium strength) to threads of mounting cap screws.

*NOTE: Rockshaft position-sensing lever must be in forward position to install inlet housing.*

15. Install inlet housing and cap screws. Tighten cap screws to specifications.

16. Connect hydraulic line.

17. Install SCVs, if equipped. (See Remove and Install Dual Selective Control Valve (SCV) and/or Remove and Install Single (Third) Selective Control Valve (SCV) in Groups 15 or 16.)

18. Tractors with cab: install seat and support, fuel tank.



19. Tractors without cab: connect right-hand fuel tank strap.

20. Tractors with and without cab: install right-hand control console and panel.

21. Tractors without cab: install right-hand fender.

**Specification**

Rockshaft Control Valve Socket	
Head Cap Screws—Torque .....	13.6 N•m (120 lb-in.)
Inlet Housing Mounting Cap	
Screws—Torque .....	35 N•m (26 lb-ft)



A—Socket Head Cap Screw (3 used)  
B—Rockshaft Control Valve  
C—O-Ring  
D—O-Ring


LV356 -UN-28FEB92

LV349 -UN-28FEB92



## Remove and Install Rockshaft Case

1. Open rate-of-drop valve (A) and lower rockshaft arms completely.
2. If equipped with SCV, move joystick or control lever through all positions.
3. Tractors without cab: remove fuel tank. (See Remove, Inspect and Install Fuel Tank—Without Cab in Section 30, Group 05.)
4. Tractors equipped with cab: remove cab. (See Cab Remove and Install in Section 90, Group 15.)
5. Remove seat and support. (See Remove and Install Seat and Support—Tractors Without Cab or Remove and Install Seat and Support Plate—Tractors With Cab in Section 90, Group 05.)
6. Tractors without cab: remove fenders, consoles and covers surrounding rockshaft case and levers.
7. Tractors with cab: remove left- and right-side control consoles and panels. (See Remove and Install Right-Side Control Console and Panel—Tractors With Cab and Remove and Install Left-Side Control Console—Tractors With Cab in Section 90, Group 15.)
8. Disconnect hydraulic line (B). Close all openings with caps and plugs.
9. Remove dipstick (D).
10. Disconnect wiring harness as necessary to allow lifting of rockshaft case.
11. Disconnect SCV cables and linkage, if equipped. (See Inspect and Repair Joystick and Linkage—With Cab or Inspect and Repair Joystick and Linkage—Without Cab and/or Inspect and Repair Single (Third) SCV Lever and Linkage in Groups 15 or 16.)
12. Remove center link and lift links (E).



A—Rate-of-Drop Valve  
 B—Hydraulic Pump Outlet Line  
 C—Rockshaft Case Assembly  
 D—Dipstick  
 E—Lift Links

LV348 -UN-28FEB92

70  
10  
15

Continued on next page

OUC1085,000016B -19-31AUG00-1/2

 **CAUTION: The approximate weight of the rockshaft case assembly is 82 kg (180 lb).**

- 13. Remove eleven cap screws, rockshaft case assembly (C), and gasket, if equipped.
- 14. Make repairs as necessary. (See procedures in this group.)
- 15. Clean mating surfaces of rockshaft case and differential housing using Clean and Cure Primer. Apply a coat of Flexible Sealant to mating surfaces.
- 16. Install rockshaft case. Install and tighten cap screws to specification.

**Specification**

Rockshaft Case Cap Screws—  
Torque ..... 125 N•m (92 lb-ft)

- 17. Install lift links and center link.
- 18. Connect SCV cables and linkage, if equipped.
- 19. Connect wiring harness.
- 20. Install fuel tank.
- 21. Connect hydraulic pump outlet line. Tighten fitting to specification.


**Specification**

Hydraulic Pump Outlet Line  
Fitting—Torque ..... 60 N•m (45 lb-ft)

- 22. Tractors without cab: install covers, consoles, and fenders.
- 23. Tractors with cab: install control consoles and seat.
- 24. Install cab. (See Cab Remove and Install in Section 90.)
- 25. Install dipstick.



## Remove, Inspect and Install Rockshaft Lift Arms



A—Retaining Ring (2 used)  
B—Right-Hand Lift Arm  
C—Washer  
D—O-Ring

E—Bushing (2 used)  
F—Retaining Ring (2 used)  
G—Crank  
H—Rockshaft

I—O-Ring  
J—Left-Hand Lift Arm  
K—Spring Pin (2 used)

L—Plate  
M—Spring Pin  
N—Piston Rod

1. Remove rockshaft case. (See Remove and Install Rockshaft Case in this group.)
2. Disconnect feedback linkage (B, G, H, and J) from plate (L).

**NOTE:** Although parts (B, G, H, and J) have indexed splines, these splines are difficult to locate. Index parts with a punch mark before disassembly to aid in correct alignment of these parts during assembly.

3. Use a punch to index parts (B, G, H, and J).
4. Remove retaining rings (A and F).
5. Remove and inspect all parts for wear or damage. Replace as necessary.

**NOTE:** Bushings (E) are pressed in rockshaft case.

6. Replace bushings (E) using a bushing driver set. Press new bushings into rockshaft case so bushing outer edge is below edge of bore to specification.

### Specification

Bushing Outer Edge to Edge of Bore—Distance (Minimum)..... 7 mm (0.283 in.)

7. Apply clean transmission/hydraulic oil to all internal parts.

**IMPORTANT:** Replace all O-rings. Damaged or used O-rings will leak.

8. Install all parts.

Continued on next page

OOU1085,000016C -19-31AUG00-1/2

LV397AE -UN-28FEB92

70  
10  
17


9. Connect feedback link.

10. Install rockshaft case.

OUO1085,000016C -19-31AUG00-2/2

## Remove, Inspect and Install Rockshaft Piston and Cylinder


1. Remove rockshaft case. (See Remove and Install Rockshaft Case in this group.)
2. Remove six cap screws (B).
3. Remove cylinder (A).
4. Remove O-ring (C).
5. Remove surge relief valve (D).



A—Rockshaft Cylinder  
B—Cap Screw (6 used)  
C—O-Ring  
D—Surge Relief Valve

OUO1085,000016D -19-31AUG00-1/3

6. Insert a 6 x 254 mm (1/4 x 10 in.) long wood dowel or brass drift through orifice (C) to remove piston (B).
7. Remove plug (E) to check oil passage (D) for clogging of debris.
8. Replace seal ring (A).
9. Inspect all parts for wear or damage. Check piston and cylinder for cracks. Replace as necessary.
10. Apply clean transmission/hydraulic oil to piston and cylinder walls.
11. Install piston.
12. Install plug.



A—Seal Ring  
B—Piston  
C—Surge Relief Valve Orifice  
D—Oil Passage  
E—Plug

Continued on next page


OUO1085,000016D -19-31AUG00-2/3

13. Install surge relief valve (D). Tighten to specification.

**Specification**

Surge Relief Valve—Torque ..... 34 N•m (25 lb-ft)

14. Install new O-ring (C).
15. Install cylinder assembly (A).
16. Install cap screws (B).
17. Install rockshaft case. (See Remove and Install Rockshaft Case in this group.)



A—Rockshaft Cylinder  
B—Cap Screw (6 used)  
C—O-Ring  
D—Surge Relief Valve

OUO1085,000016D -19-31AUG00-3/3

LV368 -UN-28FEB92



# Group 15 Dual Selective Control Valve

## Other Material

Number	Name	Use
TY9371 (U.S.) TY9478 (Canadian) 271 (LOCTITE®)	Thread Lock and Sealer (High Strength)	Apply to threads of dual SCV spool detents.
TY9369 (U.S.) NA (Canadian) 222 (LOCTITE®)	Thread Lock and Sealer (Low Strength)	Apply to threads of spool cap-to-valve housing socket head cap screws.

LOCTITE is a trademark of Loctite Corp.

OUC1089,000025B -19-18JUL02-1/1

## Specifications

Item	Measurement	Specification
Wheel Cap Screws	Torque	175 N•m (130 lb-ft)
Wheel Bolts	Torque	175 N•m (130 lb-ft)
SCV Cap Screws	Torque	12 N•m (106 lb-in.)
Main Relief Valve	Torque	51 N•m (38 lb-ft)
Spool Detents	Torque	4 N•m (35 lb-in.)
Dual SCV End Cap Socket Head Cap Screws	Torque	7 N•m (62 lb-in.)

OUC1089,000025C -19-18JUL02-1/1

70  
15  
1

## **Service Parts Kits**

The following kits are available through your parts catalog:

Tube Kit

Cap Kit


Load Check Valve Kit

Seal Kit

Lock Handle Kit

OUO1085,0000170 -19-31AUG00-1/1

## Inspect and Repair Joystick and Linkage—Without Cab



A—Joystick Assembly  
B—Support  
C—Right-Hand Shield  
D—Screw (4 used)

E—Carriage Bolt (50 mm)  
(1.969 in.)  
F—Carriage Bolt (5 used)  
G—Cable

H—Clamp (4 used)  
I—Pin (2 used)  
J—Yoke (2 used)  
K—Plate


L—Left-Hand Shield  
M—Boot  
N—Spring Pin

1. Remove right-hand wheel and fender.
2. Remove right-hand control console.
3. Remove shields (C and L).
4. Remove joystick assembly (A).
5. Remove remaining parts. Inspect parts for wear or damage. Replace as necessary.

Continued on next page

OUO1085,0000171 -19-31AUG00-1/3





A—Knob  
B—Boot  
C—Lever  
D—Spring Pin

E—Insert  
F—Compression Spring  
G—Drive  
H—Handle

I—Rod  
J—Screw (2 used)  
K—Retaining Ring  
L—Bushing (4 used)

M—Spring  
N—Lubrication Hole  
O—Seat (2 used)  
P—Piston (2 used)

6. Remove spring pin (D), rod (I), and lever (H).

7. Remove remaining parts.

Continued on next page

OOU1085,0000171 -19-31AUG00-2/3

8. Inspect all parts for wear or damage. Replace as necessary.
9. Install all parts. Apply multipurpose grease to parts (E and G) and moving components of joystick lever (C).
10. Apply multipurpose grease to hole (N).

11. Install control console.

12. Install fender and wheel. Tighten wheel cap screws to specification.

#### Specification

Wheel Cap Screws—Torque ..... 175 N•m (130 lb-ft)

OUC1085,0000171 -19-31AUG00-3/3

### Inspect and Repair Joystick and Linkage—With Cab


*NOTE: Cab removed for clarity of photo only. Access joystick linkage under right-side cab floor.*

1. Disconnect control linkage (A) and remove two cap screws (B).
2. Move floor mat and remove four cap screws (C), securing joystick mounting bracket to right-side floor kick plate.
3. Remove SCV joystick and linkage assembly. Inspect and repair as necessary. See following procedures.

A—Control Linkage  
B—Cap Screw (2 used)  
C—Cap Screw (4 used)




LV2392 -UN-20NOV97



LV2431 -UN-15DEC97

Continued on next page

OUC1085,0000172 -19-31AUG00-1/4



A—Joystick Assembly  
B—Support  
C—Right-Hand Shield  
D—Screw (4 used)

E—Carriage Bolt (50 mm)  
(1.969 in.)  
F—Carriage Bolt (5 used)  
G—Cable

H—Clamp (4 used)  
I—Pin (2 used)  
J—Yoke (2 used)  
K—Plate

L—Left-Hand Shield  
M—Boot  
N—Spring Pin


4. Remove shields (C and L).

5. Remove joystick assembly (A).

6. Remove remaining parts. Inspect parts for wear or damage. Replace as necessary.

Continued on next page

OUO1085,0000172 -19-31AUG00-2/4



A—Knob  
B—Boot  
C—Lever  
D—Spring Pin

E—Insert  
F—Compression Spring  
G—Drive  
H—Lever

I—Rod  
J—Screw (2 used)  
K—Retaining Ring  
L—Bushing (4 used)

M—Spring  
N—Lubrication Hole  
O—Seat (2 used)  
P—Piston (2 used)

7. Remove spring pin (D), rod (I), and lever (H).

8. Remove remaining parts.

Continued on next page


OUO1085,0000172 -19-31AUG00-3/4

9. Inspect all parts for wear or damage. Replace as necessary.
10. Install all parts. Apply multipurpose grease to parts (E and G) and moving components of joystick lever (C).
11. Apply multipurpose grease to hole (N).
12. Install joystick and linkage assembly to floor kick plate and reposition floor mat.
13. Connect control linkage to valve under cab floor.


OUO1085,0000172 -19-31AUG00-4/4

## Remove and Install Dual Selective Control Valve (SCV)

1. Open rate-of-drop valve and lower rockshaft arms completely.
2. Move SCV joystick through all positions.
3. Tractors without cab: remove right-hand rear wheel and fender.
4. Tractors with and without cab: remove right-side control console and panel. (See Remove and Install Right-Side Control Console and Panel—Tractors Without Cab in Section 90, Group 06 or Remove and Install Right-Side Control Console and Panel—Tractors With Cab in Section 90, Group 15.)
5. Tractors with cab: remove fuel tank. (See Remove, Inspect and Install Fuel Tank—With Cab in Section 30, Group 05.)
6. Tractors with cab: remove seat and support. (See Remove and Install Seat and Support Plate—Tractors With Cab in Section 90 Group 05.)
7. Tag all hoses to aid in installation.
8. Disconnect hoses (B—E). Close all openings using caps and plugs.
9. Disconnect control cables.
10. Remove selective control valve (A).
11. Make repairs as necessary. (See Disassemble, Inspect, and Assemble Dual Selective Control Valve (SCV) in this group.)



LV345 -UN-28FEB92



LV344 -UN-28FEB92

- A—Selective Control Valve
- B—Hydraulic Hose
- C—Hydraulic Hose
- D—Hydraulic Hose
- E—Hydraulic Hose
- F—Large Tube
- G—O-Ring (6 used)
- H—Square Cut Seal (6 used)
- I—Small Tube

Continued on next page

OUO1085,0000173 -19-31AUG00-1/3

**IMPORTANT: Always use new O-rings and seals.  
Damaged or used parts will leak.**

**NOTE:** The control valve has two large tubes with a total of four O-rings (G) and four square cut seals (H).

*In addition, the control valve also has one small tube with a total of two O-rings (G) and two square cut seals (H).*

*Tubes, O-rings, and seals are replaced together as a kit.*

12. Replace tubes (F and I), O-rings (G), and seals (H).


OUO1085,0000173 -19-31AUG00-2/3

13. Install selective control valve. Tighten cap screws to specifications.

14. Connect control cables.

15. Install new O-rings on fittings and connect hoses as follows:

- Hose D—SCV-to-left-hand (extend) coupler of pair marked I.
- Hose C—SCV-to-right-hand (retract) coupler of pair marked I.
- Hose E—SCV-to-left-hand (extend) coupler of pair marked II.
- Hose B—SCV-to-right-hand (retract) coupler of pair marked II.



A—Selective Control Valve  
B—Hydraulic Hose  
C—Hydraulic Hose  
D—Hydraulic Hose  
E—Hydraulic Hose

16. Install right-side control console and panel.

17. Tractors with cab: install fuel tank and operator seat.

18. Install fender and wheel if removed. Tighten wheel bolts to specifications.

19. Start engine and operate SCV lever. Check all connections for leaks.

#### Specification

SCV Cap Screws—Torque..... 12 N•m (106 lb-in.)  
Wheel Bolts—Torque ..... 175 N•m (130 lb-ft)


OUO1085,0000173 -19-31AUG00-3/3



## Disassemble, Inspect, and Assemble Dual Selective Control Valve (SCV)

1. Remove plugs (A), springs (B), and balls (C).
2. Remove socket head cap screws (D) and caps (E).


A—Plug (4 used)  
B—Spring (4 used)  
C—Ball (4 used)  
D—Socket Head Cap Screw (4 used)  
E—Cap (2 used)



LV341 -UN-28FEB92

Continued on next page

OUC1085,0000174 -19-23JUL02-1/4



Dual Selective Control Valve

A—O-Ring (4 used)  
B—Main Relief Valve  
C—Plug (3 used)  
D—Boom Spool  
E—Washer

F—Spring  
G—Retainer  
H—Notched Spool Detent  
I—Straight Spool Detent

J—Retainer  
K—Spring  
L—Washer  
M—Bucket Spool

N—Plug (2 used)  
O—O-Ring (2 used)  
P—Spring (2 used)  
Q—Load Check Valve (2 used)

**IMPORTANT:** Spools and housing are matched and must be replaced as a unit. Make sure spools are installed in their original bores to ensure proper operation.

**Use new O-rings during assembly. Damaged or used O-rings will leak.**

**NOTE:** Parts (D—H), (I—M), and (N—Q) are serviced as separate assemblies and are replaced as kits only.

3. Remove parts (A—Q).

4. Clamp flat end of spool in a soft-jawed vise.

**NOTE:** The threads of spool detents (H and I) are coated with high-strength thread lock and sealer. Applying moderate heat to detent end of spool softens sealer to aid detent removal.

5. Heat spool end. Remove parts (E—H) or (I—L).

Continued on next page

OUO1085,0000174 -19-23JUL02-2/4

6. Inspect all parts for wear or damage. Replace as necessary.

*NOTE: Notched spool detent (H) is used on 5-groove spool (D) only.*

7. Install parts (C) and (N—Q).  
 8. Install main relief valve (B). Tighten to specifications.  
 9. Apply thread lock and sealer (high-strength) to threads of spool detents (H and I).  
 10. Install parts (E—H) or (I—L) to spool ends.

11. Install new O-rings (A) in housing.  
 12. Coat spools and bores with clean transmission/hydraulic oil.  
 13. Install spools.  
 14. Apply multipurpose grease to springs (F and K).

#### Specification


Main Relief Valve—Torque..... 51 N•m (38 lb-ft)  
 Spool Detents—Torque ..... 4 N•m (35 lb-in.)

OUO1085.0000174 -19-23JUL02-3/4

15. Install caps (E).  
 16. Apply multipurpose grease to balls (C).  
 17. Install parts (A—C).  
 18. Apply thread lock and sealer (low strength) to threads of socket head cap screws (D).  
 19. Install socket head cap screws and tighten to specification.

#### Specification

Dual SCV End Cap Socket Head  
 Cap Screws—Torque ..... 7 N•m (62 lb-in.)




A—Plug (4 used)  
 B—Spring (4 used)  
 C—Ball (4 used)  
 D—Socket Head Cap Screw (4 used)  
 E—Cap (2 used)

LV341 -UN-28FEB92

OUO1085.0000174 -19-23JUL02-4/4

70  
15  
13

## Inspect and Replace Hydraulic Hoses—Dual Selective Control Valve (SCV)



A—Cap (4 used)  
 B—Snap Ring (8 used)  
 C—Plug (4 used)  
 D—Double-Acting Sleeve Coupler (4 used)

E—O-Ring (4 used)  
 F—Adapter (4 used)  
 G—O-Ring (8 used)  
 H—Hydraulic Hose

I—Hydraulic Hose  
 J—Hydraulic Hose  
 K—O-Ring (4 used)  
 L—Fitting (4 used)

M—Hydraulic Hose  
 N—Bracket  
 O—Drain Hose (4 used)  
 P—O-Ring (4 used)

1. Operate dual SCV joystick to relieve any pressure in the system.
2. Inspect hoses and fittings. Replace worn or damaged parts. Replace hoses that are cracked, soft, or swollen.

3. Start engine. Operate dual SCV. Check for leaks and correct hose routing.
4. Adjust transmission/hydraulic oil to correct level with proper oil. (See Transmission and Hydraulic Oil in Section 10, Group 20.)

**IMPORTANT:** Replace all O-rings. Damaged or used O-rings will leak.

LV542AE -UN-17JUN94

OUO1085,0000175 -19-01SEP00-1/1

# Group 16 Single (Third) Selective Control Valve

## Other Material

Number	Name	Use
TY9371 (U.S.) TY9478 (Canadian) 271 (LOCTITE®)	Thread Lock and Sealer (High Strength)	Apply to threads of single SCV detent spool.
TY9369 (U.S.) NA (Canadian) 222 (LOCTITE®)	Thread Lock and Sealer (Low Strength)	Apply to threads of spool cap-to-valve housing socket head cap screws.

LOCTITE is a registered trademark of Loctite Corp.

OUO1089,000025F -19-18JUL02-1/1

## Specifications

Item	Measurement	Specification
Wheel Mounting Cap Screws	Torque	175 N•m (130 lb-ft)
Wheel Bolts	Torque	175 N•m (129 lb-ft)
Single (Third) Selective Control Valve Cap Screws	Torque	12 N•m (106 lb-in.)
Single (Third) Selective Control Valve Retainer Screw	Torque	4 N•m (35 lb-in.)
Single (Third) Selective Control Valve Socket Head Cap Screws	Torque	7 N•m (62 lb-in.)

OUO1089,0000260 -19-18JUL02-1/1

## Service Parts Kits

The following kits are available through your parts catalog:

Tube Kit


Seal Kit

Cap Kit

Load Check Valve Kit

OUO1085,0000176 -19-01SEP00-1/1

## Inspect and Repair Single (Third) SCV Lever and Linkage



A—Handle  
B—SCV Lever  
C—Snap Ring (2 used)

D—Lever  
E—Bushings (2 used)  
F—Washer (2 used)

G—Link  
H—Woodruff Key

I—Cap Screw (2 used)  
J—Control Shaft

1. Tractors without cab, remove right-hand rear wheel and fender.
2. Tractors equipped with cab, remove right-side control console and panel. (See Remove and Install Right-Side Control Console and Panel—Tractors With Cab in Section 90, Group 15.)
3. Inspect parts for wear or damage. Replace as necessary.

4. Tractors without cab, install fender and wheel. Tighten wheel mounting cap screws to specification.

**Specification**

Wheel Mounting Cap Screws—

Torque..... 175 N•m (130 lb-ft)


5. Tractors with cab, install control console and panel.

LV2141 -JUN-09JUN97


OUO1085,0000177 -19-01SEP00-1/1

## Remove and Install Single (Third) Selective Control Valve (SCV)

1. Open rate-of-drop valve and lower rockshaft arms.
2. Move SCV lever back and forth.
3. Tractors without cab, remove right-hand rear wheel and fender.
4. Remove right-hand control console and panel.
5. Tag all hoses to aid in installation.
6. Disconnect hoses (C and D). Close all openings using caps and plugs.
7. Disconnect SCV joystick linkage.
8. Remove end plate (B) and selective control valve (A).
9. Make repairs as necessary. (See Disassemble, Inspect and Assemble Single (Third) Selective Control Valve (SCV) in this group.)



LV343 -UN-28FEB92



LV199 -UN-28FEB92

**IMPORTANT:** Always use new O-rings and seals.  
Damaged or used parts will leak.

**NOTE:** The control valve has two large tubes with a total of four O-rings (F) and four square cut seals (G).

*In addition, the control valve also has one small tube with a total of two O-rings (F) and two square cut seals (G).*

*Tubes, O-rings, and seals are replaced together as a kit.*

- A—Selective Control Valve
- B—End Plate
- C—SCV-to-Top Rear Outlet Hose
- D—SCV-to-Bottom Rear Outlet Hose
- E—Large Tube
- F—O-Ring (6 used)
- G—Square Cut Seal (6 used)
- H—Small Tube

10. Replace tubes (E and H), O-rings (F), and seals (G).
11. Install selective control valve and end plate. Tighten cap screws to specification.

### Specification

Single (Third) Selective Control  
Valve Cap Screws—Torque..... 12 N•m (106 lb-in.)

12. Connect SCV joystick linkage.

Continued on next page

OUC1085,0000178 -19-01SEP00-1/2



- 13. Install new O-rings on fittings and connect hoses.
- 14. Install control console and panel.
- 15. Install fender and wheel. Tighten wheel bolts to specification.


Specification

Wheel Bolts—Torque ..... 175 N•m (129 lb-ft)

- 16. Start engine and operate SCV lever. Check all connections for leaks.

OUC1085,0000178 -19-01SEP00-2/2

## Disassemble, Inspect and Assemble Single (Third) Selective Control Valve (SCV)



Single (Third) SCV

A—O-Ring (2 used)  
B—Housing  
C—Washer  
D—Spring  
E—Retainer

F—Detent Spool  
G—Plug (2 used)  
H—Spring (2 used)  
I—Ball (2 used)

J—Socket Head Cap Screw (2 used)  
K—Cap  
L—Spool

M—Load Check Valve  
N—Spring  
O—Plug  
P—O-Ring

**IMPORTANT:** Spool and housing are matched and must be replaced as a unit.

**Use new O-rings during assembly.**  
**Damaged or used O-rings will leak.**

*NOTE:* Parts (C—K) and (M—P) are serviced as two separate assemblies and are replaced as kits only.

1. Remove socket head cap screws (J).
2. Remove parts (C—P).
3. Clamp flat end of spool (L) in a soft-jawed vise.

*NOTE:* The threads on detent spool (F) are coated with high-strength thread lock and sealer. Applying moderate heat to detent end of spool softens sealer to aid detent removal.

4. Heat spool end. Remove parts (C—F).
5. Inspect all parts for wear or damage. Replace as necessary.
6. Apply thread lock and sealer (high-strength) to threads of detent spool (F).
7. Install parts (C—F). Tighten retainer screw to specifications.

Continued on next page

OUO1085,0000179 -19-01SEP00-1/2

8. Install new O-rings (A) in housing.

9. Install parts (M—P).

10. Coat spool and bore with clean transmission/hydraulic oil.

11. Install spool.

12. Apply multipurpose grease to spring (D).

13. Install cap (K) with parts (G—I).
14. Apply thread lock and sealer (low strength) to threads of socket head cap screws (J).


15. Install socket head cap screws and tighten to specifications.

Specification

Single (Third) Selective Control Valve Retainer Screw—Torque .....	4 N•m (35 lb-in.)
Single (Third) Selective Control Valve Socket Head Cap Screws—Torque .....	7 N•m (62 lb-in.)

OUC1085,0000179 -19-01SEP00-2/2

## Inspect and Replace Hydraulic Hoses—Single (Third) Selective Control Valve (SCV)



A—Cap (2 used)  
B—Snap Ring (4 used)  
C—Bracket  
D—Plug (2 used)

E—Double-Acting Sleeve  
Coupler (2 used)  
F—O-Ring (2 used)  
G—Adapter (2 used)

H—O-Ring (4 used)  
I—Hydraulic Hose  
J—O-Ring (2 used)  
K—Fitting (2 used)

L—Hydraulic Hose  
M—Drain Hose (2 used)  
N—O-Ring (2 used)

1. Operate single SCV lever to relieve any pressure in the system.
2. Inspect hoses and fittings. Replace worn or damaged parts. Replace hoses that are cracked, soft, or swollen.
3. Start engine. Operate SCV. Check for leaks and correct hose routing.
4. Adjust transmission/hydraulic oil to correct level with proper oil. (See Transmission and Hydraulic Oil in Section 10, Group 20.)

**IMPORTANT:** Replace all O-rings. Damaged or used O-rings will leak.

OUO1085,000017A -19-01SEP00-1/1


LV543AE -UN-17JUN94

70  
16  
7





Inspect and Replace Hydraulic Hoses—Mid Mount Coupler Without Cab



MID MOUNT COUPLER COMPONENTS — WITHOUT CAB

LV1628

LV1628 -19-02APR96

Continued on next page

OOU1085,000017C -19-01SEP00-1/2



A—O-Ring  
B—Oil Line  
C—Hose

D—O-Ring  
E—Adapter  
F—Breakaway Coupler

G—Snap Ring  
H—Plug  
I—Snap Ring

J—Cap Screw  
K—Bracket


1. Operate SCV joystick to relieve any pressure in the system.
2. Remove right-hand rear wheel and fender.
3. Remove right-hand control console and panel.
4. Inspect hoses, lines, and fitting. Replace worn or damaged parts. Replace hoses that are cracked, soft, or swollen.

**IMPORTANT: Replace all O-rings. Damaged or used O-rings will leak.**

5. Start engine. Operate SCV joystick. Check for leaks and correct line and hose routing.
6. Adjust transmission/hydraulic oil to correct level with proper oil. (See Transmission and Hydraulic Oil in Section 10, Group 20.)

OUO1085,000017C -19-01SEP00-2/2

Inspect and Replace Hydraulic Hoses—Mid Mount Coupler With Cab



MID MOUNT COUPLER COMPONENTS — WITH CAB

LV1629

LV1629 -19-02APR96

Continued on next page

OOU1085,000017D -19-01SEP00-1/2

A—O-Ring  
B—Oil Line  
C—Hose  
D—O-Ring

E—Adapter  
F—Breakaway Coupler  
G—O-Ring

H—Plug  
I—Snap Ring  
J—Cap Screw

K—Snap Ring  
L—Bracket  
M—Nut

1. Operate SCV joystick to relieve any pressure in the system.
2. Remove seat and support if necessary. (See Remove and Install Seat and Support Plate—Tractors With Cab in Section 90, Group 05.)
3. Remove right-side control console and panel. (See Remove and Install Right-Side Control Console and Panel—Tractors With Cab in Section 90, Group 15.)
4. Inspect hoses, lines, and fitting. Replace worn or damaged parts. Replace hoses that are cracked, soft, or swollen.

**IMPORTANT: Replace all O-rings. Damaged or used O-rings will leak.**

5. Start engine. Operate SCV joystick. Check for leaks and correct line and hose routing.
6. Install seat and right-side control console and panel.
7. Adjust transmission/hydraulic oil to correct level with proper oil. (See Transmission and Hydraulic Oil in Section 10, Group 20.)

OUO1085,000017D -19-01SEP00-2/2




Specifications

Item	Measurement	Specification
3-Cylinder Engines		
Open Center	Flow Rate	43.2 L/m (11.4 gpm)
Open Center	Pressure	18 995 kPa (190 bar) (2755 psi)
4-Cylinder Engines		
Open Center	Flow Rate	60.2 L/m (15.9 gpm)
Open Center	Pressure	18 995 kPa (190 bar) (2755 psi)

OUO1089,0000269 –19–18JUL02–1/1

## Inspect and Replace Power Beyond Hydraulic Lines and Fittings



### TRACTORS WITHOUT MID-MOUNT CONTROL VALVE AND ONE OR NO SCV

A—Power Beyond Pressure  
“P” Coupler  
B—Power Beyond Tank “T”  
Coupler

C—Power Beyond Return “R”  
Fitting  
D—Rear Power Beyond  
Coupler Bracket

E—Excess Flow Return Oil  
Port  
F—Return to Tank Port

G—End Cap  
H—Pressure Oil Port

**IMPORTANT:** Power beyond connections must be used when operating any external hydraulic orbital motor with the tractor’s hydraulic system. Failing to comply with power beyond connections will overheat and possibly damage the tractor’s hydraulic components.

**NOTE:** Be sure hydraulic functions to be connected are compatible with the tractor’s open center system of 43.2 L/m (11.4 gpm) and 18 995 kPa (190 bar) (2755 psi) for 3-cylinder engines and 60.2 L/m (15.9 gpm) and 18 995 kPa (190 bar) (2755 psi) for 4-cylinder engines.

#### 3-Cylinder Engines—Specification

Open Center—Flow Rate ..... 43.2 L/m (11.4 gpm)  
Open Center—Pressure ..... 18 995 kPa (190 bar) (2755 psi)

#### 4-Cylinder Engines—Specification

Open Center—Flow Rate ..... 60.2 L/m (15.9 gpm)  
Open Center—Pressure ..... 18 995 kPa (190 bar) (2755 psi)

**NOTE:** Refer to one of five different Power Beyond hydraulic line routing illustrations applicable to equipment.

1. Operate SCV levers to relieve any pressure in system.

**IMPORTANT:** Replace all O-rings. Damaged or used O-rings will leak.

2. Inspect lines and fittings. Replace worn or damaged parts. Replace hoses that are cracked, soft or swollen.

Continued on next page


AG,OUO1085,193 -19-16JUL02-1/6

- AG,OUO1085,193 -19-16JUL02-2/6



- AG,OUO1085,193 -19-16JUL02-3/6





## TRACTORS WITH MID-MOUNT CONTROL VALVE AND NO REAR SCV

A—Power Beyond Pressure  
“P” Coupler  
B—Power Beyond Tank “T”  
Coupler  
C—Power Beyond Return “R”  
Fitting

D—Rear Power Beyond  
Coupler Bracket  
E—Excess Flow Return Oil  
Port

F—Return to Tank Port  
G—End Cap  
H—Pressure Oil Port  
I—Pressure Oil Port

J—Mid-Mount Control Valve  
K—Power Beyond Port  
L—Return to Tank Port  
M—To Transmission Housing

1. Operate SCV levers to relieve any pressure in system.


**IMPORTANT: Replace all O-rings. Damaged or used O-rings will leak.**

2. Inspect lines and fittings. Replace worn or damaged parts. Replace hoses that are cracked, soft or swollen.

3. Adjust transmission/hydraulic oil to correct level with proper oil. (See Transmission and Hydraulic Oil in Section 10, Group 20.)

Continued on next page

AG,OUO1085,193 -19-16JUL02-4/6



## TRACTORS WITH MID-MOUNT CONTROL VALVE AND REAR SCV

- |                                     |                                     |                       |                           |
|-------------------------------------|-------------------------------------|-----------------------|---------------------------|
| A—Power Beyond Pressure “P” Coupler | D—Rear Power Beyond Coupler Bracket | F—Return to Tank Port | J—Mid-Mount Control Valve |
| B—Power Beyond Tank “T” Coupler     | E—Excess Flow Return Oil Port       | G—End Cap             | K—Power Beyond Port       |
| C—Power Beyond Return “R” Fitting   |                                     | H—Pressure Oil Port   | L—Return to Tank Port     |
|                                     |                                     | I—Pressure Oil Port   | M—To Transmission Housing |

1. Operate SCV levers to relieve any pressure in system.


**IMPORTANT: Replace all O-rings. Damaged or used O-rings will leak.**

2. Inspect lines and fittings. Replace worn or damaged parts. Replace hoses that are cracked, soft or swollen.

3. Adjust transmission/hydraulic oil to correct level with proper oil. (See Transmission and Hydraulic Oil in Section 10, Group 20.)

Continued on next page

AG,OUO1085,193 -19-16JUL02-5/6



## TRACTORS WITH 4TH AND 5TH SCV

A—Power Beyond Pressure  
“P” Coupler

B—Power Beyond Tank “T”  
Coupler

C—Power Beyond Return “R”  
Fitting

D—Rear Power Beyond  
Coupler Bracket

E—Excess Flow Return Oil  
Port

F—Return to Tank Port  
G—End Cap

H—Pressure Oil Port

I—4th and 5th SCV Return Oil  
Port

J—4th and 5th SCV

1. Operate SCV levers to relieve any pressure in system.

**IMPORTANT: Replace all O-rings. Damaged or used O-rings will leak.**


2. Inspect lines and fittings. Replace worn or damaged parts. Replace hoses that are cracked, soft or swollen.

3. Adjust transmission/hydraulic oil to correct level with proper oil. (See Transmission and Hydraulic Oil in Section 10, Group 20.)

LV7951 -UN-17JUL02

AG,OUO1085,193 -19-16JUL02-6/6

## Inspect Power Beyond Motor Control Lines and Fittings



**A—Power Beyond Motor Control**

**B—Power Beyond Return “R” Coupler**

**C—Power Beyond Tank “T” Coupler**

**D—Power Beyond Pressure “P” Coupler**

1. Operate SCV levers to relieve any pressure in system.

**IMPORTANT: Replace all O-rings. Damaged or used O-rings will leak.**

2. Inspect lines and fittings. Replace worn or damaged parts. Replace hoses that are cracked, soft or swollen.

3. Adjust transmission/hydraulic oil to correct level with proper oil. (See Transmission and Hydraulic Oil in Section 10, Group 20.)



# Section 80

## Miscellaneous Repair

### Contents

	Page
<b>Group 05—Front Axle—2WD</b>	
Specifications . . . . .	80-05-1
Remove and Install Front Axle—2WD . . . . .	80-05-1
Inspect and Replace Pivot Pin and Bushings—2WD Axle . . . . .	80-05-4
Remove and Install Spindle Assembly— 2WD Axle . . . . .	80-05-5
Inspect and Replace Spindle Shaft Bushings—2WD Axle . . . . .	80-05-6
<b>Group 10—Wheels</b>	
Specifications . . . . .	80-10-1
Inspect and Replace Front Wheel Bearings . . .	80-10-2
<b>Group 15—3-Point Hitch</b>	
Specifications . . . . .	80-15-1
Inspect and Repair Fixed Draft Links . . . . .	80-15-2
Inspect and Repair Telescoping Draft Links . .	80-15-3
Inspect and Repair Standard Lift Link . . . . .	80-15-4
Inspect and Repair Adjustable Lift Link . . . . .	80-15-5
Inspect and Repair Center Link . . . . .	80-15-6
Remove and Install Drawbar and Support . . .	80-15-8





## Specifications


Item	Measurement	Specification
2WD Front Axle	End Play	8 mm (0.030 in.)
2WD Front Axle Pivot Pin Retainer Cap Screws	Torque	135 N•m (100 lb-ft)
2WD Axle Spindle Nut	Torque	415 N•m (306 lb-ft)
2WD Tie Rod End Nut	Torque	165 N•m (122 lb-ft)
Front Wheel Cap Screws	Torque	175 N•m (130 lb-ft)

OUO1080,0000256 -19-27JUN02-1/1

## Remove and Install Front Axle—2WD

1. Raise front of tractor and remove front wheels.
2. Install support stands under front of clutch housing.
3. Disconnect hydraulic hose (A) from both ends of steering cylinder. Close all openings using caps and plugs.

A—Hydraulic Hose




LV553 -UN-27FEB92

Continued on next page

AG,OUO1023,282 -19-17JUL02-1/3

4. Place a floor jack under center of axle.
5. Remove cap screws (A).
6. Remove retainer (C) and shims (D).
7. Remove pivot pin (B).
8. Remove axle.
9. Inspect axle, pivot pin, and bushings. Make repairs as necessary. (See Inspect and Replace Pivot Pin and Bushings—2WD Axle in this group.)
10. Install axle. Lift axle into place and align axle housing hole with pivot pin hole.
11. Install pivot pin.
12. Install retainer (C), shims (D), and cap screws (A). Before tightening cap screws, check axle end play.

A—Cap Screw (2 used)  
 B—Pivot Pin  
 C—Retainer  
 D—Shim (3 used)



LV554 -UN-27FEB92

Continued on next page

AG,OUO1023,282 -19-17JUL02-2/3

13. Check axle end play between points (A and B) to specification using feeler gauges.
14. End play should not exceed 8 mm (0.030 in.) forward and aft.

**Specification**

2WD Front Axle—End Play..... 8 mm (0.030 in.)

15. Axle should oscillate freely. Remove or install shims to maintain end play.

16. Tighten pivot pin retainer cap screws to specification.

**Specification**

2WD Front Axle Pivot Pin  
Retainer Cap Screws—Torque ..... 135 N•m (100 lb-ft)

**IMPORTANT: Use new O-rings. Used or damaged O-rings will leak.**



17. Install new O-rings and connect hydraulic steering hoses.

18. Install wheels. Tighten cap screws to specification.

**Specification**

Front Wheel Cap Screws—  
Torque ..... 175 N•m (130 lb-ft)

19. Lubricate front axle pivot pin grease fittings with multipurpose grease.



A—Axle End Play Check Point  
B—Axle End Play Check Point

LV1494 -UN-20MAY02

AG,OUO1023,282 -19-17JUL02-3/3


80  
05  
3

## Inspect and Replace Pivot Pin and Bushings—2WD Axle

1. Inspect pivot pin and bushings for wear or damage. Replace if necessary.
2. Remove bushings (A) from axle using a blind hole puller set.

**NOTE:** Make sure lubrication holes in bushings (A) align with lubrication holes in axle pivot (B).

3. Install new bushings flush with axle surface using a bushing, bearing, and seal driver set.



A—Bushing  
B—Axle Pivot

LV004AE -UN-20MAY02

AG,OUO1085,195 -19-17JUL02-1/1

## Remove and Install Spindle Assembly—2WD Axle



**CAUTION:** Block pivoting front axle to prevent pinching and personal injury.

1. Install a small block of wood between front axle and tractor frame on both sides.
2. Lift and support front of tractor. Remove wheel.

**NOTE:** Tie rod end is a tapered bore fit. Use a ball joint fork or puller to ease removal.

3. Remove lock nut (A). Remove tie rod end from spindle arm.
4. Remove nut (C) and washer (B) to remove spindle assembly.
5. Inspect spindle shaft for wear or damage. Replace if necessary.
6. Inspect spindle shaft bushings for wear or damage. (See Inspect and Replace Spindle Shaft Bushings—2WD Axle in this group.)
7. Install spindle, washer, and nut. Tighten nut to specification.

### Specification

2WD Axle Spindle Nut—Torque..... 415 N•m (306 lb-ft)

8. Connect tie rod end. Install and tighten nut to specification.


### Specification

2WD Tie Rod End Nut—Torque ..... 165 N•m (122 lb-ft)

9. Install wheel and tighten wheel cap screws to specification.

### Specification

Front Wheel Cap Screws—  
Torque ..... 175 N•m (130 lb-ft)




A—Lock Nut  
B—Washer  
C—Nut  
D—Spindle Assembly

LV005 -JUN-26FEB92

80  
05  
5

## Inspect and Replace Spindle Shaft Bushings—2WD Axle



A—Bushings

B—Bearing

C—Seal

1. Inspect bearings (B) for wear or damage. Bearings must rotate smoothly and freely. Replace if necessary.
2. Inspect spindle shaft and bushings (A) for scoring or damage. Replace if necessary.
3. Remove bushings from axle using a blind hole puller set.
4. Install new bushings and seals (C) using a bushing, bearing, and seal driver set. Install seals with seal lips away from axle.
5. Apply multipurpose grease to all parts and assemble.

AG,OUO1085,197 -19-17JUL02-1/1

LV006AE -UN-26FEB92

Specifications


Item	Measurement	Specification
Front Wheel Cap Screws	Torque	175 N•m (130 lb-ft)

OUC1080,000025A -19-27JUN02-1/1



## Inspect and Replace Front Wheel Bearings

1. Remove wheel.
2. Remove cover (A), cotter pin (C), and nut (B) to remove wheel hub (E).
3. Remove bearing cones and cups (D and F) and seal (G) using a brass drift and hammer or puller.
4. Remove spacer (H) using a puller.
5. Clean all parts and allow to air dry.
6. Inspect parts for wear or damage. Replace as necessary.
7. Pack bearing cones with multipurpose grease.
8. Install inner and outer bearing cups into hub using a bearing, bushing, and seal driver set.
9. Position the inner bearing cone on the inner cup. Install seal (G) with lips of seal toward the inner bearing. Install using a bearing, bushing, and seal driver set.
10. Install spacer (H) onto spindle with the small O.D. of spacer facing outwards, away from spindle.
11. Install hub assembly, outer bearing cone, washer, and nut. Tighten until a slight drag is felt while turning hub. Back off nut just enough to install cotter pin in hole of spindle.
12. Apply flexible sealant to mating surfaces of cover (A) and hub (E). Install cover.
13. Install wheel. Tighten cap screws to specification.



A—Cover  
 B—Retaining Nut  
 C—Cotter Pin  
 D—Outer Bearing Cup and Cone  
 E—Wheel Hub  
 F—Inner Bearing Cup and Cone  
 G—Seal  
 H—Spacer

LV003AE —UN—04APR01

### Specification

Front Wheel Cap Screws—  
 Torque ..... 175 N•m (130 lb-ft)


AG,OUO1085,199 —19—17JUL02—1/1

Specifications

Item	Measurement	Specification
Draft Link Support Cap Screw	Torque	200 N•m (148 lb-ft)
Rear Drawbar Cap Screws	Torque	200 N•m (148 lb-ft)
Bottom Drawbar Cap Screws	Torque	310 N•m (228 lb-ft)

OUC1080,000025E -19-27JUN02-1/1

Inspect and Repair Fixed Draft Links



Left Side Shown


- |                       |                      |                               |                                |
|-----------------------|----------------------|-------------------------------|--------------------------------|
| A—Pin (2 used)        | D—Flanged Nut        | G—Draft Arm                   | J—Sway Link Stud               |
| B—Cotter Pin (2 used) | E—Support            | H—Clevis (2 used)             | K—Link Nut (Right-Hand Thread) |
| C—Spring Pin          | F—Cap Screw (6 used) | I—Link Nut (Left-Hand Thread) |                                |

1. Inspect draft link assembly for wear or damage.  
Replace as necessary.
2. Tighten cap screws (F) to specification.

Specification

Draft Link Support Cap	
Screw—Torque .....	200 N•m (148 lb-ft)

## Inspect and Repair Telescoping Draft Links



Left Side Shown

A—Pin (4 used)	H—Draft Link (2 used)	N—Pawl (2 used)	S—Draft Link End (2 used)
B—Clevis (4 used)	I—Strap	O—Torsion Spring (2 used)	T—Cotter Pin (4 used)
C—Cotter Pin (4 used)	J—Push Button (2 used)	P—Pin (2 used)	U—Link Nut (2 used)
D—Spring Pin (2 used)	K—Sealing Washer (2 used)	Q—Ball (2 used)	V—Stud (2 used)
E—Flange Nut (2 used)	L—Pin (2 used)	R—Spring Locking Pin (2 used)	W—Nut (2 used)
F—Support (2 used)	M—Spring Pin (4 used)		X—Link Nut (2 used)
G—Cap Screw (6 used)			

**NOTE:** Quantities listed are for both sides.

1. Inspect draft link assembly for wear or damage.  
Replace as necessary.
2. Tighten cap screws (G) to specification.

### Specification

Draft Link Support Cap  
Screw—Torque ..... 200 N•m (148 lb-ft)

LV1337 -UN-15SEP95


80  
15  
3

AG,OUO1085,202 -19-17JUL02-1/1

## Inspect and Repair Standard Lift Link

1. Remove plugs (I).
2. Thread link end (D) in until spring pin (E) is centered with plug holes.
3. Remove spring pin using a punch and hammer.
4. Thread link end out.
5. Inspect all parts for wear or damage. Replace as necessary.
6. Assemble all parts.
7. Lubricate lift link assembly at fittings (G) using multipurpose grease.

A—Quick-Lock Pin (2 used)  
 B—Pin  
 C—Ball  
 D—Lift Link End  
 E—Spring Pin  
 F—Lift Link Body  
 G—Lubrication Fitting  
 H—Retainer  
 I—Plug (2 used)  
 J—Pin



LV393AE -UN-15JUL97

AG.OUO1085,203 -19-05SEP00-1/1


## Inspect and Repair Adjustable Lift Link

1. Remove plugs (K).
2. Thread link body (J) in until spring pin (H) is centered with plug holes.
3. Remove spring pin using a punch and hammer.
4. Disassemble all parts.
5. Inspect all parts for wear or damage. Replace as necessary.

**NOTE:** Install handle (I) with notches toward lift link body (J).

6. Assemble all parts.
7. Lubricate lift link assembly at fittings (E) using multipurpose grease.

A—Quick-Lock Pin (2 used)  
 B—Pin  
 C—Ball  
 D—Lift Link End  
 E—Lubrication Fitting (2 used)  
 F—Link Rod  
 G—Spring Pin  
 H—Spring Pin  
 I—Handle  
 J—Lift Link Body  
 K—Plug (2 used)  
 L—Pin  
 M—Retainer




AG,OUO1085,204 -19-05SEP00-1/1

LV489AE -UN-26FEB92

80  
15  
5

## Inspect and Repair Center Link



A—Cap Screw (2 used)  
B—Bracket  
C—Lever

D—Quick-Lock Pin  
E—Pin  
F—Center Link End

G—Spring Pin (2 used)  
H—Center Link Body

I—Plug (4 used)  
J—Center Link End

**NOTE:** Bracket (B) is mounted to draft-sensing assembly. Loosen cap screws (A) to remove bracket.

1. Remove plugs (I).
2. Thread link ends (F and J) in until spring pins (G) are centered with plug holes.
3. Remove spring pins using a punch and hammer.

4. Disassemble all parts.
5. Inspect all parts for wear or damage. Replace as necessary.
6. Apply multipurpose grease to I.D., at both ends, of body (H).
7. Assemble all parts.


LV394AE -UN-26FEB92

AG.OUO1085,205 -19-05SEP00-1/1





# Remove and Install Drawbar and Support



LV2461 -UN-19DEC97

Continued on next page

AG,OUO1085,206 -19-17JUL02-1/2

### 3-Point Hitch

A—Shield  
B—Nut  
C—Washer  
D—Bushing  
E—Cap Screw

F—Support  
G—Rear Drawbar Cap Screw  
(6 used)  
H—Cotter Pin

I—Pin  
J—Drawbar  
K—Cap Screw (2 used)  
L—Nut

M—Bottom Drawbar Cap  
Screw (4 used)  
N—Latch  
O—Pin

1. Remove parts (A—E).
2. Lift latch (N) and pull pin (O) upward.
3. Remove drawbar (J).

*NOTE: Use a floor jack under support (F) to support weight during removal.*

4. Install floor jack under support (F) and remove cap screws (G and M).
5. Inspect all parts for wear or damage. Replace if necessary.

6. Install parts (A—O). Tighten rear drawbar cap screws (G) and bottom drawbar cap screws (M) to specification.

#### Specification

Rear Drawbar Cap Screws—

Torque..... 200 N•m (148 lb-ft)

Bottom Drawbar Cap Screws—

Torque..... 310 N•m (228 lb-ft)

AG,OUO1085,206 -19-17JUL02-2/2



# Section 90

## Operator Station Repair

### Contents

Page	Page
<b>Group 05—Seat and Support</b>	
Specifications . . . . .	90-05-1
Remove and Install Seat and Support—Tractors Without Cab . . . . .	90-05-1
Remove and Install Seat and Support Plate—Tractors With Cab . . . . .	90-05-2
<b>Group 06—Control Console and Panel—Tractors Without Cab</b>	
Remove and Install Right-Side Control Console and Panel—Tractors Without Cab . . . . .	90-06-1
Remove and Install Left-Side Control Console and Panel—Tractors Without Cab . . . . .	90-06-3
<b>Group 10—ROLL-GARD</b>	
Specifications . . . . .	90-10-1
Remove and Install ROLL-GARD™ . . . . .	90-10-1
<b>Group 15—Cab Components</b>	
Essential Tools . . . . .	90-15-1
Other Material . . . . .	90-15-1
Specifications . . . . .	90-15-1
Remove, Inspect, and Install Cab Interior Recirculating Air Filter . . . . .	90-15-2
Remove, Inspect, and Install Exterior Cab Intake Air Filter . . . . .	90-15-3
Remove and Install Front Headliner . . . . .	90-15-3
Remove and Install Rear Headliner . . . . .	90-15-4
Remove and Install Lower Front Windows . . . . .	90-15-6
Remove and Install Windowpanes . . . . .	90-15-7
Remove and Install Rear Window . . . . .	90-15-8
Remove and Install Cab Doors . . . . .	90-15-9
Remove and Install Cab Roof . . . . .	90-15-11
Remove and Install Right-Side Control Console and Panel—Tractors With Cab . . . . .	90-15-12
Remove and Install Left-Side Control Console—Tractors With Cab . . . . .	90-15-14
Cab Remove and Install . . . . .	90-15-15
Cab Floor Plate Remove and Install—Later Model Tractors. . . . .	90-15-29
Cab Floor Plates Remove and Install—Early Model Tractors. . . . .	90-15-35
<b>Group 20—Air Conditioning System</b>	
Essential Tools . . . . .	90-20-1
Service Equipment and Tools . . . . .	90-20-3
Other Material . . . . .	90-20-4
Specifications . . . . .	90-20-4
Service Parts Kits . . . . .	90-20-5
Hose and Tubing O-Ring Connector Torques . . . . .	90-20-5
Recover/Recycle Air Conditioning Refrigerant. . . . .	90-20-6
Replace Air Conditioning Receiver-Dryer. . . . .	90-20-7
Remove, Inspect, and Install Air Conditioning Condenser. . . . .	90-20-8
Remove, Inspect, and Install Air Conditioning Compressor. . . . .	90-20-10
Test Volumetric Efficiency of Compressor . . . . .	90-20-12
Test Compressor Shaft Seal Leakage . . . . .	90-20-14
Disassemble and Assemble Compressor Clutch . . . . .	90-20-15
Disassemble, Inspect, and Assemble Compressor. . . . .	90-20-16
Check Compressor Clutch Hub Clearance . . . . .	90-20-19
Inspect Compressor Manifold . . . . .	90-20-19
Remove and Install Compressor Relief Valve . . . . .	90-20-20
Remove and Install Evaporator/Heater Core Housing Cover. . . . .	90-20-21
Remove Blower Motors . . . . .	90-20-23
Remove Evaporator/Heater Core . . . . .	90-20-24
Leak Test Evaporator/Heater Core . . . . .	90-20-25
Install Evaporator/Heater Core . . . . .	90-20-26
Service Expansion Valve. . . . .	90-20-27
Expansion Valve Bench Test—Diagram . . . . .	90-20-28
Expansion Valve Bench Test. . . . .	90-20-29
Refrigerant Oil Information . . . . .	90-20-30
Check Compressor Oil Charge . . . . .	90-20-31
Determine Correct Refrigerant Oil Charge. . . . .	90-20-32
Add Refrigerant Oil to System. . . . .	90-20-34
System Information . . . . .	90-20-35
Flush Air Conditioning System . . . . .	90-20-37
Evacuate Air Conditioning System . . . . .	90-20-41
Charge Air Conditioning System . . . . .	90-20-42
<b>Group 25—Heating System</b>	
Replace Heater Temperature Control and Cable. . . . .	90-25-1

Continued on next page

	Page
Remove, Test, and Install Heater Control Valve . . . . .	90-25-5
Leak Test Heater Control Valve . . . . .	90-25-6
Install Heater Control Valve. . . . .	90-25-6

Specifications

Item	Measurement	Specification
Seat Assembly Cap Screws	Torque	125 N•m (92 lb-ft)

OUO1080,0000262 -19-02JUL02-1/1


Remove and Install Seat and Support—  
Tractors Without Cab

- 1. Disconnect wiring connector (A).
- 2. Remove cap screws (B).
- 3. Remove seat assembly.
- 4. Install seat assembly. Tighten cap screws to specification.

Specification
Seat Assembly Cap Screws— Torque ..... 125 N•m (92 lb-ft)

- 5. Connect wiring connector.

A—Wiring Connector  
B—Cap Screws (2 used)



LV2287 -UN-20NOV97

AG,OUO1085,211 -19-17JUL02-1/1



## Remove and Install Seat and Support Plate— Tractors With Cab

1. Disconnect seat safety switch wiring connector (A).
  2. Remove four nuts (B).
  3. Remove seat assembly.
  4. Remove five cap screws (C).
  5. Remove seal (D) on left and right edge of base plate.
- NOTE:** To remove base plate (E) it is necessary to remove the cab to rear axle mounting hardware.
6. Lift rear of cab upward 25 mm (1 in.) off rear mounts to aid during removal of base plate (E).
  7. Remove base plate (E) if necessary. Inspect seal for wear or damage. Replace seal if necessary.


**NOTE:** To aid during installation of seals (D) onto base plate (E), install seal on only one edge of base plate, then install other edge seal after base plate has been installed.

8. Install seal (D) on one edge of plate and install base plate (E) using cap screws (C). Install remaining seal.
9. Install seat onto base plate using four nuts (B) and connect wiring connector (A).

A—Wiring Connector  
B—Nut (4 used)  
C—Cap Screw (5 used)  
D—Seal  
E—Base Plate



LV2344 -UN-20NOV97



LV2345 -UN-20NOV97

AG,OUO1032,3419 -19-23JUN03-1/1



## Remove and Install Right-Side Control Console and Panel—Tractors Without Cab

1. Remove seat and support. (See Remove and Install Seat and Support—Tractors Without Cab in Group 05.)
2. Remove four cap screws (A) and clutch housing cover (B).

*NOTE: Right-side tire removed only for clarity of photo.*


3. Remove nuts (C), cap screws (D) and right-side fender.

A—Cap Screw (4 used)  
B—Clutch Housing Cover  
C—Nut (6 used)  
D—Cap Screw (2 used)




4. Remove cap screws (A) and rock shaft control levers (B).
5. Remove mounting hardware and lever control console (C).
6. Remove cap screws (D) and bracket (E).
7. Remove cap screws (F) and right-side control panel (G). Make repairs as necessary.
8. Install control panel (G) and cap screws (F).
9. Install bracket (E), cap screws (D), and control console (C).
10. Install rock shaft control levers (B) and cap screws (A).
11. Install right-side fender and clutch housing cover.
12. Install seat and support.

A—Cap Screw (4 used)  
 B—Rock Shaft Control Lever  
 C—Control Console  
 D—Cap Screw (3 used)  
 E—Gear Shift Lever Park Bracket  
 F—Cap Screw (3 used)  
 G—Right-Side Control Panel



LV2303 -UN-20NOV97



LV2304 -UN-20NOV97


## Remove and Install Left-Side Control Console and Panel—Tractors Without Cab

1. Remove seat and support. (See Remove and Install Seat and Support—Tractors Without Cab in Group 05.)

*NOTE: Left-side tire removed only for clarity of photo.*

2. Remove two cap screws (A).
3. Remove four cap screws (B) and clutch housing cover (C).

A—Cap Screw (2 used)  
B—Cap Screw (4 used)  
C—Clutch Housing Cover



LV2297 -UN-20NOV97



LV2298 -UN-20NOV97

90  
06  
3

Continued on next page


AG,OUO1085,213 -19-06SEP00-1/3



**NOTE:** Tractor without MFWD shown. For tractor equipped with MFWD, this procedure is similar.

540/540E knob (A) is screwed onto lever and PTO knob (B) is pressed on.

4. Unscrew and remove knob (A).
5. Turn and pull knob (B) to remove.
6. Remove cap (C), cap screw (D), and range shift knob (E).
7. Remove screws (G) and control console (H).
8. Remove cap screws and nuts (F), screw (J), and control panel (I). Make repairs as necessary.
9. Install panel (I), screw (J), and cap screws and nuts (F).
10. Install control console (H), screw (G), and knobs (A and B).
11. Install knob (E), cap screw (D), and cap (C).



- A—540/540E Control Knob  
 B—PTO Knob  
 C—Cap  
 D—Cap Screw  
 E—Range Shift Knob  
 F—Cap Screw and Nut (2 used)  
 G—Screw (5 used)  
 H—Left-Side Control Console  
 I—Left-Side Control Panel  
 J—Cap Screw


Continued on next page

AG\_OUO1085,213 -19-06SEP00-2/3

12. Install cap screws (A), clutch housing cover (C), and cap screws (B).

13. Install seat and support.

A—Cap Screw (2 used)  
B—Cap Screw (4 used)  
C—Clutch Housing Cover



LV2297 -UN-20NOV97



LV2298 -UN-20NOV97

90  
06  
5





## Specifications

Item	Measurement	Specification
Roll Guard Post Mounting Cap Screws	Torque	335 N•m (247 lb-ft)

OUO1080,000026A -19-02JUL02-1/1


## Remove and Install ROLL-GARD™

1. Remove rear wheels.
2. Remove fenders.
3. Remove locking pin (A).
4. Remove snap ring (C).

*NOTE: Pivot pin (B) is press fit in outside flange of post.*

5. Remove pivot pin (B) using a brass drift and hammer.
6. Repeat steps (3, 4, and 5) for opposite side of ROLL-GARD™.
7. Remove crossbar (D).

A—Locking Pin  
B—Pivot Pin  
C—Snap Ring  
D—Crossbar



LV2142 -UN-14MAY97

ROLL-GARD is a trademark of Deere & Company

Continued on next page

AG,OUO1085,214 -19-17JUL02-1/3

8. Disconnect wiring connectors (A).
9. Remove screw (C) and nut (B) to remove fuel tank retaining strap (D).
10. Remove four cap screws (F) and stabilizer (G) to remove post (E).
11. Repeat procedures to remove post on other side.


**NOTE:** Remove lights if ROLL-GARD™ repair or replacement is necessary.

12. Inspect all parts for damage. Replace as necessary.
13. Install post (E), stabilizer (G), and cap screws (F). Tighten cap screws to specification.

**Specification**

Roll Guard Post Mounting Cap  
Screws—Torque..... 335 N•m (247 lb-ft)

14. Install fuel tank retaining straps.
15. Connect wiring connectors.



LV510 -UN-25FEB92

Left-Hand Side

- A—Wiring Connector
- B—Nut
- C—Screw
- D—Strap
- E—Post
- F—Cap Screw (4 used)
- G—Stabilizer


ROLL-GARD is a trademark of Deere & Company

Continued on next page

AG,OUO1085,214 -19-17JUL02-2/3

16. Install crossbar (D).
17. Install parts (A—C).
18. Install fenders.
19. Install wheels.

A—Pivot Pin  
B—Retaining Pin  
C—Snap Ring  
D—Crossbar



LV2142 -UN-14MAY97

AG,OUO1085,214 -19-17JUL02-3/3



## Essential Tools

*NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).*

SERVICEGARD is a trademark of Deere & Company

OUO1080,000026B -19-02JUL02-1/2

Cab Lifting Bar . . . . . JDG1580

Remove and Install Cab

OUO1080,000026B -19-02JUL02-2/2

## Other Material

Number	Name	Use
R36757 (U.S.)	John Deere Cleaner	Cleans air filters
TY15130 (3 oz. tube) (U.S.) TY15443 (10.3 oz. cartridge) (U.S.)	Clear Silicone Adhesive Sealant	Apply to cab roof and window frames.

OUO1080,000026D -19-02JUL02-1/1

## Specifications

Item	Measurement	Specification
Lower Front Window Mounting Hardware	Torque	1.5 N•m (13.5 lb-in.)
Cab Door Hinge Mounting Screws	Torque	27 N•m (20 lb-ft)
Rear Cab Mount Nuts	Torque	203 N•m (150 lb-ft)
Rear Wheel Cap Screws	Torque	175 N•m (130 lb-ft)


OUO1080,000026E -19-02JUL02-1/1

## Remove, Inspect, and Install Cab Interior Recirculating Air Filter


**NOTE:** Screws (A) are retained in filter cover (B) with small O-rings (C), and will not fall out when removing filter cover (B).

1. Loosen six screws (A) and remove filter cover (B).
2. Remove filter (D).
3. Add John Deere R36757 filter element cleaner or an equivalent non-sudsing detergent to water. Move the filter around in this solution to loosen dirt.
4. Flush filter with clean water. Use water pressure under 208 kPa (2.0 bar) (30 psi).
5. Shake filter to remove water. Do not install filter in machine until dry.
6. Inspect filter for wear or damage. Replace if necessary.
7. Install filter (D) and cover (B).
8. Tighten screws (A).

A—Screw (6 used)  
B—Filter Cover  
C—O-Ring (6 used)  
D—Filter



LV1398 -UN-08AUG97




LV1399 -UN-10NOV95

AG.OUO1085,216 -19-06SEP00-1/1

## Remove, Inspect, and Install Exterior Cab Intake Air Filter

1. Loosen screws (A) and slide retainer plates (B) outward away from filter.
2. Remove filter retainer (C) and filter (D).
3. Inspect filter for wear or damage. Replace if necessary.
4. Install filter (D) and retainer (C).
5. Slide plates (B) onto outer edge of filter retainer (C) and tighten screws
6. Repeat the above steps for the intake filter on opposite side of cab.



Right Side Filter Shown


A—Screw (2 used)  
B—Retainer Plate (2 used)  
C—Filter Retainer  
D—Filter

AG,OUO1085,217 -19-06SEP00-1/1

## Remove and Install Front Headliner

1. Loosen six screws (A) and remove air recirculating intake cover and filter (B).

A—Screw (6 used)  
B—Filter



AG,OUO1085,218 -19-17JUL02-1/3

2. Remove five screws (A) from bottom edge of control panel.

A—Screw (5 used)



Continued on next page


AG,OUO1085,218 -19-17JUL02-2/3



**NOTE:** Dome light is snap-fit in headliner. Remove dome light and push through opening when headliner is removed.

Headliner will drop when side mounting screws are removed.

3. Remove two screws (A) on both sides of headliner.
4. Remove headliner.
5. Install headliner and four screws (A).
6. Pull dome light through opening in headliner.
7. Install dome light.
8. Install control panel lower mounting screws and recirculating air intake cover and filter.




A—Screw (4 used)

AG,OUO1085,218 -19-17JUL02-3/3

## Remove and Install Rear Headliner

1. Loosen six screws (A) and remove air recirculating intake cover and filter (B).

A—Screw (6 used)  
B—Filter




AG,OUO1085,219 -19-17JUL02-1/3

**NOTE:** Support control panel (B) using wire or rope to prevent weight of panel from pulling on wiring connectors and leads.

2. Remove twelve screws (A) and control panel (B). Support weight of control panel using wire or rope.

A—Screw (12 used)  
B—Control Panel



Continued on next page

AG,OUO1085,219 -19-17JUL02-2/3

**IMPORTANT:** When removing rear headliner, make sure speakers located behind left and right side headliner do not get damaged.

3. Pull in and downward on front corners (A) of left and right side panels.
4. Remove rear headliner (B). Replace if necessary.

*NOTE: Install back panel of headliner (B) into position first.*

5. Install rear headliner.
6. Install control panel.
7. Install recirculating air intake cover and filter.

A—Front Corner  
B—Rear Headliner



AG,OUO1085,219 -19-17JUL02-3/3

## Remove and Install Lower Front Windows

1. Remove caps (A) to access window mounting hardware.

*NOTE: Observe position and location of mounting hardware and rubber grommets during removal.*

2. Remove lower mounting hardware first from window.


*NOTE: Support lower front window to prevent it from falling when remaining hardware is removed.*

3. Remove upper mounting hardware from window and remove window (B).
4. Repeat steps 1 through 3 for opposite side of cab if necessary.
5. Install window and mounting hardware. Tighten mounting hardware to specification.

### Specification

Lower Front Window Mounting  
Hardware—Torque ..... 1.5 N•m (13.5 lb-in.)

A—Cap  
B—Window



LV2276 -UN-20NOV97

AG,OUO1085,220 -19-17JUL02-1/1

## Remove and Install Windowpanes

*NOTE: It is recommended that an auto glass dealer install the windowpanes. If an auto glass dealer is not installing the windowpanes, use the following procedure.*

**IMPORTANT: Windowpanes must have an ultraviolet barrier around the edge of the glass since ultraviolet rays will deteriorate the adhesive. Windowpanes ordered through John Deere parts have the ultraviolet barrier. If the windowpane is purchased through a glass dealer, the dealer must put an ultraviolet barrier on the glass. DO NOT apply paint to the border of the glass.**

1. Remove and scrape broken glass off existing adhesive. DO NOT remove adhesive from window frame on cab.
2. Trim existing adhesive so it has a smooth surface.
3. Apply a 12.5 mm (1/2 in.) bead of adhesive on to of the existing adhesive.
4. Put a new windowpane into position. Use light hand pressure to force windowpane down around the edges until even with metal frame. DO NOT over-press adhesive.
5. Use tape to hold windowpane in place while adhesive cures.


*NOTE: This type of silicone adhesive sealant is cured by the water vapor in the air, and a vapor of acetic acid (vinegar-like odor) is released during curing time. If you still smell a vinegar-like odor, allow for a longer cure time.*

6. Allow adhesive to cure for 24 hours at room temperature with at least a 50% relative humidity before operating machine.

## Remove and Install Rear Window

1. Remove spring clip (A), pin, and wave washer (B) from both sides of rear window.

A—Spring Clip  
B—Wave Washer




AG,OUO1085,222 -19-17JUL02-1/3

LV1438 -UN-10NOV95

2. While supporting rear window, remove four screws (A). Remove rear window assembly.
3. Position window assembly against frame and install four screws (A).

A—Screw (4 used)




AG,OUO1085,222 -19-17JUL02-2/3

LV1439 -UN-10NOV95

4. Install pin and wave washer (B) and spring clip (A) on both sides of window.

A—Spring Clip  
B—Wave Washer




AG,OUO1085,222 -19-17JUL02-3/3

LV1438 -UN-10NOV95

## Remove and Install Cab Doors

1. Disconnect cylinder (A) from door.
2. Remove two screws (B) and disconnect strap (C) from door.

A—Cylinder  
B—Screw (2 used)  
C—Strap



LV1436 -UN-20NOV97

AG,OUO1085,223 -19-17JUL02-1/3

3. Attach a suitable hoist to cab door. Weight of door is approximately 23 kg (51 lbs).
4. Remove four screws, nuts, and washers from hinges (A). Remove door.
5. Repair or replace door as necessary.
6. Position door and align hinges (A). Install four screws, nuts, and washers.
7. Gently close cab door and check alignment of door latch and seal. Align if necessary.
8. Tighten hinge mounting screws to specification.

### Specification

Cab Door Hinge Mounting  
Screws—Torque ..... 27 N•m (20 lb-ft)

A—Hinge



LV1437 -UN-10NOV95

Continued on next page


AG,OUO1085,223 -19-17JUL02-2/3

9. Connect cylinder (A) to cab door.

*NOTE: Be sure door strap is installed between door and door cylinder.*

10. Install bracket through loop on strap (C).
11. Install screws (B) and tighten securely.
12. Verify smooth operation of door and door latch. Adjust hinges if necessary.

A—Cylinder  
B—Screw (2 used)  
C—Strap



AG,OUO1085,223 -19-17JUL02-3/3




## Remove and Install Cab Roof

1. Remove antenna. (See Replace Antenna in Section 40, Group 10.)
2. Remove twenty-eight cap screws (A) with lock washers (B) and flat washers (C).
3. Remove two bolts (D) with lock washers (E) and flat washers (F). Remove roof (G).

**NOTE:** Apply clear silicone adhesive sealant inside all tapped holes on cab roof. Purpose of sealant is to prevent leakage of pressurized air inside cab roof chamber.

4. Apply a bead of silicone adhesive sealant around circumference of roof and across all cross-members.
5. Install roof. Be sure antenna hole is on correct side, and that lower edges of roof overlap tabs on cab roof frame.
6. Install twenty-eight cap screws (A) with lock washers (B) and flat washers (C).
7. Install two bolts (D) with lock washers (E) and flat washers (F). Tighten all hardware securely.
8. Install antenna. (See Replace Antenna in Section 40, Group 10.)



- A—Cap Screw (28 used)  
 B—Lock Washer (28 used)  
 C—Flat Washer (28 used)  
 D—Bolt (2 used)  
 E—Lock Washer (2 used)  
 F—Flat Washer (2 used)  
 G—Cab Roof

LV1443 -UN-06DEC95

AG\_OUO1085,224 -19-06SEP00-1/1

## Remove and Install Right-Side Control Console and Panel—Tractors With Cab


**NOTE:** It is not necessary to remove support plate under seat.

1. Remove seat. (See Remove and Install Seat and Support Plate—Tractors With Cab in Group 05.)

**NOTE:** Avoid removing knobs from rockshaft control levers to prevent damage to knobs. Remove knobs only if necessary.

2. Remove four screws (A). Lift cover (B) up to access rockshaft control levers mounting hardware (not shown). Remove levers (C) and cover (B).

A—Screw (4 used)  
B—Cover  
C—Lever



LV2386 -UN-20NOV97


AG,OUO1085,227 -19-17JUL02-1/3

**NOTE:** To avoid damage to cab upholstery during installation and removal, place thin rigid cardboard or plastic panel between inside cab walls and control panel.

3. Remove six screws (A) and knob (B).
4. Remove screw and plastic tub (C).
5. Remove right-side control console. Make repairs as necessary.

**NOTE:** To aid during installation of plastic tub under right-side control console, tie or tape in place under control console.

6. Install right-side control console and plastic tub (C) with screws (A).



LV2387 -UN-20NOV97


A—Screw (6 used)  
B—Knob  
C—Plastic Tub

Continued on next page

AG,OUO1085,227 -19-17JUL02-2/3

7. Place levers (C) through cover (B) and install levers to controls using four cap screws.
8. Install screws (A).
9. Install seat. (See Remove and Install Seat and Support Plate—Tractors With Cab in Group 05.)

A—Screw (4 used)  
B—Cover  
C—Lever




AG.OUO1085,227 -19-17JUL02-3/3

## Remove and Install Left-Side Control Console—Tractors With Cab


**NOTE:** To avoid damage to cab upholstery during installation and removal, place thin rigid cardboard or plastic panel between inside cab wall and control panel.

1. Remove seat and support. (See Remove and Install Seat and Support Plate—Tractors With Cab in Group 05.)
2. Remove knobs from all control levers on left-side control console.
3. Remove five screws (A) and control console (B).
4. Remove screws (C and D) and left-side panel (E). Make repairs as necessary.
5. Install panel (E) using screws (C and D).
6. Install console (B), screws (A), and control knobs.
7. Install seat and support. (See Remove and Install Seat and Support Plate—Tractors With Cab in Group 05.)

A—Screw (5 used)  
 B—Control Console  
 C—Screw  
 D—Cap Screw (3 used)  
 E—Control Panel



LV2388 -UN-21NOV97




LV2389 -UN-21NOV97

## Cab Remove and Install

1. Disconnect battery, negative (–) cable first. Remove battery.
2. Drain fuel tank and radiator.
3. Recover/recycle air conditioning refrigerant. (See Recover/Recycle Air Conditioning Refrigerant in Group 20.)
4. Remove rear wheels and support tractor on suitable jack stands.
5. Remove two screws (A) and screws and nuts (B) securing crop guard (C) to cab. Remove crop guard.
6. Remove battery box.
7. Remove mid-mount coupler bracket, if equipped.

A—Screw (2 used)  
B—Screw and Nut  
C—Crop Guard




LV2336 –UN-20NOV97

AG,OUO1085,231 –19-17JUL02-1/20

**NOTE:** Close all openings using caps and plugs.

8. Disconnect two coolant hoses (A and B) at left front corner of cab. Tag hoses for identification to aid during installation. Cap or plug hoses and tubes.

A—Coolant Hose  
B—Coolant Hose



LV1454 –UN-05DEC95

Continued on next page


AG,OUO1085,231 –19-17JUL02-2/20




**NOTE:** Cut all wiring tie straps as necessary.

9. Remove lower trim strip from inside of left front cab post. Disconnect two wiring connectors (A and B). Pull wires through bottom of cab post.
10. Follow remaining red wire lead 002C from left cab post to fuse link junction block on right side of engine and remove red wire lead 002C from right post (C). Pull wire lead away from tractor.

A—Wiring Connector  
B—Wiring Connector  
C—Right Post



LV1455 -UN-05DEC95




LV2337 -UN-20NOV97

Continued on next page

AG,OUO1085,231 -19-17JUL02-3/20

11. Remove three cap screws and nuts (A) and two cap screws (B) securing crop guard (C) to cab. Remove crop guard.

A—Cap Screw and Nut (3 used)  
B—Cap Screw (2 used)  
C—Crop Guard




LV2338 —UN-20NOV97

AG,OUO1085,231 —19-17JUL02-4/20

**NOTE:** Cut all wiring tie straps as necessary.

12. Remove lower trim strip from inside of right front cab post. Disconnect wiring connectors (A). Pull wires through bottom of cab post.

A—Wiring Connector



LV2339 —UN-16DEC97

Continued on next page

AG,OUO1085,231 —19-17JUL02-5/20

90  
15  
17



13. Disconnect A/C Tubing (A). Cap tube ends to prevent contamination.


14. At location in front of left rear axle:

- Disconnect fuel supply line and fuel return line going to fuel tank. Cap or plug all openings.
- Disconnect wire #118A (cab rear tail lights circuit).
- Cut all tie straps as necessary.

15. At location in front of right rear axle:

- Disconnect fuel level sender wiring connector.
- Cut all tie straps as necessary.

A—A/C Tubing




LV2340 -JUN-20NOV97

AG,OOU1085,231 -19-17JUL02-6/20

16. Remove five cap screws and nuts (A), and two screws (B). Repeat this procedure for opposite side of cab.

A—Cap Screw and Nut (5 used)

B—Screw (2 used)



LV2341 -JUN-20NOV97

Continued on next page

AG,OOU1085,231 -19-17JUL02-7/20

17. Remove two screws (A). Repeat this procedure for opposite side of cab.
18. Remove left- and right-side lower front cab windows. (See Remove and Install Lower Front Windows in this group.)

A—Screw (2 used)




LV2342 -UN-20NOV97

AG,OUO1085,231 -19-17JUL02-8/20

19. Remove nut (A), flat washer, and rubber washer from left and right rear cab mounts.
20. Position draft and center lift links fully downward for clearance during cab removal.

A—Nut



LV1459 -UN-13FEB96

Left Rear Cab Mount Shown

Continued on next page


AG,OUO1085,231 -19-17JUL02-9/20

21. Install JDG1580 Cab Lifting Bar (A) to a suitable hoist.
22. Remove retaining lock pin (B) and eye bolt (C) from cab lifting bar (A). Repeat this step on opposite end of cab lifting bar.


**IMPORTANT: Make sure not to crack or damage cab outer roof when installing eye bolt.**

23. Remove two large cap screws located on cab roof and install two 5/8 in. eye bolts (C) in cab roof. Make sure not to crack or damage cab outer roof when installing eye bolt.

A—Cab Lifting Bar JDG1580  
B—Retaining Lock Pin  
C—Eye Bolt (5/8 in.)



Cab Lifting Bar JDG1580



LV7556 —UN-26OCT01

LV7930 —UN-22MAY02


LV7927 —UN-22MAY02

Continued on next page

AG,OUO1085,231 —19-17JUL02-10/20

24. Position hoist and cab lifting bar over tractor.
25. Attach middle holes in cab lifting bar to both 5/8 in. eye bolts (B) using retaining pins (A) as shown. Repeat this step for opposite side of cab.

**A—Retaining Lock Pin (2 used)**  
**B—Eye Bolt (5/8 in.) (2 used)**



Continued on next page

AG,OUO1085,231 -19-17JUL02-11/20


**CAUTION:** Use proper lifting equipment. Lifting the cab from this tractor without using the essential cab lifting bar in this procedure can cause severe injury or damage to cab.

**IMPORTANT:** Cab must be removed rearward from the tractor.

Lift cab slowly! Check all disconnect points to ensure all hoses, tubes, and wires have been disconnected and that there is no binding. Be careful not to tear cab upholstery on control levers. Ensure that rear of cab does not catch on tub under right-side control console.

26. Raise cab slowly and remove from tractor.
27. Lower cab to rest on jack stands or blocks of wood.
28. Make sure rear rubber cab grommets do not stay inside rear cups of cab mounts. Remove rubber grommets from rear cup mounts.
29. With cab off, make repairs to cab or tractor as necessary.

**NOTE:** If necessary, remove cab floor plates. (See *Cab Floor Plates Remove and Install—Early Model Tractors* or *Cab Floor Plate Remove and Install—Later Model Tractors* in this group.)



TS226 -UN-23AUG88

LV7929 -UN-22MAY02

Continued on next page

AG\_OUO1085,231 -19-17JUL02-12/20

**NOTE:** Place thin rigid cardboard or plastic panels against inside cab walls to prevent control levers and console from tearing upholstery when cab is lowered.


*Do not pinch or bind wires, cables, or hoses when installing cab.*

30. Install spacer (A) and washer (B) on chassis. Install rubber mount (C) into cup on bottom of cab. Repeat this procedure for opposite side of cab.
31. Carefully lower cab onto chassis. Install rubber washer (D), flat washer (E), and nut (F), but do not tighten nut at this time. Repeat this procedure for opposite side of cab.

A—Spacer  
B—Washer  
C—Rubber Mount  
D—Rubber Washer  
E—Washer  
F—Nut



LV7929 -UN-22MAY02



LV1627 -UN-13FEB96

Continued on next page

AG,OUO1085,231 -19-17JUL02-13/20

**NOTE:** Use a floor jack under floor plate to raise or lower floor plate to aid during installation of cab to floor plate mounting hardware.

32. Install the five cap screws and nuts (A) and two screws (B). Repeat this procedure for opposite side of cab. Tighten screws and nuts securely.
33. Tighten nuts for rear cab mounts (previously installed) to specification.

**Specification**

Rear Cab Mount Nuts—Torque ..... 203 N•m (150 lb-ft)

34. At location in front of left rear axle:


- Connect fuel supply line and fuel return line going to fuel tank.
- Connect wire #118A (cab rear tail lights circuit).
- Install tie straps as necessary.

35. At location in front of right rear axle:

- Connect fuel level sender wiring connector.
- Install tie straps as necessary.

A—Cap Screw and Nut (5 used)

B—Screw (2 used)



LV2341 -UN-20NOV97

Continued on next page

AG,OUO1085,231 -19-17JUL02-14/20



36. Install lower front cab windows on both sides of cab.  
(See Remove and Install Lower Front Windows in this group.)
37. Install two cap screws (A); the longer of the two screws installs in upper inside corner. Repeat this procedure for opposite side of cab.


A—Cap Screw (2 used)



AG,OUO1085,231 -19-17JUL02-15/20

38. Route wiring harness through right-side cab post and connect wiring connectors (A).
39. Install lower right-side trim strip on interior cab post.

A—Wiring Connector



Continued on next page


AG,OUO1085,231 -19-17JUL02-16/20

**NOTE:** Install new O-rings in A/C tubing. Used or damaged O-rings and seals will leak.

40. Connect A/C tubing (A) at right front corner of cab. Install tie straps as necessary.

41. Install right-side crop guard to front of cab.

**A—A/C Tubing**




LV2340 -UN-20NOV97

AG,OUO1085,231 -19-17JUL02-17/20

42. Route wiring harness through left-side cab post. Connect wiring connectors (A and B) at left front cab post.

43. Install lower trim strip on interior cab post.

**A—Wiring Connector**  
**B—Wiring Connector**





LV1455 -UN-05DEC95

Continued on next page

AG,OUO1085,231 -19-17JUL02-18/20

44. Connect coolant hoses (A and B) at left front corner of cab using tags for identification added during removal.
45. Connect red wire lead 002D/E from left cab post to right post (C) of fuse link junction block on right side of engine.
46. Install tie straps as necessary.
47. Install battery box and battery.
48. Install mid-mount coupler bracket, if removed.

A—Coolant Hose  
B—Coolant Hose  
C—Right Post



Continued on next page

AG,OUO1085,231 -19-17JUL02-19/20

49. Install crop guard (C) on front of cab using cap screws (A) and screws and nuts (B).

50. Install rear wheels. Tighten cap screws to specification.

**Specification**

Rear Wheel Cap Screws—Torque..... 175 N•m (130 lb-ft)


51. Connect battery, positive (+) cable first.

52. Fill fuel tank and radiator.

53. Evacuate and charge air conditioning system. (See Evacuate Air Conditioning System and Charge Air Conditioning System in Group 20.)

54. Start engine and allow it to reach proper operating temperature. Check coolant level in radiator and add coolant as necessary. See Operator's Manual for coolant recommendations.

55. Perform Operational Checkout Procedures. See Section 210, Group 10 of this manual and also Operator's Manual.



A—Cap Screw  
B—Screw and Nut  
C—Crop Guard

LV2336 —UN-20NOV97

AG,OUO1085,231 —19-17JUL02-20/20

## **Cab Floor Plate Remove and Install—Later Model Tractors**

1. Remove cab. (See Cab Remove and Install in this group.)
2. Remove seat and support. (See Remove and Install Seat and Support Plate—Tractors With Cab in this group.)
3. Remove floor mat and sound suppression mat from cab floor.
4. Remove left- and right-side control consoles and panels. (See Remove and Install Right-Side Control Console and Panel—Tractors With Cab and Remove and Install Left-Side Control Console—Tractors With Cab in this group.)
5. Remove battery. (See Remove and Install Battery—Tractors With Cab in Section 40, Group 05.)

Continued on next page

AG,OUO1085,232 –19–17JUL02–1/7

6. Remove nut, cap screw, flat washer, and rubber washer (A). Repeat this step for opposite side of tractor.

7. Remove two cap screws (B). Repeat this step for opposite side of tractor.

**NOTE:** Install a floor jack under battery box to support battery box during removal.

8. Install a floor jack under battery box and remove six cap screws (C) and battery box (D).

9. Remove five cap screws (E) and cover plate (F).

A—Nut, Cap Screw, Flat Washer, and Rubber Washer  
(2 used)


B—Cap Screw (4 used)

C—Cap Screw (6 used)


D—Battery Box

E—Cap Screw (5 used)

F—Cover Plate



LV2390 -UN-20NOV97



LV2391 -UN-20NOV97


Continued on next page

AG,OUO1085,232 -19-17JUL02-2/7




10. Disconnect joystick control cables (A) and remove two cap screws (B).
11. Remove split pin (C) using a punch and hammer.
12. Remove differential lock pedal (D) from lever.
13. Remove receiver-dryer support bracket cap screws (E).

A—Joystick Control Cables  
B—Cap Screw (2 used)  
C—Split Pin  
D—Differential Lock Pedal  
E—Cap Screw (2 used)



LV2392 -UN-20NOV97



LV2393 -UN-20NOV97


Continued on next page

AG,OUO1085,232 -19-17JUL02-3/7



14. Remove two cap screws (A) and throttle pedal.  
Remove floor plate. Make repairs as necessary.

A—Cap Screw (2 used)




LV2394 -UN-20NOV97

AG,OUO1085,232 -19-17JUL02-4/7

15. Install cab floor plate, two cap screws (A), and throttle pedal.

A—Cap Screw (2 used)




LV2394 -UN-20NOV97

Continued on next page


AG,OUO1085,232 -19-17JUL02-5/7

16. Connect joystick control cables (A) and install cap screws (B) securing control cable bracket.
17. Install pedal (D) and split pin (C).
18. Position receiver-dryer support bracket under floor plate and install cap screws (E).

A—Joystick Control Cables  
 B—Cap Screw (2 used)  
 C—Split Pin  
 D—Differential Lock Pedal  
 E—Cap Screw (2 used)



LV2392 -UN-20NOV97



LV2393 -UN-20NOV97

Continued on next page

AG,OUO1085,232 -19-17JUL02-6/7

19. Install cap screw, flat washer, rubber washer, and nut (A). Repeat this step for opposite side of tractor.

20. Install two cap screws (B). Repeat this step for opposite side of tractor.

**NOTE:** Use a floor jack under battery box to support battery box during installation.

21. Install battery box (D) and six cap screws (C).

22. Install cover plate (F) and cap screws (E).

23. Install sound suppression and floor mat on cab floor.

24. Install left- and right-side control consoles and panels. (See Remove and Install Left-Side Control Console—Tractors With Cab and Remove and Install Right-Side Control Console and Panel—Tractors With Cab in this group.)

25. Install seat and support. (See Remove and Install Seat and Support Plate—Tractors With Cab in Group 05.)

26. Install cab. (See Cab Remove and Install in this group.)

A—Nut, Cap Screw, Flat Washer, and Rubber Washer  
(2 used)


B—Cap Screw (4 used)

C—Cap Screw (6 used)


D—Battery Box

E—Cap Screw (5 used)

F—Cover Plate



LV2390 -UN-20NOV97



LV2391 -UN-20NOV97

AG,OUO1085,232 -19-17JUL02-7/7

## Cab Floor Plates Remove and Install—Early Model Tractors

1. Remove cab. (See Cab Remove and Install in this group.)
2. Remove seat and support. (See Remove and Install Seat and Support Plate—Tractors With Cab in Group 05.)
3. Remove floor mat and sound suppression mat from cab floor.
4. Remove left- and right-side control consoles and panels. (See Remove and Install Right-Side Control Console and Panel—Tractors With Cab and Remove and Install Left-Side Control Console—Tractors With Cab in this group.)
5. Remove battery. (See Remove and Install Battery—Tractors With Cab in Section 40, Group 05.)

Continued on next page


AG,OUO1085,233 -19-08SEP00-1/3

6. Remove foot throttle lever.
7. Remove heel plate (A). Repeat for opposite side.
8. Remove lower cowl sealing bracket (B). Repeat for opposite side.
9. Remove front transmission cover (C).

**CAUTION:** Support cab floor plates with a hoist or stands before removing rear transmission cover.

10. With cab floor plates adequately supported, remove rear transmission cover (D).
11. Remove bolt (E) with flat washer and rubber washer. Repeat for opposite side of tractor.
12. Remove floor plates. Make repairs as necessary.

A—Heel Plate (2 used)  
 B—Sealing Bracket  
 C—Front Transmission Cover  
 D—Rear Transmission Cover  
 E—Bolt (2 used)




LV1462 -UN-05DEC95

Continued on next page

AG,OUO1085,233 -19-08SEP00-2/3

13. Install floor plates.
14. Install bolt (E) with flat washer and rubber washer. Repeat for opposite side of tractor.
15. Install rear transmission cover (D).
16. Install front transmission cover (C).
17. Install lower cowl sealing bracket (B). Repeat for opposite side.
18. Install heel plate (A). Repeat for opposite side.
19. Install foot throttle lever.
20. Install battery. (See Remove and Install Battery—Tractors With Cab in Section 40, Group 05.)
21. Install left- and right-side control consoles and panels. (See Remove and Install Left-Side Control Console—Tractors With Cab and Remove and Install Right-Side Control Console and Panel—Tractors With Cab in this group.)
22. Install floor mat and sound suppression mat from cab floor.
23. Install seat and support. (See Remove and Install Seat and Support Plate—Tractors With Cab in Group 05.)
24. Install cab. (See Cab Remove and Install in this group.)



A—Heel Plate (2 used)  
 B—Sealing Bracket  
 C—Front Transmission Cover  
 D—Rear Transmission Cover  
 E—Bolt (2 used)

LV1462 -UN-05DEC95

AG,OUO1085,233 -19-08SEP00-3/3





## Essential Tools


**NOTE:** Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1080,000026F -19-02JUL02-1/12

Recovery and Recycling Station . . . . . JT02050<sup>1</sup>

Servicing air conditioning system using R134a refrigerant.




<sup>1</sup>Used with JT02046 Charging Station. JT02047 Recovery, Recycling, and Recharging Station can be substituted for JT02046 and JT02050.

OUO1080,000026F -19-02JUL02-2/12

RW21613 -UN-17AUG92

Charging Station . . . . . JT02046<sup>1</sup>

Servicing air conditioning system using R134a refrigerant.



<sup>1</sup>Used with JT02050 Recovery and Recycling Station. JT02047 Recovery, Recycling, and Recharging Station can be substituted for JT02046 and JT02050.

OUO1080,000026F -19-02JUL02-3/12

RW21595 -UN-17AUG92

RW19932 -UN-19MAY92

A/C Compressor Clutch Spanner . . . . . JDG747

Remove compressor clutch.




OUO1080,000026F -19-02JUL02-4/12

RW40022 -UN-08SEP93

Pulley Remover . . . . . D05277ST

Remove compressor pulley.



Continued on next page


OUO1080,000026F -19-02JUL02-5/12

## Air Conditioning System

RW19935 -UN-19MAY92

Jaws . . . . . JDG748

Removing compressor pulley (used with D05277ST Puller).




OOU1080,000026F -19-02JUL02-6/12

RW21598 -UN-17AUG92

Forcing Screw Pilot. . . . . JDG771

Removing compressor clutch.




OOU1080,000026F -19-02JUL02-7/12

RW19943 -UN-19MAY92

Compressor Seal Protector . . . . . JDG746


Install seal on compressor.



OOU1080,000026F -19-02JUL02-8/12

Air Conditioning Flushing Unit . . . . . JT02075

Flush air conditioning system.




RW25566 -UN-16DEC96

OOU1080,000026F -19-02JUL02-9/12

RW40022 -UN-08SEP93

Flushing Attachment Kit. . . . . JT02078

Flush air conditioning system.




OOU1080,000026F -19-02JUL02-10/12

RW40022 -UN-08SEP93

Air Conditioning R12/134a Fitting Unit . . . . . JT02098

Connect flushing, purging, and pressure equipment.



OOU1080,000026F -19-02JUL02-11/12

Recovery, Recycling, and Charging Station . . . . JT02047

Servicing air conditioning system using R134a refrigerant

OOU1080,000026F -19-02JUL02-12/12

Service Equipment and Tools

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.

SERVICEGARD is a trademark of Deere & Company

OUO1080,0000270 -19-02JUL02-1/4

Electronic Leak Detector . . . . .JT02081

Detect refrigerant leaks

OUO1080,0000270 -19-02JUL02-2/4

Compressor Holding Fixture . . . . .DFRW20<sup>1</sup>

Hold compressor during repair

<sup>1</sup>Dealer Fabricated Tool—See Section 299

OUO1080,0000270 -19-02JUL02-3/4

Manifold Pressure Gauge Assembly . . . . .JT02051

Test air conditioning system

OUO1080,0000270 -19-02JUL02-4/4

**Other Material**

Number	Name	Use
TY15949 (12 oz) (U.S.) TY15950 (15 lb) (U.S.) TY15951 (30 lb) (U.S.)	Refrigerant R134a	Charge the system.
TY22025 (8.5 oz.) (U.S.)	R134a Compressor Oil	Lubricate the system
2004 (U.S.)	Genesolv Solvent	Flushing air conditioning systems
JT02077 (U.S.)	ART338 A/C Flushing Solvent	Flushing air conditioning systems
673 (U.S.)	Naphtha Parts Solvent	Flushing air conditioning systems
TY16134 (U.S.)	R134a Flushing Solvent	Flush system

OUO1080,0000271 -19-02JUL02-1/1

**Specifications**

Item	Measurement	Specification
Compressor Shaft Bolt	Torque	14 N•m (10 lb-ft)
Compressor Through Bolts	Torque	26 N•m (19 lb-ft)
Compressor Pulley-to-Clutch Hub	Clearance	0.35—0.65 mm (0.014—0.026 in)
Compressor Relief Valve	Torque	12—16 N•m (9—12 lb-ft)
Manifold-to-Compressor Cap Screws	Torque	26 N•m (19 lb-ft)
Evacuating System	Vacuum	94.4 kPa (0.9 bar) (28.6 in. Hg) required at sea level
Flushing Solvent—Suction Port	Volume	240 ml (8 fl oz)
Flushing Solvent—Discharge Port	Volume	120 ml (4 fl oz)
Clutch Coil	Current Draw	2.6 amps at 12 volts, 20° C (68°F)
Clutch Coil	Resistance	3.5—4.0 ohms at 20° C (68°F)
Compressor Discharge Line	Torque	32—40 N•m (24—29 lb-ft)
Compressor Suction Line	Torque	34—42 N•m (25—31 lb-ft)

OUO1080,0000272 -19-02JUL02-1/1

## Service Parts Kits

The following kits are available through your parts catalog:

- Compressor Shaft Seal Kit
- Compressor Clutch Hub and Pulley Kit
- Compressor Clutch Coil Kit
- Compressor Hardware Kit

AG,OUO1085,234 -19-08SEP00-1/1

## Hose and Tubing O-Ring Connector Torques

Metal Tube Outside Diameter	Thread and Fitting Size	Torque	
1/4	7/16	14—20 N•m	10—15 lb-ft
3/8	5/8	14—20 N•m	10—15 lb-ft
1/2	3/4	33—39 N•m	24—29 lb-ft
5/8	7/8	35—42 N•m	26—31 lb-ft
3/4	1-1/16	41—47 N•m	30—35 lb-ft

AG,OUO1085,295 -19-17JUL02-1/1

## Recover/Recycle Air Conditioning Refrigerant

Operate the air conditioning system for 10 minutes with engine at 2000 rpm if the compressor is operable. Set temperature control for maximum cooling and blower switch at high. This allows the refrigerant oil to be circulated through the system and indicates the quantity of oil in the compressor.

Stop the engine and use the following procedure to recover and recycle the A/C refrigerant.

**IMPORTANT: Use only R134a Refrigerant Recovery, Recycling, and Charging machines. Do not mix R134a equipment, refrigerant, and refrigerant oils with R-12 systems to prevent compressor damage.**

1. Connect JT020 R134a Refrigerant Recovery and Recycling Unit to a JT02046 HFC134a Refrigerant Charging Unit.

*NOTE: JT02047 R134a Refrigerant Recovery, Recycling, and Charging Unit can be substituted for the JT02046 and JT02050.*

2. Connect low-side hose (blue) from the charging unit to suction fitting (A) on the compressor. Connect high-side hose (red) to the discharge fitting (B) on the compressor.
3. Follow the manufacturer's instructions and discharge the system. Cap the fittings to prevent contamination from entering the system.



A—Suction Fitting (Low Side)  
B—Discharge Fitting (High Side)

LV2395 -UN-16DEC97

AG,OUO1085,235 -19-08SEP00-1/1

## Replace Air Conditioning Receiver-Dryer

**NOTE:** The receiver-dryer is not serviceable. If malfunction is suspected, install new receiver-dryer.

*If the air conditioning system is discharged for servicing and the receiver-dryer is two years old or older, it should be replaced. If receiver-dryer is less than two years old, it should be replaced only if the system was contaminated.*

1. Recover/recycle air conditioning refrigerant. (See Recover/Recycle Air Conditioning Refrigerant in this group.)

**NOTE:** Receiver-dryer is located under right-side cab floor.


2. Remove right-side crop guard.

**NOTE:** Cap or plug all lines to prevent contamination.

3. Disconnect lines (A and B) from receiver-dryer. Cap or plug all lines to prevent contamination
4. Remove nut and cap screw (C) located between receiver-dryer and transmission housing. Replace receiver-dryer.

**NOTE:** When a new receiver-dryer is installed and there were no leaks found in the system, add 15 ml (0.5 oz) of R134a refrigerant oil. If leaks are evident in the system, follow procedure for checking and adding refrigerant oil. (See Determine Correct Refrigerant Oil Charge in this group.)

5. Install receiver-dryer marked (TOP) in up position. Tighten lines (A and B).
6. Install and tighten cap screw and nut (C).
7. Evacuate and charge the system. (See Evacuate Air Conditioning System and Charge Air Conditioning System in this group.)



A—Line  
B—Line  
C—Cap Screw and Nut

LV2397 -UN-16DEC97



## Remove, Inspect, and Install Air Conditioning Condenser

1. Recover/recycle air conditioning refrigerant. (See Recover/Recycle Air Conditioning Refrigerant in this group.)

2. Remove right and left side grille panels.

**NOTE:** Cap or plug all lines to prevent contamination.


3. Disconnect condenser outlet line (A) and inlet line (B).  
Cap or plug all lines to prevent contamination
4. Remove nut (C) from each side of condenser.
5. Remove cap screws and nuts (D) from each side of condenser.
6. Remove and inspect condenser.

**CAUTION:** Reduce compressed air to less than 210 kPa (2 bar) (30 psi) when using for cleaning purposes between fins. Clear area of bystanders, guard against flying chips, and wear personal protection equipment including eye protection.

7. Check condenser for debris lodged in fins. Clean condenser using compressed air or pressure washer.
8. Inspect condenser for bent fins, cracks, and damaged seams. Repair as necessary.
9. Test condenser for leaks by spraying the surface using a 50-50 mixture of liquid soap and water.
10. Cap or plug the outlet tube on the condenser.
11. Apply 689 kPa (68.9 bar) (100 psi) of air pressure to the inlet tube and check for leaks.

**NOTE:** Minor leaks may be repaired, but condenser should be replaced if there is a major leak or restriction.

12. Repair or replace condenser unit as required.



A—Condenser Outlet Line  
B—Condenser Inlet Line  
C—Nut (2 used)  
D—Cap Screw and Nut (6 used)


Continued on next page

AG,OUO1085,237 -19-08SEP00-1/2

**IMPORTANT:** Always use new O-rings and seals.  
Damaged or used O-rings and seals will leak.

13. Flush the air conditioning condenser if condenser was tested for leaks using air pressure. (See Flush Air Conditioning System in this group.)
14. Install air conditioning condenser.
15. Install cap screws and nuts (D) on each side of condenser.
16. Install nuts (C) on each side of condenser.
17. Connect condenser outlet line (A) and inlet line (B).
18. Install right and left side grille panels.
19. Evacuate and charge air conditioning system. (See Evacuate Air Conditioning System and Charge Air Conditioning System in this group.)

A—Condenser Outlet Line  
B—Condenser Inlet Line  
C—Nut (2 used)  
D—Cap Screw and Nut (6 used)




LV2253 -UN-16DEC97

AG,OUO1085,237 -19-08SEP00-2/2


## Remove, Inspect, and Install Air Conditioning Compressor

1. Recover/recycle air conditioning refrigerant. (See Recover/Recycle Air Conditioning Refrigerant in this group.)
2. Remove right and left side grille panels.
3. Remove nut (A), cap screw (B), and bracket (C).
4. Release tension on belt tensioner (D) and remove belt (E) off compressor pulley.

A—Nut  
B—Cap Screw  
C—Radiator Support Bracket  
D—Belt Tensioner  
E—Drive Belt



LV2398 -UN-16DEC97



LV2399 -UN-16DEC97

Continued on next page


AG.OUO1085,238 -19-08SEP00-1/2

5. Disconnect clutch coil wire connector (A).

*NOTE: Cap all lines and fittings to prevent contamination.*

6. Disconnect suction line (B) and discharge line (C) from compressor. Cap all lines and fittings to prevent contamination.
7. Remove three cap screws (D) and ground wire (E). Remove compressor.
8. Repair or replace compressor if necessary.
9. Flush the complete system if the compressor failed internally due to damaged parts or seizure. (See Flush Air Conditioning System in this group.)
10. Determine correct compressor oil charge. (See Determine Correct Refrigerant Oil Charge in this group.)
11. Position compressor on mounting bracket. Install three cap screws (D) and ground wire (E).
12. Connect suction (B) and discharge (C) lines to compressor.
13. Connect clutch coil wire connector (A).
14. Install drive belt on compressor pulley.
15. Install radiator support bracket and side grille panels.
16. Evacuate and recharge system. (See Evacuate Air Conditioning System and Charge Air Conditioning System in this group.)

**IMPORTANT:** If new compressor clutch was installed, turn compressor on and off (with engine running) in one second intervals for five seconds (cycle five times in five seconds). This will burnish clutch and hub drive surfaces.



A—Wire Connector  
B—Suction Line  
C—Discharge Line  
D—Cap Screw (3 used)  
E—Ground Wire

LV2400 -UN-16DEC97



## Test Volumetric Efficiency of Compressor

1. Drain oil from compressor and record amount.
2. Remove front cover from compressor pulley and rotate drive shaft using a speed wrench and 10 mm socket, 30 turns.
3. Drain remaining oil from compressor and record amount.


If oil was drained in steps 1 and 3, go to step 4.

If no oil was drained, add two ounces of R134a refrigerant oil in suction port and slowly roll compressor in each direction at least two times. Repeat steps 1, 2, and 3.

4. Secure compressor in a vise with ports upward.
5. Install JT02099 Adapter in suction port with JT03194 Cap.
6. Connect suction hose coupler of gauge set to suction test port (A) on manifold.
7. Close discharge side valve of gauge set and open valve on suction side of gauge set.
8. Rotate compressor drive shaft with speed wrench to obtain peak vacuum on low-side gauge. Check for even suction (no pulsing) while turning wrench at a slow rate to maintain peak vacuum (25 in. Hg minimum).
9. Stop rotating shaft and check leak-down time. Compressor should hold peak vacuum for three seconds minimum.

If compressor does not hold peak vacuum for three seconds, inspect compressor valve plates and cylinder walls for damage. Repair compressor.

10. Open suction port of compressor to atmosphere.



A—Suction Test Port

LV1463 -UN-05DEC95

Continued on next page

AG,OUO1085,239 -19-17JUL02-1/2


11. Connect gauge set suction hose to discharge port (A) using Adapters JT02100 and JT02121, and JT02109 Hose.
12. Close gauge set suction side valve.
13. Rotate drive shaft no faster than two turns per second for six turns.
14. Record pressure after six complete turns. Pressure should be 380 kPa (3.8 bar) (55 psi) minimum.

*NOTE: Pressure normally leaks down when rotation stops.*

15. Continue to rotate compressor at a uniform speed to obtain peak pressure. Compression pressure should increase smoothly and should not vary more than 34 kPa (0.34 bar) (5 psi) at peak pressure. Bleed off pressure and repeat steps 12, 13, 14, and 15 four times.

*NOTE: Pressure varying more than 34 kPa (0.34 bar) (5 psi) indicates a leaking reed valve or piston seal. Inspect compressor valve plates and cylinder walls for damage. Repair compressor.*

16. Leak test compressor. (See Test Compressor Shaft Seal Leakage in this group.)



A—Discharge Port

LV1464 -UN-05DEC95

AG,OUO1085,239 -19-17JUL02-2/2

## Test Compressor Shaft Seal Leakage

1. Remove front plate from compressor pulley.
2. Remove clutch hub and screw.

**IMPORTANT: Do not lose inner clutch hub shims.**

3. Install JT02099 Adapter in suction port and JT02100 in discharge port. Cap discharge port adapter using JT03194.
4. Connect gauge set and/or container of R134a refrigerant to suction port of compressor as shown in photo.
5. Open valves to pressurize compressor.

**IMPORTANT: Do not exceed range of low pressure gauge.**

6. Check the following for leaks using leak detector or 50-50 mix of soap and water:
  - Shaft seal
  - Manifold seal
  - Housing seals at front, rear, and midsection of compressor body
  - Relief valve
  - Suction coupler Schrader valve

Leakage should not exist. Repair compressor if required, and repeat test.

7. Assemble compressor and add required oil. (See Determine Correct Refrigerant Oil Charge in this group.)



LV1465 -UN-05DEC95



## Disassemble and Assemble Compressor Clutch


1. Mount compressor on DFRW20 Compressor Holding Fixture using two 6 in. x 1/4 in. eye bolts with nuts as illustrated. (See DFRW20—Compressor Holding Fixture in Section 299.)
2. Remove dust cover.
3. Hold clutch hub using JDG747 Compressor Clutch Spanner (A) and remove clutch shaft bolt (B).
4. Remove clutch hub (C). Remove shims (H) from clutch hub and save for installation.
5. Remove and discard snap ring (D). Remove pulley (E) using a plastic hammer or D05277ST Puller, JDG748 Jaws, and JDG771 Forcing Screw Pilot.
6. Disconnect clutch coil lead wire. Remove and discard snap ring (F) and remove the clutch coil (G).

**NOTE:** The bearing in the pulley is **NOT** serviceable.


7. Check pulley bearing operation. Replace pulley and bearing as required.
8. Install clutch coil (G) and new snap ring (F) with flat side of snap ring down. Connect clutch coil lead wire.
9. Install Pulley (E) and new snap ring (D) with flat side of snap ring down. Apply grease to shims (H) and install to clutch hub (C).
10. Install clutch hub (C) and shaft bolt (B) and tighten to specification. Install dust cover.

### Specification

Compressor Shaft Bolt—Torque ..... 14 N•m (10 lb-ft)



LV1466 -UN-05DEC95




- A—JDG747 Compressor Clutch Spanner  
 B—Clutch Shaft Bolt  
 C—Clutch Hub  
 D—Pulley Snap Ring  
 E—Pulley  
 F—Clutch Coil Snap Ring  
 G—Clutch Coil  
 H—Shim

RW21158 -UN-29JUL98

AG,OUO1085,241 -19-17JUL02-1/1

## Disassemble, Inspect, and Assemble Compressor



A—Rear Pins  
B—Rear Housing

C—Rear Gasket  
D—Rear Discharge Reed Valve  
E—Rear Valve Plate  
F—Rear Suction Reed Valve

G—Rear O-Ring  
H—Front O-Ring  
I—Front Suction Reed Valve  
J—Front Valve Plate  
K—Front Discharge Reed Valve

L—Front Gasket  
M—Snap Ring  
N—Lip Seal  
O—Washer  
P—Through Bolt

Q—Felt Holder  
R—Felt  
S—Front Housing  
T—Front Pins

1. Clean compressor using solvent before disassembly. Mount compressor on holding fixture and remove clutch. (See Disassemble and Assemble Compressor Clutch this group.)

**IMPORTANT:** When removing front and rear housing, be careful NOT to damage sealing surfaces.

2. Disassemble compressor as illustrated and discard O-rings, gaskets, lip seal, snap ring, and through bolt washers. Replace parts.

**NOTE:** Valve plates, reed valves, cylinders, and cylinder housing are NOT serviceable. Some cylinder scuffing (light scratches) is normal.

3. Inspect valves for an even wear pattern, and cylinders for scoring or excessive wear. Replace compressor as required.
4. Remove shaft seal snap ring (M). Turn housing over and remove felt holder (Q) and felt (R) from front housing (S).

RW21161 -UN-24JUN92

Continued on next page

AG,OUO1085,242 -19-17JUL02-1/4

*Air Conditioning System*

5. Remove shaft lip seal (N) from front housing (S) using a small tool with 5/8 in. OD.

6. Wash all parts in clean solvent and dry using moisture-free compressed air before assembly.

Continued on next page

AG,OUO1085,242 -19-17JUL02-2/4

**IMPORTANT:** Lubricate O-rings, gaskets, and lip seal using only TY22025 (R134a) refrigerant oil during assembly. Other oils could damage the compressor.

7. Apply R134a oil to the bore of the front housing and install new lip seal (N) to the bottom of the bore using a socket. Install new snap ring (M) flat side down.

**IMPORTANT:** Bushing spacer (U) must be in position before assembling the compressor.

8. Install pins (A) and new O-ring (G) in the rear cylinder.

*NOTE: The rear valve plate is marked with an "R" and is installed face up.*

9. Install parts (F—D) over the pins on the rear cylinder.

10. Install a new gasket (C) flat side down and the rear housing (B) on the rear cylinder. Mount the compressor onto the holding fixture.

11. Install pins (T) and new O-ring (H) in the front cylinder.

*NOTE: The front valve plate is marked with an "F" and is installed face up.*

12. Install parts (I—K) over the pins on the front cylinder.

13. Install a new gasket (L) flat side down. Put JDG746 lip seal protector on the shaft and lubricate with R134a oil.


14. Install the front housing (S) on the front cylinder and remove the lip seal protector. Install through bolts (P) and new washers (O).

15. Partially tighten the through bolts and then tighten to specification.

#### Specification

Compressor Through Bolts—  
Torque ..... 26 N•m (19 lb-ft)

16. Install the felt (R) and felt holder (Q) using the clutch hub.



C—Rear Gasket  
D—Rear Discharge Reed Valve  
E—Rear Valve Plate  
F—Rear Suction Reed Valve  
U—Bushing Spacer

RW21162 -UN-24JUN92

RW21163 -UN-24JUN92

Continued on next page

AG,OUO1085,242 -19-17JUL02-3/4

17. Install the pulley-clutch hub and check clearance.  
(See Disassemble and Assemble Compressor Clutch in this group.)

AG,OUO1085,242 -19-17JUL02-4/4

## Check Compressor Clutch Hub Clearance

**NOTE:** The clutch coil is NOT polarity sensitive.

1. Check pulley-to-clutch hub clearance using a dial indicator. Mount the gauge to the pulley as illustrated and connect a set of jumper wires from the compressor to a 12V battery.
2. Rotate the pulley and check clearance in three equally spaced locations around the clutch hub. Add or remove shims as required to meet specification.


### Specification

Compressor Pulley-to-Clutch  
Hub—Clearance ..... 0.35—0.65 mm (0.014—0.026 in)

3. Tighten clutch shaft bolt to specification after correct clearance is obtained.

### Specification

Compressor Shaft Bolt—Torque ..... 14 N•m (10 lb-ft)




AG,OUO1085,243 -19-17JUL02-1/1

## Inspect Compressor Manifold

1. Remove cap screws (A) and the manifold (B).
2. Remove and discard seal (C). Inspect porting surfaces.
3. Lubricate and install a new seal (C).
4. Install manifold (B) and tighten cap screws (A) to specification.

### Specification

Compressor Through Bolts—  
Torque ..... 26 N•m (19 lb-ft)



A—Manifold Cap Screw  
B—Manifold  
C—Manifold Seal

AG,OUO1085,244 -19-17JUL02-1/1

## Remove and Install Compressor Relief Valve



**CAUTION:** High pressure may exist at the discharge fitting. If this pressure is released too rapidly, there may be considerable discharge of refrigerant and oil.

1. Recover/recycle air conditioning refrigerant. (See Recover/Recycle Air Conditioning Refrigerant in this group.)
2. Slowly remove relief valve (A) from compressor.


**NOTE:** The relief valve is not serviceable. Replace valve as required.

3. Install relief valve (A) and tighten to specification.

### Specification

Compressor Relief Valve—  
Torque ..... 12—16 N•m (9—12 lb-ft)

4. Charge the system. (See Charge Air Conditioning System in this group.)



LV2401 -UN-16DEC97

**A—Relief Valve**

AG,OUO1085,245 -19-17JUL02-1/1




## Remove and Install Evaporator/Heater Core Housing Cover

1. Remove cab roof. (See Remove and Install Cab Roof in Group 15.)
2. Remove front headliner. (See Remove and Install Front Headliner in Group 15.)
3. Remove four screws (A) and headliner support bracket (B). Repeat procedure for opposite side of cab. Cut tie straps as necessary.
4. Remove two screws (C) retaining lower leg of housing cover. Repeat procedure for opposite side of cab.


**NOTE:** During removal of evaporator/heater core housing cover, move wiring harnesses in cab roof away from cover.

5. Remove thirteen screws (D). Slide cover (E) toward front of cab and remove cover. Make repairs as necessary.

A—Screw (8 used)  
 B—Headliner Support Bracket  
 C—Screw (14 used)  
 D—Screw (13 used)  
 E—Evaporator/Heater Core Housing Cover



Headliner Support Bracket Left Side




Continued on next page

AG,OUO1085,246 -19-08SEP00-1/2




6. Install housing cover (E) and thirteen screws (D).
7. Install screws (C) securing housing cover lower leg to cab frame. Repeat procedure for opposite side of cab.
8. Install headliner support bracket (B) and screws (A). Secure drain tubes using tie straps as necessary. Repeat procedure for opposite side of cab.
9. Install front headliner. (See Remove and Install Front Headliner in Group 15.)
10. Install cab roof. (See Remove and Install Cab Roof in Group 15.)

**A—Screw (8 used)**  
**B—Headliner Support Bracket**  
**C—Screw (14 used)**  
**D—Screw (13 used)**  
**E—Evaporator/Heater Core Housing Cover**




Headliner Support Bracket Left Side

LV2406 -UN-06JAN98



LV2407 -UN-16DEC97




LV2408 -UN-06JAN98

## Remove Blower Motors


**NOTE:** Evaporator/heater core housing shown removed from cab for clarity of photos only. It is not necessary to remove housing.

1. Remove evaporator/heater core housing cover. (See Remove and Install Evaporator/Heater Core Housing Cover in this group.)
2. Disconnect blower motor wiring connectors (A).
3. Remove clamp securing hose (B) to housing.
4. Remove four screws (C) and remove blower motor. Repeat this procedure for left-side blower motor if removal is necessary.
5. When installing motor, be sure resistor assembly (D) is installed in air flow of right-side blower motor as shown.

A—Wiring Connectors  
B—Hose  
C—Screws  
D—Resistor Assembly



LV1446 -UN-05DEC95



LV1447 -UN-05DEC95

AG\_OUO1085,247 -19-08SEP00-1/1

## Remove Evaporator/Heater Core


1. Remove evaporator/heater core housing cover. (See Remove and Install Evaporator/Heater Core Housing Cover in this group.)

**NOTE:** Remove right-side blower motor to aid during removal of ALLEN HEAD® screw (B).


2. Remove right-side blower motor only. (See Remove Blower Motors in this group.)
3. Disconnect coolant inlet hose (A) and outlet hose from heater core tubes.
4. Remove ALLEN HEAD® screw (B) and clamping plate. Remove tubes (C and D). Cap all openings to prevent contamination.

**NOTE:** Take note of routing and position of wiring harness and grommets (F and G).

5. Lift evaporator/heater core and expansion valve from housing as a unit.
6. Disconnect expansion valve (E) from core. Cap all lines and fittings to prevent contamination.



LV1448 -UN-05DEC95



LV1449 -UN-05DEC95

- A—Inlet Hose
- B—ALLEN HEAD® Screw
- C—Tube
- D—Tube
- E—Expansion Valve
- F—Grommet
- G—Grommet

ALLEN HEAD is a trademark of Holo-Krome Technology

AG,OUO1085,248 -19-11SEP00-1/1

## Leak Test Evaporator/Heater Core

1. Install JT02106 Test Block using JT02124 and JT02123 Plates, JT02126 and JT02125 Screws, and JT02105 and JT02103 Adapters. Cap one adapter with JT03094. Connect shop air to other adapter.
2. Apply shop air pressure and spray surface using 50-50 mixture of liquid soap and water to check for leaks.

*NOTE: Minor leaks may be repaired, but evaporator/heater core should be replaced if there is a major leak or restriction.*

3. Repair or replace evaporator/heater core as required.


AG,OUO1085,249 -19-11SEP00-1/1

## Install Evaporator/Heater Core


1. Check condenser tray (directly under evaporator/heater core) to make sure drain outlets are not plugged.
2. Flush evaporator core if evaporator was air tested.
3. If evaporator was completely flushed or replaced with a new unit, and no major system leaks were found, add 60 ml (2.0 oz) of refrigerant oil before installation. If leaks are found in the system, check refrigerant oil charge. (See Determine Correct Refrigerant Oil Charge in this group.)

**NOTE:** Install new O-rings at all A/C connections during assembly. Used or damaged O-rings will leak.

4. Assemble the expansion valve (E) to the evaporator core and install the evaporator/heater core in the housing. Route wire harness through housing and install grommets (F and G) as shown.
5. Connect tubes (C and D) to expansion valve (E) and install clamping plate with ALLEN HEAD® screw (B).
6. Connect coolant inlet hose (A) and outlet hose to heater core tubes.
7. Install right-side blower motors. (See Remove Blower Motors in this group.)
8. Install evaporator/heater core housing cover. (See Remove and Install Evaporator/Heater Core Housing Cover in this group.)



LV1448 -UN-05DEC95



LV1449 -UN-05DEC95

- A—Inlet Hose
- B—ALLEN HEAD® Screw
- C—Tube
- D—Tube
- E—Expansion Valve
- F—Grommet
- G—Grommet

ALLEN HEAD is a trademark of Holo-Krome Technology

AG,OUO1085,250 -19-11SEP00-1/1

## Service Expansion Valve


*NOTE: The expansion valve is assembled to the evaporator/heater core prior to installation and is removed as a unit from the HVAC box.*

1. Remove expansion valve. (See Remove Evaporator/Heater Core this group.)
2. Test expansion valve. (See Expansion Valve Bench Test—Diagram and Expansion Valve Bench Test in this group.)
3. Replace expansion valve as required and assemble to evaporator/heater core.
4. Install expansion valve and evaporator/heater core as a unit in the HVAC box. (See Install Evaporator/Heater Core in this group.)

AG,OUO1085,251 -19-11SEP00-1/1



# Expansion Valve Bench Test—Diagram



RW40024 -UN-27AUG93

- |                         |                             |                            |                                    |
|-------------------------|-----------------------------|----------------------------|------------------------------------|
| A—Regulator             | G—Hose (JT02108)            | L—Plate (R115927/JT02123)  | Q—Plate (L77942/JT02124)           |
| B—Tee (JT03191)         | H—Regulator Inlet (#218887) | M—Screw (AT127259/JT02125) | R—Screw (M67175/JT02126)           |
| C—Orifice Cap (JT02111) | I—Tube (JT02103)            | N—Tube (JT02109)           | S—Air Inlet Tee Assembly (JT02112) |
| D—Hose (JT02109)        | J—Tube (JT02105)            | O—Elbow (JT05483)          | T—Power Head                       |
| E—Tube (JT02105)        | K—Cap (JT03194)             | P—Orifice Cap (JT02111)    |                                    |
| F—Expansion Valve       |                             |                            |                                    |

AG.OUO1085,252 -19-11SEP00-1/1



## Expansion Valve Bench Test

1. Connect expansion valve to regulator (A) capable of 820 kPa (8.2 bar) (120 psi).
  - Install tee (B) with 0.020 in. orifice cap (C) at regulator outlet.
  - Connect blue hose (D) between tee (B) and tube (E) on inlet side of expansion valve (F).
  - Connect red hose (G) between elbow at inlet of regulator (H) and tube (I) at inlet of expansion valve.
  - Install tube (J) with cap (without orifice) (K) on expansion valve outlet. Secure tubes with plate (L) and screws (M).
  - Install tube (N) with 90° elbow (O) and orifice cap (P) on expansion valve outlet. Secure tubes with plate (Q) and screw (R).

*NOTE: Both orifice caps used must have a 0.020 in. orifice. Any other size will produce false results.*

2. Fill container with ice water.
3. Attach regulator assembly to air supply (S) of 620 kPa (6.2 bar) (90 psi) minimum.
4. Adjust regulator unit until air flowing from outlet side of expansion valve (P) is shut off. Air should stop flowing at 520—590 kPa (5.2—5.9 bar) (75—85 psi).
5. Adjust regulator to approximately 70 kPa (0.7 bar) (10 psi). Hold power head of expansion valve (T) in ice water and slowly adjust regulator to increase pressure. Air flow from orifice (P) should stop at 170—240 kPa (1.7—2.4 bar) (25—35 psi).
6. Adjust regulator to 280 kPa (2.8 bar) (40 psi). Valve should close when power head of expansion valve is dipped in ice water. Valve should open after removing valve from water and warming power head.
7. Repeat step 6, adjusting regulator to 480 kPa (4.8 bar) (70 psi).
8. Replace valve if any test failed. Install valve.

Continued on next page

AG,OUO1085,253 -19-11SEP00-1/2

90  
20  
29

9. Perform diagnostic checks. (See Operation and Test TM—Section 290, Group 10.)

AG,OUO1085,253 -19-11SEP00-2/2

## Refrigerant Oil Information



**CAUTION:** New compressors are charged with a mixture of nitrogen, R134a refrigerant, and TY22025 (R134a) refrigerant oil. Wear safety goggles and discharge compressor slowly to avoid possible injury.

New compressors contain 230—255 ml (7.7—8.5 fl oz) of new oil. The oil level visible through the suction port is normally below the drive shaft. The amount of trapped oil is 81 ml (2.7 fl oz). Approximately 60 ml (2.0 fl oz) will seep into the cylinders during shipping and storage.

Typically 21 ml (0.7 fl oz) of oil covers internal surfaces of the compressor exposed to refrigerant gas and cannot be drained.

The oil level will be above the drive shaft when 255 ml (8.5 fl oz) is put in a dry compressor.

The normal operating oil level of a used compressor is 30—45 ml (1.0—1.5 fl oz) and cannot be seen through the suction port.

AG,OUO1085,254 -19-11SEP00-1/1

## Check Compressor Oil Charge

1. Remove compressor. (See Remove, Inspect, and Install Air Conditioning Compressor in this group.)
2. Remove manifold caps and drain oil. Record amount.

*NOTE: Save oil if compressor is new.*

3. If **more** than 6 ml (0.2 fl oz) of oil was drained and appears normal, or any other components were replaced or flushed, see Determine Correct Refrigerant Oil Charge in this group.

If **less** than 6 ml (0.2 fl oz) of oil was drained or appears very black, perform the following:

- Perform a volumetric efficiency test on compressor to determine serviceable condition. Flush with solvent to internally wash out oil if compressor is serviceable. (See Test Volumetric Efficiency of Compressor in this group.)
- Remove, clean, and bench test expansion valve, but do not disassemble valve. (See Expansion Valve Bench Test—Diagram and Expansion Valve Bench Test in this group.)
- Remove and discard receiver-dryer. (See Replace Air Conditioning Receiver-Dryer in this group.)
- Install a new receiver-dryer.
- Flush complete system. (See Flush Air Conditioning System in this group.)
- Install required oil. (See Determine Correct Refrigerant Oil Charge in this group.)
- Connect all components.
- Purge, evacuate, and charge system. (See Flush Air Conditioning System, Evacuate Air Conditioning System and Charge Air Conditioning System in this group.)

AG,OUO1085,255 -19-11SEP00-1/1

## Determine Correct Refrigerant Oil Charge

**NOTE:** Determine amount of oil charge for system prior to installation of compressor.

Compressors are divided into three categories when determining correct oil charge.

- New compressor
- Used compressor, not flushed
- Used compressor, flushed

1. If complete system, lines, and components were flushed, add correct amount of oil:

- New compressor contains correct amount of new oil, 255 ml (8.5 fl oz).
- Used compressor (drained) —  
Not Flushed: add 230 ml (7.7 fl oz) of new oil  
Flushed: add 255 ml (8.5 fl oz) of new oil

2. If complete system was not flushed, add correct amount of oil for compressor plus amount of oil for each component serviced:

- New compressor contains 255 ml (8.5 fl oz) of new oil. Connect battery to clutch coil and rotate drive shaft to remove all oil. Return 45 ml (1.5 fl oz) of oil to compressor.
- Used compressor (drained) —  
Not Flushed: add 45 ml (1.5 fl oz) of new oil  
Flushed: add 60 ml (2.0 fl oz) of new oil

**IMPORTANT: Use care in checking and adding oil. Too much oil will reduce cooling capacity. Too little oil will result in poor lubrication of the compressor, leading to early failure.**

Remove compressor to determine correct oil charge if any components listed below have been removed, drained, and flushed.

Use the following chart as a guide for adding oil:

Continued on next page

AG,OUO1085,257 -19-17JUL02-1/2

**NOTE:** If the complete system was purged with all components in place, the amount of oil lost is negligible.

Adding Oil—Refrigerant Oil Charge	
Evaporator	60 ml (2.0 fl oz)
Condenser	60 ml (2.0 fl oz)
Receiver-Dryer	15 ml (0.5 fl oz)
Compressor	60 ml (2.0 fl oz)
Hoses	60 ml (2.0 fl oz)

**NOTE:** Hoses = 3 ml per 30 cm (0.1 fl oz per ft).  
Approximate total length equals 600 cm (20 ft).

If any section of hose is removed and flushed or replaced, measure length of hose and use the formula to determine correct amount of oil to be added.

**IMPORTANT:** DO NOT leave the system or R134a compressor oil containers open. Oil easily absorbs moisture.

**DO NOT** spill R134a compressor oil on acrylic or ABS plastic. Oil will deteriorate these materials rapidly.

**Identify R134a oil containers and measures to eliminate accidental mixing of different oils.**

AG,OUO1085,257 -19-17JUL02-2/2

## Add Refrigerant Oil to System

1. Add approximately 170 ml (5.6 fl oz) of oil through compressor suction port and 85 ml (2.9 fl oz) into discharge port when system has been completely flushed.

**IMPORTANT:** Use only TY22025 (R134a) refrigerant oil.

*NOTE: Some oil may have to be added through compressor line and fitting.*

2. Install manifold to compressor, if removed. Tighten cap screws to specification.

### Specification

Manifold-to-Compressor Cap

Screws—Torque..... 26 N•m (19 lb-ft)

AG,OUO1085,258 -19-17JUL02-1/1

## System Information

### Flushing:

Flushing the system or a component is a cleaning process using a liquid solvent to wash out oil and debris. Purging is always necessary after flushing to remove solvent from the system or component.

### Purging:

Purging the system or a component is a cleaning process using a gas to force liquid from the system. Purging alone will not force refrigerant oil out of the system.

### Evacuating:

Evacuating the system is a process to draw air and moisture from the system with a vacuum.

#### Specification

Evacuating System—Vacuum ..... 94.4 kPa (0.9 bar) (28.6 in. Hg)  
required at sea level

### When to flush an air conditioning system:

- The compressor has an internal failure
- No oil remains in used compressor
- Oil drained from compressor appears or smells overheated
- System was contaminated with a mixture of refrigerant oils
- System was left open to the atmosphere long enough for dirt, moisture, or debris to enter the tubing or components
- System has an internal blockage

### When to purge an air conditioning system:

- After flushing system with solvent, to prevent oil dilution
- System was contaminated with nitrogen or two refrigerants
- System was left open to the atmosphere and flushing could not be performed
- A repair required installation of new lines, condenser, or evaporator

### Solvents

Continued on next page

AG,OUO1085,259 -19-17JUL02-1/2

90  
20  
35



The following three solvents are recommended for flushing air conditioning systems. Each adequately dissolves oil and sludge but at a different rate. Use only solvents with an equivalent MSDS.

1. Genesolv 2004 Solvent
2. ART338 A/C Flushing Solvent (JT02077)
3. Naphtha 673 Parts Solvent

AG,OUO1085,259 -19-17JUL02-2/2

Flush Air Conditioning System

Review air conditioning system diagram showing adapters used at each hose and component connection.

Add flushing solvent to system with JT02075 Flusher and JT02078 Attachment Kit. Use JT02098 Fitting Kit.

- 1. Discharge system. (See Recover/Recycle Air Conditioning Refrigerant in this group.)
- 2. Remove compressor and measure oil drained from both manifold ports.
- 3. Clean compressor as follows:
  - Pour 240 ml (8 fl oz) of flushing solvent into suction port and 120 ml (4 fl oz) into discharge port. Plug both ports in compressor manifold, using JT02099 and JT02100 with JT03194 caps.

Specification

Flushing Solvent—Suction Port—  
Volume..... 240 ml (8 fl oz)  
Flushing Solvent—Discharge  
Port—Volume ..... 120 ml (4 fl oz)

- Turn compressor end for end and roll it side to side.
- Remove both plugs from manifold ports and drain solvent from compressor.
- Connect battery power to compressor clutch coil. Rotate pulley at least five revolutions to move solvent out of cylinders.

Specification

Clutch Coil—Current Draw..... 2.6 amps at 12 volts, 20° C  
(68°F)  
Clutch Coil—Resistance..... 3.5—4.0 ohms at 20° C (68°F)

- Invert compressor, roll to all sides, and drain thoroughly.
- Let compressor sit inverted for three to five minutes.
- Repeat previous steps at least three times.

- 4. Remove and discard receiver-dryer.

5. Flushing can be performed on tractor. Divide system into two circuits:

- Condenser, including inlet and outlet hoses. (Steps 6 through 13.)
- Evaporator, including inlet and outlet hoses. (Steps 14 through 30.)

**IMPORTANT: DO NOT attempt to flush through compressor or receiver-dryer. Flushing through expansion valve or an orifice tube is acceptable if refrigerant oil has a normal odor and appearance.**

#### Flush/Purge condenser:

6. Connect flusher outlet hose to inlet connection of compressor discharge line (3) using JT02102 Adapter to flush condenser.

#### Specification

Compressor Discharge Line—

Torque ..... 32—40 N•m (24—29 lb-ft)

7. Attach a return hose and aerator nozzle to connection of receiver-dryer inlet line (8) using JT03197 Adapter. Put nozzle in container to collect flushing solvent.

8. Fill flusher tank with 4 L (1 gal) of solvent and fasten all connections.

*NOTE: Air pressure must be at least 620 kPa (6.2 bar) (90 psi) for flushing and purging.*

9. Connect a line of moisture-free compressed air or dry nitrogen to flusher air valve.

10. Open air valve to force flushing solvent into condenser circuit. Flusher tank is empty when hose pulsing stops. Additional flushing cycles are required if system is heavily contaminated with burned oil or metal particles.

11. Purging the condenser circuit takes 10—12 minutes to thoroughly remove solvent.

Continued on next page

AG,OUO1085,260 -19-17JUL02-2/4

12. Disconnect hose form aeration nozzle to check circuit for solvent. Hod hose close to a piece of cardboard; continue purging until discharge air on cardboard is dry.

13. Go to Step 27 if evaporator does not require flushing.

**Flush evaporator:**

Remove expansion valve to flush evaporator (go to Step 14) if system is contaminated with burned refrigerant oil or debris.

Go to Step 23 to flush evaporator through expansion valve if oil appears normal.

14. Remove operator seat and operator cover to access expansion valve. Drain 5 gal (19 L) of coolant from engine and radiator to prevent spillage into evaporator housing.

15. Install JT02106 Flushing Block in place of expansion valve.

16. Connect flusher outlet hose to compressor suction line (22) using JT02101 Adapter.

**Specification**

Compressor Suction Line—

Torque ..... 34—42 N•m (25—31 lb-ft)

17. Attach a hose and aerator nozzle to receiver-dryer outlet line (11) connector using JT03188 Adapter. Put nozzle in container to collect flushing solvent.

18. Repeat Steps 8, 9, and 10 to flush evaporator.

19. Purging the evaporator circuit takes 12—15 minutes to thoroughly remove solvent.

20. Disconnect hose from aeration nozzle to check circuit for solvent. Hold hose close to a piece of cardboard; continue purging until discharge air on cardboard is dry.

Continued on next page

AG,OUO1085,260 -19-17JUL02-3/4

21. Reinstall expansion valve and reconnect heater coolant tubing. Clean up spilled anti-freeze in evaporator housing and return coolant to radiator. Install operator seat.

22. Go to Step 27.

**Flush evaporator through expansion valve:**

23. Connect flusher outlet hose to connection of receiver-dryer outlet line (11) using JT03188 Adapter.

24. Attach a hose and aerator nozzle to connection of compressor suction line (22) using JT02101 Adapter. Put nozzle in a container to collect solvent.

25. Repeat Steps 8,9, and 10 to flush evaporator.

26. Repeat Steps 19 and 20 to purge evaporator.

27. Install a new receiver-dryer compatible with R134a refrigerant. Fasten connections and mounting brackets.

28. Add required oil. (See Determine Correct Refrigerant Oil Charge in this group.)

29. Install compressor and connect refrigerant lines to manifold.

30. Connect clutch coil wire and install drive belt.

31. Purge system. (See Flush Air Conditioning System in this group.)

AG,OUO1085,260 -19-17JUL02-4/4

## Evacuate Air Conditioning System

**IMPORTANT:** Use only R134a Refrigerant Recovery, Recycling, and Charging machines. Do not mix R134a equipment, refrigerant, and refrigerant oils with R-12 systems to prevent compressor damage.

1. Connect JT02046 R134a Refrigerant Charging Unit.

**NOTE:** A JT02047 R134a Refrigerant Recovery, Recycling, and Charging Unit can be substituted for the JT02046.

*Pump must be capable of pulling at least 28.6 in. Hg vacuum (sea level). Deduct 1 in. Hg from 29.9 in. for each 300 m (100 ft) elevation above sea level.*

2. Connect low-side hose (blue) from charging unit to suction fitting (A) on compressor. Connect high-side hose (red) to discharge fitting (B) on condenser.

**IMPORTANT:** Do not operate compressor during evacuation.


3. Follow manufacturer's instructions and evacuate system. Evacuate system for 15 minutes if ambient temperature is below 30° C (85° F), to remove nitrogen and air.

Evacuate system for 30 minutes if ambient temperature is above 30° C (85° F).

4. Charge system. (See Charge Air Conditioning System in this group.)



LV1469 -UN-05DEC95



LV1470 -UN-05DEC95

**A—Suction Fitting**  
**B—Discharge Fitting**

AG,OUO1085,261 -19-12SEP00-1/1

## Charge Air Conditioning System

*NOTE: Bubbles may appear in sight glass when charging below 18° C (65° F) ambient temperature. Bubbles will disappear when temperature rises.*

1. Evacuate system. (See Evacuate Air Conditioning System in this group.)

**IMPORTANT: Use only R134a Refrigerant Recovery, Recycling, and Charging machines. Do not mix R134a equipment, refrigerant, and refrigerant oils with R-12 systems to prevent compressor damage.**

2. Connect JT02047 R134a Refrigerant Recovery, Recycling, and Charging Station to charge system.

*NOTE: JT02046 HFC134a Refrigerant Charging Unit can be substituted for JT02047.*

3. Connect low-side hose (blue) to suction fitting on compressor. Connect high-side hose (red) to discharge fitting on compressor.

**IMPORTANT: Do not run engine. System must hold a minimum vacuum of 28.6 in. Hg. Deduct 1 in. Hg from 29.9 in. for each 300 m (1000 ft) elevation above sea level.**

4. Follow manufacturer's instructions and charge system.
5. Weigh refrigerant supply tank and invert so refrigerant enters system as a liquid.
6. Begin charging through discharge port first. As suction pressure nearly equals discharge pressure, open suction valve.

**IMPORTANT: Close discharge valve on gauge manifold before starting engine and compressor to prevent over-pressurizing refrigerant container.**

7. Continue charging system until 1.4—1.6 kg (3.0—3.5 lb) is installed. Start engine to complete charging system if a heated cylinder is not being used.

Continued on next page

AG,OUO1085,262 -19-12SEP00-1/2



*NOTE: Add 0.45 kg (1.0 lb) after bubbles disappear from sight glass.*

8. Close both gauge manifold valves and perform a system operational check as follows:
  - Engine at 2000 rpm. Close door and all windows.
  - Compressor operating with temperature control at maximum cooling, and blower at Purge.
  - Check ambient air temperature, cab air duct temperature, suction, and discharge pressures. Compare to the temperature-pressure chart and temperature drop specifications in Operation and Test TM—Section 290, Group 15.


AG,OUO1085,262 -19-12SEP00-2/2



## Replace Heater Temperature Control and Cable

1. Disconnect battery negative (-) cable.
2. Loosen six screws (A) and remove air recirculating intake cover and filter (B).

A—Screw (6 used)  
B—Filter




LV1398 -UN-08AUG97

AG,OUO1085,263 -19-17JUL02-1/7

3. Remove control knob (A).

A—Control Knob




LV2409 -UN-16DEC97

AG,OUO1085,263 -19-17JUL02-2/7


**NOTE:** Support control panel (B) using wire or rope to prevent weight of panel from pulling on wiring connectors and leads during removal of heater control and cable.

4. Remove twelve screws (A) and control panel (B). Support weight of control panel using wire or rope.
5. Remove nut (C).
6. Disconnect control cable (D).
7. Replace heater control.

A—Screw (12 used)  
B—Control Panel  
C—Nut  
D—Control Cable



LV1401 -UN-08AUG97



LV1405 -UN-10NOV95

Continued on next page

AG,OUO1085,263 -19-17JUL02-3/7

8. Remove cab roof. (See Remove and Install Cab Roof in Group 15.)

9. Disconnect hoses (A and B).


10. Remove heater control valve (C).

11. Remove cable retaining clip (D) and disconnect control cable (E) from valve.

*NOTE: Follow routing path of control cable (E) before removing to aid during installation.*


12. Replace heater control cable (E).

- A—Heater Valve Outlet Hose
- B—Heater Valve Inlet Hose
- C—Heater Control Valve
- D—Clip
- E—Control Cable



LV1406 -UN-10NOV95

Top Left Side of Cab Roof Shown



LV1407 -UN-19APR01


Closed Position

Continued on next page


AG,OUO1085,263 -19-17JUL02-4/7

13. Connect cable (D) and tighten nut (C).
14. Install control panel (B) and screws (A).
15. Install heater control knob.

A—Screw (12 used)  
 B—Control Panel  
 C—Nut  
 D—Control Cable



LV1401 -UN-08AUG97




LV1405 -UN-10NOV95

AG,OUO1085,263 -19-17JUL02-5/7

16. Install recirculating air intake cover and filter (B). Tighten screws (A).
17. Adjust heater control cable. (See Adjust Heater Temperature Control Cable in Section 290, Group, 15.)

A—Screw (6 used)  
 B—Filter



LV1398 -UN-08AUG97


Continued on next page

AG,OUO1085,263 -19-17JUL02-6/7


**NOTE:** Make sure the heater control knob and the heater control valve are in the closed position as shown below before installing clip (D).

18. Connect cable (E) and install clip (D).
19. Install heater control valve (C) and connect hoses (A and B).
20. Install cab roof. (See Remove and Install Cab Roof in Group 15.)
21. Connect battery negative (–) cable.

A—Heater Valve Outlet Hose  
 B—Heater Valve Inlet Hose  
 C—Heater Control Valve  
 D—Clip  
 E—Control Cable



LV1406 –UN–10NOV95



LV1407 –UN–19APR01

AG,OUO1085,263 –19–17JUL02–7/7


## Remove, Test, and Install Heater Control Valve

1. Remove cab roof. (See Remove and Install Cab Roof in Group 15.)


*NOTE: A small amount of coolant will leak out of valve and heater core.*

2. Disconnect hoses (A and B) and remove valve (C).
3. Remove clip (D) and disconnect cable (E).

A—Heater Valve Outlet Hose  
B—Heater Valve Inlet Hose  
C—Heater Valve  
D—Clip  
E—Control Cable



Top Left Corner of Cab Roof Shown



AG,OUO1085,264 -19-17JUL02-1/1

LV1407 -UN-19APR01

LV1406 -UN-10NOV95



## Leak Test Heater Control Valve

1. Connect water pressure hose to control valve inlet and turn the valve arm to closed position.
2. Turn water pressure on and check for leakage from the valve outlet.

*NOTE: The heater control valve is not serviceable.*

3. Replace valve as required.

AG.OUO1085,265 -19-12SEP00-1/1

## Install Heater Control Valve

1. Inspect heater hoses and replace as necessary.

*NOTE: Make sure the heater control knob and the heater control valve are in the closed position before connecting cable.*

2. Install heater control valve and connect control cable and hoses.
3. Adjust heater control cable. (See Adjust Heater Temperature Control Cable in Section 290, Group 15.)
4. Add coolant to radiator if necessary. Start engine and run the heating system to check for leaks.
5. Install cab roof. (See Remove and Install Cab Roof in Group 15.)

AG.OUO1085,266 -19-12SEP00-1/1

# Section 210

# Operational Checkout Procedures

## Contents

	Page
<b>Group 10—Operational Checkout Procedures</b>	
Operational Checkout Procedure	
Information . . . . .	210-10-1
Engine Oil Level and Condition Check . . . . .	210-10-2
Coolant Level and Condition Check . . . . .	210-10-3
Transmission and Hydraulic Oil Check . . . . .	210-10-4
Fan and V-Belt Check—5210 and 5310 . . . . .	210-10-5
Fan and Serpentine Belt Check—5410 and 5510 . . . . .	210-10-6
Compressor Belt Check . . . . .	210-10-7
Fuel System Check . . . . .	210-10-8
Air Intake System Check . . . . .	210-10-9
Electrical System Check . . . . .	210-10-10
Hydraulic System Check . . . . .	210-10-11
MFWD Oil Check . . . . .	210-10-12
Indicator Lamps Check . . . . .	210-10-13
Cab Blower Motor Check . . . . .	210-10-14
A/C Compressor Clutch Check . . . . .	210-10-15
Engine Start Check . . . . .	210-10-16
Transmission Neutral Start Check . . . . .	210-10-17
PTO Neutral Start Check . . . . .	210-10-18
Engine Fast and Slow Idle Operation . . . . .	210-10-19
Power Steering Check . . . . .	210-10-20
Differential Lock Check . . . . .	210-10-21
PTO Engagement Check . . . . .	210-10-22
Clutch Check . . . . .	210-10-23
Transmission Shift Check . . . . .	210-10-24
Range Lever Shift Check . . . . .	210-10-25
MFWD Drive Check . . . . .	210-10-26
Brake Check . . . . .	210-10-27
Rockshaft Check . . . . .	210-10-28
Selective Control Valve Check . . . . .	210-10-29
A/C System Operational Check . . . . .	210-10-30
Cab Heater Valve Check . . . . .	210-10-30
Miscellaneous Checks . . . . .	210-10-31



## **Operational Checkout Procedure Information**

The procedures covered in this group are used to give a quick checkout of all the systems and components on the unit. These checkouts should be run to insure proper operation after any extended storage, when the unit comes in for service, and after repairs have been made on the unit. They can also be helpful in determining the value of the unit at trade-in time. The unit should be placed on a level surface to run the checkouts. All the checkouts should be done and all of the steps of each checkout should be followed.

Each checkout lists:

- Conditions—How the unit should be set up for the checkout.
- Procedure—The specific action to be done.
- Normal—What should happen or be heard or be seen.
- If Not Normal—Where to go if other tests or adjustments are needed.

When performing the checkout, be sure to set your machine up to the test conditions listed and follow the sequence carefully. The “Normal” paragraph gives the result that should happen when performing the checkout. If the results are not normal, go to the Section and Group listed in the “If Not Normal” paragraph to determine the cause and repair the malfunction.

The photograph that accompanies each checkout procedure is included to help conduct the checkout.

MX,21010HE,1A -19-12SEP00-1/1

## Engine Oil Level and Condition Check

### CONDITIONS:

- Machine parked on level surface.
- Key switch in off position.
- Transmission in park position.
- Engine not run for at least five minutes.

### PROCEDURE:


- Clean dirt from area around dipstick opening.
- Remove and wipe off dipstick.
- Install dipstick until seated in tube.
- Remove dipstick and check level and condition of oil.

### NORMAL:

- Oil level between full and add marks of dipstick.
- Oil not excessively thick or thin.
- No fuel odor in oil.
- No visible foreign material in oil.

### IF NOT NORMAL:

- Add proper oil to full mark on dipstick. Go to Diesel Engine Oil Section 10, Group 20.
- Replace contaminated oil and filter.
- Go to Diagnosis, Tests, and Adjustments Section 220, Group 15 for engine diagnosis, tests and adjustments.



M45603 -UN-06AUG90

AG,OUO1023,327 -19-12SEP00-1/1

## Coolant Level and Condition Check

### CONDITIONS:

- Key switch in OFF position.
- Machine parked on level surface.

### PROCEDURE:

- Observe level of coolant in recovery tank.
- Check condition of recovery tank and tank-to-radiator hose.

### NORMAL:

- Recovery tank and hose in good condition, no holes or cracks.
- Coolant at full mark if engine at operating temperature.
- Coolant clean; no oil, rust-like discoloration or foreign material in fluid.

### IF NOT NORMAL:

- Replace recovery tank or hose, add coolant, and recheck level after operation.
- Add coolant to proper mark on tank.
- Check radiator-to-tank hose and recovery tank for holes or cracks.
- Change coolant and flush cooling system.
- Go to Diagnosis, Tests, and Adjustments Section 220, Group 15 for diagnosis, tests and adjustments.



LV2432 -UN-15DEC97

AG\_OUO1085,267 -19-12SEP00-1/1


## Transmission and Hydraulic Oil Check

### CONDITIONS:

- Machine parked on level surface.
- Key switch in OFF position.
- Transmission in park position.

### PROCEDURE:

- Clean dirt from area around dipstick (A) opening.
- Remove and wipe off dipstick.
- Install dipstick until seated in tube.
- Remove dipstick and check level and condition of oil.



LV664 -UN-21SEP94

A—Dipstick

### NORMAL:

- Oil level between full and add marks of dipstick.
- Oil not excessively thick or thin.
- No visible foreign material in oil.

### IF NOT NORMAL:

- Add proper oil to full mark on dipstick.
- Replace contaminated oil and filter.
- Go to Sections 250, 260, or 270, Group 15 for transmission and hydraulic system diagnosis, tests and adjustments.

AG,OUO1023,335 -19-12SEP00-1/1



## Fan and V-Belt Check—5210 and 5310

### CONDITIONS:

- Key switch in OFF position.
- Engine not run for at least 15 min.
- Transmission in park position.

### PROCEDURE:


- Inspect fan and V-belt for damage.
- Check belt tension. (See Fan/Alternator V-Belt Adjustment (5210 and 5310) in Section 220, Group 15.)

### NORMAL:

- Fan undamaged; no cracks or bent blades.
- Belt not cracked, frayed or glazed.
- Belt does not “squeal” during operation.

### IF NOT NORMAL:

- Replace damaged fan or belt.
- Adjust belt tension. Go to Fan/Alternator V-Belt Adjustment (5210 and 5310) in Section 220, Group 15.



LV416 -UN-18FEB92

AG,OUO1085,292 -19-12SEP00-1/1

## Fan and Serpentine Belt Check—5410 and 5510

### CONDITIONS:

- Key switch in OFF position.
- Engine not run for at least 15 min.
- Transmission in park position.

### PROCEDURE:


- Inspect fan and serpentine belt for damage.
- Check belt tensioner (A) spring tension. (See Inspect and Replace Belt Tensioner—Models 5410 and 5510 in Section 20, Group 10.)

### NORMAL:

- Fan undamaged; no cracks or bent blades.
- Belt not cracked, frayed or glazed.
- Belt does not “squeal” during operation.

### IF NOT NORMAL:

- Replace damaged fan or serpentine belt.
- Adjust belt tensioner. Go to Inspect and Replace Belt Tensioner—Models 5410 and 5510 in Section 20, Group 10.



LV2152 -UN-09JUN97

A—Belt Tensioner

AG,OUO1085,293 -19-12SEP00-1/1

## Compressor Belt Check

**NOTE:** Four cylinder tractor shown. Some procedures for the three cylinder tractor are slightly different, see specifics below.

### CONDITIONS:

- Key switch in OFF position.
- Engine not run for at least 15 min.
- Transmission in park position.

### PROCEDURE:


- Inspect belt for damage.
- 3-cylinder engines check belt tension. (See Fan/Alternator V-Belt Adjustment (5210 and 5310) in Section 220, Group 15.)
- 4-cylinder engines inspect belt tensioner and spring tension. (See Inspect and Replace Belt Tensioner—Models 5410 and 5510 in Section 20, Group 10.)

### NORMAL:

- Belt not cracked, frayed or glazed.
- Belt does not “squeal” during operation.

### IF NOT NORMAL:

- Replace damaged compressor belt.
- 3-cylinder engines adjust belt tension. Go to Fan/Alternator V-Belt Adjustment (5210 and 5310) in Section 220, Group 15.
- 4-cylinder engines replace belt tensioner. Go to Inspect and Replace Belt Tensioner—Models 5410 and 5510 in Section 20, Group 10.



LV2249 -UN-08AUG97

AG,OUO1085,299 -19-13SEP00-1/1

210  
10  
7

## Fuel System Check

### CONDITIONS:

- Key switch in OFF position.
- Transmission in park position.
- Fuel drain valves (A) closed.
- Fuel shut-off valve (B) open.

### PROCEDURE:

- Observe fuel level and condition.
- Check fuel tank cap and seal condition.
- Check filter condition.
- Check fuel tank, fuel drain valve, lines, and hoses for kinks, leaks, or damage.

### NORMAL:

- Fuel level OK.
- Correct type and grade of clean fuel.
- Fuel tank overflow hose and vent valve in good condition. (No pressure or vacuum observed in fuel tank when cap is removed.)
- No leaks in system.
- No water or sediment in fuel filter bowl.

### IF NOT NORMAL:

- Add correct type and grade of clean fuel. Go to Diesel Fuel Specifications in Section 10, Group 20.
  - Clean contaminated fuel tank, filter, or lines.
  - Repair or replace damaged fuel tank, cap, drain valve, filter, or lines.
- Go to Fuel System Section 30, Group 05 for fuel system repair.

A—Fuel Drain Valve  
B—Fuel Shut-off Valve



Fuel Tank



Fuel Filter

AG.OUO1085,300 -19-13SEP00-1/1

## Air Intake System Check

### CONDITIONS:

- Key switch OFF.
- Transmission in park position.

### PROCEDURE:

- Observe condition of air filter elements.
- Check condition of air intake hose, tube, or turbocharger.
- Observe air cleaner restriction indicator on dash. (Engine running.)

### NORMAL:


- Air intake and elements free of debris.
- Air intake hoses and tube in good condition. Hose clamps tight. Intake tube gasket intact.
- Air cleaner unloader valve not plugged.
- Air cleaner housing sealed.
- Air cleaner restriction indicator light off.
- 5310 or 5510: turbocharger operates with no grinding or bearing noise.

### IF NOT NORMAL:

- Clean, repair or replace as required.
- 5310 or 5510: repair damaged turbocharger, if equipped.
- Go to Diagnosis, Tests, and Adjustments Section 220, Group 15 for air intake system diagnosis, tests and, adjustments.
- Go to Air Intake System Section 30, Group 10 for inspection and repair.



*Air Filter (5310 Shown)*



*Turbocharger (5310 Shown)*

AG.OUO1023,331 -19-21OCT99-1/1



## Electrical System Check

### CONDITIONS:

- Key switch in OFF position.
- Transmission in park position.

### PROCEDURE:

- Check battery electrolyte level.
- Check battery cable condition.
- Check ground cable connection (A).
- Check condition of starter and alternator connections.
- Check fuses; located below key switch panel.

### NORMAL:

- Battery electrolyte between full and add indicators.
- All electrical connections clean and tight.
- Fuses good and of correct rating.


### IF NOT NORMAL:

- Add distilled water to battery to bring electrolyte to proper level.
- Clean and tighten electrical connections.
- Replace fuses as required. Determine reason for blown fuses. Go to Diagnosis, Test and Adjust Section 240, Group 15 for electrical system diagnosis, tests, and adjustments.



Battery

LV430 -UN-03FEB92



Fuses

LV855 -UN-21JUL95

A—Ground Cable Connection

AG,OUO1085,301 -19-13SEP00-1/1

## Hydraulic System Check

### CONDITIONS:

- Engine running.
- Hydraulic oil at operating temperature.
- Transmission in park position.

### PROCEDURE:


- Check on and under machine for signs of hydraulic oil leakage. (Engine not running.)
- Operate all hydraulic controls.

### NORMAL:

- No oil leakage.
- Hydraulic controls operate smoothly through entire range of function.

### IF NOT NORMAL:

- Repair oil leaks.
- Replace damaged oil lines.
- Repair hydraulic components as required.
- Go to Diagnosis Section 270, Group 15 for diagnosis, tests, and adjustments.
- Go to Hydraulic System Section 70 for component repair or replacement.



LV432 -UN-03FEB92

AG,OUO1085,302 -19-13SEP00-1/1



## MFWD Oil Check

### CONDITIONS:

- Machine parked on level ground.
- OIL LEVEL arrow (A) parallel to ground.
- Transmission in park position.
- Key switch in off position.

### PROCEDURE:


- Remove filler plug (B).
- Observe level of oil.

### NORMAL:

- Oil level even with bottom of filler plug hole.

### IF NOT NORMAL:

- Drain excess oil or add oil to proper level.



A—Oil Level Arrow  
B—Filler Plug

LV439 -UN-03FEB92

AG,OUO1023,336 -19-27OCT99-1/1

## Indicator Lamps Check

*NOTE: Steering wheel removed for clarity of photo.*

### CONDITIONS:

- Key switch in ON position.

### PROCEDURE:


- Turn light switch to “H1” (High Beam) position.
- Push PTO control lever forward to PTO engage position.

### NORMAL:

- Indicator lamps (A—D) should light. [Lamp (C) will light with key switch in OFF position.]
- Lamps (C and D) should be off when engine is running.
- Lamp (F) will light when key is advanced to “START” position.
- Lamp (E) will light when key is advanced to “START” position.

### IF NOT NORMAL:

- Check lamps and wiring circuit.
- Go to Diagnosis, Test and Adjust Section 240, Group 15 for electrical diagnosis, tests, and adjustments.
- If lamps (D or F) remain on when engine is running, stop engine. Go to Diagnosis, Tests, and Adjustments Section 220, Group 15 for engine diagnosis, tests, and adjustments.



LV2145 -UN-14MAY97

- A—PTO Engaged Indicator
- B—High Beam Indicator
- C—Charging System Indicator
- D—Engine Oil Pressure Indicator
- E—Park Brake Indicator
- F—Air Cleaner Restriction Indicator

AG\_OUO1085.303 -19-13SEP00-1/1


## Cab Blower Motor Check

### CONDITIONS:

- Cab 30-amp fuses F13 and F15 removed.

### PROCEDURE:

- Turn key switch on but do NOT start engine.
- Turn blower motor switch (A) to PURGE position (fully clockwise).
- Both blower motors should be off.



A—Blower Motor Switch

### NORMAL:

- The left-hand blower motor should operate when fuse F13 is TEMPORARILY installed.
- The right-hand blower motor should operate when fuse F15 is TEMPORARILY installed.
- Reinstall both fuses.
- Both blower motors should operate with the blower motor switch in the LOW, MEDIUM, HIGH, and PURGE positions, and not operate when switch is off.

### IF NOT NORMAL:

- Go to Diagnosis, Tests, and Adjustments Section 240 for electrical system operation, tests, and adjustments.

AG,OUO1085,304 -19-13SEP00-1/1


## A/C Compressor Clutch Check

### CONDITIONS:

- Cab door open.
- A/C compressor switch (A) ON.
- Engine off.

### PROCEDURE:

- Turn key switch on but do NOT start engine.
- Operate blower motor switch from OFF to LOW several times while listening for click indicating compressor clutch engagement at engine.



A—A/C Compressor Switch

### NORMAL:

- Compressor clutch engages and disengages when blower switch motor is turned ON and OFF.

**NOTE:** *The evaporator temperature must be above 3°C (37°F) so contacts of temperature control switch will be closed.*

*System must also be charged with 300—400 kPa (3—4 bar) (45—60 psi) so the A/C low pressure switch will be closed.*

### IF NOT NORMAL:

- Go to Diagnosis, Tests and Adjustments Section 240, Group 15 for Electrical System Operation, Tests and Adjustments and/or Diagnosis, Tests, and Adjustments Section 290, Group 10 for A/C system diagnosis, tests, and adjustments.

LV2246 -UN-15JUL97

AG\_OUO1085.305 -19-13SEP00-1/1

## Engine Start Check

### CONDITIONS:

- PTO lever in disengaged position.
- Transmission in park or neutral position.
- Cold weather starting aids used, if necessary.

### PROCEDURE:


- Push throttle lever forward about one-third of travel.
- Turn key clockwise.
- Release key when engine starts.

### NORMAL:

- Engine starts within 20 seconds.

### IF NOT NORMAL:

- Wait 2 minutes for starter to cool.
- Try to start engine again.
- Repeat start procedure two more times, if necessary.
- Go to Diagnosis, Tests, and Adjustments Section 220, Group 15 for engine diagnosis, tests, and adjustments.



AG,OUO1085,306 -19-13SEP00-1/1

## Transmission Neutral Start Check

### CONDITIONS:

- PTO lever (A) in disengaged position.
- Transmission gear shift lever (B) in forward or reverse gear.
- Tractors equipped with PowrReverser™ transmission: place selector lever (C) in forward or reverse.
- Operator on seat.

### PROCEDURE:

- Turn key switch to START position.

### NORMAL:

- Starter should not crank engine.

### IF NOT NORMAL:

- Go to Diagnosis, Test and Adjust Section 240, Group 15 for electrical diagnosis, tests, and adjustments.

A—PTO Lever  
B—Transmission Gear Shift Lever  
C—Selector Lever



LV2146 -UN-09JUN97



LV2147 -UN-09JUN97



LV2148 -UN-09JUN97

## PTO Neutral Start Check

### CONDITIONS:

- Transmission in park or neutral position.
- PTO lever (A) pushed to forward (engaged) position.
- Operator on seat.

### PROCEDURE:

- Turn key switch to START position.

### NORMAL:

- Starter should not crank engine.

### IF NOT NORMAL:

- Go to Diagnosis, Test and Adjust Section 240, Group 15 for electrical diagnosis, tests and adjustments.



A—PTO Lever

AG,OUO1085,308 -19-13SEP00-1/1



## Engine Fast and Slow Idle Operation

### CONDITIONS:

- Transmission in park position.
- Operator on seat.

### PROCEDURE:


- Start engine and warm up for several minutes between 1500 and 1900 rpm.
- Move throttle lever from slow to fast idle several times slowly and rapidly.

### NORMAL:

- Engine runs smoothly at all throttle settings.
- Engine accelerates and decelerates smoothly without misfiring or stumbling.

### IF NOT NORMAL:

- Go to Diagnosis, Tests, and Adjustments Section 220, Group 15 for engine diagnosis, tests, and adjustments.



LV441 -UN-03FEB92

AG,OUO1085,309 -19-13SEP00-1/1

## Power Steering Check

### CONDITIONS:

- Operator on seat.
- Transmission in neutral position.
- Engine running.

### PROCEDURE:

- Turn steering wheel from full left to full right and back.

### NORMAL:

- Tires move from stop-to-stop.
- Wheel moves smoothly in both directions.
- Wheel stops turning when released.

### IF NOT NORMAL:

- Go to Diagnosis, Tests and Adjustments Section 260, Group 15 for steering diagnosis, tests, and adjustments.



LV445 -UN-03FEB92

AG,OUO1085,310 -19-13SEP00-1/1

## Differential Lock Check

### CONDITIONS:

- Operator on seat.
- Transmission in forward gear.
- Engine running at slow idle.

### PROCEDURE:


- Depress differential pedal (A).
- Briefly turn steering wheel left or right.

### NORMAL:

- Machine must try to go straight forward when steering wheel is turned.
- Differential operates quietly.

### IF NOT NORMAL:

- Go to Diagnosis, Tests, and Adjustments—CS/SS Transmissions or Diagnosis, Tests, and Adjustments—PowrReverser™ Section 250, Groups 15 or 16 for differential diagnosis, tests, and adjustments.



A—Differential Pedal

LV446 -UN-03FEB92

AG,OUO1085,311 -19-13SEP00-1/1

## PTO Engagement Check

### CONDITIONS:

- Operator on seat.
- Engine running.

### PROCEDURE:

- Move PTO lever (A) forward into the engaged position.
- Move PTO lever (A) rearward into the disengage position.
- Operator rise off seat while PTO lever is in engage position.

### NORMAL:

- PTO engages and disengages with lever movement.
- Warning horn sounds if operator rises off seat while PTO lever is in engage position.

### IF NOT NORMAL:

- Go to Diagnosis, Tests, and Adjustments—CS/SS Transmissions or Diagnosis, Tests, and Adjustments—PowrReverser™ Section 250, Groups 15 or 16 for PTO diagnosis, tests, and adjustments.
- Go to Diagnosis, Test and Adjust Section 240, Group 15 for electrical diagnosis, tests, and adjustments.



A—PTO Lever

AG,OUO1085,312 -19-14SEP00-1/1

LV2146 -UN-09JUN97

## Clutch Check

### CONDITIONS:

- Operator on seat.
- Engine running.

### PROCEDURE:


- Depress clutch pedal (A).
- Move shift lever to any forward gear. If equipped with hydraulic reverser selector lever, move lever into forward position.
- Slowly release clutch pedal.

### NORMAL:

- Clutch engages smoothly and machine moves forward smoothly.

### IF NOT NORMAL:

- Go to Diagnosis, Tests, and Adjustments— CS/SS Transmissions or Diagnosis, Tests, and Adjustments— PowrReverser™ Section 250, Groups 15 or 16 for clutch diagnosis, tests, and adjustments.



A—Clutch Pedal

AG,OUO1085,313 -19-14SEP00-1/1

## Transmission Shift Check

### CONDITIONS:

- Operator on seat.
- Engine running.

### PROCEDURE:

- Depress clutch pedal.
- Put transmission shift lever (A) in first gear. Put PowrReverser™ selector lever in forward, if equipped.
- Release clutch pedal and move machine in gear.
- Depress clutch pedal and stop machine.
- Repeat above procedure with remaining forward gears and reverse.
- Move transmission shift lever to neutral and park.



A—Transmission Shift Lever

### NORMAL:

- Machine moves in appropriate direction but does not move in neutral or park.
- Transmission stays in gear selected.
- Gears do not clash excessively when engaged.

### IF NOT NORMAL:

- Go to Diagnosis, Tests, and Adjustments—CS/SS Transmissions or Diagnosis, Tests, and Adjustments—PowrReverser™ Section 250, Groups 15 or 16 for transmission diagnosis, tests, and adjustments.

AG,OUO1085,314 -19-25JUL02-1/1

## Range Lever Shift Check

### CONDITIONS:

- Operator on seat.
- Engine running at specific rpm.

### PROCEDURE:

- Depress clutch pedal.
- Put transmission shift lever (A) in gear.
- Put range shift lever (B) in speed range A. Put PowrReverser™ selector lever, if equipped, in forward position.
- Release clutch pedal and move machine in gear.
- Depress clutch pedal and stop machine.
- Repeat above procedure with remaining speed ranges.

### NORMAL:

- Machine moves smoothly. Ground speed increases as higher gears and speed range are selected.
- Range shift stays in range selected.
- No excessive gear noise.


### IF NOT NORMAL:

- Go to Diagnosis, Tests, and Adjustments—CS/SS Transmissions or Diagnosis, Tests, and Adjustments—PowrReverser™ Section 250, Groups 15 or 16 for diagnosis, tests, and adjustments.

**A—Transmission Shift Lever**  
**B—Range Shift Lever**



LV2149 -UN-09JUN97



LV2150 -UN-09JUN97

AG,OUO1085,315 -19-25JUL02-1/1



## MFWD Drive Check

### CONDITIONS:

- Machine on slippery surface.
- Engine running.

### PROCEDURE:

- Depress clutch pedal.
- Push MFWD lever (A) forward to engage.
- Put PowrReverser™ selector lever, if equipped, in forward position.
- Put transmission in gear, release clutch, and move machine forward.

### NORMAL:

- Machine moves with increased traction.
- No excessive noise.
- MFWD lever stays in position.

### IF NOT NORMAL:

- Check MFWD oil level.
- Go to Diagnosis, Tests, and Adjustments— CS/SS Transmissions or Diagnosis, Tests, and Adjustments— PowrReverser™ Section 250, Groups 15 or 16 for diagnosis, tests, and adjustments.



A—MFWD Lever

LV2151 -UN-09JUN97

AG,OUO1085,316 -19-25JUL02-1/1

## Brake Check

### CONDITIONS:

- Operator on seat.
- Engine running.
- Transmission in gear.

### PROCEDURE:


- Disengage brake pedal Lock (A).
- Operate brake pedals individually.
- Hold brake pedal to limit of travel for 15 seconds.
- Engage pedal bar.
- Operate brake pedals together.

### NORMAL:

- Machine turns toward side with brake engaged when pedals operated individually.
- Machine stops evenly when pedals operated together.
- Pedal remains firm and does not sink when held.
- Brakes operate smoothly and quietly.

### IF NOT NORMAL:

- Bleed brake system.
- Repair or replace parts as required.
- Go to Diagnosis, Tests and Adjustments Section 260, Group 15 for brake system diagnosis, tests, and adjustments.
- Go to Brake Repair Section 60, Group 10 for brake repair.



A—Brake Pedal Lock

LV433 -UN-03FEB92

AG,OUO1085,317 -19-14SEP00-1/1

## Rockshaft Check

### CONDITIONS:

- Engine running.
- Hydraulic oil at operating temperature.
- Transmission in park position.

### PROCEDURE:


- Move control lever stop (B) to forward position (arrow).
- Move draft control lever (C) to forward position.
- Move position control lever (A) to forward position.
- Move position control lever (A) to rearward position.
- Observe the rate-of-drop with implement attached.

### NORMAL:


- Hitch should raise fully when lever (A) is pulled rearward, and lower when lever is pushed forward.
- Rockshaft rate-of-drop should be adjustable to a minimum of 2 seconds by turning rockshaft rate-of-drop knob (D).

### IF NOT NORMAL:

- Go to Diagnosis Section 270, Group 15 for rockshaft diagnosis, tests, and adjustments.



LV434 -UN-02AUG94



LV1061 -UN-15NOV94

- A—Position Control Lever
- B—Control Lever Stop
- C—Draft Control Lever
- D—Rate-of-Drop Knob

AG.OUO1085,319 -19-14SEP00-1/1

## Selective Control Valve Check

### CONDITIONS:

- Engine running.
- Hydraulic oil at operating temperature.
- Transmission in park position.

### PROCEDURE:

- Move control lever (A) forward and rearward.
- Move control lever (A) from side to side.
- Move control lever (B) forward and rearward.


### NORMAL:

- Moving control lever (A) forward and rearward should extend and retract a cylinder attached to outlets (C).
- Moving control lever (A) from side to side should extend and retract a cylinder attached to outlets (D).
- Moving control lever (B) should extend and retract a cylinder attached to outlets (E).
- Levers should return to neutral (centered) position when released. Lever (A) will not return to neutral when in float position (lever fully forward).


### IF NOT NORMAL:

- Go to Diagnosis Section 270, Group 15 for hydraulic diagnosis, tests, and adjustments.


A—Joystick Control Lever  
 B—Control Lever  
 C—Hydraulic Outlets  
 D—Hydraulic Outlets  
 E—Hydraulic Outlets



Dual SCV Joystick



Single SCV Lever



Hydraulic Outlets

AG,OUO1085,320 -19-14SEP00-1/1

## A/C System Operational Check

### CONDITIONS:

- Engine running at 2000 rpm.
- Doors and windows closed.

### PROCEDURE:

- Set A/C control for maximum cooling.
- Turn blower motor switch to HIGH position (fully clockwise).
- Air from air ducts should be cold after approximately six minutes of operation.
- Check ambient outside air temperature (in shade) and check air temperature at air duct outlet in cab headliner after approximately 15 minutes of operation. Compare temperature difference to following chart:

Ambient Temperature	Minimum Temperature Difference
Below 24°C (75°F)	12°C (20°F)
Between 24—32°C (75—90°F)	14°C (25°F)
Above 32°C (90°F)	16°C (30°F)

### IF NOT NORMAL:

- Go to Diagnosis, Tests, and Adjustments Section 290, Group 10 for air conditioning system diagnosis, tests, and adjustments.

AG,OUO1085,321 -19-14SEP00-1/1


## Cab Heater Valve Check

### CONDITIONS:

- Engine running at 2000 rpm and fully warmed up.

### PROCEDURE:

- Turn heater control (A) clockwise approximately halfway. Air from air ducts should begin to warm up within two minutes.
- Turn heater control fully counterclockwise. Air from air ducts should become cool within 2 or 3 minutes.



LV1404 -UN-05DEC95

A—Cab Heater Control

AG,OUO1085,322 -19-14SEP00-1/1

## Miscellaneous Checks

### CONDITIONS:

- Key switch in OFF position.
- Transmission in park position.

### NORMAL:

- Tires in good condition, properly inflated.
- Seat and safety belt in good condition.
- Directional lights functional.
- ROPS securely fastened.
- Wheel cap screws and nuts tight.
- 3-point hitch in good condition.

### IF NOT NORMAL:

- Replace or tighten hardware.
- Repair, replace, or adjust as necessary.
- Go to Diagnosis, Test and Adjust Section 240, Group 15 for electrical diagnosis, tests, and adjustments.

AG,OUO1023,366 -19-02NOV99-1/1





# Section 220

## Engine Operation, Tests, and Adjustments

### Contents

	Page		Page
<b>Group 05—Component Location</b>			
Component Location Information . . . . .	220-05-1	Fast Idle Adjustment . . . . .	220-15-22
Engine External Components—Left-Hand Side . . . . .	220-05-2	Injection Pump Timing Adjustment . . . . .	220-15-23
Engine External Components— Right-Hand Side . . . . .	220-05-3	Check and Adjust Valve Clearance . . . . .	220-15-24
4-Cylinder Engine External Components— Left-Hand Side . . . . .	220-05-4	Fan/Alternator V-Belt Adjustment (5210 and 5310) . . . . .	220-15-27
4-Cylinder Engine External Components— Right-Hand Side . . . . .	220-05-5	Compressor Drive Belt Adjustment— 3-Cylinder . . . . .	220-15-29
<b>Group 10—Theory of Operation</b>			
Theory of Operation Information . . . . .	220-10-1	Turbocharger Boost Pressure Test—5310 and 5510 . . . . .	220-15-30
Engine Lubrication System Operation . . . . .	220-10-2	Bleed Fuel System . . . . .	220-15-32
Engine Lubrication System Operation— Continued . . . . .	220-10-4		
Engine Cooling System Operation— 3-Cylinder . . . . .	220-10-6		
Engine Cooling System Operation— 4-Cylinder . . . . .	220-10-8		
<b>Group 15—Diagnosis, Tests, and Adjustments</b>			
Diagnostic Information . . . . .	220-15-1		
Engine Turns Over But Will Not Start or Starts Hard . . . . .	220-15-2		
Engine Runs Irregularly or Stalls Frequently . . . . .	220-15-3		
Engine Runs Rough . . . . .	220-15-4		
Engine Has Low Power . . . . .	220-15-4		
Engine Smokes—Black or Grey . . . . .	220-15-6		
Engine Smokes Excessively—White . . . . .	220-15-7		
Engine Uses Excess Fuel . . . . .	220-15-8		
Engine Has Excess Noise or Vibration . . . . .	220-15-9		
Engine Uses Excess Oil or Smokes Blue . . . . .	220-15-10		
Engine Has Low Oil Pressure . . . . .	220-15-10		
Engine Coolant Operating Temperature Incorrect . . . . .	220-15-11		
Oil In Coolant or Coolant in Oil . . . . .	220-15-12		
Radiator Bubble Test . . . . .	220-15-13		
Cooling System Test . . . . .	220-15-14		
Radiator Cap Pressure Test . . . . .	220-15-15		
Engine Oil Pressure Test . . . . .	220-15-16		
Cylinder Compression Pressure Test . . . . .	220-15-18		
Fuel Shut-Off Solenoid Check . . . . .	220-15-19		
Throttle Lever Adjustment . . . . .	220-15-20		
Slow Idle Adjustment . . . . .	220-15-21		



### **Component Location Information**

This group contains component location drawings for the following engine system components:


- 3- and 4-Cylinder Engine External Components
  - Left-Hand Side
  - Right-Hand Side

Use the drawings when diagnosing an engine problem to help locate the components to be tested.

LV,22005HA,A1 -19-04JUN96-1/1

220  
05  
1

# Engine External Components—Left-Hand Side



LV2154

## 3 CYLINDER ENGINE EXTERNAL COMPONENTS — LEFT-HAND SIDE

A—Oil Pan  
B—Crankshaft Pulley  
C—Oil Filter  
D—Fan Belt  
E—Water Pump Pulley

F—Alternator/Regulator  
G—Thermostat Housing  
H—Rocker Arm Cover  
I—Air Intake Pipe (5310 only)  
J—Turbocharger (5310)

K—Exhaust Manifold  
L—Turbocharger Lubrication Lines (5310 only)  
M—Fuel Supply Line


N—Flywheel  
O—Fuel Injection Pump  
P—Engine Oil Pressure Switch  
Q—Engine Speed Sensor

**NOTE:** 5210 is a naturally aspirated engine. 5310 is turbocharged.

Engine without cab air conditioning compressor shown.

LV2154 —UN-23APR98

# Engine External Components—Right-Hand Side



LV2153

## 3 CYLINDER ENGINE EXTERNAL COMPONENTS — RIGHT-HAND SIDE

A—Starter  
B—Hydraulic Pump  
C—Crankcase Breather Hose  
D—Fuel Filter/Priming Pump  
E—Cylinder Head  
F—Manifold Heater

G—Crankcase Breather  
H—Air Intake Pipe (5310 only)  
I—Turbocharger (5310 only)  
J—Alternator/Regulator  
K—Thermostat Housing

L—Water Pump Pulley  
M—Fan Belt  
N—Oil Cooler Lines  
O—Crankshaft Pulley  
P—Timing Gear Cover


Q—Oil Pan  
R—Engine Oil Filler Tube  
S—Oil Filter  
T—Oil Cooler  
U—Oil Dipstick

**NOTE:** 5210 is a naturally aspirated engine. 5310 is turbocharged.

Engine without cab air conditioning compressor shown.

LV2153 -UN-23APR98

# 4-Cylinder Engine External Components—Left-Hand Side



LV2156

## 4 CYLINDER ENGINE EXTERNAL COMPONENTS — LEFT-HAND SIDE

A—Oil Pan  
B—Crankshaft Pulley  
C—Fan Belt  
D—Water Pump Pulley  
E—Belt Tensioner

F—Alternator/Regulator  
G—Thermostat Housing  
H—Rocker Arm Cover  
I—Air Intake Pipe (5510 only)

J—Turbocharger (5510 only)  
K—Exhaust Manifold  
L—Engine Speed Sensor  
M—Fuel Supply Line


N—Engine Oil Filler Tube  
O—Fuel Injection Pump  
P—Oil Dipstick  
Q—Engine Oil Pressure Switch

**NOTE:** 5410 is a naturally aspirated engine. 5510 is turbocharged.

Engine without air conditioning compressor shown.

LV2156 —UN-23APR98

## 4-Cylinder Engine External Components—Right-Hand Side



LV2155

## 4 CYLINDER ENGINE EXTERNAL COMPONENTS — RIGHT-HAND SIDE

A—Starter  
B—Crankcase Breather Hose  
C—Oil Cooler Tubes  
D—Fuel Filter/Priming Pump  
E—Oil Filter

F—Oil Filter Head  
G—Manifold Heater  
H—Cylinder Head  
I—Intake Pipe (5510 only)  
J—Turbocharger (5510 only)

K—Alternator/Regulator  
L—Belt Tensioner  
M—Fan Drive Mount  
N—Fan Belt

O—Water Pump Pulley  
P—Crankshaft Pulley  
Q—Oil Cooler  
R—Hydraulic Pump

**NOTE:** 5410 is a naturally aspirated engine. 5510 is turbocharged.

Engine without cab air conditioning compressor shown.

LV2155 -UN-23APR98



220  
05  
6

## **Theory of Operation Information**

This group divides the engine system into individual components or systems by function. The story contains information on function, component identification, and theory of operation.


The following systems or components are covered:

- Lubrication System
- Cooling System

LV,22010HA,A1 -19-25JUL02-1/1

220  
10  
1

## Engine Lubrication System Operation



LVC261AE

## ENGINE LUBRICATION SYSTEM OPERATION

- |                                 |                                                        |                                            |                            |
|---------------------------------|--------------------------------------------------------|--------------------------------------------|----------------------------|
| A—Oil Pump                      | F—Main Oil Gallery                                     | K—Return Line-to-Crankcase (5310 and 5510) | O—Lower Idler Gear Bushing |
| B—Oil Bypass Valve              | G—Camshaft Bearings                                    | L—Main Bearings                            | P—Intake Screen            |
| C—Oil Pressure Regulating Valve | H—Upper Idler Gear Bushing                             | M—Oil Pressure Switch                      | Q—Engine Pressure Oil      |
| D—Oil Filter                    | I—Spray Jet (3 used)                                   | N—Connecting Rod Bearings                  | R—Pressure-Free Oil        |
| E—Oil Cooler                    | J—Lubricating Oil Line-to-Turbocharger (5310 and 5510) |                                            |                            |

FUNCTION:

Continued on next page

AG,OUO1085,327 -19-03JUL02-1/2

A full pressure system lubricates engine parts with clean oil.

#### MAJOR COMPONENTS:

- Cylinder Head
- Engine Block
- Gear Case
- Rocker Arms
- Rocker Arm Shaft
- Crankshaft Main Bearings
- Camshaft Bearings
- Idler Gear Bushings
- Oil Pump
- Intake Screen
- Oil Bypass Valve
- Oil Cooler
- Oil Filter
- Pressure Regulating Valve
- Oil Pressure Switch

#### THEORY OF OPERATION:

The pressure lubrication system consists of a positive displacement gear-driven pump (A), filter strainer in the suction pipe, full flow oil filter (D), oil cooler (E), oil pressure regulating valve (C), oil bypass valve (B) and an electrical pressure warning switch (M). Additionally, the oil cooler and oil filter have their own bypass valve.

The pump draws lubrication oil from the crankcase through a strainer and a suction line. The oil is then pumped through an oil line to the oil cooler, oil filter and through the main oil gallery (F) of the cylinder block.

From the oil gallery, oil is forwarded under pressure to the main bearings (L) and spray jets (I) to cool the pistons. Drilled cross-passages in the crankshaft distribute oil from the main bearings to connecting rod bearings (N).

Lube oil holes in numbers 1, 3, and 4 main bearing oil grooves are provided to direct oil to the camshaft bearings (G).


A drilled passage from the rear camshaft bearings through the cylinder block and cylinder head supplies lubricating oil to the rocker arm shaft.

5310 and 5510: Oil passages direct from the main oil gallery through external line provide lubricating oil to the shaft of the turbocharger.

Oil pressure switch (M) activates an indicator light to alert the operator to shut down the engine if oil pressure drops below 100 kPa (1.0 bar) (15 psi).

AG,OUO1085.327 -19-03JUL02-2/2

## Engine Lubrication System Operation—Continued



I PRESSURE OIL      J PRESSURE-FREE OIL      K COOLANT FROM COOLING SYSTEM

LVC262AE

## ENGINE LUBRICATION SYSTEM OPERATION — CONTINUED

A—Oil Pressure Switch	E—Bypass Valve	H—Main Oil Gallery	K—Coolant from Cooling System
B—Oil Cooler Bypass Valve	F—Oil Pump	I—Pressure Oil	
C—Oil Cooler	G—Oil Pressure Regulating Valve	J—Pressure-Free Oil	
D—Oil Filter Relief Valve			

THEORY OF OPERATION—CONTINUED:

Continued on next page

AG,OUO1085,328 -19-14SEP00-1/2

An externally non-adjustable pressure regulating valve is located at the front cylinder block in the oil gallery (H). It controls the oil pressure and provides constant pressure in the main gallery and in the complete lubrication system.

The valve consists of a valve cone held against a seat by a spring and plug. If oil pressure exceeds spring pressure, the valve cone is raised from the seat, permitting oil to bypass to the crankcase and maintain constant pressure.


An oil bypass valve (E) is located in the cylinder block behind the front plate and near the oil pressure regulating valve (G). Should the difference between the pressure in the main oil gallery and oil pump (F) become excessive, this valve would open and let oil bypass the filter and oil cooler to reach the main gallery faster. This valve has a permanent setting which cannot be changed.

The oil filter is mounted on the right-hand side of the engine. It is a full-flow type with a spin-on type replacement element. If the filter clogs, a relief valve (D) in the element opens to keep a full flow of the oil to vital engine parts.

Oil cooler (C) is used to help reduce the temperature of engine oil. Pressurized oil enters the oil cooler and passes through a network of tubing surrounded by engine coolant. Prior to entering the oil cooler, the engine coolant passes through the radiator, which transfers much of the coolant's heat into the surrounding air. The coolant, its temperature now reduced, enters the oil cooler and passes over the warmer tubing. Heat transfers from the oil to the coolant, thus reducing oil temperature.

AG,OUO1085,328 -19-14SEP00-2/2

## Engine Cooling System Operation—3-Cylinder



LV2247

## ENGINE COOLING SYSTEM OPERATION — 3 CYLINDER

A—Coolant Temperature  
Sender  
B—Water Pump

C—Thermostat  
D—Coolant Recovery Tank

E—Radiator Cap  
F—Radiator

G—Lower Radiator Hose  
H—Engine Oil Cooler

## FUNCTION:

The water pump circulates coolant through the cooling system, drawing hot coolant from the engine block, circulating it through the radiator for cooling.

## MAJOR COMPONENTS:

- Radiator
- Coolant Hoses
- Water Pump

Continued on next page

AG,OUO1032,3296 —19-31MAY00-1/2



- Cooling Fan
- Fan Belt
- Engine Block
- Cylinder Head
- Thermostat
- Coolant Temperature Sender
- Coolant Recovery Tank
- Pressure Cap
- Engine Oil Cooler

#### THEORY OF OPERATION:

The pressurized cooling system includes the radiator, water pump, fan and thermostat.

During the warm-up period, thermostat (C) remains closed and coolant is directed through a bypass passage to suction side of water pump (B). The coolant then circulates through the cylinder block providing a fast warm-up period.

Once the engine has reached operating temperature, the thermostat opens and coolant is pumped from the bottom of radiator (F) via the lower radiator hose (G) into the cylinder block. Here it circulates through the block and around the cylinder liners. From the block, coolant is then directed through the cylinder head, and into thermostat housing. With the thermostat open,

82°C (180°F), warm engine coolant passes through the housing into the top of radiator where it is circulated to dissipate heat.

When coolant system pressure exceeds 48 kPa (0.48 bar) (7 psi), a valve in the radiator cap (E) opens to allow coolant to discharge into the coolant recovery tank (D).


When temperature is reduced, a vacuum is produced in the radiator and coolant is drawn back out of the coolant recovery tank through a valve in the radiator cap.

Oil cooler (H) is used to help reduce the temperature of engine oil. Pressurized oil enters the oil cooler and passes through a network of tubing surrounded by engine coolant. Prior to entering the oil cooler, the engine coolant passes through the radiator, which transfers much of the coolant's heat into the surrounding air. The coolant, its temperature now reduced, enters the oil cooler and passes over the warmer tubing. Heat transfers from the oil to the coolant, thus reducing oil temperature.

Coolant temperature sender (A) senses critical coolant temperature and sends a signal to a gauge in the instrument panel.

AG,OUO1032,3296 -19-31MAY00-2/2

## Engine Cooling System Operation—4-Cylinder



LV2252

## ENGINE COOLING SYSTEM OPERATION — 4 CYLINDER

A—Thermostat  
B—Coolant Temperature  
Sender

C—Upper Radiator Hose  
D—Radiator Cap  
E—Coolant Recovery Tank

F—Radiator  
G—Lower Radiator Hose  
H—Water Pump

I—Oil Cooler  
J—Bypass Hose

## FUNCTION:

The water pump circulates coolant through the cooling system, drawing hot coolant from the engine block, circulating it through the radiator for cooling.

## MAJOR COMPONENTS:

- Radiator
- Coolant Hoses
- Water Pump

Continued on next page

AG,OUO1085,329 -19-14SEP00-1/2

- Cooling Fan
- Fan Belt
- Engine Block
- Cylinder Head
- Thermostat
- Coolant Temperature Sender
- Coolant Recovery Tank
- Pressure Cap
- Engine Oil Cooler

#### THEORY OF OPERATION:

The pressurized cooling system includes the radiator, water pump, fan, and thermostat.

During the warm-up period, thermostat (A) remains closed and coolant is directed through a bypass hose (J) to suction side of water pump (H). The coolant then circulates through the cylinder block providing a fast warm-up period.

Once the engine has reached operating temperature, the thermostat opens and coolant is pumped from the bottom of radiator (F) via the lower radiator hose (G) into the cylinder block. Here it circulates through the block and around the cylinder liners. From the block, coolant is then directed through the cylinder head, and into thermostat housing. With the thermostat open,

82°C (180°F), warm engine coolant passes through the housing into the top of radiator where it is circulated to dissipate heat.

When coolant system pressure exceeds 48 kPa (0.48 bar) (7 psi), a valve in the radiator cap (D) opens to allow coolant to discharge into the coolant recovery tank (E).

When temperature is reduced, a vacuum is produced in the radiator and coolant is drawn back out of the coolant recovery tank through a valve in the radiator cap.

Oil cooler (I) is used to help reduce the temperature of engine oil. Pressurized oil enters the coil cooler and passes through a network of tubing surrounded by engine coolant. Prior to entering the oil cooler, the engine coolant passes through the radiator, which transfers much of the coolant's heat into the surrounding air. The coolant, its temperature now reduced, enters the oil cooler and passes over the warmer tubing. Heat transfers from the oil to the coolant, thus reducing oil temperature.

Coolant temperature sender (B) senses critical coolant temperature and sends a signal to a gauge in the instrument panel.

AG,OUO1085,329 -19-14SEP00-2/2

220  
10  
10

## Diagnostic Information

The diagnostic information in this group is used to test components related to a specific problem. Select the appropriate symptom from the list that best matches your problem and follow the test procedures under that heading. The symptom headings are:

- Engine turns over but will not start or starts hard
- Engine runs irregularly or stalls frequently
- Engine runs rough
- Engine has low power
- Engine smokes—black or grey
- Engine smokes excessively—white
- Engine uses excess fuel
- Engine has excess noise or vibration
- Engine uses excess oil or smokes blue
- Engine has low oil pressure
- Engine coolant operating temperature incorrect
- Oil in coolant or coolant in oil

The diagnostic procedure lists:

- Test conditions
- Test sequence
- Test location
- Normal reading
- Check or test to perform if reading is not normal

When performing the test or check, be sure to set your machine up to the test conditions listed and follow the sequence carefully. The middle “Normal” column gives the specification or condition that should be obtained when performing the test or check. If the results are not normal, perform the test, check, or adjustment listed in the third “If Not Normal” column to repair the malfunction. The detailed tests or adjustments referred to in the “If Not Normal” column are located at the end of this group.

LV,22015HA,A1 -19-04JUN96-1/1

## Engine Turns Over But Will Not Start or Starts Hard

### CONDITIONS:

- Transmission in park.
- PTO disengaged.
- Key switch OFF.
- Engine and fuel system repair in CTM104 or CTM125.
- Engine and fuel/air tests and adjustments found in this group.
- Ignition and electrical tests in Section 240, Group 15.

Test Location	Normal	If Not Normal
1. Fuel tank caps.	No pressure or vacuum when removed from tank.	Replace tank vent or hose.
2. Fuel tank.	Diesel fuel of correct grade for ambient temperature.	Replace with correct fuel.
3. Fuel shut-off solenoid.	Opens to allow fuel flow when key switch is turned on.	Reset solenoid by turning key switch off, then on.
4. Fuel filter.	Fuel flows at outlet when primer pump operated.	Drain water and sediment. Replace element. Bleed air from supply line.
5. Fuel leak-off line.	Small amount of fuel flows when engine running.	Clean or replace line.
6. Starter (not shown).	Turns engine over easily at 90 rpm minimum when engine is cranked.	Check starter and starting circuit.
7. Injection pump.	Delivers fuel to injection nozzles when engine is cranked (lines loosened at nozzles). Injection properly timed.	Adjust injection pump timing. Repair pump.
8. Injection nozzles.	Correct spray pattern when tested. See CTM104 or CTM125.	Check fuel lines for obstruction. Clean, repair, adjust or replace as necessary.
9. Valves.	Intake clearance: 0.35 mm (0.014 in.) Exhaust clearance: 0.45 mm (0.018 in.)	Adjust.
10. Manifold heater (not shown).	Element heats when key switch is pushed in.	Check element and circuit.
11. Crankcase oil.	Flows easily.	Replace with correct viscosity.

AG\_OUO1085,330 -19-14SEP00-1/1

**Engine Runs Irregularly or Stalls Frequently****CONDITIONS:**

- Transmission in park.
- PTO disengaged.
- Key switch OFF.
- Engine and fuel/air system repair in CTM104 or CTM125.
- Engine and fuel/air tests and adjustments found in this group.
- Ignition and electrical tests in Section 240, Group 15.

Test Location	Normal	If Not Normal
1. Fuel tank cap.	No pressure or vacuum when removed from tank.	Replace tank vent or hose.
2. Fuel tank.	Clean diesel fuel of correct grade.	Replace with correct fuel.
3. Air cleaner.	No excessive restriction in elements.	Clean or replace elements.
4. Fuel filter.	Fuel flows at outlet when primer pump operated.	Drain water and sediment. Replace element. Bleed air from supply line.
5. Fuel shut-off solenoid.	Opens to allow fuel flow when key switch turned on.	Check electrical circuit.
6. Temperature gauge.	Gauge reads in green band.	See Engine Coolant Operating Temperature Incorrect in this group.
7. Valves.	Intake clearance: 0.35 mm (0.014 in.) Exhaust clearance: 0.45 mm (0.018 in.)	Adjust.
8. Exhaust system (not shown).	Low restriction. (Operate briefly without muffler to check.)	Replace parts as required.
9. Cylinders.	Minimum pressure of 2400 kPa (24 bar) (350 psi). No more than 350 kPa (3.50 bar) (50 psi) difference between highest and lowest cylinder readings.	Check piston rings, valves, cylinder head, and gasket.
10. Injection nozzles.	Opening pressure and spray pattern tests normal. See CTM104 or CTM125.	Clean, adjust, repair, or replace as required.

AG\_OUO1085,331 -19-14SEP00-1/1



**Engine Runs Rough****CONDITIONS:**

- Transmission in park.
- Key switch OFF.
- Engine and fuel/air system repair in CTM104 or CTM125.
- Engine and fuel/air tests and adjustments found in this group.

Test Location	Normal	If Not Normal
1. Fuel filter.	Fuel flows at outlet when primer pump operated.	Drain water and sediment. Replace element.
2. Fuel leak-off line.	Small amount of fuel flow to tank when engine is running.	Clean or replace.
3. Injection nozzles.	Opening pressure and spray tests normal. See CTM104 or CTM125.	Clean, adjust, repair or replace as required.
4. Valves.	Intake clearance: 0.35 mm (0.014 in.) Exhaust clearance: 0.45 mm (0.018 in.)	Adjust.
5. Cylinders.	Minimum compression of 2400 kPa (24 bar) (350 psi). No more than 350 kPa (3.50 bar) (50 psi) difference between highest and lowest cylinder readings.	Check piston rings, valves, cylinder head and gasket.
6. Temperature gauge.	Reads in green band.	See Engine Coolant Operating Temperature Incorrect in this group.
7. Injection pump.	Delivers fuel to injectors when engine is cranked (lines slightly open at nozzles). Injection properly timed.	Adjust injection pump timing. Repair pump.
8. Injection lines.	Tight, free from leaks.	Tighten or replace injection lines.

AG,OUO1085,332 -19-14SEP00-1/1

**Engine Has Low Power****CONDITIONS:**

- Transmission in park.
- PTO disengaged.
- Key switch OFF.
- Engine and fuel/air system repair in CTM104 or CTM125.
- Engine and fuel/air tests and adjustments found in this group.
- Ignition and electrical tests in Section 240, Group 15.

Continued on next page

AG,OUO1085,333 -19-14SEP00-1/2

Test Location	Normal	If Not Normal
1. Tachometer.	Reads rated rpm of 2400 at full load.	Load excessive—reduce load or shift to lower gear. Check fast idle speed. Adjust speed control linkage.
2. Temperature gauge.	Gauge reads in green band.	See Engine Coolant Operating Temperature Incorrect in this group.
3. Tires (not shown).	Slippage 10—15% 2-WD, 8—12% MFWD with transmission in gear and engine running.	Adjust amount of ballast. Reduce excess load.
4. Implement (not shown).	Properly adjusted.	Adjust for proper operation.
5. Air cleaner.	No excessive restriction.	Clean or replace air cleaner elements.
6. Fuel tank.	Correct grade of clean diesel fuel.	Drain and replace fuel.
7. Fuel filter.	Fuel flows at outlet when primer pump operated. Element not restricted.	Drain water and sediment. Replace element.
8. Fuel leak-off line.	Small amount of fuel flows when engine running.	Clean or replace line.
9. Fuel shut-off solenoid.	Opens to allow fuel flow when key switch is turned on.	Check electric circuit.
10. Injection nozzles.	Correct spray pattern/opening pressure when tested. See CTM104 or CTM125.	Clean, repair, adjust or replace as required.
11. Valves.	Intake clearance: 0.35 mm (0.014 in.) Exhaust clearance: 0.45 mm (0.018 in.)	Adjust.
12. Cylinders.	Minimum compression of 2400 kPa (24 bar) (350 psi). No more than 350 kPa (3.50 bar) (50 psi) difference between highest and lowest cylinder readings.	Check piston rings, valves, cylinder head and gasket.
13. Hydraulic system (not shown).	No load with valves in neutral.	See Section 270.
14. Muffler.	Low restriction (operate briefly without muffler to check).	Replace muffler if significant improvement when operated without.
15. Injection pump.	Delivers fuel to nozzles when engine cranked (lines loosened at nozzles). Injection properly timed.	Adjust pump timing. Service pump.
16. Turbocharger (5310 and 5510).	Operates smoothly. Boost pressure correct. See this group.	Repair turbocharger.
17. Exhaust manifold.	No leaks at gaskets.	Check for manifold warpage. Replace gaskets.
18. Hydraulic dipstick.	Oil level up to marks.	Add oil as needed.

AG,OUO1085,333 -19-14SEP00-2/2

**Engine Smokes—Black or Grey****CONDITIONS:**

- Transmission in park.
- PTO disengaged.
- Key switch OFF.
- Fuel/air system repair in CTM104 or CTM125.
- Fuel/air tests and adjustments found in this group.

Test Location	Normal	If Not Normal
1. Air cleaner.	No excessive restriction.	Service.
2. Fuel tank.	Diesel fuel of correct grade.	Replace with fuel of correct specifications.
3. Injection nozzles.	Correct spray pattern/opening pressure when tested. See CTM104 or CTM125.	Clean, repair, adjust or replace as necessary.
4. Injection pump/governor.	Delivers correct amount of fuel for load with engine running. Pump timed correctly.	Reduce load or shift to lower gear. Adjust pump timing. Service pump.
5. Turbocharger (5310 and 5510).	Delivers correct volume of air for fuel delivered with engine running.	Check turbocharger boost pressure. Check condition of turbocharger sealing rings.

AG,OUO1085,334 -19-14SEP00-1/1

**Engine Smokes Excessively—White****CONDITIONS:**

- Transmission in park.
- PTO disengaged.
- Key switch OFF.
- Engine and fuel/air system repair in CTM104 or CTM125.
- Engine and fuel/air tests and adjustments found in this group.
- Ignition and electrical tests in Section 240, Group 15.

Test Location	Normal	If Not Normal
1. Temperature gauge.	Reads in green band. (Engine operating at normal operating temperature.)	Allow engine to warm up. See Engine Coolant Operating Temperature Incorrect in this group.
2. Fuel tank.	Correct grade of clean diesel fuel.	Replace with higher octane rated fuel.
3. Starter (not shown).	Starter turns engine easily at 90 rpm minimum when engine is cranked.	Check starter and circuits.
4. Manifold heater (not shown).	Element heats when key switch is pushed in.	Check element and circuit.
5. Injection pump.	Delivers fuel properly timed when engine is cranked.	Adjust pump timing. Service pump.
6. Injection nozzles.	Correct spray pattern/opening pressure when tested. See CTM104 or CTM125.	Clean, repair, adjust or replace as required.
7. Cylinders.	Minimum compression of 2400 kPa (24 bar) (350 psi). No more than 350 kPa (3.50 bar) (50 psi) difference between highest and lowest cylinder readings.	Check piston rings, valves, cylinder head and gasket.

AG,OUO1085,335 -19-14SEP00-1/1

**Engine Uses Excess Fuel****CONDITIONS:**

- Transmission in park.
- PTO disengaged.
- Key switch OFF.
- Fuel/air system repair in CTM104 or CTM125.
- Fuel/air tests and adjustments found in this group.

Test Location	Normal	If Not Normal
1. Air cleaner.	No excess restriction in elements.	Clean or replace elements.
2. Fuel tank.	Correct grade of clean diesel fuel.	Replace with correct fuel.
3. Fuel system.	No leaks in lines, tank, filter or fittings.	Repair or replace defective parts.
4. Turbocharger (5310 and 5510).	Operates smoothly.	Check vanes and bearings. Check clearances.
5. Injection nozzles.	Correct spray pattern/opening pressure when tested. See CTM104 or CTM125.	Clean, repair, adjust, or replace as required.
6. Injection pump.	Properly timed.	Adjust pump timing.
7. Load or implement (not shown).	Within horsepower range of tractor.	Reduce load. Adjust implement.

AG,OUO1085,336 -19-14SEP00-1/1

## Engine Has Excess Noise or Vibration

### CONDITIONS:

- Forward/reverse selector in neutral.
- Park brake engaged.
- PTO disengaged.
- Key switch OFF.
- Engine and fuel/air system repair in CTM104 or CTM125.
- Engine and fuel/air tests and adjustments found in this group.
- Ignition and electrical tests in Section 240, Group 15.

Test Location	Normal	If Not Normal
1. Crankcase.	Correct quantity and viscosity of oil.	Add oil. Replace incorrect, dirty or contaminated oil.
2. Oil pressure switch port.	Oil pressure within specifications. See this group.	Low oil pressure: Check oil level and viscosity. Replace pressure regulating valve. Test oil pressure switch. Check oil pump and screen. 5310 and 5510—check turbocharger oil seal. Repair excessive external oil leaks. Repair excessive bearing clearances or cracks in block or oil galleries.
3. Valves.	Intake clearance: 0.35 mm (0.014 in.) Exhaust clearance: 0.45 mm (0.018 in.)	Adjust valves.
4. Injection pump.	Correctly timed.	Adjust pump timing.
5. Front pulley and flywheel.	Matched unbalanced front pulley and flywheel.	Replace with correct matched unbalanced three-cylinder pulley and flywheel.
6. Turbocharger (5310 and 5510).	Smooth operation of compressor wheel.	Check clearances. Check bearings.
7. Engine and fan.	Clearances and parts within specifications.	Repair parts as necessary. Replace damaged fan.

AG\_OUO1085.337 -19-14SEP00-1/1

**Engine Uses Excess Oil or Smokes Blue****CONDITIONS:**

- Transmission in park.
- PTO disengaged.
- Key switch OFF.
- Engine repair in CTM104 or CTM125.
- Engine tests found in this group.

Test Location	Normal	If Not Normal
1. Engine gaskets and seals.	No external leaks.	Replace.
2. Crankcase breather.	No restrictions.	Clean or replace elements.
3. Crankcase.	Correct viscosity oil for ambient temperature.	Replace with correct viscosity oil.
4. Oil pressure switch port.	Oil pressure of 483 kPa (4.83 bar) (70 psi) MAX. at 2575 rpm.	Replace regulating valve.
5. Valve seals.	No cracks, controls oil.	Replace seals.
6. Engine internal parts.	Within wear limits and piston rings not stuck. See CTM104 or CTM125.	Replace defective parts.

AG,OUO1085,330 -19-14SEP00-1/1

**Engine Has Low Oil Pressure****CONDITIONS:**

- Transmission in park.
- PTO disengaged.
- Key switch OFF.
- Engine repair in CTM104 or CTM125.
- Ignition and electrical tests in Section 240, Group 15.

Test Location	Normal	If Not Normal
1. Crankcase dipstick.	Level between marks.	Add to correct level.
2. Crankcase.	Correct viscosity oil for ambient temperature.	Drain and replace with correct oil.
3. Oil pressure indicator.	Light on at less than 100 kPa (1 bar) (15 psi).	See Section 240.
4. Oil pressure regulating valve.	Valve free in bore.	Replace valve.
5. Oil pump intake screen.	Screen clear.	Clean or replace.
6. Oil pump.	Clearances within specifications. See CTM104 or CTM125.	Replace worn parts.
7. Bearings (not shown).	Clearance within specification. See CTM104 or CTM125.	Replace worn parts.

AG,OUO1085,331 -19-14SEP00-1/1



## Engine Coolant Operating Temperature Incorrect

### CONDITIONS:

- Transmission in park.
- PTO disengaged.
- Key switch OFF.
- Engine fuel/air system repair in CTM104 or CTM125.
- Engine and fuel/air tests and adjustments found in this group.
- Electrical tests in Section 240, Group 15.

Test Location	Normal	If Not Normal
1. Coolant recovery tank.	Level between lines of recovery tank.	Fill to correct level.
2. Fan/alternator drive belt.	Belt deflection within specifications. See this group. Correct fan installed properly.	Adjust fan belt. Replace damaged or incorrect fan. Install fan correctly.
3. Radiator.	Free of dirt/trash in radiator fins. No leaks. No bubbles in coolant.	Clean and pressure test radiator. Check cylinder head, cylinders and head gasket for cracks.
4. Shroud.	Correct undamaged shroud.	Replace shroud.
5. Radiator cap.	Operating within range. Not leaking.	Replace cap.
6. Temperature gauge.	Reads in green band.	Test circuit.
7. Thermostat.	Starts to open at 71°C (160°F) full open 95°C (202°F).	Replace.
8. Cooling system.	Passages clear.	Flush radiator and engine block.
9. Hoses.	Hoses flexible with no cracks, swelling or spongy feel. Clamps tight.	Replace hoses. Tighten loose clamps.
10. Water pump.	Clearance within specifications. No "play" in bearing.	Repair or replace pump.
11. Load applied (not shown).	Within horsepower available.	Reduce load/shift to lower gear.
12. Crankcase.	Correct capacity and viscosity of oil.	Add or replace oil.
13. Fuel tank (not shown).	Correct grade of fuel.	Replace with correct fuel.
14. Injection pump (not shown).	Properly timed pump.	Time pump.
15. Pistons.	No scoring.	Replace.

AG,OUO1085,332 -19-14SEP00-1/1

**Oil In Coolant or Coolant in Oil****CONDITIONS:**

- Transmission in park.
- PTO disengaged.
- Key switch OFF.
- Engine repair in CTM104 or CTM125.

Test Location	Normal	If Not Normal
1. Oil cooler.	No cracks.	Replace.
2. Head gasket.	Complete seal.	Check head and block for flatness.
3. Block/head.	No cracks.	Replace.
4. Cylinder liners.	No cracks. Liner seals in good condition.	Check cylinder liners for cracks or leaking seals.

AG,OUO1085,333 -19-14SEP00-1/1

## Radiator Bubble Test

**NOTE:** 5210 and 5310 tractors shown. 5410 and 5510 tractors are similar.

### REASON:

To determine if compression pressure is leaking from cylinder.

### EQUIPMENT:


- JT01679 Adapter
- JT02017 Clamp

### PROCEDURE:


1. With coolant at proper level and radiator cap tight, run engine to operating temperature.
2. Remove cap from coolant recovery tank.
3. Check for bubbles coming from hose (A) at bottom of recovery tank.
4. Isolate source of compression leak: Remove injector nozzles.
5. Install JT01679 Adapter (B) and JT02017 Clamp (C) in injector port of cylinder to be tested.
6. Move piston to bottom of stroke with intake and exhaust valves closed.
7. Connect hose from compressed air source (2400 kPa) (24 bar) (350 psi) maximum) to adapter.
8. Check for bubbles in recovery tank or air escaping from exhaust pipe, air cleaner or oil fill opening.
9. Repeat steps (5—8) for each cylinder.

**NOTE:** Cylinder being tested when bubbles appear or air escapes is usually the defective cylinder.

### RESULTS:



3-Cylinder Recovery Tank



Injection Port

A—Hose  
B—JT01679 Adapter  
C—JT02017 Clamp

- If bubbles are present, check for cracks in cylinder head, cylinder liner, and block. Check for damaged head gasket.
- If air escapes from exhaust pipe, check for worn exhaust valve.
- If air escapes from air cleaner, check for worn intake valve.
- If air escapes from engine oil fill, check for worn piston rings.
- Go to CTM104 or CTM125 and service as needed.

AG,OUO1085,334 -19-14SEP00-2/2

## Cooling System Test

### REASON:

Inspect cooling system for leaks.

### EQUIPMENT:

- D05104ST Cooling System Pressure Pump

### CONNECTIONS:

1. Remove cap and connect pressure pump to radiator.

### PROCEDURE:

1. Apply 120 kPa (1.20 bar) (18 psi) maximum pressure.
2. Check for leaks throughout cooling system.

### SPECIFICATIONS:

- Minimum pressure after 15 seconds: 90 kPa (0.90 bar) (13 psi).

### RESULTS:

- Pressure should hold to specifications. If pressure decreases, check for leaks. Go to Section 20 and service as needed.
- If pressure test still indicates leakage and all external leaks have been stopped, a defective head gasket, cracked block, cylinder head or oil cooler may be the cause. (Go to Radiator Bubble Test in this group.)



Pressure Pump

LV402 -UN-18FEB92

AG,OUO1085,336 -19-14SEP00-1/1

## Radiator Cap Pressure Test

### REASON:

Test radiator cap for operating in correct pressure range.

### EQUIPMENT:

- D05104ST Cooling System Pressure Pump

### CONNECTIONS:

1. Install radiator cap on pressure pump.

### PROCEDURE:

1. Apply pressure and observe when pressure valve in cap relieves.

### SPECIFICATIONS:


Opening pressure should be within the following specifications:

#### Specification

Radiator Cap Pressure Valve—  
Opening Pressure ..... 43—53 kPa (0.43—0.53 bar)  
(6.25—7.75 psi)

### RESULTS:

- If cap leaks, retighten and test again. Replace cap if pressure is not within specifications.



Pressure Pump

M54060 -UN-16JUL90

220  
15  
15

AG\_OUO1085,339 -19-14SEP00-1/1

## Engine Oil Pressure Test

**NOTE:** 4-cylinder tractor shown. 3-cylinder tractor is similar.

### REASON:

To determine if bearings or lubrication system components are worn.

### EQUIPMENT:

- JDG465 Special Socket
- JT05577 Pressure Gauge Assembly
- JT03017 Hose Assembly
- JT05487 Connector (From JT01767 Kit)
- JDG282 Temperature Gauge


### CONNECTIONS:

1. Remove oil pressure sender (JDG465 Socket may be used).

**NOTE:** Thread is 1/8" M NPT, use JT05487 Connector, hose and 0-700 kPa (0—6.9 bar) (0—100 psi) gauge.

2. Install JT05487 Connector.
3. Connect JT05577 Pressure Gauge Assembly and JT03017 Hose Assembly.

### PROCEDURE:



LV2157 -JUN-14MAY97

Continued on next page

AG,OUO1085,340 -19-22NOV02-1/2

**IMPORTANT: If pressure reading is below 72 kPa (0.72 bar) (10.5 psi), STOP ENGINE.**

*NOTE: 5210 and 5310 engine oil filter shown. 5410 and 5510 are similar.*

1. Install JDG282 Temperature Gauge (A) on engine oil filter.

*NOTE: Tolerance extremes in engine and gauge can result in the gauge reading up to 582 kPa (5.82 bar) (85 psi). This is not detrimental to the engine.*


2. Run engine approximately 5 minutes to heat oil to specifications, then check oil pressure.

#### Specification

Engine Oil Temperature at 850 rpm Engine Speed—Temperature .....	93°C (200°F)
Engine Oil Temperature at 1600—2400 rpm Engine Speed—Temperature .....	105°C (220°F)
Minimum Oil Pressure at 850 rpm Engine Speed—Pressure .....	100 kPa (1 bar) (15 psi)
Minimum Oil Pressure at 1600—2400 rpm Engine Speed—Pressure .....	277—483 kPa (2.77—4.83 bar) (40—70 psi)

#### RESULTS:

- If oil pressure is not within specifications, inspect oil pressure regulating valve for broken or worn spring, stuck or damaged valve. (Go to CTM104 or CTM125 and service as needed.)
- If pressure does not increase, go to Engine Has Low Oil Pressure in this group and service as needed.



A—JDG282 Temperature Gauge



## Cylinder Compression Pressure Test

### REASON:

To determine the condition of the pistons, rings, cylinder walls and valves.

### EQUIPMENT:

- JT01682 Compression Gauge Assembly
- JT01679 Adapter
- JT02017 Clamp

### CONNECTIONS:

1. Run engine for 10—15 minutes to bring to operating temperature. Shut off engine.
2. Remove injection nozzles.
3. Install JT01682 Compression Gauge Assembly, JT01679 Adapter and JT02017 Clamp.

### PROCEDURE:

1. Disconnect fuel shut-off solenoid wiring lead (A).

**IMPORTANT: DO NOT overheat starting motor during test.**

2. Crank engine for five seconds with starter.
3. Record pressure reading for each cylinder.
4. After test is completed, bleed the fuel system. (See this group.)

### Cylinder—Specification


Cylinder—Pressure.....	2400 kPa (24 bar) (350 psi)
	Minimum
Maximum Difference Between	
Cylinders—Pressure.....	350 kPa (3.50 bar) (50 psi)

### RESULTS:

- If pressure reading is below specification, squirt approximately 2 teaspoons of clean engine oil into cylinders through injector ports and repeat test.



LV405 -UN-18FEB92



LV2158 -UN-14MAY97

A—Solenoid Wiring Lead

Continued on next page

AG,OUO1085,343 -19-14SEP00-1/2

- If pressure increases significantly, check piston, rings, and cylinder walls for wear or damage. Go to CTM104 or CTM125 and service as needed.
- If pressure does not increase significantly after retest, check for leaking valves, valve seats or cylinder head gasket. Go to CTM104 or CTM125 and service as needed.

AG\_OUO1085,343 -19-14SEP00-2/2

## Fuel Shut-Off Solenoid Check

### REASON:

To ensure proper operation of control solenoid.

### CONNECTIONS:


1. Check for clean tight connection at terminal (A).

### PROCEDURE:

1. Turn key switch to ON position. Solenoid plunger should pull in fully with an audible "click".

### RESULTS:

- If "click" is not heard, connect jumper wire from battery positive terminal to solenoid terminal screw.
- If solenoid "clicks" when connected to battery, check wiring circuit to solenoid. Go to Section 240.
- If solenoid does not "click" when connected to battery, replace solenoid.



A—Terminal

LV2112 -UN-19MAY97

AG\_OUO1085,344 -19-14SEP00-1/1

## Throttle Lever Adjustment


### REASON:

To achieve smooth throttle lever movement with a slight drag.

### PROCEDURE:

*NOTE: Instrument panel removed for clarity.*

1. Remove key switch panel.
2. Adjust spring tension by loosening or tightening lock nut (A) until throttle lever movement is smooth throughout range of travel with only slight drag.



A—Lock Nut

LV407 -UN-18FEB92

AG,OUO1085,345 -19-14SEP00-1/1

## Slow Idle Adjustment

### REASON:

To achieve correct slow idle rpm.

### EQUIPMENT:

- JT05719 Hand Held Digital Tachometer

### CONNECTIONS:

1. Attach reflective tape to crankshaft sheave (A).

### PROCEDURE:

1. Run engine to normal operating temperature.
2. Pull throttle lever back (toward turtle) until it stops.
3. Check rpm.

#### Specification


Engine—Slow Idle—Speed .....  $825 \pm 25$  rpm

### RESULTS:


- If rpm is not within specifications, adjust screw (B) until correct slow idle rpm is obtained.
- If correct slow idle rpm cannot be obtained, go to Fast Idle Adjustment in this group.

A—Crankshaft Sheave

B—Screw



Crankshaft Sheave



Slow Idle Adjustment Screw

AG,OUO1085,346 -19-14SEP00-1/1

220  
15  
21

LV408 -UN-18FEB92

LV2159 -UN-14MAY97



## Fast Idle Adjustment

### REASON:

To achieve correct fast idle rpm.

### EQUIPMENT:

- JT05719 Hand Held Digital Tachometer

### CONNECTIONS:

1. Attach reflective tape to crankshaft sheave (A).

### PROCEDURE:

1. Run engine to normal operating temperature.
2. Loosen nuts (D).
3. Push throttle lever fully forward (toward rabbit) until linkage plate (B) contacts bracket (C).
4. Check rpm using tachometer.
5. Push lever (E) until screw (F) touches fast idle screw stop. Adjust screw to fast idle specifications.
6. Tighten nuts (D) while holding lever (E) against screw stop.
7. Check rpm.


### Specification

Engine—Fast Idle—Speed..... 2625 ± 25 rpm


### RESULTS:

- If rpm cannot be brought to specifications, go to Engine Has Low Power in this group.


- A—Crankshaft Sheave
- B—Linkage Plate
- C—Stop Bracket
- D—Nuts
- E—Lever
- F—Idle Screw



Crankshaft Sheave



Linkage plate and Stop Bracket



Fast Idle Adjustment Screw

## Injection Pump Timing Adjustment

**NOTE:** This procedure is used if pump timing was disturbed, or a new pump is installed. If a new front plate (without a timing mark) has been installed, see instructions to transfer fuel injection pump timing mark to new front plate in CTM104 or CTM125.

### REASON:

To correctly set injection pump timing for proper engine operation.

### PROCEDURE:

1. Loosen nut (B) on the three mounting studs.
2. Pivot injection pump away from engine as far as slots (A) will allow.
3. Pivot injection pump toward engine to exactly align timing marks (C and D).
4. Tighten nuts (B) to specification.


### Specification

Fuel Injection Pump Mounting

Nuts—Torque ..... 25 N•m (216 lb-in.)

### RESULTS:

- Injection pump is properly timed for beginning of injection.



A—Adjustment Slot  
B—Nut  
C—Pump Housing Alignment Mark  
D—Front Cover Alignment Mark

220  
15  
23

LV2161 -UN-14MAY97

AG,OUO1085,349 -19-14SEP00-1/1


## Check and Adjust Valve Clearance

Insufficient valve clearance forces valves out of time. Valves open too early and close too late. Hot combustion gases rush past valves, causing the valves to overheat. Overheating lengthens valve stems preventing proper valve seating. Valves seat so briefly or poorly that normal heat transfer to the valve seat and cooling system does not have time to take place, resulting in burned valves and low power.

Excessive valve clearance produces a lag in valve timing resulting in engine valve train imbalance. The air-fuel mixtures enters cylinders late during the intake stroke. The exhaust valve closes early and prevents waste gases from being completely removed from the cylinders. Also, the valves close with a great deal of force, which may crack or break the valves and scuff the camshaft and followers.

**NOTE:** Valve clearance *MUST BE* checked with engine cold.

1. Remove rocker arm cover and ventilator tube.
2. Remove plugs or cover plate from engine timing holes (A).



**A—Engine Timing Holes**

RG6305 -UN-03AUG92

Continued on next page

AG,OUO1085,350 -19-14SEP00-1/4



3. Using engine rotation tool and timing pin, rotate engine in running direction (clockwise viewed from front) until No. 1 cylinder is at TDC compression stroke.

If No. 1 cylinder rocker arms are loose, the engine is at No. 1 TDC compression. If No. 1 cylinder rocker arms are not loose, rotate engine one full revolution (360°) to No. 1 TDC compression.

**NOTE:** Some engines are equipped with flywheel housing which do not allow use of an engine rotation tool.

4. Check and adjust valve clearance to specifications, as directed in the following procedures for 3, 4, or 6-cylinder engines.

**Valve Clearance (Rocker Arm-to-Valve Tip)—Specification**


Intake Valve—Clearance.....	0.35 mm (0.014 in.)
Exhaust Valve—Clearance.....	0.45 mm (0.018 in.)

5. If rocker arm is equipped with adjusting screw and jam nut (A), tighten jam nut to specification after adjusting valve clearance.


**Specification**

Rocker Arm Jam Nut—Torque.....	27 N•m (20 lb-ft)
--------------------------------	-------------------

**A—Jam Nut**



No. 1 Cylinder




Jam Nut

AG,OUO1085,350 -19-14SEP00-2/4

**NOTE:** Firing order is 1—2—3.

- a. 3-CYLINDER ENGINE: Lock No. 1 piston at TDC compression stroke (B).
- b. Adjust valve clearance on No. 1 and 2 exhaust valves and No. 1 and 3 intake valves.
- c. Turn crankshaft 360° and lock No. 1 piston at TDC exhaust stroke (C).
- d. Adjust valve clearance on No. 3 exhaust valve and No. 2 intake valve.




A—Front of Engine  
B—No. 1 Piston at TDC Compression Stroke  
C—No. 1 Piston at TDC Exhaust Stroke  
E—Exhaust Valve  
I—Intake Valve

Continued on next page

AG,OUO1085,350 -19-14SEP00-3/4

**NOTE:** Firing order is 1—3—4—2.

- 4-CYLINDER ENGINE: Lock No. 1 piston at TDC compression stroke (B).
- Adjust valve clearance on No. 1 and 3 exhaust valves and No. 1 and 2 intake valves.
- Turn crankshaft 360°. Lock No. 4 piston at TDC compression stroke (C).
- Adjust valve clearance on No. 2 and 4 exhaust valve and No. 3 and 4 intake valves.



A—Front of Engine  
 B—No. 1 Piston at TDC Compression Stroke  
 C—No. 4 Piston at TDC Compression Stroke  
 E—Exhaust Valve  
 I—Intake Valve

RG4776 -UN-31OCT97

AG.OUO1085,350 -19-14SEP00-4/4

## Fan/Alternator V-Belt Adjustment (5210 and 5310)

### REASON:

To keep proper tension on belt to drive water pump and alternator. To prevent shortened belt and bearing life.

### EQUIPMENT:

- JDG529, JDST28, or JT05975 Belt Tension Gauge
- Straight edge

### PROCEDURE:

**NOTE:** Run engine for five minutes to warm a cold belt.  
Let hot belt cool for 15 minutes before adjustment.


1. Check belt tension using appropriate gauge: JDG529 or JDST28 gauge for standard V-belt, JT05975 or JDST28 gauge for poly V-belt.
2. Loosen both alternator mounting cap screws.

**IMPORTANT:** Do not pry against alternator rear frame when adjusting belt. Alternator can be damaged.


3. Apply outward pressure to alternator front frame until belt tension is to specifications.
4. Tighten cap screws.
5. Run engine for 10 minutes.
6. Check belt tension. If not within used belt specifications, wait 10 minutes to cool belt and adjust belt to used belt tension.

### Specification

New Standard V-Belt—JDG529	
Gauge Method—Tension .....	578—622 N (130—140 lb-force)
Used Standard V-Belt—JDG529	
Gauge Method—Tension .....	378—423 N (85—94 lb-force)
Standard V-Belt—JDST28	
Gauge/Straight Edge Method—	
Belt Deflection at 89 N (20	
lb-force).....	19 mm (0.750 in.)
New Poly V-Belt—JT05975	
Gauge Method—Tension .....	890—1068 N (200—240 lb-force)



M54014



A—Belt Deflection

Specification

Used Poly V-Belt—JT05975  
Gauge Method—Tension ..... 800—979 N (180—220 lb-force)  
Poly V-Belt—JDST28  
Gauge/Straight Edge Method—  
Belt Deflection at 130 N (30  
lb-force)..... 13 mm (0.500 in.)

AG,OUO1085,351 -19-15SEP00-2/2

## Compressor Drive Belt Adjustment— 3-Cylinder

### REASON:

To keep proper tension on belt to drive air conditioning compressor. To prevent shortened belt and bearing life.

### EQUIPMENT:

- JDG529 or JDST28 Belt Tension Gauge
- Straight edge

### PROCEDURE:


**NOTE:** Run engine for five minutes to warm a cold belt.  
Let hot belt cool for 15 minutes before adjustment.

1. Check belt tension using appropriate gauge: JDG529 or JDST28 Gauge for standard V-belt.
2. Loosen compressor mounting cap screw (C) and jam nut (A).
3. Turn adjustment screw (B) clockwise until belt tension is to specifications.


#### Specification

New Standard V-Belt—JDG529  
Gauge Method—Tension ..... 578—622 N (130—140 lb-force)  
Used Standard V-Belt—JDG529  
Gauge Method—Tension ..... 378—423 N (85—94 lb-force)  
Standard V-Belt—JDST28  
Gauge/Straight Edge Method—  
Belt Deflection at 89 N (20  
lb-force)..... 19 mm (0.750 in.)

4. Tighten jam nut and cap screws.
5. Run engine for 10 minutes.
6. Check belt tension. If not within used belt specifications, wait 10 minutes to cool belt and adjust belt to used belt tension.



LV885 -UN-21DEC95



LV1613 -UN-02FEB96

A—Jam Nut  
B—Adjustment Screw  
C—Cap Screw  
D—Belt Deflection

220  
15  
30

Turbocharger Boost Pressure Test—5310 and 5510

REASON:

To determine if turbocharger is operating properly within specifications.

EQUIPMENT:

- JT03470 Fitting
- JDE147 Kit

CONNECTIONS:

1. Remove manifold heater from intake manifold.
2. Install JT03470 Fitting in manifold.
3. Connect hose and gauge from JDE147 kit and follow procedures on next page.

PROCEDURE:

1. Run engine until lubricating oil reaches operating temperature of 105°C (220°F).

**IMPORTANT:** Engine speed and load should be stabilized before taking readings on gauge. Be sure that gauge works properly.

Pressure checks are only a guide to determine if there is an engine problem (valve leakage, defective nozzles, etc.). Low readings are not a valid reason for increasing injection pump fuel delivery. Pump adjustment should be within specification as established by an authorized pump repair station.

2. Observe gauge. Reading should be within specifications at specified load speed.

Specification

Load—Speed..... 2400 rpm



LV417 -UN-18FEB92

**Specification**

3029T—Minimum Turbocharger	
Boost—Pressure.....	69 kPa (0.69 bar) (10 psi)
4045T—Minimum Turbocharger	
Boost—Pressure.....	117 kPa (1.20 bar) (17 psi)

**RESULTS:**

If boost pressure is too high, check for:

- Excessive fuel injection pump pressure.
- Low injection nozzle opening pressure.
- Excessive injection nozzle valve lift.
- Injection nozzle seat leakage.
  - Go to CTM104 or CTM125 and service as needed.

If boost pressure is too low, check for:

- Restricted air filter.
- Restricted fuel filter or lines.
  - Go to Section 30 and service as needed.
- Incorrect fast idle adjustment.
- Incorrect injection pump timing.
- Low compression pressure.
  - Go to Section 220 and service as needed.
- Exhaust manifold leaks.
- Intake manifold leaks.
- Faulty fuel injection nozzles.
- Carbon build-up in turbocharger.
- Turbocharger compressor or turbine wheel rubbing housing.
- Low fuel injection pump delivery.
  - Go to CTM104 or CTM125 and service as needed.

AG,OUO1085,352 –19–22NOV02–2/2

220  
15  
31



## Bleed Fuel System

**CAUTION:** Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.


### REASON:

If the fuel system has been serviced (lines disconnected or filter removed), it will be necessary to bleed air from the system.


**IMPORTANT:** Do not attempt to start engine while bleeding fuel system. Injection pump can be damaged.

### PROCEDURE:

1. Check that fuel level in tank is adequate.
2. Open fuel shut-off valve (A) at fuel filter.
3. Open filter bleed plug (B).
4. Operate supply pump primer (C) until air-free fuel flows from plug. Tighten plug (B) securely.
5. Start engine and check for leakage. If engine will not start, it may be necessary to bleed air from fuel system at fuel injection pump or injection nozzles as explained next.



X9811 -UN-23AUG88



LV2167 -UN-14MAY97

A—Fuel Shut-Off Valve  
B—Filter Bleed Plug  
C—Fuel Pump Primer

Continued on next page

AG,OUO1032,3323 -19-31MAY00-1/2

6. Slightly loosen fuel line (A) at fuel injection pump.

7. Operate primer on fuel filter until air-free fuel flows from line (A). Tighten line to specification.

**Specification**

Fuel Injection pump line—Torque ..... 16 N•m (12 lb-ft)

8. Move the speed control lever to half throttle position.

9. Loosen fuel line connection (B) at injection nozzle.

10. Crank engine with starter motor (but do not start engine), until air-free fuel flows from connection. Tighten fuel line connection (B) to specification.

**Specification**


Fuel Injection Nozzle Line Nuts—

Torque ..... 27 N•m (20 lb-ft)


11. Repeat this procedure for remaining injection nozzles (if necessary) until all air has been removed from fuel system.

A—Fuel Line

B—Fuel Line Connection



LV2166 -UN-14MAY97



LV2168 -UN-14MAY97

AG,OUO1032,3323 -19-31MAY00-2/2



# Fuel/Air Operation, Tests, and Adjustments

## Contents

### Page

#### Group 05—Component Location

Component Location Information . . . . .	230-05-1
Fuel System Components . . . . .	230-05-2
Air Intake System Components—Without Turbocharger . . . . .	230-05-4
Air Intake System Components—With Turbocharger . . . . .	230-05-5

#### Group 10—Theory of Operation

Theory of Operation Information . . . . .	230-10-1
Fuel System Operation . . . . .	230-10-2
Fuel Filter/Priming Pump Operation . . . . .	230-10-4
Fuel Injection Nozzle Operation . . . . .	230-10-6
Air Intake System Operation—Without Turbocharger . . . . .	230-10-8
Air Intake System Operation—With Turbocharger . . . . .	230-10-10
Turbocharger Operation—5310 and 5510 . . . . .	230-10-12

#### Group 15—Diagnosis, Tests and Adjustments

Diagnostic Information . . . . .	230-15-1
Fuel/Air Diagnosis, Tests and Adjustments . . . . .	230-15-1



## Component Location Information

This group contains component location drawings for the following fuel/air system components:


- Fuel System
- Air Intake System
  - With Turbocharger
  - Without Turbocharger

Use the drawings when diagnosing a fuel/air problem and to help locate the components to be tested.

AG,OUO1085,355 –19–15SEP00–1/1

230  
05  
1

# Fuel System Components



## FUEL SYSTEM COMPONENTS

LV2169

LV2169 -UN-08JUN97

Continued on next page

AG,OUO1085,356 -19-15SEP00-1/2



Component Location


- |                       |                           |                       |                          |
|-----------------------|---------------------------|-----------------------|--------------------------|
| A—Injection Pump      | E—Fuel Filter/Primer Pump | I—Fuel Tank Vent Hose | M—Fuel Supply Hose       |
| B—Fuel Leak-Off Line  | F—Fuel Supply Line        | J—Fuel Tank Vent      | N—High Pressure Lines    |
| C—Injection Nozzles   | G—Fuel Shut-Off Valve     | K—Fuel Level Sender   | O—Fuel Shut-Off Solenoid |
| D—Fuel Filter Element | H—Fuel Return Hose        | L—Fuel Tank           | Terminal                 |

NOTE: Three-cylinder engine shown; four-cylinder engine uses same components.

AG,OUO1085,356 -19-15SEP00-2/2

230  
05  
3

# Air Intake System Components—Without Turbocharger



LV2170

## AIR INTAKE SYSTEM COMPONENTS—WITHOUT TURBOCHARGER

A—Cylinder Head  
B—Manifold Heater  
C—Air Intake Hose

D—Secondary Safety Element  
E—Air Cleaning Housing  
F—Primary Element


G—Air Cleaner Cover  
H—Left-Hand Grille Panel  
I—Front Grille Panel

J—Right-Hand Grille Panel  
K—Air Filter Restriction Indicator

**NOTE:** Three-cylinder engine without turbocharger shown; four-cylinder engine without turbocharger is similar.

LV2170 -UN-24FEB98

## Air Intake System Components—With Turbocharger



LV2171

## AIR INTAKE SYSTEM COMPONENTS—WITH TURBOCHARGER

A—Cylinder Head  
B—Manifold Heater  
C—Air Intake Pipe  
D—Turbocharger

E—Air Intake Hose  
F—Air Cleaner Housing  
G—Air Filter Restriction Indicator

H—Primary Element  
I—Left-Hand Grille Panel  
J—Front Grille Panel

K—Right-Hand Grille Panel  
L—Secondary Safety Element

**NOTE:** Four-cylinder engine with turbocharger shown; three-cylinder engine with turbocharger is similar.

LV2171 -UN-18MAR98

230  
05  
6

## Theory of Operation Information

This group divides the fuel/air system into individual components or sub-systems by function. The story contains information on function, component or sub-system identification, and theory of operation.


The following systems or components are covered:

- Fuel System
- Fuel Filter/Priming Pump
- Fuel Injection Pump
- Injection Nozzle
- Air Intake System
- Turbocharger

AG,OUO1085,359 -19-15SEP00-1/1

230  
10  
1

## Fuel System Operation



## FUEL SYSTEM OPERATION

LVC2172

LVC2172 -UN-10JUN97

Continued on next page

AG,OUO1085,360 -19-15SEP00-1/2

A—Injection Pump  
B—Injection Nozzles  
C—Fuel Filter

D—Fuel Tank Vent  
E—Fuel Tank  
F—High Pressure Fuel

G—Suction Fuel  
H—Trapped Fuel

I—Return Fuel  
J—Ventilation

#### FUNCTION:

Fuel system supplies fuel to injector nozzles.

#### MAJOR COMPONENTS:

- Fuel Tank
- Fuel Tank Vent
- Fuel Filter/Primer Pump
- Injection Pump
- Injection Nozzles
- Supply Hose and Line
- High Pressure Lines
- Return Line and Hoses

*NOTE: Three-cylinder engine shown; four-cylinder engine uses same components.*

#### THEORY OF OPERATION:

Suction fuel (G) flows from tank (E) to filter (C) to injection pump (A). The injection pump meters fuel as

determined by its internal governor and throttle position, and delivers the fuel (F) at high pressure to the injection nozzles (B). The injector nozzle prevents flow until sufficiently high pressure is reached, opening the valve and spraying atomized fuel into the combustion chamber. Injection lines have trapped fuel (H) whenever injection is not taking place.

Vent (D) will open to permit air to escape if fuel tank becomes pressurized. Vent will also open to permit air to enter tank if sufficient vacuum is created, to allow suction fuel (G) to supply system.

Any air in the system is bled out with return fuel (I) to the fuel tank. Manual bleeding of fuel system is usually necessary only after servicing components of fuel system.


More fuel is routed through the system than is required for injection. Excess fuel serves to cool and lubricate the injection pump and nozzles, and warm the fuel in the fuel tank.

AG,OUO1085,360 -19-15SEP00-2/2

230  
10  
3



## Fuel Filter/Priming Pump Operation



LV248A

## FUEL FILTER/PRIMING PUMP OPERATION

A—Priming Pump  
B—Fuel Inlet

C—Bleed Screw  
D—Second Stage Filter

E—First Stage Filter  
F—Drain Plug

G—Fuel Outlet

## FUNCTION:

Fuel filter provides clean, moisture free fuel for the injection process. The priming pump aids in the removal of excess air from the filter and lines so the injection pump can then draw fuel from the tank.

## MAJOR COMPONENTS:

- Fuel Filter Base
- Fuel Filter Element
- Priming Pump
- Bleed Screw

Continued on next page

LV,23010HA,A5 -19-19FEB92-1/2

- Drain Plug

#### THEORY OF OPERATION:

Fuel enters the filter at inlet (B) and flows through a first stage filter (E) and a second stage filter (D) before flowing through outlet (G) to the fuel injection pump. The filter elements are housed in a sediment bowl attached to the base with a threaded ring.

Since water and contaminants settle at the bottom of the sediment bowl, a drain plug (F) is provided.


Air in the system can be expelled through the air vent when the bleed screw (C) is loosened.

Priming pump (A) draws fuel from the fuel tank to fill the filter bowl in the event of a filter change. Priming pump also supplies fuel from the filter to the injection pump.

LV,23010HA,A5 -19-19FEB92-2/2

230  
10  
5

## Fuel Injection Nozzle Operation



LVC265AE

## FUEL INJECTION NOZZLE OPERATION

*Fuel Injection Nozzle Operation*

A—Carbon Stop Seal  
 B—Nozzle Valve  
 C—Nozzle Body  
 D—Seal Washer  
 E—Nozzle Valve Guide  
 F—Spring Seat  
 G—Adjustable Pressure Spring

H—Spacer Washer  
 I—Hex Nut  
 J—Lock Nut  
 K—Lock Nut  
 L—Leak-Off Tee  
 M—Lift Adjusting Screw

N—Pressure Adjusting Screw  
 O—Grommet  
 P—Location Clamp  
 Q—Filter Screen  
 R—Fuel Pressure Line  
 S—Nipple

T—Line Nut  
 U—Connection For Injection Line  
 V—Spray Tip  
 W—Injection Pressure Fuel  
 X—Return Fuel

FUNCTION:

LVC265AE -19-21MAY96

Continued on next page

LV,23010HA,A9 -19-22MAY96-1/2

The fuel injection nozzle sprays fuel in an atomized form directly into cylinder.

#### MAJOR COMPONENTS:

- Spray Tip
- Nozzle Valve
- Nozzle Body
- Nozzle Valve Guide
- Adjustable Pressure Spring
- Lift Adjusting Screw
- Leak-Off Tee
- Pressure Adjusting Screw

#### THEORY OF OPERATION:

The spring and valve type injection nozzles, located in the engine cylinder head, are hydraulically operated by the fuel delivered from the injection pump.

A location clamp (P) positions the nozzle assembly in the cylinder head. The nozzle is sealed at the lower end by a seal washer (D). A carbon stop seal (A), located on the lower end of the nozzle body, prevents carbon from collecting around the nozzle in the cylinder head.

Enclosed in the nozzle body (C) are nozzle valve (B), adjustable pressure spring (G), and spring seat (F).

Nozzle operating pressure is controlled by pressure adjusting screw (N) in the upper end of the nozzle body. Valve lift is adjusted by lift adjusting screw (M) located in the pressure adjusting screw. The spray tip (V) is pressed into the nozzle body and cannot be separated.


A leak-off tee (L) is attached to the upper end of injection nozzle, secured by a grommet (O) and hex nut (I).

Metered fuel, under high pressure, is delivered by the injection pump through the nozzle inlet on the valve body into the area surrounding the valve. When fuel pressure reaches nozzle opening pressure, the valve is forced from its seat against the pressure of the spring, permitting a measured amount of fuel to enter the combustion chamber through four small holes in the spray tip.

After fuel has been injected, the spring closes the valve. In actual operation, the valve opens and closes very rapidly, providing a distinct chatter.

A small amount of fuel leaks past the valve into the spring area to provide lubrication for the nozzle working parts. The excess fuel is removed from the nozzle at the top by means of a leak-off line connected to the fuel tank.

## Air Intake System Operation—Without Turbocharger



LV2173

## AIR INTAKE SYSTEM OPERATION—WITHOUT TURBOCHARGER

A—Air Intake Hose  
B—Secondary Safety Element  
C—Primary Element

D—Air Cleaner Housing  
E—Unloader Valve  
F—Grille Panels

G—Air Cleaner Intake  
H—Air Filter Restriction Indicator

I—Cylinder Head  
J—Manifold Heater

**NOTE:** Three-cylinder engine without turbocharger shown; four-cylinder engine without turbocharger is similar.

**FUNCTION:**

Air intake system filters air needed for combustion.

**MAJOR COMPONENTS:**

- Grille Panels

Continued on next page

AG,OUO1085,361 -19-15SEP00-1/2

- Air Cleaner Housing
- Primary Element
- Secondary Element
- Air Intake Hose
- Cylinder Head
- Manifold Heater
- Air Filter Restriction Indicator

**THEORY OF OPERATION:**

Air enters through grille panels and into the air cleaner intake (G) located under air cleaner housing (E).

Directing air around primary element (C) in a circular motion, throwing larger particles to the unloader valve (E). Air is then directed through a secondary element (B) through hose (A) to cylinder head (I).


An electronic air filter restriction indicator (H) is located at air cleaner outlet to indicate clogged or restricted air cleaner elements. An indicator in dash will light.

An electric manifold heater (J) warms intake air, by heating coils or metal strips as air passes through them, to aid in cold starting.

AG,OUO1085,361 -19-15SEP00-2/2

230  
10  
9

## Air Intake System Operation—With Turbocharger



LV2174

### AIR INTAKE SYSTEM OPERATION—WITH TURBOCHARGER

A—Turbocharger  
B—Air Intake Hose  
C—Air Cleaner Housing  
D—Air Filter Restriction Indicator

E—Primary Element  
F—Air Cleaner Intake  
G—Grille Panels

H—Secondary Safety Element  
I—Unloader Valve  
J—Cylinder Head

K—Manifold Heater  
L—Air Intake Pipe

**NOTE:** Four-cylinder engine with turbocharger shown; three-cylinder engine with turbocharger is similar.

#### FUNCTION:

Air intake system filters air needed for combustion.

Continued on next page

AG,OUO1085,362 -19-15SEP00-1/2



Turbocharger provides extra air to the combustion chamber, allowing more fuel to be burned for increased engine power.

**MAJOR COMPONENTS:**

- Grille Panels
- Air Cleaner Housing
- Primary Element
- Secondary Element
- Air Intake Hose
- Air Intake Pipe
- Cylinder Head
- Manifold Heater
- Air Filter Restriction Indicator
- Turbocharger

**THEORY OF OPERATION:**

Air enters through grille panels (G) and into the air cleaner intake (F) and into the air cleaner intake (F) and air cleaner housing (C), through primary element (E) depositing larger particles to the unloader valve (I). Air is then directed through a secondary safety element (H), through hose (B) to turbocharger (A). The turbocharger forces filtered air through pipe (L) and into cylinder head (J).


An electronic air filter restriction indicator (D) is located at air cleaner outlet to indicate clogged or restricted air cleaner elements. An indicator in dash will light.

An electric manifold heater (K) warms intake air, by warm coils or metal strips as air passes through them, to aid in cold starting.

AG,OUO1085,362 -19-15SEP00-2/2

230  
10  
11

## Turbocharger Operation—5310 and 5510



LV251A

## TURBOCHARGER OPERATION

A—Compressor Wheel  
B—Compressor Housing

C—Shaft  
D—Turbine Housing

E—Turbine Wheel

F—Center Housing

## FUNCTION:

To force more air into the engine cylinders to allow the engine to efficiently burn more fuel, thereby producing more power.

## MAJOR COMPONENTS:

- Turbine Wheel
- Turbine Housing
- Compressor Wheel
- Compressor Housing
- Center Housing
- Shaft Assembly

## THEORY OF OPERATION:

The turbine wheel (E) is driven by engine exhaust gases flowing through the turbine housing (D). The rotary motion of the turbine wheel causes the shaft (C) to spin the compressor wheel (A). The compressor wheel draws filtered air from the air cleaner, compresses and forces it into the engine cylinders.

Because a greater volume of air is being forced into the cylinders, a greater amount of fuel can be injected also. This increase of air and fuel results in increased power.

Because turbine speed is controlled by exhaust energy, the turbocharger delivers a volume of air based on engine load and power output.

LV251A -19-18MAR92

Diagnostic Information

The diagnostic information is used to test components related to a specific problem or system. Select a symptom or system from the list and follow the test procedures under that heading.

The diagnostic procedure lists:

- Test conditions
- Test sequence
- Test location
- Normal reading
- Check or test to perform if reading is not normal

When performing the test or check, be sure to set your machine up to the test conditions listed and follow the sequence carefully. The middle “Normal” column gives the reading or condition that should be obtained when performing the test or check. If the results of the test or check are not normal, perform the test, check, or adjustment listed in the third “If Not Normal” column to repair the malfunction. The detailed tests or adjustments referred to in the “If Not Normal” column are located at the end of this group.

MX,23015HE,A1A –19–13DEC94–1/1

Fuel/Air Diagnosis, Tests and Adjustments

For this product, all diagnosis, tests and adjustments for the fuel/air system are discussed in Section 220, Group 15. This is done since many engine complaints can be caused by the fuel/air system and diagnosing them separately is difficult.

MX,23015HE,1A –19–04DEC92–1/1

230  
15  
2

# Section 240

# Electrical System Operation, Tests & Adjust

## Contents

Page	Page
<b>Group 05—Component Location</b>	
Component Location Information . . . . .	240-05-1
Engine Electrical Components—4-Cylinder . .	240-05-2
Dash Electrical Components . . . . .	240-05-3
Machine Electrical Components—	
5210—5410 Without Cab. . . . .	240-05-5
Machine Electrical Components—5510	
Without Cab. . . . .	240-05-6
Machine Electrical Components—	
5210—5510 With Cab . . . . .	240-05-8
Cab Control Panel and Electrical	
Components . . . . .	240-05-10
<b>Group 10—Theory of Operation</b>	
Theory of Operation Information . . . . .	240-10-1
Fuse Block and Fuses—Without Cab . . . . .	240-10-2
Fuse Block and Fuses—With Cab. . . . .	240-10-3
Cab Fuse Block and Fuses . . . . .	240-10-4
Relays. . . . .	240-10-5
Starting System Operation—Normal . . . . .	240-10-6
Starting System Operation—Bypass	
Attempt . . . . .	240-10-8
Manifold Heater System Operation . . . . .	240-10-10
Charging System Operation . . . . .	240-10-12
Lighting System Operation—Turn Signals . .	240-10-14
Lighting System Operation—Warning	
Lights. . . . .	240-10-16
Lighting System Operation—Tail Light. . . .	240-10-18
Lighting System Operation—Headlights and	
Instrument Lights . . . . .	240-10-20
Instrument Panel System Operation—	
Tachometer . . . . .	240-10-22
Instrument Panel System Operation—Fuel	
Gauge . . . . .	240-10-24
Instrument Panel System Operation—	
Temperature Gauge. . . . .	240-10-26
Instrument Panel System Operation—	
Hourmeter . . . . .	240-10-28
PTO Warning System Operation . . . . .	240-10-30
Air Filter Restriction Indicator Operation . .	240-10-32
Rear Work Light Operation—Without Cab . .	240-10-34
Optional Horn Operation . . . . .	240-10-35
Accessory Relay and Trailer Connector	
Operation. . . . .	240-10-36
Flood Light Operation—With Cab . . . . .	240-10-38
Blower Motor Operation—With Cab. . . . .	240-10-40
A/C Compressor Operation—Cab Only . . . .	240-10-42
Front Wiper/Washer Operation—Cab	
Only. . . . .	240-10-44
Rear Wiper/Washer Operation—Cab Only . .	240-10-46
Dome Light Operation—Cab Only . . . . .	240-10-48
<b>Group 15—Diagnosis, Test and Adjust</b>	
Diagnostic Information. . . . .	240-15-1
Wire Color Chart . . . . .	240-15-2
Starting System Test Points—Normal	
Operation. . . . .	240-15-4
Starting System Test Points—Bypass	
Attempt . . . . .	240-15-8
Manifold Heater Test Points . . . . .	240-15-11
Charging System Test Points . . . . .	240-15-14
Lighting System Test Points—Turn	
Signals (Tractors Without Cab) . . . . .	240-15-18
Lighting System Test Points—Turn	
Signals (Tractors With Cab). . . . .	240-15-21
Lighting System Test Points—Warning Lights	
(All Tractors) . . . . .	240-15-26
Lighting System Test Points—Rear Work	
Light (Tractors Without Cab) . . . . .	240-15-28
Lighting System Test Points—Flood Lights	
(Tractors With Cab) . . . . .	240-15-31
Lighting System Test Points—Tail Lights	
(Tractors Without Cab). . . . .	240-15-37
Lighting System Test Points—Tail Lights	
(Tractors With Cab) . . . . .	240-15-40
Lighting System Test Points—Headlights and	
Instrument Lights . . . . .	240-15-43
Lighting System Test Points—Dome Light	
(Tractors With Cab) . . . . .	240-15-48
Instrument Panel System Test Points—	
Tachometer/Hourmeter . . . . .	240-15-51
Instrument Panel System Test Points—	
Fuel Gauge . . . . .	240-15-54
Instrument Panel System Test Points—	
Temperature Gauge. . . . .	240-15-57
Instrument Panel System Test Points—Oil	
Pressure . . . . .	240-15-60
PTO Warning System Test Points. . . . .	240-15-64
Air Filter Restriction Test Points . . . . .	240-15-67
Optional Horn Test Points . . . . .	240-15-71

Continued on next page

Page

Accessory Relay and Trailer Connector	
Test Points . . . . .	240-15-73
Blower Motor Test Points (Tractors With Cab) . . . . .	240-15-76
A/C Compressor Clutch Coil Test Points (Tractors With Cab) . . . . .	240-15-81
Front Wiper/Washer Test Points (Tractors With Cab) . . . . .	240-15-83
Rear Wiper/Washer Test Points (Tractors With Cab) . . . . .	240-15-87
Battery Voltage and Specific Gravity Tests . . . . .	240-15-91
Charge Battery . . . . .	240-15-93
Battery Load Test . . . . .	240-15-95
Starter Amp Draw/RPM Test . . . . .	240-15-97
Starter No-Load Amp Draw/RPM Test . . . . .	240-15-99
Alternator/Regulator Test . . . . .	240-15-100
Starter Solenoid Test . . . . .	240-15-101
Starter Relay Test . . . . .	240-15-102
Key Switch Test . . . . .	240-15-103
Plug-In Relay Test . . . . .	240-15-104
Diode Pack Test . . . . .	240-15-105
Fuse Test . . . . .	240-15-106
Neutral Start Switch Test . . . . .	240-15-107
PTO Switch Test . . . . .	240-15-108
PTO Seat Switch Test . . . . .	240-15-109
Light Switch Test . . . . .	240-15-110
Turn Signal Controller Test . . . . .	240-15-111
Fuel Shut-Off Solenoid Test . . . . .	240-15-112
Blower Switch Test . . . . .	240-15-113
Blower Motor Resistors . . . . .	240-15-114
A/C Thermostatic Control Switch Test . . . . .	240-15-115
Front Wiper/Washer Switch Test . . . . .	240-15-116
Rear Wiper/Washer Switch Test . . . . .	240-15-117
Door Switch Test . . . . .	240-15-118
Dome Light Switch Test . . . . .	240-15-119

**Group 20—Wiring Schematics**

Schematic Information . . . . .	240-20-1
Component Identification Table . . . . .	240-20-1
5210—5510 Electrical Schematics and Legend (Tractors Without Cab) . . . . .	240-20-4
5210—5510 Electrical Schematic and Legend (Tractors With Cab) . . . . .	240-20-6

## Component Location Information

This group contains component location drawings for the following electrical components:

- Engine Components
- Dash Components
- Machine Components


Use the drawings when troubleshooting an electrical problem to help locate the components to be tested.

AG.OUO1023,585 -19-03MAR00-1/1

240  
05  
1



## Engine Electrical Components—4-Cylinder



LV2175

### ENGINE ELECTRICAL COMPONENTS — 4 CYLINDER

A—M1 Starter  
B—R1 Manifold Heater  
C—F13 Fuse Link

D—K1 Manifold Heater Relay  
E—G2 Alternator/Regulator

F—B3 Coolant Temperature Sender


G—B4 Engine Speed Sensor  
H—B5 Oil Pressure Switch

**NOTE:** 4-cylinder engine shown, 3-cylinder is similar.

*Engine without cab air conditioning compressor shown.*

LV2175 -UN-26NOV97

# Dash Electrical Components



**DASH ELECTRICAL COMPONENTS**

A—K6 Turn Signal Controller  
 B—S6 Horn Switch (Optional)  
 C—Instrument Panel  
 D—H1 PTO Indicator  
 E—P3 Fuel Gauge  
 F—P5 Tachometer  
 G—P2 Engine Coolant Temperature Gauge

H—Park Brake Indicator  
 I—H8 Engine Oil Pressure Indicator  
 J—S5 Light Switch  
 K—H7 Charge Indicator  
 L—P1 Hourmeter

M—H2 High Beam Indicator  
 N—H9 Air Filter Restriction Indicator  
 O—K4 Start Relay  
 P—B1 Horn/Timer  
 Q—S1 Key Switch

R—Fuse Block  
 S—K5 Accessory Relay  
 T—K2 Fuel Shut-Off Relay  
 U—K3 Bypass Start Relay  
 V—V1 Diode Pack

Continued on next page

AG,OUO1085,365 -19-18SEP00-1/2


Component Location

*NOTE: Manifold heater relay is mounted on right side of engine, near manifold heater. (See Machine Electrical Components in this group.)*

AG,OUO1085,365 -19-18SEP00-2/2

240  
05  
4

# Machine Electrical Components—5210—5410 Without Cab



LV2177

## MACHINE ELECTRICAL COMPONENTS – 5210-5410 W/O CAB

A—P4 Fuel Level Sender  
B—H5 Right Warn/Turn Light  
C—E4 Rear Work Light  
D—E3 Tail/H3 Left Warn/Turn Light

E—S3 Seat Switch  
F—Fuse Block  
G—B2 Horn (Optional)  
H—S7 Air Filter Restriction Switch

I—E1/E2 Headlights  
J—G1 Battery  
K—K1 Manifold Heater Relay  
L—F13 Fuse Link

M—S2 Rear PTO Switch  
N—S4 Neutral Start Switch  
O—X22 7-Pin Trailer Connector


**NOTE:** Unit with Collar Shift/SyncShuttle™ transmission shown. On units with PowerReverser™ transmission, neutral start

switch (N) is located on PowerReverser™ control valve on left side of transmission housing.

240  
05  
5

LV2177 -UN-18DEC97

# Machine Electrical Components—5510 Without Cab



LV2178

## MACHINE ELECTRICAL COMPONENTS – 5510 W/O CAB

- |                                    |                                    |                            |                                     |
|------------------------------------|------------------------------------|----------------------------|-------------------------------------|
| A—H5 Right Warn/Turn Light         | F—S3 Seat Switch                   | J—E1/E2 Headlights         | O—S4 Neutral Start Switch           |
| B—P4 Fuel Level Sender             | G—Fuse Block                       | K—G1 Battery               | P—X22 7-Pin Trailer Connector       |
| C—E4 Rear Work Light               | H—B2 Horn (Optional)               | L—K1 Manifold Heater Relay | Q—E8 Right Front Fender Flood Light |
| D—E3 Tail/H3 Left Warn/Turn Light  | I—S7 Air Filter Restriction Switch | M—F13 Fuse Link            |                                     |
| E—E7 Left Front Fender Flood Light | N—S2 Rear PTO Switch               |                            |                                     |

Continued on next page

AG,OUO1085,367 –19–18SEP00–1/2

*NOTE: Unit with Collar Shift/SyncShuttle™ transmission shown. On units with PowrReverser™ transmission, neutral start*

*switch (O) is located on PowrReverser™ control valve on left side of transmission housing.*

AG,OUO1085,367 -19-18SEP00-2/2

The diagram illustrates the electrical system components of a tractor, with labels and leader lines pointing to their locations. The components are as follows:

- E14** RIGHT REAR FLOOD LIGHT
- E10** RIGHT REAR WARN/TURN LIGHT
- E5** LEFT TAIL LIGHT
- B4** FUEL LEVEL SENDER
- E6** RIGHT TAIL LIGHT
- X92** 7-PIN TRAILER CONNECTOR
- S4** NEUTRAL START SWITCH (COLLAR SHIFT/SyncShuttle™ TRANSMISSION)
- S3** SEAT SWITCH
- S2** REAR PTO SWITCH
- E13** LEFT REAR FLOOD LIGHT
- E8** LEFT REAR WARN/TURN LIGHT
- E15** LEFT FRONT FLOOD LIGHT
- E7** LEFT FRONT WARN/TURN LIGHT
- E16** RIGHT FRONT FLOOD LIGHT
- E9** RIGHT FRONT WARN/TURN LIGHT
- FUSE BLOCK**
- F17** FUSE LINK
- B7** AIR FILTER RESTRICTION SWITCH
- E1/E2/E3/E4** HEADLIGHTS
- B2** HORN (OPTIONAL)
- K1** MANIFOLD HEATER RELAY
- G1** BATTERY
- S4** NEUTRAL START SWITCH (PowerReverser™ TRANSMISSION)

Letters A through W are used as sub-labels for specific components or connection points, often corresponding to the letters in the component codes.

## MACHINE ELECTRICAL COMPONENTS—WITH CAB

AG,OUO1085,368 -19-18SEP00-1/2



## Component Location

A—E6 Right Tail Light	H—E15 Left Front Flood Light	O—B7 Air Filter Restriction Switch	T—S2 Rear PTO Switch
B—B4 Fuel Level Sender	I—E7 Left Front Warn/Turn Light	P—E1, E2, E3, and E4 Headlights	U—S3 Seat Switch
C—E5 Left Tail Light	J—E16 Right Front Flood Light	Q—K1 Manifold Heater Relay	V—S4 Neutral Start Switch (Collar Shift/SyncShuttle™ transmission)
D—E10 Right Rear Warn/Turn Light	K—E9 Right Front Warn/Turn Light	R—G1 Battery	W—X92 7-Pin Trailer Connector
E—E14 Right Rear Flood Light	L—Fuse Block	S—S4 Neutral Start Switch (PowrReverser™ transmission)	
F—E13 Left Rear Flood Light	M—F17 Fuse Link		
G—E8 Left Rear Warn/Turn Light	N—B2 Horn (Optional)		


**NOTE:** On units with Collar Shift/SyncShuttle™ transmission, the neutral start switch (V) is located on the right side of transmission housing. On units with PowrReverser™

transmission, neutral start switch (S) is located on PowrReverser™ control valve on left side of transmission housing.

AG,OUO1085,368 -19-18SEP00-2/2

240  
05  
9

## Cab Control Panel and Electrical Components



LV1632

- |                                    |                               |                                |                                |
|------------------------------------|-------------------------------|--------------------------------|--------------------------------|
| A—Junction Block                   | D—K8 Left Blower Motor Relay  | G—Convenience Outlet           | J—S9 Front Wiper/Washer Switch |
| B—K11 Front/Rear Flood Light Relay | E—K9 Right Blower Motor Relay | H—Fuse Block                   | K—S7 Blower Switch             |
| C—K7 Main Cab Relay                | F—S8 Air Condition Switch     | I—S10 Rear/Wiper Washer Switch | L—Heater Control               |

LV1632 -19-23APR01

## Theory of Operation Information

This group divides the electrical system into individual circuits by function. Each circuit has been isolated from the main wiring schematic and only shows the components that are used in that circuit. The theory of operation story explains: function of the circuit, operating conditions, components used, and current flow.

The circuit schematic that accompanies each theory story shows the operating condition with the battery or power circuit on top and the ground circuit on the bottom. COLOR IS USED TO IDENTIFY DIFFERENT SUB-CIRCUITS. THE COLOR USED DOES NOT NECESSARILY INDICATE COLOR OF THE WIRE.

The circuit numbers used in the schematics represent entire circuit sections using the same number. Actual circuits may have letter suffixes added to indicate specific portions of the circuit. For the exact designation, refer to Group 15 in this section or to the tractor wiring harness.

The following systems or components are covered:



- Fuse Block
- Relays
- Starting Systems

- Normal Operation
- Bypass Operation
- Manifold Heater System
- Charging System
- Lighting System
  - Turn Signals
  - Warning Lights
  - Tail Light
  - Headlights
  - Instrument Lights
  - Rear Work Light
  - Accessory Relay and Trailer Connector
- Instrument Panel System
  - Fuel Gauge
  - Temperature Gauge
  - Hourmeter
- PTO Warning System
- Air Filter Restriction Indicator
- Cab-Related Circuits
  - Blower Motors
  - A/C Compressor
  - Front Wiper/Washer
  - Rear Wiper/Washer
  - Dome Light
- Optional Equipment
  - Dual Horns

AG,OUO1085,370 –19–18SEP00–1/1

240  
10  
1

## Fuse Block and Fuses—Without Cab



LVC2180

## FUSE BLOCK AND FUSES—WITHOUT CAB

A—F1  
B—F2  
C—F3

D—F4  
E—F5 (not used)  
F—F6

G—F7  
H—F8  
I—F9

J—F10  
K—F11  
L—F12 (not used)

## FUNCTION:

Protect circuits from electrical overload.

## MAJOR COMPONENTS:

- Fuse Block
- Fuses

## THEORY OF OPERATION:

Fuse block uses push-in, blade-type fuses to limit current flow in their respective circuits. When flow exceeds rating on fuse, its conductor melts, thus preventing circuit damage.


A total of twelve fuses may be used. Fuse locations (E and L) may be empty as these fuses are used only to



protect auxiliary circuits. Fuse ratings and the circuits they protect are as follows:

- F1, 10-Amp: Alternator, instruments and engine-related warning indicators.
- F2, 20-Amp: Fuel shut-off solenoid.
- F3, 20-Amp: Warning lights (flashers) and turn indicators.
- F4, 20-Amp: Rear work light.
- F5, 30-Amp: Auxiliary circuit (power from battery).
- F6, 30-Amp: Key switch, starting circuit, PTO warning circuit, manifold heater circuit.
- F7, 30-Amp: Horn, lights, turn signals.
- F8, 30-Amp: Accessory relay.
- F9, 20-Amp: Tail lights.
- F10, 20-Amp: High-beam headlights and indicator.
- F11, 20-Amp: Low-beam headlights.
- F12, 20-Amp: Auxiliary circuit (key activated).

LVC2180 -JUN-10JUN97

## Fuse Block and Fuses—With Cab



 10 AMP FUSE  
 20 AMP FUSE  
 30 AMP FUSE

LVC2181

## FUSE BLOCK AND FUSES—CAB TRACTORS

A—F1  
 B—F2  
 C—F3

D—F4  
 E—F5  
 F—F6

G—F7  
 H—F8  
 I—F9

J—F10  
 K—F11  
 L—F12

### FUNCTION:

Protect circuits from electrical overload.

### MAJOR COMPONENTS:

- Fuse Block
- Fuses

### THEORY OF OPERATION:

Fuse block uses push-in, blade-type fuses to limit current flow in their respective circuits. When flow exceeds rating on fuse, its conductor melts, thus preventing circuit damage.

A total of twelve fuses may be used. Fuse locations (E) and (L) may be empty as these fuses are used

only to protect auxiliary circuits. Fuse ratings and the circuits they protect are as follows:

- F1, 10-Amp: Alternator, instruments and engine-related warning indicators.
- F2, 20-Amp: Fuel shut-off solenoid.
- F3, 20-Amp: Warning lights and turn indicators.
- F4, 20-Amp: Flood lights.
- F5, 30-Amp: Radio, dome light, and convenience outlet.
- F6, 30-Amp: Key switch, starting circuit, PTO warning circuit, manifold heater circuit.
- F7, 30-Amp: Horn, lights, turn signals.
- F8, 30-Amp: Accessory relay.
- F9, 20-Amp: Tail lights.
- F10, 20-Amp: High-beam headlights and indicator.
- F11, 20-Amp: Low-beam headlights.

Continued on next page

AG,OUO1085,372 -19-18SEP00-1/2

- F12, 20-Amp: Radio, convenience outlet, front and rear wiper/washer (key activated).

AG,OUO1085,372 -19-18SEP00-2/2

## Cab Fuse Block and Fuses

### FUNCTION:

Protect cab circuits from electrical overload.

### MAJOR COMPONENTS:


- Fuse Block
- Fuses

### THEORY OF OPERATION:

Fuse block uses push-in, blade-type fuses to limit current flow in their respective circuits. When flow exceeds rating on fuse, its conductor melts, thus preventing circuit damage.

Cab fuse block is located on right side of overhead control panel. Four fuses are used. Fuse ratings and the circuits they protect are as follows:

- F13, 30-Amp: Blower switch and left blower motor circuit.
- F14, 30-Amp: Flood light circuits.
- F15, 30-Amp: Right side blower motor circuit.
- F16, 10-Amp: A/C compressor clutch coil circuit.



A—F13  
 B—F14  
 C—F15  
 D—F16  
 E—30 Amp Fuse  
 F—10 Amp Fuse

AG,OUO1085,373 -19-18SEP00-1/1

## Relays

### FUNCTION:

Control current flow through circuits with high current loads.

### MAJOR COMPONENTS:

- Manifold Heater Relay, K1 (Mounted on Engine Intake Manifold)
- Fuel Shut-Off Relay, K2
- Bypass Start Relay, K3
- Start Relay, K4
- Accessory Relay, K5
- Turn Signal Controller, K6
- Cab Relays:
  - HVAC Relay, K7
  - Blower Motor Relays, K8 and K9
  - Flood Light Relay, K10

### THEORY OF OPERATION:

Relays vary slightly in configuration and terminals, but work the same way. As current passes through relay windings, a magnetic field develops which draws contacts together. This activates controlled circuit and reduces current flow through system switches.


*NOTE: Specific operation of each relay is covered in theory of operation for that circuit.*

AG,OUO1085,374 -19-18SEP00-1/1

240  
10  
5



## Starting System Operation—Normal



## STARTING SYSTEM OPERATION — NORMAL

LVC2183

LVC2183 -UN-09JUL02

Continued on next page

AG,OUO1085,375 -19-18SEP00-1/2

A—Battery  
B—Fuse Link  
C—30-Amp Fuse  
D—Key Switch  
E—Rear PTO Switch

F—20-Amp Fuse  
G—Neutral Start Switch  
H—Start Relay  
I—Bypass Start Relay  
J—Diode Pack

K—Starter  
L—Fuel Shut-Off Relay  
M—Fuel Shut-Off Solenoid  
N—Start Resistor (4-Cyl Only)

O—Ground  
P—Power Circuit  
Q—Ground Circuit  
R—Energizing Circuit

#### FUNCTION:

The starting system converts electrical energy into the mechanical force necessary to crank the engine. A safety interlock system composed of switches and relays prevents bypass starting.

#### MAJOR COMPONENTS:

- 30-Amp Fuse
- 20-Amp Fuse
- Key Switch
- Rear PTO Switch
- Neutral Start Switch
- Start Relay
- Bypass Start Relay
- Fuel Shut-Off Relay
- Fuel Shut-Off Solenoid
- Starter
- Starter Resistor (4-Cyl Only)

#### THEORY OF OPERATION:

When key switch (D) is turned to START position, current flows through 30-amp fuse (C), through contacts of key switch and out circuit 571. Current then flows through rear PTO switch (E), circuit 573, and through neutral start switch (G). Current leaving the neutral start switch travels on circuit 301 to both the start (H) and bypass start (I) relays.

Current passing through start relay windings creates a magnetic field, which closes relay contacts. This


connects circuit 002 to 309, providing a current path to the starter S terminal. The starter (K) then cranks the engine.

At the same time, current travels to the bypass start relay on circuits 301 and 309. Current through circuit 301 creates a magnetic field in the windings of the bypass start relay which pulls its relay blade into contact with terminal 87. Current flow then stops on circuit 309 because of an open circuit between relay terminals 30 and 87A.

During normal operation, fuel shut-off relay (L) remains inactive. However, circuits 302 and 092 are connected through normally-closed relay contacts between terminals 30 and 87A. This energizes the fuel shut-off solenoid (M) and allows fuel flow through the fuel injection pump.

On 4-cylinder tractors, a small amount of voltage can be created at the end of a start cycle. This undesired voltage results when the starter does not immediately disengage when the key switch is released from the START position, thus causing the engine to turn the starter. When this happens, the starter acts as a generator, creating approximately 0.7—1.5 volts that backfeeds through the starter solenoid and the normally closed contacts of the bypass start relay to the coil of fuel shut-off relay (L). This voltage may be enough to energize the fuel shut-off relay, thus stopping fuel flowing to the fuel injection pump. To prevent this from occurring, start resistor (N) is provided to take this unwanted voltage to ground.

## Starting System Operation—Bypass Attempt



## STARTING SYSTEM OPERATION — BYPASS ATTEMPT

LVC2184

LVC2184 -UN-09/JUL02

Continued on next page

AG,OUO1085,376 -19-18SEP00-1/2

A—Battery  
B—Fuse Link  
C—30-Amp Fuse  
D—Key Switch  
E—Rear PTO Switch

F—20-Amp Fuse  
G—Neutral Start Switch  
H—Start Relay  
I—Bypass Start Relay  
J—Diode Pack

K—Starter  
L—Fuel Shut-Off Relay  
M—Fuel Shut-Off Solenoid  
N—Start Resistor (4-Cyl Only)  
O—Ground

P—Power Circuit  
Q—Ground Circuit  
R—Energizing Circuit  
S—Bypass Circuit

#### FUNCTION:

Prevents the engine from starting in the event starting circuit is bypassed.

#### MAJOR COMPONENTS:

- 30-Amp Fuse
- 20-Amp Fuse
- Key Switch
- Rear PTO Switch
- Neutral Start Switch
- Start Relay
- Bypass Start Relay
- Fuel Shut-Off Relay
- Fuel Shut-Off Solenoid
- Starter

#### THEORY OF OPERATION:

When starting circuit is bypassed by jumping terminals S and B at starter (K), current flows on circuit 309 to


bypass start relay (I). Current travels across normally-closed contacts of relay between terminals 30 and 87A and out to circuit 313. Current continues to flow through diode pack (J) and circuit 311 to terminals 86 and 87 of fuel shut-off relay (L).

After entering terminal 86, current flow creates a magnetic field in the relay windings which draws relay blade into contact with terminal 87. This interrupts current flow between circuits 092 and 302 that normally occurs with key switch (D) in the RUN position. At this time, the fuel shut-off solenoid (M) disengages and stops fuel flow through the injection pump, preventing engine starting.

A jumper circuit connected to terminal 87 and circuit 311 locks the relay in this position as long as key switch is in the on position. Diode pack prevents current from returning and engaging starter.

AG,OUO1085,376 -19-18SEP00-2/2

# Manifold Heater System Operation



LVC2185

## MANIFOLD HEATER SYSTEM OPERATION

A—Battery  
B—Fuse Link  
C—30-Amp Fuse

D—Key Switch  
E—Manifold Heater Relay  
F—Manifold Heater

G—Ground  
H—Power Circuit

I—Ground Circuit  
J—Energizing Circuit

### FUNCTION:

Heats air entering engine to aid cold-weather starting.

### MAJOR COMPONENTS:

- 30-Amp Fuse
- Key Switch
- Manifold Heater Relay
- Manifold Heater

Continued on next page

AG,OUO1085,377 -19-18SEP00-1/2

**THEORY OF OPERATION:**


System is controlled by operator only. No automatic control is used. When operator pushes in on key in RUN or START position, current flows through 30-amp fuse (C) and across starting aid contacts of key switch

(D). Current exits key switch on circuit 385 and travels to terminal 86 of manifold heater relay (E). As current passes through windings of relay, a magnetic field develops which pulls relay contacts and connects terminals 30 and 87. Current then passes from battery through circuit 002 and to manifold heater (F).

AG,OUO1085,377 -19-18SEP00-2/2

240  
10  
11

## CHARGING SYSTEM OPERATION



LVC2182 -UN-21JUN97

Continued on next page

AG,OUO1023,372 -19-09NOV99-1/2



A—Battery  
B—Fuse Link  
C—30-Amp Fuse  
D—Alternator/Regulator

E—Stator  
F—Rectifier Diode  
G—Rotor  
H—Voltage Regulator

I—10-Amp Fuse  
J—Charge Indicator  
K—Key Switch  
L—Ground

M—Direct Current  
N—Field Current  
O—Alternating Current  
P—Ground Circuit

#### FUNCTION:

Recharges battery after discharge from starter or other electrical load. Also supplies current for electrical accessories with tractor running.

#### MAJOR COMPONENTS:

- Battery
- Alternator
- Voltage Regulator

#### THEORY OF OPERATION:

Alternator stator (E) consists of three separate sets of windings connected in a Y configuration. Field current passes from voltage regulator (H) to rotor (G). Rotor spins inside stator windings, inducing an alternating current into the stator.

Alternating current cannot be used for charging battery or operating accessories. Rectifier diodes (F) change alternating current to direct current. Current flows

through rectifier diodes to terminal B of alternator (D) and to battery.

Voltage regulator controls ground side of rotor as a means of limiting field current flow. Increasing the duration of field current flow boosts alternator output. Decreasing the duration of field current flow reduces alternator output. Voltage regulator controls field current based on system voltage.

Regulator is a non-adjustable, integrated-circuit type located inside alternator. Voltage is regulated at 14.2—14.8 volts at 25°C (77°F), 5000 rpm and 10 amps, but varies depending on a number of factors.


Charge indicator (J) alerts operator of low or no charging system output. Under normal conditions, voltage at both sides of indicator is the same. No current flows through light; therefore, light stays off.

When no or low charging system output occurs, voltage on one side of light drops. This causes current to flow through light, thus causing it to come on.

AG,OUO1023,372 -19-09NOV99-2/2

240  
10  
13

## Lighting System Operation—Turn Signals



LVC2186

## LIGHTING SYSTEM OPERATION — TURN SIGNALS

A—Battery  
B—Fuse Link  
C—30-Amp Fuse  
D—Turn Signal Controller

E—Right Turn Indicator  
F—Right Warn/Turn Light  
G—Left Warn/Turn Light

H—Left Turn Indicator  
I—Ground  
J—Power Circuit

K—Flashing Current  
L—Ground Circuit  
M—Steady Current

## FUNCTION:

Alerts approaching traffic of operator's intent to turn.

## MAJOR COMPONENTS:

- 30-Amp Fuse
- Turn Signal Controller
- Right Warn/Turn Light
- Left Warn/Turn Light
- Right Turn Indicator

Continued on next page

AG,OUO1085,378 -19-18SEP00-1/2

- Left Turn Indicator

**THEORY OF OPERATION:**

Unswitched power from battery (A) is available at terminal 2 of turn signal controller (D). Because of this, the turn signals will operate whenever the turn signal controller is moved to the left-turn or right-turn positions regardless of position of the key switch.

When the turn signal lever is moved to the left-turn position, current flows from battery (A), through fuse link (B), circuit 002, and 30-amp fuse (C). From fuse (C), current flows through circuit 122 to terminal 2 of the turn signal controller.

A flasher unit, located inside the turn signal controller, converts the battery's steady DC current into a flashing

(or pulsing) DC current. The pulsing DC current flows out circuit 125 to left warn/turn light (G) and left turn indicator (H) (located on the instrument panel), causing these lights to flash.

At the same time, the turn signal controller supplies a steady DC current through circuit 115 to right warn/turn light (F) and right turn indicator (E) (located on the instrument panel), causing these lights to stay on steady.


Right-turn signal operation is similar to left-turn signal operation except that pulsing DC current flows through circuit 115 and steady DC current flows through circuit 125.

*NOTE: Tractors with cab have four warn/turn lights located at front and rear end of cab roof.*

AG,OUO1085,378 -19-18SEP00-2/2

240  
10  
15

## Lighting System Operation—Warning Lights



LVC2187

## LIGHTING SYSTEM OPERATION — WARNING LIGHTS

A—Battery  
B—Fuse Link  
C—30-Amp Fuse  
D—Light Switch

E—20-Amp Fuse  
F—Turn Signal Controller  
G—Right Turn Indicator  
H—Right Warn/Turn Light

I—Left Warn/Turn Light  
J—Left Turn Indicator  
K—Ground  
L—Power Circuit

M—Energizing Circuit  
N—Ground Circuit  
O—Flashing Circuit

## FUNCTION:

Alerts approaching traffic of tractor's presence.

## MAJOR COMPONENTS:

- 30-Amp Fuse
- 20-Amp Fuse
- Light Switch
- Turn Signal Controller
- Right Warn/Turn Light

Continued on next page

AG,OUO1085,379 -19-18SEP00-1/2

- Left Warn/Turn Light
- Right Turn Indicator
- Left Turn Indicator

**THEORY OF OPERATION:**

Unswitched power from battery (A) is available at light switch (D). Because of this, the warning lights will operate whenever the light switch is turned from OFF position to position 1 (WARNING), position 3 (HD1; high beam), or position 4 (HD2; low beam) regardless of position of the key switch.

When the light switch is turned to positions 1, 3, or 4, current flows from battery (A), through fuse link (B), circuit 002, 30-amp fuse (C), and circuit 122, to light

switch (D). From the light switch, current flows through circuit 102 to 20-amp fuse (E). From fuse (E), current flows through circuit 126 to terminal 1 of turn signal controller (F).


A flasher unit, located inside the turn signal controller, converts the battery's steady DC current into a flashing (or pulsing) DC current. The pulsing DC current flows out circuits 115 and 125 to both right and left warn/turn lights (H and I) and both right and left turn indicators (G and J) (located on the instrument panel), causing all these lights to flash.

*NOTE: Tractors with cab have four warn/turn lights located at front and rear of cab roof.*

AG,OUO1085,379 -19-18SEP00-2/2

240  
10  
17

## Lighting System Operation—Tail Light



LVC2188

## LIGHTING SYSTEM OPERATION — TAIL LIGHT

A—Battery  
B—Fuse Link  
C—30-Amp Fuse

D—Light Switch  
E—20-Amp Fuse

F—Tail Light  
G—Ground

H—Power Circuit  
I—Ground Circuit

## FUNCTION:

Alerts approaching traffic of tractor's presence.

## MAJOR COMPONENTS:

- 30-Amp Fuse

- 20-Amp Fuse
- Light Switch
- Tail Light

## THEORY OF OPERATION:

Continued on next page

AG,OUO1085,380 -19-18SEP00-1/2

**NOTE:** *Illustration shows tail light circuit of tractor without cab. Tractors with cab use two tail lights.*

Tractors without cab use a single tail light located on the left side of the tractor. Tractors with cab use two tail lights both mounted at rear of cab. The tail light(s) come on whenever the light switch is turned from the OFF position to position 3 (HD1; high beam), or position 4 (HD2; low beam).


When the light switch is turned to positions 3 or 4, current from battery (A) flows through circuit 002, fuse link (B), 30-amp fuse (C), and circuit 122, to light switch (D). From the light switch, current flows through circuit 103, 20-amp fuse (E), circuit 118, to tail light(s) (F) (located inside left warn/turn lamp assembly), causing the light(s) to come on.

AG,OUO1085,380 -19-18SEP00-2/2

240  
10  
19



## Lighting System Operation—Headlights and Instrument Lights



## LIGHTING SYSTEM OPERATION — HEADLIGHTS AND INSTRUMENT LIGHTS

LVC2189

LVC2189 -UN-21JUN97

Continued on next page

AG,OUO1085,381 -19-18SEP00-1/2

A—Battery  
B—Fuse Link  
C—30-Amp Fuse  
D—Light Switch  
E—Diode Pack

F—Instrument Lights  
G—Fuel Gauge  
H—Temperature Gauge  
I—High Beam Indicator  
J—20-Amp Fuse

K—20-Amp Fuse  
L—Right Headlight  
M—Left Headlight  
N—Ground  
O—Power Circuit

P—Low Beam Current  
Q—Instrument Light Current  
R—Ground Circuit  
S—High Beam Current

#### FUNCTION:

Provide low and high beam illumination for visibility at night. Also provide illumination for gauges in instrument panel.

#### MAJOR COMPONENTS:

- 30-Amp Fuse
- 20-Amp Fuses
- Light Switch
- Diode Pack
- Right Headlight
- Left Headlight
- Instrument Lights

#### THEORY OF OPERATION:

When light switch is moved to fourth position from off, current flows on circuit 002 from battery, through

30-amp fuse (C), then through switch contacts and out circuit 134. Flow continues through 20-amp fuse (K) to circuit 114 and the low beam filament of the headlight bulbs. Current also flows through one diode of diode pack (E) to instrument lights (F). Remaining diode blocks current from passing into high beam circuit.


When light switch is moved to third position from off, current passes from switch on circuit 113 and passes through 20-amp fuse (J). Current moves on circuit 119 to high beam filament of both headlight bulbs and high beam indicator (I) light.

Light switch operates instrument lights (F) in either headlight position. Depending on switch position, current will flow out of switch on circuit 134 or 113 and through its respective fuse. Flow continues through diode pack to circuit 138 and on to instrument lights. Diode pack also blocks current flow from feeding back across one headlight circuit to the other.

AG,OUO1085,381 -19-18SEP00-2/2

240  
10  
21

## Instrument Panel System Operation—Tachometer



## LVC2190 INSTRUMENT PANEL SYSTEM OPERATION — TACHOMETER

A—Battery  
B—Fuse Link  
C—30-Amp Fuse

D—Key Switch  
E—10-Amp Fuse  
F—Tachometer

G—Engine Speed Sensor  
H—Ground  
I—Power Circuit

J—Sensor Circuit  
K—Ground Circuit

## FUNCTION:

Informs operator of engine speed.

## MAJOR COMPONENTS:

- 10-Amp Fuse
- Tachometer
- Engine Speed Sensor
- Key Switch

Continued on next page

AG,OUO1085,382 -19-18SEP00-1/2

**THEORY OF OPERATION:**

Current passes through closed contacts of key switch (D) to circuit 022, then through 10-amp fuse (E) to circuit 072 and into tachometer (F).

Engine speed sensor (G) contains a permanent magnet and a set of windings. The sensor is mounted close to the gear teeth of fuel injection pump. As gear turns, its moving teeth induce a small amount of


alternating current in the sensor. Voltage leaving sensor travels through circuit 325 to tachometer and 010 to ground.

Sensor output voltage depends on engine rpm. Low rpm produces low voltage. As engine rpm increases, voltage output increases accordingly. Tachometer reads frequency of voltage signal and displays it as rpm.

AG,OUO1085,382 -19-18SEP00-2/2

240  
10  
23

## Instrument Panel System Operation—Fuel Gauge



## LVC2191 INSTRUMENT PANEL SYSTEM OPERATION — FUEL GAUGE

A—Battery  
B—Fuse Link  
C—30-Amp Fuse

D—Key Switch  
E—10-Amp Fuse  
F—Fuel Gauge

G—Fuel Level Sender  
H—Ground  
I—Power Circuit

J—Sensing Circuit  
K—Ground Circuit

## FUNCTION:

Informs operator of fuel level.

## MAJOR COMPONENTS:

- 10-Amp Fuse
- Fuel Gauge
- Fuel Gauge Sender

## THEORY OF OPERATION:

Continued on next page

AG.OUO1023,378 -19-15NOV99-1/2

Current passes through closed contacts of key switch (D) to circuit 022, then through 10-amp fuse (E) to circuit 072 and into fuel gauge (F). Sensing terminal of gauge connects to fuel level sender (G) through circuit 353.


Sender assembly consists of a movable float mounted to a variable resistor (potentiometer). Resistance of potentiometer on gauge sensing circuit controls the fuel level shown on gauge.

As float moves up or down with changes in fuel level, electrical resistance of potentiometer changes accordingly. When tank is full, resistance is low and gauge needle moves to full position. When tank is empty, resistance is high, and gauge needle moves to empty position. Potentiometer resistance between these two positions varies in direct proportion to changes in fuel level. This allows gauge to accurately display quantity of fuel in tank regardless of its level.

AG,OUO1023,378 -19-15NOV99-2/2

240  
10  
25

## Instrument Panel System Operation—Temperature Gauge



## INSTRUMENT PANEL SYSTEM OPERATION — TEMPERATURE GAUGE

LVC2192

A—Battery  
B—Fuse Link  
C—30-Amp Fuse

D—Key Switch  
E—10-Amp Fuse  
F—Temperature Gauge

G—Coolant Temperature  
Sender  
H—Ground

I—Power Circuit  
J—Sensing Circuit  
K—Ground Circuit

## FUNCTION:

Informs operator of engine coolant temperature.

## MAJOR COMPONENTS:

- 10-Amp Fuse
- Temperature Gauge
- Coolant Temperature Sender

## THEORY OF OPERATION:

Continued on next page

AG.OUO1023,379 -19-15NOV99-1/2



Current passes through closed contacts of key switch (D) to circuit 022, then through 10-amp fuse (E) to circuit 072 and into temperature gauge (F). Sensing terminal of gauge connects to coolant temperature sender (G) through circuit 359.

Temperature sender is a variable resistor that responds to changes in coolant temperature. Low coolant temperatures cause high resistance. High temperatures cause low resistance.

Current attempts to flow back to ground from gauge on circuit 359. If resistance of sender is high (low

temperatures), only a slight amount of current passes to ground. This results in little or no movement of the gauge needle. A low temperature reading results.


If resistance of sender is low (high temperatures), current flows readily through sensor back to ground. Needle movement increases and the gauge displays a reading that corresponds with the warmer temperature.

Sensor resistance between these two positions varies in proportion to changes in coolant temperature. Therefore, gauge can display accurate reading for any engine temperature.

AG.OUO1023,379 -19-15NOV99-2/2

240  
10  
27

## Instrument Panel System Operation—Hourmeter



LVC2193

**INSTRUMENT PANEL SYSTEM OPERATION — HOURMETER**

A—Battery  
B—Fuse Link  
C—30-Amp Fuse

D—Key Switch  
E—10-Amp Fuse  
F—Hourmeter

G—Alternator/Regulator  
H—Ground

I—Power Circuit  
J—Ground Circuit

**FUNCTION:**

Displays operating hours.

**MAJOR COMPONENTS:**

- 10-Amp Fuse
- Hourmeter

Continued on next page

AG,OUO1085,383 -19-18SEP00-1/2

### *Theory of Operation*


Current flows from battery (A), across closed contacts or key switch (D) and out circuit 022. Flow continues through 10-amp fuse (E) to circuit 072 and to alternator/regulator (G) hourmeter positive side.

Negative side of hourmeter (F) connects to ground through circuit 010. Hourmeter runs whenever engine is running.

AG,OUO1085,383 -19-18SEP00-2/2

240  
10  
29

## PTO Warning System Operation



## PTO WARNING SYSTEM OPERATION

LVC2194

LVC2194 -UN-21JUN97

Continued on next page

AG.OUO1023,380 -19-15NOV99-1/2

A—Battery  
B—Fuse Link  
C—30-Amp Fuse

D—Key Switch  
E—Rear PTO Switch  
F—Seat Switch

G—Horn/Timer  
H—PTO Indicator  
I—Ground

J—Power Circuit  
K—Ground Circuit

#### FUNCTION:

Alerts operator by sight and sound that PTO is engaged.

#### MAJOR COMPONENTS:

- 30-Amp Fuse
- Key Switch
- Rear PTO Switch
- Seat Switch
- Horn/Timer
- PTO Indicator Light

#### THEORY OF OPERATION:

When PTO is engaged and key switch (D) is in the RUN or START position, current travels through


30-amp fuse (C), key switch contacts, and one side of rear PTO switch (E).

PTO indicator (H) lights as current continues to flow through circuit 574, through bulb, then to ground.

The horn/timer (G) also uses the seat switch (F) for control. The switch is closed when the operator is off the seat. Current passes through circuit 574, then across contacts of the seat switch to horn/timer. Horn/timer will buzz for about 6 to 8 seconds. Each time the operator rises from seat with PTO engaged, horn/timer buzzes for another 6 to 8 seconds after a 2-second delay.

AG,OUO1023,380 -19-15NOV99-2/2

## Air Filter Restriction Indicator Operation



## AIR FILTER RESTRICTION INDICATOR OPERATION

LVC2195

A—Battery  
 B—Fuse Link  
 C—30-Amp Fuse

D—Key Switch  
 E—10-Amp Fuse  
 F—Air Filter Restriction Indicator

G—Air Filter Restriction Switch  
 H—Ground

I—Power Circuit  
 J—Ground Circuit

## FUNCTION:

Alerts operator of the need to service air filter.

## MAJOR COMPONENTS:

- Air Filter Restriction Switch
- Restriction Indicator Light
- 30-Amp Fuse
- 10-Amp Fuse

Continued on next page

AG.OUO1023,381 -19-15NOV99-1/2

#### THEORY OF OPERATION:

Voltage is applied to one side of air filter restriction indicator (F) at all times when key switch is on. Supply path from battery includes circuit 002, 30-amp fuse (C), key switch (D), circuit 022, 10-amp fuse (E), and circuit 072.

Air filter restriction switch (G) contains a set of normally-open, vacuum-activated contacts. One


contact connects to other side of restriction indicator light. Other contact connects with ground. During normal operation, contacts remain open and indicator light stays off. When air filter becomes restricted, vacuum builds in air filter housing. This causes contacts to close and current flows through light.

AG,OUO1023,381 -19-15NOV99-2/2

240  
10  
33



## Rear Work Light Operation—Without Cab



LVC2196

### REAR WORK LIGHT OPERATION TRACTORS WITHOUT CAB

A—Battery  
B—Fuse Link  
C—30-Amp Fuse

D—Light Switch  
E—20-Amp Fuse

F—Rear Work Light  
G—Ground

H—Power Circuit  
I—Ground Circuit

## FUNCTION:

Lights work area at rear of tractor.

## MAJOR COMPONENTS:

- 30-Amp Fuse
- 20-Amp Fuse
- Light Switch
- Rear Work Light

## THEORY OF OPERATION:


When light switch (D) in the second position from off, current flows from battery (A) through circuit 002, then through 30-amp fuse (C) and circuit 122 to light switch. Current passes across switch contacts, out circuit 137, through 20-amp fuse (E) to circuit 147 and on to rear work light (F).

Current also flows to high beam headlights with light switch in the same position. Refer to LIGHTING SYSTEM OPERATION—HEADLIGHTS AND INSTRUMENT LIGHTS earlier in this group.

AG,OUO1085,384 -19-18SEP00-1/1

LVC2196 -UN-27JUN02

## Optional Horn Operation



LVC2197

## OPTIONAL HORN OPERATION

A—Battery  
B—Fuse Link

C—30-Amp Fuse  
D—Horn Switch

E—Horn  
F—Ground

G—Power Circuit  
H—Ground Circuit

## FUNCTION:

Operates as a warning device to traffic and bystanders.

## MAJOR COMPONENTS:

- 30-Amp Fuse
- Horn
- Horn Switch

## THEORY OF OPERATION:


When operator pushes horn switch (D), current flows from battery (A) on circuit 002 to 30-amp fuse (C). Flow continues on circuit 122 to horn switch and to horn (E). Horn mounting brackets complete the horn circuit by providing a connection with chassis ground. Since horn circuit connects directly to battery, horns will work regardless of key switch position.

AG,OUO1023,382 -19-15NOV99-1/1

240  
10  
35

LVC2197 -JUN-21JUN97

## Accessory Relay and Trailer Connector Operation



LVC2198

LVC2198 -UN-16DEC97

Continued on next page

AG,OUO1085,385 -19-18SEP00-1/2

A—Battery  
B—Fuse Link  
C—30-Amp Fuse

D—Key Switch  
E—30-Amp Fuse  
F—Accessory Relay

G—Trailer Connector  
H—Ground

I—Power Circuit  
J—Ground Circuit

#### FUNCTION:

Provides light and accessory power connections for trailer.

#### MAJOR COMPONENTS:

- 30-Amp Fuses
- Key Switch
- Accessory Relay
- 7-Pin Trailer Connector

#### THEORY OF OPERATION:

When key switch (D) is in ACCESSORY or RUN position, current passes through contacts of key switch and through circuit 212 to accessory relay (F). Current passing through windings of accessory relay creates a magnetic field which closes the relay contacts.

With relay contacts closed, current passes through 30-amp fuse (E), through accessory relay, and through circuit 222 to accessory terminals 4 and 7 of trailer connector (G) which can be used for auxiliary equipment.

Remainder of trailer connector terminals are connected as follows:

No. 1—Ground, circuit 010.

No. 2—Rear flood light, circuit 147.

No. 3— Left turn, circuit 125.


No. 5—Right turn, circuit 115.

No. 6—Tail light, circuit 118.

AG,OUO1085,385 -19-18SEP00-2/2

240  
10  
37

## Flood Light Operation—With Cab



LVC2199

## FLOOD LIGHT OPERATION — CAB TRACTORS ONLY

Continued on next page

AG,OUO1085,386 -19-19SEP00-1/2

A—Battery  
B—Fuse Link  
C—30-Amp Fuse  
D—Light Switch

E—20-Amp Fuse  
F—30-Amp Fuse  
G—Flood Light Relay  
H—Left Front Flood Light

I—Right Front Flood Light  
J—Left Rear Flood Light  
K—Right Rear Flood Light

L—Ground  
M—Power Circuit  
N—Ground Circuit

#### FUNCTION:

Illuminates work area at front and rear of tractor.

#### MAJOR COMPONENTS:

- 30-Amp Fuses
- 20-Amp Fuse
- Light Switch
- Flood Light Relay

#### THEORY OF OPERATION:


With light switch (D) in second position from off, current flows from battery (A) through circuit 002 and fuse link (B), then through 30-amp fuse (C) and circuit 122 to light switch. Current passes across switch contacts and through circuit 137, then through 20-amp fuse (E) and circuit 147 to flood light relay (G).

Current passing through flood light relay windings creates a magnetic field which closes the relay contacts. This connects circuit 272 to circuit 167 providing a current path to the front and rear flood lights (H—K).

AG,OUO1085,386 -19-19SEP00-2/2

240  
10  
39

## Blower Motor Operation—With Cab



## BLOWER MOTOR OPERATION — CAB TRACTORS ONLY

LVC1496

LVC1496 -19-20APR01

Continued on next page

AG,OUO1085,387 -19-19SEP00-1/2



A—Battery  
B—Fuse Link  
C—30-Amp Fuse  
D—Key Switch  
E—30-Amp Fuse  
F—30-Amp Fuse

G—HVAC Relay  
H—Blower Switch  
I—Blower Motor Resistors  
J—Blower Motor Relay #1  
K—Blower Motor Relay #2

L—Blower Motor  
M—Blower Motor  
N—Ground  
O—Power Circuit  
P—Low Speed Circuit

Q—High Speed Circuit  
R—Ground Circuit  
S—Medium Speed Circuit  
T—Purge Speed Circuit  
U—Blower Motor Circuit

#### FUNCTION:

The blower motors are located in the evaporator/heater core housing mounted in the cab roof. They force cooled or heated air from the evaporator/heater core housing through the vents in the cab headliner to heat or cool the cab.

#### MAJOR COMPONENTS:

- Key Switch
- HVAC Relay
- Blower Switch
- Blower Motor Resistors
- Blower Relays
- Blower Motors

#### THEORY OF OPERATION:

When key switch (D) is in RUN position, current flows from battery (A) through fuse link (B), 30-amp fuse (C), and across key switch contacts to circuit 972. Current then flows through circuit 972 to energize the coil windings of HVAC relay (G).

When HVAC relay is energized, the relay blade contacts terminal 87 and current from battery flows through circuit 002, through 30-amp fuse (E) and circuit 282 to terminal B of blower switch (H).

The blower switch provides four operating speeds for the blower motors: low, medium, high, and purge.


When low, medium, or high speeds are selected, current flows through circuit 227, 221, or 225 to blower motor resistors (I); through circuit 216 to terminal 87A of the blower motor relays (J and K); and through the relays to the blower motors (L and M).

The speed of the blower motors is affected by the number of resistors in the circuit. Current from circuit 227 flows through four resistors; the current to the blower motors is low and the blower speed is low. Current from circuit 225 flows through only two resistors, thus the current drop is less and the blower speed is higher.

When PURGE speed is selected, current flows through circuit 223 and energizes the coil windings of the blower motor relays. When the relays are energized, the relay blade shifts to terminal 87 and current flows from circuits 042 and 052 to the blower motors. The current is not affected by the blower motor resistor, thus the blower motors turn at their highest speed.

30-amp fuses (E and F) protect the blower motor circuits from overload.

## A/C Compressor Operation—Cab Only



LVC1497

## A/C COMPRESSOR — CAB TRACTORS ONLY

LVC1497 -19-27JUN02

Continued on next page

AG,OUO1085,388 -19-19SEP00-1/2

A—Battery  
B—Fuse Link  
C—30-Amp Fuse  
D—Key Switch  
E—30-Amp Fuse

F—HVAC Relay  
G—Blower Switch  
H—A/C Temperature Control  
I—10-Amp Fuse

J—A/C Low Pressure Switch  
K—A/C High Pressure Switch  
L—A/C Compressor Clutch  
Coil

M—Ground  
N—Power Circuit  
O—Ground Circuit  
P—Compressor Circuit

#### FUNCTION:

The A/C compressor circuit controls the air conditioning function for the operator's station.

#### MAJOR COMPONENTS:

- Key Switch
- HVAC Relay
- Blower Switch
- A/C Temperature Control
- A/C Low Pressure Switch
- A/C High Pressure Switch
- A/C Compressor Clutch

#### THEORY OF OPERATION:

The air conditioning compressor clutch (L) is controlled by the blower switch (G), the A/C temperature control (H) and the low and high pressure switches (J and K).

When key switch (D) is in RUN position, current flows from battery (A) through fuse link (B), 30-amp fuse (C) and across key switch contacts to circuit 972. Current then flows through circuit 972 to energize the coil windings of HVAC relay (F).

When HVAC relay is energized, the relay blade contacts terminal 87 and current from battery flows through circuit 002 through 30-amp fuse (E), through circuit 042 and through HVAC relay and circuit 282 to terminal B of blower switch (G).

When the blower switch is turned to any of the four operating positions (low, medium, high, or purge), current flows through circuit 227 to the A/C temperature control.

The A/C temperature control is a rotary switch with a gas-filled temperature sensing tube that is inserted into the evaporator core. The switch end of the sensing tube uses a diaphragm switch wired to the compressor clutch circuit. The A/C temperature control also has a mechanical on/off feature; the switch is open when fully turned counterclockwise.



When the A/C temperature control switch is turned clockwise past the OFF position, the gas in the sensing tube either opens or closes the diaphragm switch (depending on the temperature in the evaporator core and the setting of the temperature control). This either completes or interrupts the circuit through the switch. When the switch is closed, current flows through 10-amp fuse (I) and the low and high pressure switches to the compressor clutch coil.

The A/C compressor drive shaft is pulley-driven by the engine and is turning whenever the engine is running. When the compressor clutch coil is energized, the compressor electro-magnetic clutch engages and high pressure gas is sent to the condensor.

When the temperature in the evaporator core reaches the temperature selected by the A/C temperature control, the diaphragm switch opens and current flow to the compressor clutch coil is interrupted and the compressor clutch disengages.

The high and low pressure switches are located in the condensor line. If the pressure in the condensor line drops below the setting of the low pressure switch or rises above the setting of the high pressure switch, the switch opens and current flow to the compressor clutch coil is interrupted.

## Front Wiper/Washer Operation—Cab Only



LVC1498

## FRONT WIPER/WASHER OPERATION — CAB TRACTORS ONLY

A—Battery  
B—Fuse Link  
C—30-Amp Fuse  
D—Key Switch  
E—30-Amp Fuse

F—Accessory Relay  
G—20-Amp Fuse  
H—Front Wiper Switch  
I—Front Wiper Motor

J—Front Washer Pump  
K—Ground  
L—Power Circuit  
M—Ground Circuit

N—Park Circuit  
O—Low Speed Circuit  
P—High Speed Circuit  
Q—Washer Circuit

## FUNCTION:

Controls operation of front windshield wiper and washer pump.

## MAJOR COMPONENTS:

- Accessory Relay
- Front Wiper Switch

Continued on next page

AG,OUO1085,389 -19-19SEP00-1/2

- Front Wiper Motor
- Front Washer Pump
- Key Switch

**THEORY OF OPERATION:**

Current from the battery (A) flows through fuse link (B), 30-amp fuse (C), and circuit 012 to the key switch (D). When key switch is in ACCESSORY or RUN position current flows through circuit 212 and energized accessory relay (F). When the relay is energized current flows from circuit 002, through 30-amp fuse (E), accessory relay (F), through circuit 222 to 20-amp fuse (G). From 20-amp fuse (G) current flows through

circuit 202 to front wiper switch position, current flows through circuit 234 to the front wiper motor (I) and the wiper blade is reset to its “park” position.


When the front wiper switch is rotated to the first detent, current flows through circuit 229 and the windshield wiper runs at low speed. When the front wiper switch is rotated to the second detent, current flows through circuit 224 and the windshield wiper runs at high speed.

When the front wiper switch knob is pressed, current flows through circuit 238 and activates the front washer pump (J).

AG,OUO1085,389 -19-19SEP00-2/2

240  
10  
45

## Rear Wiper/Washer Operation—Cab Only



LVC1499

## REAR WIPER/WASHER OPERATION — CAB TRACTORS ONLY

Rear Wiper/Washer Circuit Schematic

A—Battery  
B—Fuse Link  
C—30-Amp Fuse  
D—Key Switch

E—30-Amp Fuse  
F—Accessory Relay  
G—20-Amp Fuse  
H—Rear Wiper Switch

I—Rear Wiper Motor  
J—Rear Washer Pump  
K—Ground  
L—Power Circuit

M—Ground Circuit  
N—Wiper Circuit  
O—Washer Circuit

FUNCTION:

Continued on next page

AG,OUO1085,390 -19-19SEP00-1/2

Controls operation of rear windshield wiper and washer pump.

**MAJOR COMPONENTS:**

- Accessory Relay
- Key Switch
- Rear Wiper Switch
- Rear Wiper Motor
- Rear Washer Pump

**THEORY OF OPERATION:**

Current from the battery (A) flows through fuse link (B), 30-amp fuse (C), and circuit 012 to the key switch (D).

When key switch is in ACCESSORY or RUN position current flows through circuit 212 and energizes accessory relay (F). When the relay is energized current flows from circuit 002, through 30-amp fuse (E), accessory relay (F), and circuit 222 to 20-amp fuse (G). From 20-amp fuse (G) current flows through circuit 202 to rear wiper switch (H). When the rear wiper switch is pressed to the first detent, current flows through circuit 224 and activates the rear wiper motor (I).


When the rear wiper switch is pressed in the WASHER position, current flows through circuit 239 and activates rear washer pump (J).

AG,OUO1085,390 -19-19SEP00-2/2

240  
10  
47



## Dome Light Operation—Cab Only



### DOME LIGHT OPERATION — CAB TRACTORS ONLY

LVC1600

LVC1600 -19-21MAY96

A—Battery  
B—Fuse Link  
C—30-Amp Fuse

D—Dome Light  
E—Dome Light Switch  
F—Left Door Switch

G—Right Door Switch  
H—Ground

I—Power Circuit  
J—Ground Circuit

**FUNCTION:**

Dome light illuminates interior of cab.

**MAJOR COMPONENTS:**

- Dome Light Switch
- Left and Right Door Switches
- Dome Light

**THEORY OF OPERATION:**

Current from battery (A) flows on circuit 002 through fuse link (B), 30-amp fuse (C) and circuit 262 to dome light (D).

Dome light switches (F and G) are normally-closed switches. Closing the doors opens the switches. When dome light switch (E) is on the OFF position and both doors are closed, current flowing through circuit 255 to the left and right door switches is interrupted and the dome light is off. If either door is open, the switch closes and the circuit to ground is completed. The dome light will illuminate.

When the dome light switch is in the ON position, current flows through to ground and the dome light illuminates regardless of door position.

## Diagnostic Information

The diagnostic information in this group is used to test components related to a specific problem or system. Select a symptom or system from the list and follow the test procedures under that heading. The symptom or system headings are:

- Starting System—Normal Operation
- Starting System—Bypass Attempt
- Manifold Heater
  
- Charging System
- Lighting System—Turn Signals Without Cab)
- Lighting System—Turn Signals (With Cab)
- Lighting System—Warning Lights (All Tractors)
- Lighting System—Rear Work Light (Without Cab)
- Lighting System—Flood Lights (With Cab)
- Lighting System—Tail Light (Without Cab)
- Lighting System—Tail Light (With Cab)
- Lighting System—Headlights and Instrument Lights
- Dome Light (With Cab)
- Instrument Panel System—Tachometer
- Instrument Panel System—Fuel Gauge
- Instrument Panel System—Temperature Gauge
- Instrument Panel System—Hourmeter
- Instrument Panel System—Oil Pressure
- PTO Warning System
- Air Filter Restriction
- Optional Dual Horn
- Accessory Relay and Trailer Connector

- Blower Motor (With Cab)
- A/C Compressor Clutch Coil (With Cab)
- Front Wiper/Washer (With Cab)
- Rear Wiper/Washer (With Cab)

The diagnostic procedure lists:

- Test conditions
- Test sequence
- Test location
- Normal reading
- Check or test to perform if reading is not normal

When performing the test or check, be sure to set your machine up to the test conditions listed and follow the sequence carefully. The middle “Normal” column gives the reading or condition that should be obtained when performing the test or check. If the results of the test or check are not normal, perform the test, check, or adjustment listed in the third “If Not Normal” column to repair the malfunction. The detailed tests or adjustments referred to in the “If Not Normal” column are located at the end of this group.

The system diagram that accompanies each test procedure is drawn to resemble machine components. The key number on the art matches the number in the “Test Location” column and the arrow points to the exact test point.

AG\_OUO1085.392 -19-19SEP00-1/1

240  
15  
1

## Wire Color Chart

WIRE COLOR ABBREVIATION	WIRE COLOR
Blu	Blue
Blu/Blk	Blue/Black
Blu/Red	Blue/Red
Blk	Black
Blk/Wht	Black/White
Blk/Yel	Black/Yellow
Brn	Brown
Brn/Wht	Brown/White
Brn/Yel	Brown/Yellow
Clr	Clear
Dk Blu	Dark Blue
Dk Brn/Lt Grn	Dark Brown/Light Green
Dk Brn/Red	Dark Brown/Red
Dk Brn/Yel	Dark Brown/Yellow
Dk Grn	Dark Green
Grn	Green
Grn/Wht	Green/White
Gry	Gray
Lt Blu	Light Blue
Lt Grn	Light Green
Org	Orange
Org/Wht	Orange/White
Pnk	Pink
Pur	Purple
Pur/Blk	Purple/Black
Pur/Wht	Purple/White
Red	Red
Red/Blk	Red/Black
Red/Blu	Red/Blue
Red/Wht	Red/White
Red/Yel	Red/Yellow
Tan	Tan
Wht	White
Wht/Blk	White/Black
Wht/Blu	White/Blue
Wht/Red	White/Red
Yel	Yellow
Yel/Blk	Yellow/Black

Continued on next page

MX,24010HE,2 -19-27SEP91-1/2


*Diagnosis, Test and Adjust*

WIRE COLOR ABBREVIATION	WIRE COLOR
Yel/Red	Yellow/Red
Yel/Wht	Yellow/White

MX,24010HE,2 -19-27SEP91-2/2

240  
15  
3

## START SYSTEM TEST POINTS – NORMAL OPERATION



LV2227 -UN-16DEC97

AG,OUO1085,394 -19-19SEP00-1/4

**CONDITIONS:**

- Transmission in P, park position.
- PTO disengaged.
- Key switch in RUN position.
- Meter positive lead (red) on numbered test point.

- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Starter battery terminal.	Battery voltage.	Check for corroded connections or break in wire between battery and starter.
3. Left post of fuse link junction block.	Battery voltage.	Check for corroded terminal or break in wire between starter and fuse link.
4. Right post of fuse link junction block.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
5. Top terminal of fuse, F6.	Battery voltage.	Check for corroded connections or break in wire or splice between fuse link and fuse, F6.
6. Bottom terminal B of fuse, F6.	Battery voltage.	Check for failed fuse, F6. If fuse is good, check for corroded or loose terminals.
7. BAT terminal of key switch.	Battery voltage.	Check for corroded connections or break in wire between fuse block and key switch.
8. IGN terminal of key switch.	Battery voltage.	Check that key switch is in RUN position. If switch is in RUN, switch is bad. Replace.
9. Right terminal of fuse, F2.	Battery voltage.	Check for corroded connections or break in splice or wire between key switch and fuse F2.
10. Left terminal of fuse, F2.	Battery voltage.	Check for failed fuse, F2. If fuse is good, check for corroded or loose terminals.
11. Terminal 30 of fuel shut-off relay.	Battery voltage.	Check for corroded connections or break in wire between fuse block and fuel shut-off relay.
12. Terminal 87A of fuel shut-off relay.	Battery voltage.	Test fuel shut-off relay. If relay is good, check for corroded or loose terminals.
13. Terminal A of male pin side of 10-pin connector.	Battery voltage.	Check for corroded connections or break in wire between fuel shut-off relay and 10-pin connector.
14. Terminal A of female socket side of 10-pin connector.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
15. Fuel shut-off solenoid terminal.	Battery voltage.	Check for corroded connections or break in wire between 10-pin connector and fuel shut-off solenoid.

**CONDITIONS:**

- White wire disconnected from starter solenoid terminal S.

- Hold key switch in START position.

Continued on next page

AG,OUO1085,394 –19–19SEP00–2/4

Test Location	Normal	If Not Normal
16. Terminal ST of key switch.	Battery voltage.	Test key switch.
17. Terminal D of rear PTO switch.	Battery voltage.	Check for corroded connections or break in wire between key switch and rear PTO switch.
18. Terminal E of rear PTO switch.	Battery voltage.	Check switch position. If switch is positioned properly, test switch and replace if necessary.
19. Terminal A of neutral start switch.	Battery voltage.	Check for corroded connections or break in wire between rear PTO switch and neutral start switch.
20. Terminal B of neutral start switch.	Battery voltage.	Check for corroded or loose connections. Test neutral start switch, replace if necessary.
21. Terminal 86 of start relay.	Battery voltage.	Check for corroded connections or break in wire between neutral start switch and start relay.
22. Terminal 85 of start relay.	Less than 0.2 volt.	Check continuity to ground of black wire Nos. 010G and 010K. If black wires are good to ground, test start relay.
23. Terminal 30 of start relay.	Battery voltage.	Check for corroded connections or break in splice or wire between start relay and starter.
24. Terminal 87 of start relay.	Battery voltage.	Check for corroded or loose terminals. Test start relay.
25. Terminal 86 of bypass start relay.	Battery voltage.	Check for corroded connections or break in splice or wire between start relay and bypass start relay.
26. Terminal 85 of bypass start relay.	Less than 0.2 volt.	Check continuity to ground of black wire Nos. 010J and 010K. If black wires are good to ground, test bypass start relay.
27. Terminal 30 of bypass start relay.	Battery voltage.	Check for corroded connections or break in splice or wire between start relay and bypass start relay.
28. Terminal E of male pin side of 10-pin connector.	Battery voltage.	Check for corroded connections or break in splice or wire between start relay and 10-pin connector.
29. Terminal E of female socket side of 10-pin connector.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace coupler.
30. Wire disconnected from starter terminal S.	Battery voltage.	Check for corroded connections or break in wire between 10-pin connector and starter end of wire.

**CONDITIONS:**

- Connect white wire to starter solenoid terminal S.
- Red wire disconnected from fuel shut-off solenoid at injection pump.

- Hold key switch in START position.

Continued on next page

AG,OUO1085,394 -19-19SEP00-3/4

*Diagnosis, Test and Adjust*


Test Location	Normal	If Not Normal
31. Starter solenoid.	Engages and remains engaged.	Replace solenoid.
32. Test voltage drop between test points 1 and 2.	Less than 0.5 volt.	Check battery-to-starter cable and connections.
33. Test starter amp draw/rpm.	Less than 275 amps at 240 rpm.	Check that engine is not locked up.
34. Remove starter and perform no-load amp/rpm test. (See this group.)	190 amp maximum and 3600 rpm minimum.	Replace starter.

AG,OUO1085,394 -19-19SEP00-4/4

240  
15  
7



# Starting System Test Points—Bypass Attempt



## STARTING SYSTEM TEST POINTS – BYPASS ATTEMPT

LV2228

LV2228 –UN–16DEC97

Continued on next page

AG,OUO1085,395 –19–19SEP00–1/3

**CONDITIONS:**

- Transmission in P, park position.
- PTO disengaged.
- Key switch in RUN position.
- Meter positive lead (red) on numbered test point.

- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical test and adjustments in this section and group.

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Starter battery terminal.	Battery voltage.	Check for corroded connections or break in wire between battery and starter.
3. Left post of fuse link junction block.	Battery voltage.	Check for corroded terminal or break in wire between starter and fuse link.
4. Right post of fuse link junction block.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
5. Top terminal of fuse, F6.	Battery voltage.	Check for corroded connections or break in wire or splice between fuse link junction block and 30-amp fuse, F6.
6. Bottom terminal of fuse, F6.	Battery voltage.	Check for failed fuse, F6. If fuse is good, check for corroded or loose terminals.
7. BAT terminal of key switch.	Battery voltage.	Check for corroded connections or break in wire between fuse block and key switch.
8. IGN terminal of key switch.	Battery voltage.	Check that key switch is in RUN position. If switch is in RUN, switch is bad. Replace.
9. Right terminal of fuse, F2.	Battery voltage.	Check for corroded connections or break in splice or wire between key switch and fuse, F2.
10. Left terminal of fuse, F2.	Battery voltage.	Check for failed fuse, F2. If fuse is good, check for corroded or loose terminals.
11. Terminal 30 of fuel shut-off relay.	Battery voltage.	Check for corroded connections or break in wire between middle fuse block and fuel shut-off relay.

**CONDITIONS:**

- Connect jumper wire (A) between starter solenoid terminals S and M.

Continued on next page

AG,OUO1085,395 –19–19SEP00–2/3

**IMPORTANT: Operate starter in 20-second intervals. Allow starter to cool**

**between intervals to prevent starter damage.**

Test Location	Normal	If Not Normal
12. Terminal S of starter solenoid.	Battery voltage.	Poor connection or bad jumper wire.
13. Terminal E of female socket side of 10-pin connector.	Battery voltage.	Check for corroded connections or break in wire between starter solenoid and 10-pin connector.
14. Terminal E of male pin side of 10-pin connector.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
15. Terminal 30 of bypass start relay.	Battery voltage.	Check for corroded connections or break in splice or wire between 10-pin connector and bypass relay.
16. Terminal 87A of bypass start relay.	Battery voltage.	Test bypass start relay. If relay is good, check for corroded or loose terminals.
17. Terminal 4 of diode pack.	Battery voltage.	Check for corroded connections or break in wire between bypass start relay and diode pack.
18. Terminal 5 of diode pack.	Battery voltage.	Check for corroded or loose terminals. Test diode pack.
19. Terminal 87 of fuel shut-off relay.	Battery voltage.	Check for corroded connections or break in splice or wire between diode pack and fuel shut-off relay.
20. Terminal 86 of fuel shut-off relay.	Battery voltage.	Check for corroded connections or break in splice or wire between diode pack and fuel shut-off relay.
21. Terminal 85 of fuel shut-off relay.	Less than 0.2 volt.	Check continuity to ground of black wire Nos. 010H and 010K. If black wires are good to ground, test fuel shut-off relay.

AG,OUO1085,395 -19-19SEP00-3/3



## CONDITIONS:

- Transmission in P, park position.
- PTO disengaged.
- Key switch in RUN position.
- Meter positive lead (red) on numbered test point.
- Meter negative lead (black) on battery negative (–) post.

- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

*NOTE: Test points will give same results when key switch is in START position.*

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Starter battery terminal.	Battery voltage.	Check for corroded connections or break in wire between battery and starter.
3. Left post of fuse link junction block.	Battery voltage.	Check for corroded terminal or break in wire between starter and fuse link junction box.
4. Right post of fuse link junction block.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
5. B terminal of alternator.	Battery voltage.	Check for corroded connections or break in wire between starter and alternator.
6. Terminal 30 of manifold heater relay.	Battery voltage.	Check for corroded connections or break in wire between alternator and manifold heater relay.
7. Top terminal of fuse, F6.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse link junction box and 30-amp fuse, F6.
8. Bottom terminal of fuse, F6.	Battery voltage.	Check for failed fuse, F6. If fuse is good, check for corroded or loose terminals.
9. BAT terminal of key switch.	Battery voltage.	Check for corroded connections or break in wire between fuse block and key switch.

## CONDITIONS:

- Key switch pushed in.

Continued on next page


AG,OUO1085,396 –19–19SEP00–2/3

Test Location	Normal	If Not Normal
10. AID terminal of key switch.	Battery voltage.	Check that key switch is in the RUN or START position and pushed in. If switch is in RUN or START and pushed in, switch is bad. Replace.
11. Terminal D of female socket side of 10-pin connector.	Battery voltage.	Check for corroded connections or break in wire between key switch and 10-pin connector.
12. Terminal D of male pin side of 10-pin connector.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace coupler.
13. Terminal 86 of manifold heater relay.	Battery voltage.	Check for corroded connections or break in wire between 10-pin coupler and manifold heater relay.
14. Terminal 85 of manifold heater relay.	Less than 0.2 volts.	Check continuity to ground of black wire Nos. 010D and 010E. If black wires are good to ground, test manifold heater relay.
15. Terminal 87 of manifold heater relay.	Battery voltage.	Check for corroded or loose terminals. Test manifold heater relay.
16. Manifold heater terminal.	Battery voltage.	Check for corroded connections or break in wire between heater relay and heater.

AG,OUO1085,396 -19-19SEP00-3/3

240  
15  
13

# Charging System Test Points



CHARGING SYSTEM TEST POINTS

LV2230

LV2230 -UN-16DEC97

Continued on next page

AG,OUO1085,397 -19-19SEP00-1/4

CONDITIONS:

- Transmission in P, park position.
- PTO disengaged.
- Key switch in RUN position.
- Meter positive lead (red) on numbered test point.
- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

Continued on next page

AG,OUO1085,397 –19–19SEP00–2/4

240  
15  
15



Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Starter battery terminal.	Battery voltage.	Check for corroded connections or break in wire between battery and starter.
3. Left post of fuse link junction block.	Battery voltage.	Check for corroded terminal or break in wire between starter and fuse link junction block.
4. Right post of fuse link junction block.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
5. Top terminal of fuse, F6.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse link junction block and 30-amp fuse, F6.
6. Bottom terminal of fuse, F6.	Battery voltage.	Check for failed fuse, F6. If fuse is good, check for corroded or loose terminals.
7. BAT terminal of key switch.	Battery voltage.	Check for corroded connections or break in wire between fuse block and key switch.
8. IGN terminal of key switch.	Battery voltage.	Check that key switch is in the RUN position. If key switch is in RUN, switch is bad. Replace.
9. Right terminal of fuse, F1.	Battery voltage.	Check for corroded connections or break in splice or wire between key switch and fuse, F1.
10. Left terminal of fuse, F1.	Battery voltage.	Check for failed fuse, F1. If fuse is good, check for corroded or loose terminals.
11. Terminal J of male pin side of 10-pin connector.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
12. Terminal J of female socket side of 10-pin connector.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
13. Upper terminal of alternator connector.	Battery voltage.	Check for corroded connections or break in wire between 10-pin connector and alternator.
14. Alternator case.	Less than 0.2 volt.	Check alternator mounts for good ground contact to engine.
15. Terminal A of female terminal side of instrument panel connector.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and instrument panel connector.
16. Top terminal of charge indicator bulb.	Battery voltage.	Check for corroded bulb socket or circuit board connections.
17. Green/blue wire terminal of charge indicator bulb.	Less than 0.2 volt.	Check or replace bulb. Check indicator circuit from alternator using test points 17—21.
18. Terminal A of instrument panel connector.	Less than 0.2 volt.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.

Continued on next page

AG,OUO1085,397 -19-19SEP00-3/4

Test Location	Normal	If Not Normal
19. Terminal A of male pin side of 2-pin connector.	Less than 0.2 volt.	Check for corroded connections or break in splice or wire between instrument panel connector and 2-pin connector.
20. Terminal A of female socket side of 2-pin connector.	Less than 0.2 volt.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
21. Lower terminal of alternator connector.	Less than 0.2 volt.	Check for corroded connections or break in wire between 2-pin connector and alternator connector.
22. Output terminal of alternator.	Battery voltage.	Check for corroded connections or break in cable between starter and alternator.

**CONDITIONS:**


- Start engine and operate at fast idle.

Test Location	Normal	If Not Normal
23. Output terminal of alternator.	14.2—14.8 volts.	Check belt tension. Test alternator.

AG,OUO1085,397 -19-19SEP00-4/4

240  
15  
17

## LIGHTING SYSTEM TEST POINTS – TURN SIGNALS



LV2231 -UN-26NOV97

AG,OUO1085,398 -19-20SEP00-1/3

CONDITIONS:

- Key switch off.
- Transmission in P, park position.
- Meter positive lead (red) on the numbered test point.

- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Starter battery terminal.	Battery voltage.	Check for corroded connections or break in wire between battery and starter.
3. Left post of fuse link junction block.	Battery voltage.	Check for corroded terminal or break in wire between starter and fuse link junction block.
4. Right post of fuse link junction block.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
5. Top terminal of fuse, F6.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse link junction block and fuse, F6.
6. Bottom terminal of fuse, F7.	Battery voltage.	Check for failed fuse, F7. If fuse is good, check for corroded or loose terminals.
7. Terminal 2 of turn signal controller.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and turn signal controller.

CONDITIONS:

- Turn signal controller moved to left turn position.

Test Location	Normal	If Not Normal
8. Terminal 3 of turn signal connector.	Battery voltage (pulsing).	Replace turn signal controller.
9. Terminal D of instrument connector.	Battery voltage (pulsing).	Check for corroded connections or break in splice or wire between turn signal controller and instrument panel connector.
10. Top terminal of left turn indicator socket.	Battery voltage (pulsing).	Check for corroded connections between instrument panel circuit board and left turn indicator socket.
11. Bottom terminal of left turn indicator socket.	Less than 0.2 volt.	Check or replace bulb. Check ground connections of black wire, circuit No. 010, from turn indicator socket through instrument panel to ground connection on center control console.
12. Male end of bullet connector for green wire of left turn light.	Battery voltage (pulsing).	Check for corroded connections or break in splice or wire between turn signal controller and bullet connector.
13. Female end of bullet connector for green wire of left turn light.	Battery voltage (pulsing).	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
14. Left turn light lens mounting screw.	Less than 0.2 volt.	Check or replace bulb. Check for good ground from base of turn light to ROPS through the mounting bolts.

Continued on next page

AG,OUO1085,398 –19–20SEP00–2/3

CONDITIONS:

- Remove left rear lens and turn signal bulb.

Test Location	Normal	If Not Normal
15. Center terminal of left turn bulb socket.	Battery voltage (pulsing).	Check for corroded connections or break in wire between bullet connector and left turn signal.
16. Terminal 4 of turn signal controller.	Battery voltage.	Replace turn signal controller.
17. Terminal D of female terminal side of instrument panel controller.	Battery voltage.	Check for corroded connections or break in splice or wire between turn signal controller and instrument panel connector.
18. Top terminal of right turn indicator socket.	Battery voltage.	Check for corroded connections between instrument panel circuit board and right turn indicator socket.
19. Bottom terminal of right turn indicator socket.	Less than 0.2 volt.	Check or replace bulb. Check ground connections of black wire circuit No. 010, from turn indicator socket through instrument panel connector to ground connection on center control console.
20. Male end of bullet connector of right turn light.	Battery voltage.	Check for corroded connections or break in splice or wire between turn signal controller and bullet connector.
21. Female end of bullet connector of right turn light.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
22. Right turn lens mounting screw.	Less than 0.2 volt.	Check or replace bulb. Check for good ground from base of turn light to ROPS, through the mounting bolts.

CONDITIONS:


- Remove right lens and turn signal bulb.

Test Location	Normal	If Not Normal
23. Center terminal of right turn bulb socket.	Battery voltage.	Check for corroded connections or break in wire between bullet connector and left turn socket.

**NOTE:** To check right turn circuit, move turn signal controller to right turn position, and repeat test

locations 8 through 23. Pulsing voltage will be in the right circuit, No. 115.

# Lighting System Test Points—Turn Signals (Tractors With Cab)



**LIGHTING SYSTEM TEST POINTS – TURN SIGNALS (TRACTORS WITH CAB)**

LV2226

LV2226 –UN-26NOV97

Continued on next page

AG,OUO1085,399 –19-20SEP00-1/5

CONDITIONS:

- Key switch off.
- Transmission in P, park position.
- Meter positive lead (red) on the numbered test point.

- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Left post of fuse link junction block.	Battery voltage.	Check for corroded terminal or break in wire between battery and fuse link junction block.
3. Right post of fuse link junction block.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
4. Top terminal of fuse, F6.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse link junction block and fuse, F6.
5. Bottom terminal of fuse, F7.	Battery voltage.	Check for failed fuse, F7. If fuse is good, check for corroded or loose terminals.
6. Terminal 2 of turn signal controller.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and turn signal controller.

CONDITIONS:

- Turn signal controller moved to left turn position.

Continued on next page

AG,OUO1085,399 –19–20SEP00–2/5

Test Location	Normal	If Not Normal
7. Terminal 3 of turn signal connector.	Battery voltage (pulsing).	Replace turn signal controller.
8. Terminal E of female terminal side of instrument panel connector.	Battery voltage (pulsing).	Check for corroded connections or break in splice or wire between turn signal controller and instrument panel connector.
9. Top terminal of left turn indicator socket.	Battery voltage (pulsing).	Check for corroded connections between instrument panel circuit board and left turn indicator socket.
10. Bottom terminal of left turn indicator socket.	Less than 0.2 volt.	Check or replace bulb. Check ground connections of black wire, circuit No. 010, from turn indicator socket through instrument panel connector to ground connection on center control console.
11. Female end of bullet connector for green wire at bottom of left front cab post.	Battery voltage (pulsing).	Check for corroded connections or break in splice or wire between turn signal controller and bullet connector.
12. Male end of bullet connector for green wire at bottom of left front cab post.	Battery voltage (pulsing).	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
13. Terminal A of female terminal side of 2-pin connector for left front warn/turn light.	Battery voltage (pulsing).	Check for corroded connections or break in splice or wire between bullet connector and 2-pin connector.
14. Terminal A of male terminal side of 2-pin connector for left front warn/turn light.	Battery voltage (pulsing).	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
15. Ground connection for left front warn/turn bulb.	Less than 0.2 volt.	Check or replace bulb. Check for corroded connections or broken ground wire between ground screw and bulb socket.

**CONDITIONS:**

- Remove left front warn/turn bulb.

Test Location	Normal	If Not Normal
16. Terminal A of left front warn/turn bulb socket.	Battery voltage (pulsing).	Check for corroded connections or break in splice or wire between 2-pin connector and bulb socket.
17. Terminal A of female terminal side of 2-pin connector for left rear warn/turn light.	Battery voltage (pulsing).	Check for corroded connections or break in splice or wire between bullet connector and 2-pin connector.
18. Terminal A of male terminal side of 2-pin connector for left rear warn/turn light.	Battery voltage (pulsing).	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
19. Ground connection for left rear warn/turn bulb.	Less than 0.2 volt.	Check or replace bulb. Check for corroded connections or broken ground wire between ground screw and bulb socket.

**CONDITIONS:**

- Remove left rear warn/turn bulb.

Continued on next page

AG,OUO1085,399 -19-20SEP00-3/5



Test Location	Normal	If Not Normal
20. Terminal A of left rear warn/turn bulb socket.	Battery voltage (pulsing).	Check for corroded connections or break in splice or wire between 2-pin connector and bulb socket.
21. Terminal 4 of turn signal controller.	Battery voltage.	Replace turn signal controller.
22. Terminal D of female terminal side of instrument panel connector.	Battery voltage.	Check for corroded connections or break in splice or wire between turn signal controller and instrument panel connector.
23. Top terminal of right turn indicator socket.	Battery voltage.	Check for corroded connections between instrument panel circuit board and right turn indicator socket.
24. Bottom terminal of right turn indicator socket.	Less than 0.2 volt.	Check or replace bulb. Check ground connections of black wire circuit No. 010, from turn indicator socket through instrument panel connector to ground connection on tractor frame behind instrument panel.
25. Female end of bullet connector at bottom of right front cab post.	Battery voltage.	Check for corroded connections or break in splice or wire between turn signal controller and bullet connector.
26. Male end of bullet connector at bottom of right front cab post.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
27. Terminal A of female terminal side of 2-pin connector for right front warn/turn light.	Battery voltage.	Check for corroded connections or break in splice or wire between bullet connector and 2-pin connector.
28. Terminal A of male terminal side of 2-pin connector for right front warn/turn light.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
29. Ground connection for right front warn/turn bulb.	Less than 0.2 volt.	Check or replace bulb. Check for corroded connections or broken ground wire between ground screw and bulb socket.

**CONDITIONS:**

- Remove right front warn/turn bulb.

Test Location	Normal	If Not Normal
30. Terminal A of right front warn/turn bulb socket.	Battery voltage.	Check for corroded connections or break in splice or wire between 2-pin connector and bulb socket.
31. Terminal A of female terminal side of 2-pin connector for right rear warn/turn light.	Battery voltage.	Check for corroded connections or break in splice or wire between bullet connector and 2-pin connector.
32. Terminal A of male terminal side of 2-pin connector for right rear warn/turn light.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
33. Ground connection for right rear warn/turn bulb.	Less than 0.2 volt.	Check or replace bulb. Check for corroded connections or broken ground wire between ground screw and bulb socket.

Continued on next page

AG,OUO1085,399 -19-20SEP00-4/5

CONDITIONS:

Remove right rear warn/turn bulb.

Test Location	Normal	If Not Normal
34. Terminal A of right rear warn/turn bulb socket.	Battery voltage.	Check for corroded connections or break in splice or wire between 2-pin connector and bulb socket.


*NOTE: To check right turn circuit, move turn signal controller to right turn position and repeat test*

*locations 8 through 34. Pulsing voltage will be in the right circuit, no. 115.*

AG,OUO1085,399 -19-20SEP00-5/5

240  
15  
25

## LIGHTING SYSTEM TEST POINTS – WARNING LIGHTS (ALL TRACTORS)



LV2232

LV2232 -UN-26NOV97

Continued on next page

AG,OUO1085,400 -19-20SEP00-1/2

CONDITIONS:

- Key switch off.
- Transmission in P, park position.
- Park brake engaged.
- Meter positive lead (red) on the numbered test point.

- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Starter battery terminal.	Battery voltage.	Check for corroded connections or break in wire between battery and starter.
3. Left post of fuse link junction block.	Battery voltage.	Check for corroded terminal or break in wire between battery and fuse link junction block.
4. Right post of fuse link junction block.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
5. Top terminal of fuse, F6.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse link junction block and fuse, F6.
6. Bottom terminal of fuse, F7.	Battery voltage.	Check for failed fuse, F7. If fuse is good, check for corroded or loose terminals.
7. Terminal B of light switch.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and light switch.

CONDITIONS:

*NOTE: Warning lights operate in three light switch positions, W, H<sub>1</sub>, and H<sub>2</sub>.*


Turn light switch to W, H<sub>1</sub>, or H<sub>2</sub>.

Test Location	Normal	If Not Normal
8. Terminal W of light switch.	Battery voltage.	Check that light switch is in W, H <sub>1</sub> or H <sub>2</sub> position. If switch is in proper position, switch is bad. Replace.
9. Right terminal of fuse, F3.	Battery voltage.	Check for corroded connections or break in wire between light switch and fuse, F3.
10. Left terminal of fuse, F3.	Battery voltage.	Check for failed fuse, F3. If fuse is good, check for corroded or loose terminals.
11. Terminal 1 of turn signal controller.	Battery voltage.	Check for corroded connections or break in wire between fuse block and turn signal controller.
12. Terminal 3 of turn signal controller.	Battery voltage (pulsing).	Replace turn signal controller.
13. Terminal 4 of turn signal controller.	Battery voltage (pulsing).	Replace turn signal controller.

*NOTE: The remaining indicators and lights are the same as turn signal circuit. Refer to turn signal diagnosis if further diagnosis is required. In procedures for tractors without cab, perform*

*steps 7–21. For tractors with cab, perform steps 9–34. When warning lights function, both right and left sides flash.*

# Lighting System Test Points—Rear Work Light (Tractors Without Cab)



LV2241

## LIGHTING SYSTEM TEST POINTS – REAR WORK LIGHT

Continued on next page

AG,OUO1085,401 -19-20SEP00-1/3

CONDITIONS:

- Transmission in P, park position.
- PTO disengaged.
- Meter positive lead (red) on numbered test points.

- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Starter battery terminal.	Battery voltage.	Check for corroded connections or break in wire between battery and starter.
3. Left post of fuse link junction block.	Battery voltage.	Check for corroded terminal or break in wire between battery and fuse link junction block.
4. Right post of fuse link junction block.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
5. Top terminal of fuse, F6.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse link junction block and fuse, F6.
6. Bottom terminal B of fuse, F7.	Battery voltage.	Check for failed fuse, F7. If fuse is good, check for corroded or loose terminals.
7. Terminal B of light switch.	Battery voltage.	Check for corroded connections or break in wire between fuse block and light switch.

CONDITIONS:

*NOTE: High beam headlights will also come on.*

Turn light switch to F position.

Test Location	Normal	If Not Normal
8. Terminal FL of light switch.	Battery voltage.	Check that light switch is in F position. If switch is in F position, switch is bad. Replace.
9. Right terminal of fuse, F4.	Battery voltage.	Check for corroded connections or break in wire between light switch and fuse, F4.
10. Left terminal of fuse, F4.	Battery voltage.	Check for failed fuse, F4. If fuse is good, check for corroded or loose terminals.

Continued on next page

AG,OUO1085,401 –19–20SEP00–2/3


**NOTE:** Illustration shows the rear work light connectors disconnected for identification

purposes only. Disconnect connector(s) only if test requires it.

Test Location	Normal	If Not Normal
11. Female end of purple wire bullet connector located below left support of ROPS. (Disconnect bullet connector.)	Battery voltage.	Check for corroded connections or break in wire between bullet connector and fuse block.
12. Terminal A of female socket side of rear work light connector.	Battery voltage.	Check for corroded connections or break in wire between fuse block and work light connector.
13. Terminal B of female socket side of rear work light connector.	Less than 0.2 volt.	Check or replace bulb. Check continuity of black wires Nos. 010R-010A through bullet connector to cap screw (ground) on rockshaft cover.

AG,OUO1085,401 -19-20SEP00-3/3

# Lighting System Test Points—Flood Lights (Tractors With Cab)



## LIGHTING SYSTEM TEST POINTS – FLOOD LIGHTS (TRACTORS WITH CAB)

LV1607

240  
15  
31

LV1607 -19-15DEC97

Continued on next page

AG,OUO1085,402 -19-20SEP00-1/6



CONDITIONS:

- Transmission in P, park position.
- PTO disengaged.
- Meter positive lead (red) on numbered test points.

- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Left post of fuse link.	Battery voltage.	Check for loose or corroded terminal or break in wire between battery and fuse link.
3. Right post of fuse link.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
4. Top terminal of 30-amp fuse, F7.	Battery voltage.	Check for loose or corroded terminal or break in splice or wire between fuse link and fuse, F7.
5. Bottom terminal of fuse, F7.	Battery voltage.	Check for failed fuse, F7. If fuse is good, check for loose or corroded terminals.
6. Terminal B of light switch.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and light switch.

CONDITIONS:

- Turn light switch to F position.

Continued on next page

AG,OUO1085,402 –19–20SEP00–2/6

**NOTE:** High beam headlights will also come on.

Test Location	Normal	If Not Normal
7. Terminal FL of light switch.	Battery voltage.	Check that light switch is in F position. If switch is in F position, switch is bad. Replace.
8. Left terminal of fuse, F4.	Battery voltage.	Check for corroded connections or break in splice or wire between light switch and fuse block.
9. Right terminal of fuse, F4.	Battery voltage.	Check for failed fuse, F7. If fuse is good, check for loose or corroded terminals.
10. Female side of rear harness-to-cab connector at bottom of left front cab post.	Battery voltage.	Check for loose or corroded connections or break in splice or wire between fuse block and connector.
11. Male side of rear harness-to-cab harness connector at bottom of left front cab post.	Battery voltage.	Be sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
12. Terminal A of female side of 2-wire connector at left front corner of cab roof.	Battery voltage.	Check for loose or corroded connection or break in wire between cab harness connector and 2-wire connector.
13. Terminal A of male side of 2-wire connector at left front corner of cab roof.	Battery voltage.	Be sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
14. Terminal 86 of flood light relay (located behind cab overhead control panel).	Battery voltage.	Check for loose or corroded connection or break in wire between 2-wire connector and relay.
15. Terminal 85 of flood light relay.	Battery voltage.	Check for continuity to ground of black wire No. 010M, or test flood light relay.
16. Left terminal of fuse F14 (red wire No. 002E) in overhead control panel.	Battery voltage.	Check for loose or corroded connection or break in wire between 2-wire connector and relay.
17. Right terminal of fuse, F14.	Battery voltage.	Check for failed fuse, F14. If fuse is good, check for loose or corroded connections.
18. Terminal 30 of flood light relay.	Battery voltage.	Check for loose or corroded connections or break in wire between cab fuse block and flood light relay.
19. Terminal 87 of flood light relay.	Battery voltage.	Check for loose or corroded connections. Test flood light relay.
20. Terminal B of female side of 2-wire connector at left front corner of cab roof.	Battery voltage.	Check for loose or corroded connections or break in splice or wire. 2-wire connector and flood relay.
21. Terminal B of male side of 2-wire connector at left front corner of cab roof.	Battery voltage.	Be sure connector is fully pushed together. check for corroded or damaged terminals. Repair or replace connector.

Continued on next page

AG,OUO1085,402 -19-20SEP00-3/6

Test Location	Normal	If Not Normal
22. Female side of left rear flood light connector.	Battery voltage.	Check for loose or corroded connections or break in wire between 2-wire connector and flood light connector.
23. Male side of left rear flood light connector.	Battery voltage.	Be sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.

**CONDITIONS:**

- Flood light lens removed. Bulb socket removed from lens.

Test Location	Normal	If Not Normal
24. Terminal A of flood light bulb socket.	Battery voltage.	Check for loose or corroded connection or break in wire between flood light connector and bulb socket.
25. Bulb terminal corresponding to terminal A of bulb socket.	Battery voltage.	Make sure bulb is fully seated in connector. Check for corroded or damaged terminals. Repair or replace connector.
26. Terminal B of flood light bulb socket.	Less than 0.2 volt.	Check or replace bulb. Check for continuity to ground between terminal B and ground screw.
27. Female side of right rear flood light connector.	Battery voltage.	Check for loose or corroded connections or break in wire between 2-wire connector and flood light connector.
28. Male side of right rear flood light connector.	Battery voltage.	Be sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.

**CONDITIONS:**

- Flood light lens removed. Bulb socket removed from lens.

Continued on next page

AG,OUO1085,402 -19-20SEP00-4/6

Test Location	Normal	If Not Normal
29. Terminal A of flood light bulb socket.	Battery voltage.	Check for loose or corroded connection or break in wire between flood light connector and bulb socket.
30. Bulb terminal corresponding to terminal A of bulb socket.	Battery voltage.	Make sure bulb is fully seated in connector. Check for corroded or damaged terminals. Repair or replace connector.
31. Terminal B of flood light bulb socket.	Less than 0.2 volt.	Check or replace bulb. Check for continuity to ground between terminal B and ground screw.
32. Female side of left front flood light connector.	Battery voltage.	Check for loose or corroded connections or break in wire between 2-wire connector and flood light switch.
33. Male side of left front flood light connector.	Battery voltage.	Be sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.

**CONDITIONS:**

- Flood light lens removed. Bulb socket removed from lens.

Test Location	Normal	If Not Normal
34. Terminal A of flood light bulb socket.	Battery voltage.	Check for loose or corroded connection or break in wire between flood light connector and bulb socket.
35. Bulb terminal corresponding to terminal A of bulb socket.	Battery voltage.	Make sure bulb is fully seated in connector. Check for corroded or damaged terminals. Repair or replace connector.
36. Terminal B of flood light bulb socket.	Less than 0.2 volt.	Check or replace bulb. Check for continuity to ground between terminal B and ground screw.
37. Female side of right front flood light connector.	Battery voltage.	Check for loose or corroded connections or break in splice or wire between 2-wire connector and flood light relay.
38. Male side of right front flood light connector.	Battery voltage.	Be sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.

**CONDITIONS:**

- Flood light lens removed. Bulb socket removed from lens.

Continued on next page


AG,OUO1085,402 -19-20SEP00-5/6

*Diagnosis, Test and Adjust*

Test Location	Normal	If Not Normal
39. Terminal A of flood light bulb socket.	Battery voltage.	Check for loose or corroded connection or break in wire between flood light connector and bulb socket.
40. Bulb terminal corresponding to terminal A of bulb socket.	Battery voltage.	Make sure bulb is fully seated in connector. Check for corroded or damaged terminals. Repair or replace connector.
41. Terminal B of flood light bulb socket.	Less than 0.2 volt.	Check or replace bulb. Check for continuity to ground between terminal B and ground screw.

AG,OUO1085,402 -19-20SEP00-6/6

# Lighting System Test Points—Tail Lights (Tractors Without Cab)



## LIGHTING SYSTEM TEST POINTS – TAIL LIGHT (TRACTORS WITHOUT CAB)

LV2233

LV2233 –UN-26NOV97

Continued on next page

OUC1085,0000193 –19-21SEP00-1/3

CONDITIONS:

- Key switch off.
- Transmission in P, park position.
- Light switch in H<sub>1</sub> or H<sub>2</sub> position.
- Meter positive lead (red) on the numbered test point.
- Meter negative lead (black) on battery negative (–) post.

- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

*NOTE: Tail light is on when light switch is in H<sub>1</sub> or H<sub>2</sub> position.*

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Starter battery terminal.	Battery voltage.	Check for corroded connections or break in wire between battery or starter.
3. Left post of fuse link.	Battery voltage.	Check for loose or corroded terminal or break in wire between battery and fuse link junction block.
4. Right post of fuse link.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
5. Top terminal of fuse, F6.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse link junction block and fuse, F6.
6. Bottom terminal of fuse, F7.	Battery voltage.	Check for failed fuse, F7. If fuse is good, check for corroded or loose terminals.
7. Terminal B of light switch.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and light switch.
8. Terminal TL of light switch.	Battery voltage.	Check that light switch is in H <sub>1</sub> or H <sub>2</sub> position. If switch is in proper position, switch is bad. Replace.
9. Top terminal of fuse, F9.	Battery voltage.	Check for corroded connections or break in wire between light switch and fuse, F9.
10. Bottom terminal of fuse, F9.	Battery voltage.	Check for failed fuse, F9. If fuse is good, check for corroded or loose terminals.
11. Female end of bullet connector for gray wire of tail light.	Battery voltage.	Check for corroded connections or break in wire between fuse block and bullet connector.
12. Male end of bullet connector for black wire of tail light.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminal. Repair or replace connector.
13. Left turn lens mounting screw.	Less than 0.2 volt.	Check or replace bulb. Check for good ground from base of turn light to ROPS through the mounting bolts.

CONDITIONS:

- Remove left rear lens and turn signal bulb.

Continued on next page

OUC1085,0000193 –19–21SEP00–2/3

*Diagnosis, Test and Adjust*


Test Location	Normal	If Not Normal
14. Outer terminal of tail light socket.	Battery voltage.	Check for corroded connections or break in wire between bullet connector and tail light socket terminal.

OUO1085,0000193 -19-21SEP00-3/3

240  
15  
39



# Lighting System Test Points—Tail Lights (Tractors With Cab)



**LIGHTING SYSTEM TEST POINTS – TAIL LIGHTS (TRACTORS WITH CAB)**

LV1606

LV1606 -19-15DEC97

Continued on next page

OUO1085,0000194 -19-21SEP00-1/3

CONDITIONS:

- Key switch off.
- Transmission in P, park position.
- Light switch in H<sub>1</sub> or H<sub>2</sub> position.
- Meter positive lead (red) on the numbered test point.
- Meter negative lead (black) on battery negative (–) post.

- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

*NOTE: Tail lights are on when light switch is in H<sub>1</sub> or H<sub>2</sub> position.*

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Left post of fuse link junction block.	Battery voltage.	Check for corroded terminal or break in wire between battery and fuse link.
3. Right post of fuse link junction block.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
4. Top terminal of fuse, F6.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse link and fuse block.
5. Bottom terminal of fuse, F7.	Battery voltage.	Check for failed fuse, F7. If fuse is good, check for corroded or loose terminals.
6. Terminal B of light switch.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and light switch.
7. Terminal TL of light switch.	Battery voltage.	Check that light switch is in H <sub>1</sub> or H <sub>2</sub> position. If switch is in proper position, switch is bad. Replace.
8. Top terminal of fuse, F9.	Battery voltage.	Check for corroded connections or break in wire between light switch and fuse, F9.
9. Bottom terminal of fuse, F9.	Battery voltage.	Check for failed fuse, F9. If fuse is good, check for corroded or loose terminals.
10. Female end of bullet connector for tail light harness.	Battery voltage.	Check for corroded connections or break in wire between fuse block and bullet connector.
11. Male end of bullet connector for tail light harness.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminal. Repair or replace connector.

CONDITIONS:

- Left tail light lens removed.

Test Location	Normal	If Not Normal
12. Male terminal of left tail light connector.	Battery voltage.	Check for loose or corroded connection or break in splice or wire between bullet connector and tail light connector.

CONDITIONS:

- Left tail light bulb removed.

Test Location	Normal	If Not Normal
13. Center terminal of left tail bulb socket.	Battery voltage.	Check for corroded connections or break in wire between tail light connector and tail light socket.

CONDITIONS:

- Right tail light lens removed.

Test Location	Normal	If Not Normal
14. Male terminal of right tail light connector.	Battery voltage.	Check for loose or corroded connection or break in splice or wire between bullet connector and tail light connector.


CONDITIONS:

- Right tail light bulb removed.

Test Location	Normal	If Not Normal
15. Center terminal of right tail bulb socket.	Battery voltage.	Check for corroded connections or break in wire between tail light connector and tail light socket.

OUO1085,0000194 -19-21SEP00-3/3

## LIGHTING SYSTEM TEST POINTS – HEADLIGHTS AND INSTRUMENT LIGHTS



LV2234 -UN-26NOV97

OUO1085,0000196 -19-22SEP00-1/5

CONDITIONS:

- Key switch off.
- Transmission in P, park position.
- Light switch in H<sub>1</sub> position.
- Meter positive lead (red) on the numbered test point.
- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

Continued on next page

OUO1085,0000196 –19–22SEP00–2/5

Test Location	Normal	If Not Normal
<b>HIGH BEAM HEADLIGHT CIRCUIT</b>		
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Starter battery terminal.	Battery voltage.	Check for corroded connections and starter.
3. Left post of fuse link junction block.	Battery voltage.	Check for corroded terminal or break in wire between starter and fuse link junction block.
4. Right post of fuse link junction block.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
5. Top terminal of fuse, F6.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse link junction block and fuse, F6.
6. Bottom terminal of fuse, F7.	Battery voltage.	Check for failed fuse, F7. If fuse is good, check for corroded or loose terminals.
7. Terminal B of light switch.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and light switch.
8. Terminal HD1 of light switch.	Battery voltage.	Check that light switch is in H <sub>1</sub> position. If switch is in H <sub>1</sub> , switch is bad. Replace.
9. Top terminal of fuse, F10.	Battery voltage.	Check for corroded connections or break in wire between light switch and fuse, F10.
10. Bottom terminal of fuse, F10.	Battery voltage.	Check for failed fuse, F10. If fuse is good, check for corroded or loose terminals.
11. Terminal G of male pin side of 10-pin connector.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and 10-pin connector.
12. Terminal G of female socket side of 10-pin connector.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
13. Terminal A of right headlight connector	Battery voltage.	Check for corroded connections or break in splice or wire between 10-pin connector and headlight.
14. Terminal C of right headlight connector.	Less than 0.2 volt.	Check or replace bulb. Check continuity to ground of black wire Nos. 010D and 010E to tractor frame on left side near battery.
15. Terminal A of left headlight connector.	Battery voltage.	Check for corroded connections or break in splice or wire between 10-pin connector and headlight.
16. Terminal C of left headlight connector.	Less than 0.2 volt.	Check or replace bulb. Check continuity to ground of black wire Nos. 010F and 010E to tractor frame on left side near battery.
17. Terminal C of female terminal side of instrument panel connector.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and instrument panel connector.
18. Top terminal of high beam indicator socket.	Battery voltage.	Check for corroded connections or break in wire between instrument panel connector and high beam indicator socket.

Continued on next page

OUC1085,0000196 -19-22SEP00-3/5

Test Location	Normal	If Not Normal
19. Bottom terminal of high beam indicator socket.	Less than 0.2 volts.	Check or replace bulb. Check ground continuity of black wire circuit No. 010, from indicator socket through instrument panel connector to ground connection on tractor frame behind instrument panel.
<b>INSTRUMENT LIGHTS CIRCUIT</b>		
20. Terminal 3 of diode pack.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and diode pack.
21. Terminal 2 of diode pack.	Battery voltage.	Check for corroded or loose terminals. Test diode pack.
22. Terminal B of female terminal side of instrument panel connector.	Battery voltage.	Check for corroded connections or break in wire between diode pack and instrument panel connector.
23. Red/white terminal of each instrument light bulb socket.	Battery voltage.	Check for corroded connections or break in splice or wire between instrument panel connector and each light socket.
24. Black wire terminal of each instrument light bulb socket.	Less than 0.2 volt.	Check or replace bulb(s). Check ground continuity of black wire circuit No. 010, from each light socket through instrument panel connector to ground connection on tractor frame behind instrument panel.

**CONDITIONS:**

- Turn light switch to H<sub>2</sub> position.

Continued on next page

OUC1085,0000196 -19-22SEP00-4/5

Test Location	Normal	If Not Normal
LOW BEAM HEADLIGHT CIRCUIT		
25. Terminal H <sub>2</sub> of light switch.	Battery voltage.	Check that light switch is in H <sub>2</sub> position. If switch is in H <sub>2</sub> , switch is bad. Replace.
26. Top terminal of fuse, F11.	Battery voltage.	Check for corroded connections or break in splice or wire between light switch and fuse block.
27. Bottom terminal of fuse, F11.	Battery voltage.	Check for failed fuse, F11. If fuse is good, check for corroded or loose terminals.
28. Terminal F of male pin side of 10-pin connector.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and 10-pin connector.
29. Terminal F of female socket side of 10-pin connector.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
30. Terminal B of right headlight connector.	Battery voltage.	Check for corroded connections or break in splice or wire between 10-pin connector and headlight.
31. Terminal B of left headlight connector.	Battery voltage.	Check for corroded connections or break in splice or wire between 10-pin connector and headlight.
32. Terminal 1 of diode pack.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and diode pack.


**NOTE:** Terminal 2 of diode pack allows power from terminals 1 and 3 to flow to the instrument panel lights.

Repeat test points 21 through 24 if instrument lights are not on when light switch is in H<sub>2</sub> position.

OUC1085,0000196 -19-22SEP00-5/5



# Lighting System Test Points—Dome Light (Tractors With Cab)



## DOME LIGHT TEST POINTS (TRACTORS WITH CAB)

LV1609

LV1609 -19-15DEC97

Continued on next page

OUO1085,0000197 -19-22SEP00-1/3

CONDITIONS:

- Transmission in P, park position.
- PTO Disengaged.
- Key switch in RUN position.
- Meter positive lead (red) on the numbered test points.

- Cab doors closed.
- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Left post of fuse link.	Battery voltage.	Check for loose or corroded terminal, or break in wire between battery and fuse link.
3. Right post of fuse link.	Battery voltage.	Check for loose or corroded terminal, or replace fuse link.
4. Top terminal of 30-amp fuse, F5.	Battery voltage.	Check for loose or corroded terminal or break in splice or wire between fuse link and fuse, F5.
5. Bottom terminal of fuse, F5.	Battery voltage.	Check for failed fuse, F5. If fuse is good, check for corroded or loose terminals.
6. Terminal A of female side of 3-wire connector at bottom of right front cab post.	Battery voltage.	Check for loose or corroded terminal or break in splice or wire between fuse block and connector.
7. Terminal A of male side of 3-wire connector.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
8. Dome light terminal for red wire No. 262.	Battery voltage.	Check for loose or corroded connection or break in wire between 3-wire connector and dome light.
9. Dome light terminal for black wire No. 010.	Less than 0.2 volt.	Check or replace bulb. Check for continuity to ground through black wire No. 010.

CONDITIONS:

- Left door open.

- Dome light switched to OFF position.

Test Location	Normal	If Not Normal
10. Dome light terminal for green wire No. 255.	Less than 0.02 volt.	Check or replace bulb. Test dome light switch.
11. Left door switch terminal for green wire No. 255.	Less than 0.02 volt.	Check for loose or corroded connection or break in splice or wire between dome light and door switch.
12. Left door switch terminal for black wire No. 010.	Less than 0.2 volt.	Check for continuity to ground through black wire. Test door switch.

CONDITIONS:

- Dome light switched to OFF position.
- Right door open.

Continued on next page

OUC1085,0000197 –19–22SEP00–2/3

*Diagnosis, Test and Adjust*

Test Location	Normal	If Not Normal
13. Right door switch terminal for green wire No. 255.	Less than 0.02 volt.	Check for loose or corroded connection or break in splice or wire between dome light and door switch.
14. Right door switch terminal for black wire No. 010.	Less than 0.2 volt.	Check for continuity to ground through black wire. Test door switch.

OUO1085,0000197 -19-22SEP00-3/3

# INSTRUMENT PANEL SYSTEM TEST POINTS – HOURMETER AND TACHOMETER



LV2235 -UN-26NOV97

AG,OUO1023,481 -19-24JAN00-1/3

CONDITIONS:

- Transmission in P, park position.
- PTO disengaged.
- Key switch in RUN position.
- Meter positive lead (red) on numbered test points.

- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Starter battery terminal.	Battery voltage.	Check for corroded connections or break in wire between battery and starter.
3. Left post of fuse link junction block.	Battery voltage.	Check for corroded terminal or break in wire between starter and fuse link junction block.
4. Right post of fuse link junction block.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
5. Top terminal of fuse, F6.	Battery voltage.	Check for corroded connections or break in wire or splice between fuse link junction block and 30-amp fuse, F6.
6. Bottom terminal of fuse, F6.	Battery voltage.	Check for failed fuse, F6. If fuse is good, check for corroded or loose terminals.
7. BAT terminal of key switch.	Battery voltage.	Check for corroded connections or break in wire between fuse block and key switch.
8. IGN terminal of key switch.	Battery voltage.	Check that key switch is in RUN position. If switch is in RUN, switch is bad. Replace.
9. Right terminal of fuse, F1.	Battery voltage.	Check for corroded connections or break in splice or wire between key switch and fuse F1.
10. Left terminal of fuse, F1.	Battery voltage.	Check for failed fuse, F1. If fuse is good, check for corroded or loose terminals.
11. Terminal A of instrument panel wiring harness connector.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and instrument panel connector. Check continuity to ground of black wires Nos. 010L and 010K. If connections and wires are good to ground, replace hourmeter and tachometer by replacing instrument panel.

CONDITIONS:

- Engine operating at slow idle.
- Meter on AC volts.

Continued on next page


AG,OUO1023,481 –19–24JAN00–2/3

Test Location	Normal	If Not Normal
12. Green wire terminal of magnetic pickup sensor.	Sensor output voltage (1 VAC minimum).	Check continuity to ground of black wire Nos. 010B and 010E. If black wires are good to ground, check or replace magnetic pickup sensor.
13. Terminal K of female socket side of 10-pin connector.	Sensor output voltage.	Check for corroded connections or break in wire between pickup sensor and 10-pin connector.
14. Terminal K of male pin side of 10-pin connector.	Sensor output voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
15. Terminal D of female terminal side of instrument panel connector.	Sensor output voltage.	Check for corroded connection or break in wire between 10-pin connector and instrument panel connector. If hourmeter and tachometer does not function, replace hourmeter and tachometer by replacing instrument panel.

AG,QUO1023,481 -19-24JAN00-3/3

240  
15  
53

# Instrument Panel System Test Points—Fuel Gauge



INSTRUMENT PANEL SYSTEM TEST POINTS – FUEL GAUGE

LV2236

LV2236 –UN-25JUL02

Continued on next page

OUC1085,0000198 –19-22SEP00-1/3

CONDITIONS:

- Transmission in P, park position.
- PTO disengaged.
- Key switch in RUN position.
- Meter positive lead (red) on numbered test points.

- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Starter battery terminal.	Battery voltage.	Check for corroded connections or break in wire between battery and starter.
3. Left post of fuse link junction block.	Battery voltage.	Check for corroded terminal or break in wire between starter and fuse link junction block.
4. Right post of fuse link junction block.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
5. Top terminal of fuse, F6.	Battery voltage.	Check for corroded connections or break in wire or splice between fuse link junction block and 30-amp fuse, F6.
6. Bottom terminal of fuse, F6.	Battery voltage.	Check for failed fuse, F6. If fuse is good, check for corroded or loose terminals.
7. BAT terminal of key switch.	Battery voltage.	Check for corroded connections or break in wire between fuse block and key switch.
8. IGN terminal of key switch.	Battery voltage.	Check that key switch is in RUN position. If switch is in RUN, switch is bad. Replace.
9. Right terminal of fuse, F1.	Battery voltage.	Check for corroded connections or break in splice or wire between key switch and fuse, F1.
10. Left terminal of fuse, F1.	Battery voltage.	Check for failed fuse, F1. If fuse is good, check for corroded or loose terminals.
11. Terminal A of female terminal side of instrument panel connector.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and instrument panel connector.

CONDITIONS:

- Remove wire from center terminal (A) of fuel gauge sender.

Test Location	Normal	If Not Normal
12. Fuel gauge.	Gauge indicates EMPTY.	Replace instrument panel.

CONDITIONS:

- Connect wire from center terminal (A) to black wire on sender plate.

Continued on next page

OUC1085,0000198 –19–22SEP00–2/3



*Diagnosis, Test and Adjust*

Test Location	Normal	If Not Normal
13. Fuel gauge.	Gauge indicates FULL.	Check for corroded connections or break in orange wire between sender and instrument panel connector. Check for continuity to ground through black wire Nos. 010B and 010K to cap screw on rockshaft cover. Replace instrument panel.

CONDITIONS:


- Key switch in off position.

- Use a long wire to raise and lower sender float.

Test Location	Normal	If Not Normal
14. Fuel gauge sender.	Resistance smoothly increases/decreases between 4.5—97.5 ohms as float is raised and lowered.	Replace front gauge sender.

OUC1085,0000198 -19-22SEP00-3/3

# Instrument Panel System Test Points—Temperature Gauge



## INSTRUMENT PANEL SYSTEM TEST POINTS – TEMPERATURE GAUGE

LV2237

LV2237 –UN-25JUL02

240  
15  
57

Continued on next page

OUC1085,0000199 –19-22SEP00-1/3

CONDITIONS:

- Range shift lever in P, park position.
- PTO disengaged.
- Key switch in RUN position.
- Meter positive lead (red) on numbered test points.

- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Starter battery terminal.	Battery voltage.	Check for corroded connections or break in wire between battery and starter.
3. Left post of fuse link junction block.	Battery voltage.	Check for corroded terminal or break in wire between battery and fuse link junction block.
4. Right post of fuse link junction block.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
5. Top terminal of fuse, F6.	Battery voltage.	Check for corroded connections or break in wire or splice between fuse link junction block and 30-amp fuse, F6.
6. Bottom terminal of fuse, F6.	Battery voltage.	Check for failed fuse, F6. If fuse is good, check for corroded or loose terminals.
7. BAT terminal of key switch.	Battery voltage.	Check for corroded connections or break in wire between fuse block and key switch.
8. IGN terminal of key switch.	Battery voltage.	Check that key switch is in RUN position. If switch is in RUN, switch is bad. Replace.
9. Right terminal of fuse, F1.	Battery voltage.	Check for corroded connections or break in splice or wire between key switch and fuse, F1.
10. Left terminal of fuse, F1.	Battery voltage.	Check for failed fuse, F1. If fuse is good, check for corroded or loose terminals.
11. Terminal A of female terminal side of instrument panel connector.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and instrument panel connector.

CONDITIONS:

- Remove wire from temperature sender (A).

Test Location	Normal	If Not Normal
12. Temperature gauge.	Gauge indicates COLD.	Replace instrument panel.

CONDITIONS:

- Connect wire from temperature sender (A) to ground using a jumper wire.

Continued on next page

OUC1085,0000199 –19–22SEP00–2/3

Test Location	Normal	If Not Normal
13. Temperature gauge.	Gauge indicates HOT.	Check for corroded connections or break in white wires between temperature sender and 10-pin connector or between 10-pin connector and instrument panel connector. Replace instrument panel.

CONDITIONS:

- Wire removed from temperature sender.
- Meter on ohm scale.


*NOTE: Remove temperature sender to check resistance at various temperatures. Put in water heated to a specified temperature.*

Test Location	Normal	If Not Normal
14. Temperature sender.	60°C (140°F) 134 ± 13.5 ohms 90°C (194°F) 51.2 ± 4.3 ohms 100°C (212°F) 38.5 ± 3.0 ohms	Replace temperature sender.

OUC1085,0000199 -19-22SEP00-3/3

240  
15  
59

# Instrument Panel System Test Points—Oil Pressure



INSTRUMENT PANEL SYSTEM TEST POINTS – OIL PRESSURE

LV2244

LV2244 –UN-26NOV97

Continued on next page

OOU1085,000019A –19-22SEP00-1/4

CONDITIONS:

- Transmission in P, park position.
- PTO disengaged.
- Key switch in RUN position.
- Connector removed from oil pressure switch (A).
- Meter positive lead (red) on numbered test points.
- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

Continued on next page

OUC1085,000019A –19–22SEP00–2/4

240  
15  
61

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Starter battery terminal.	Battery voltage.	Check for corroded connections or break in wire between battery and starter.
3. Left post of fuse link junction block.	Battery voltage.	Check for corroded terminal or break in wire between starter and fuse link junction block.
4. Right post of fuse link junction block.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
5. Top terminal of fuse, F6.	Battery voltage.	Check for corroded connections or break in wire or splice between fuse link junction block and 30-amp fuse, F6.
6. Bottom terminal of fuse, F6.	Battery voltage.	Check for failed fuse, F6. If fuse is good, check for corroded or loose terminals.
7. BAT terminal of key switch.	Battery voltage.	Check for corroded connections or break in wire between fuse block and key switch.
8. IGN terminal of key switch.	Battery voltage.	Check that key switch is in RUN position. If switch is in RUN, switch is bad. Replace.
9. Right terminal of fuse, F1.	Battery voltage.	Check for corroded connections or break in splice or wire between key switch and fuse, F1.
10. Left terminal of fuse, F1.	Battery voltage.	Check for failed fuse, F1. If fuse is good, check for corroded or loose terminals.
11. Terminal A of female terminal side of instrument panel connector.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and instrument panel connector.
12. Top terminal of oil pressure indicator socket.	Battery voltage.	Check for corroded connections between circuit board and oil pressure indicator bulb socket.
13. Bottom terminal of oil pressure indicator socket.	Battery voltage.	Check for bad indicator bulb, socket, or corroded terminals.
14. Terminal 8 of female terminal side of instrument panel connector.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
15. Terminal C of male pin side of 10-pin connector.	Battery voltage.	Check for corroded connections or break in wire between instrument panel connector and 10-pin connector.
16. Terminal C of female socket side of 10-pin connector.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
17. Pressure switch connector.	Battery voltage.	Check for corroded connections or break in wire between 10-pin connector and engine oil pressure switch connector.

**CONDITIONS:**

- Meter on 1X ohm scale.

Continued on next page

OUO1085,000019A -19-22SEP00-3/4

*Diagnosis, Test and Adjust*

Test Location	Normal	If Not Normal
18. Terminal of pressure switch.	Maximum 0.5 ohm resistance. (Switch contacts closed.)	Replace oil pressure switch.


*NOTE: Oil pressure switch contacts open when engine oil pressure reaches 38—72 kPa (5.5—10.5 psi) (.38—.72 bar).*

OUO1085,000019A -19-22SEP00-4/4

240  
15  
63



# PTO Warning System Test Points



PTO WARNING SYSTEM TEST POINTS

LV2239

LV2239 -JUN-12JUL02

Continued on next page

OUC1085,000019B -19-26JUN02-1/3

**CONDITIONS:**

- Transmission in P, park position.
- PTO disengaged.
- Key switch in RUN position.
- Meter positive lead (red) on numbered test points.

- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Starter battery terminal.	Battery voltage.	Check for corroded connections or break in wire between battery and starter.
3. Left post of fuse link junction block.	Battery voltage.	Check for corroded terminal or break in wire between starter and fuse link junction block.
4. Right post of fuse link junction block.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
5. Top terminal of fuse, F6	Battery voltage.	Check for corroded connections or break in wire or splice between fuse link junction block and 30-amp fuse, F6.
6. Bottom terminal of fuse, F6.	Battery voltage.	Check for failed fuse, F6. If fuse is good, check for corroded or loose terminals.
7. BAT terminal of key switch.	Battery voltage.	Check for corroded connections or break in wire between fuse block and key switch.
8. IGN terminal of key switch.	Battery voltage.	Check that key switch is in the RUN position. If switch is in RUN, switch is bad. Replace switch.
9. Terminal C of PTO switch.	Battery voltage.	Check for corroded connections or break in splice or wire between key switch and PTO switch.
10. Terminal A of PTO switch.	No voltage.	Make sure connector is fully pushed together and PTO lever is in disengaged position. Check for corroded or damaged terminals. Replace switch if damaged or defective.

**CONDITIONS:**

- Operator on seat.
- Move PTO lever to engaged position.

Continued on next page

OUC1085,000019B –19–26JUN02–2/3

Test Location	Normal	If Not Normal
11. Terminal A of PTO switch.	Battery voltage.	Make sure connector is fully pushed together and PTO lever is in engaged position. Check for corroded or damaged terminals. Replace switch if damaged or defective.
12. Terminal B of female terminal side of instrument panel connector.	Battery voltage.	Check for corroded connections or break in splice or wire between PTO switch and instrument panel connector.
13. Top terminal of PTO indicator socket.	Battery voltage.	Check for corroded connections or break in wire between instrument panel connector and indicator socket.
14. Bottom terminal of PTO indicator socket.	Less than 0.2 volt.	Check or replace bulb. Check ground connections of black wire, circuit No. 010, from PTO indicator socket through instrument panel connector to ground connection on tractor frame, behind instrument panel.
15. Terminal C of seat switch.	Battery voltage.	Check for corroded connections or break in splice or wire between PTO switch and seat switch.
16. Terminal A of seat switch.	No voltage.	Make sure connector is fully pushed together and seat has moved switch lever down. Check for corroded or damaged terminals. Replace switch if damaged or defective.

CONDITIONS:


*NOTE: Horn/timer will sound for approximately 6—8 seconds.*

- Operator off seat.

Test Location	Normal	If Not Normal
17. Terminal A of seat switch.	Battery voltage	Make sure connector is fully pushed together and seat has moved switch lever down. Check for corroded or damaged terminals. Replace switch if damaged or defective.
18. Terminal A of horn/timer.	Battery voltage.	Check for corroded connections or break in wire between seat switch and horn/timer.
19. Terminal B of horn/timer.	Less than 0.2 volt.	Check for continuity to ground through black wire Nos. 010M and 010K to ground connection on tractor frame, behind instrument panel. Replace horn/timer.

OUO1085,000019B -19-26JUN02-3/3

Air Filter Restriction Test Points



AIR FILTER RESTRICTION TEST POINTS

LV2240

LV2240 -UN-26NOV97

Continued on next page

OOU1085,000019C -19-22SEP00-1/4

CONDITIONS:

- Transmission in P, park position.
- PTO disengaged.
- Key switch in RUN position.
- Meter positive lead (red) on numbered test points.
- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustment in this section and group.

Continued on next page

OUO1085,000019C –19–22SEP00–2/4

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Starter battery terminal.	Battery voltage.	Check for corroded connections or break in wire between battery and starter.
3. Left post of fuse link junction block.	Battery voltage	Check for corroded terminal or break in wire between starter and fuse link junction block.
4. Right post of fuse link junction block.	Battery Voltage	Check for loose or corroded terminal or replace fuse link.
5. Top terminal of fuse, F6.	Battery voltage	Check for corroded connections or break in wire or splice between fuse link junction block and 30-amp fuse, F6.
6. Bottom terminal of fuse, F6.	Battery voltage	Check for failed fuse, F6. If fuse is good, check for corroded or loose terminals.
7. BAT terminal of key switch.	Battery voltage	Check for corroded connections or break in wire between fuse block and key switch.
8. IGN terminal of key switch.	Battery voltage.	Check that key switch is in RUN position. If switch is in RUN, switch is bad. Replace.
9. Right terminal of fuse, F1.	Battery voltage.	Check for corroded connections or break in splice or wire between key switch and fuse, F1.
10. Left terminal of fuse, F1.	Battery voltage.	Check for failed fuse, F1. If fuse is good, check for corroded or loose terminals.
11. Terminal A of female terminal side of instrument panel connector.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and instrument panel connector.
12. Top terminal of air restriction indicator socket.	Battery voltage.	Check for corroded connections or break in splice or wire between instrument panel connector and air restriction indicator.
13. Bottom terminal of air restriction indicator socket.	Battery voltage.	Check for bad indicator bulb, socket, or corroded terminals.
14. Terminal G of female terminal side of instrument panel connector.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
15. Terminal B of male pin side of 2-pin connector.	Battery voltage.	Check for corroded connections or break in wire between instrument panel connector and 2-pin connector.
16. Terminal B of female socket side of 2-pin connector.	Battery voltage.	Make sure the connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
17. Terminal A of air restriction switch.	Battery voltage.	Check for corroded connections or break in wire between 2-pin connector and air restriction switch.

**CONDITIONS:**

- Remove connector from air restriction switch (A).
- Meter on 1X ohm scale.

- Meter test leads on terminals of air restriction switch.

Continued on next page

OUO1085,000019C -19-22SEP00-3/4

*Diagnosis, Test and Adjust*


Test Location	Normal	If Not Normal
18. Air restriction switch terminals.	No continuity. (Switch contacts are open.)	Replace switch.

*NOTE: Air restriction switch contacts close when a vacuum of 4.98—7.48 kPa (20—30 in. H<sub>2</sub>O) is present at switch port (B).*

OUO1085,000019C -19-22SEP00-4/4

240  
15  
70

# Optional Horn Test Points



OPTIONAL HORN TEST POINTS

LV2242

240  
15  
71

LV2242 -UN-26NOV97

Continued on next page

OUC1085,000019D -19-22SEP00-1/2



CONDITIONS:

- Transmission in P, park position.
- PTO disengaged.
- Remove connector from horn (A).
- Meter positive lead (red) on numbered test points.

- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustments in this section and group.


Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Starter battery terminal.	Battery voltage.	Check for corroded connections or break in wire between battery and starter.
3. Left post of fuse link junction block.	Battery voltage.	Check for corroded terminal or break in wire between starter and fuse link junction block.
4. Right post of fuse link junction block.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
5. Top terminal of fuse, F6.	Battery voltage.	Check for corroded connections or break in wire or splice between fuse link junction block and 30-amp fuse, F6.
6. Bottom terminal of fuse, F7.	Battery voltage.	Check for failed fuse, F7. If fuse is good, check for corroded or loose terminals.
7. Red wire terminal of horn switch.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and horn switch.

CONDITIONS:

- Push horn button and hold.

Test Location	Normal	If Not Normal
8. Orange wire terminal of horn switch.	Battery voltage.	Check for corroded or loose terminals. Replace horn switch.
9. Terminal H of male pin side of 10-pin connector.	Battery voltage.	Check for corroded connections or break in wire between horn switch and 10-pin connector.
10. Terminal H of female socket side of 10-pin connector.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
11. Horn harness connector, female side.	Battery voltage.	Check for corroded connections or break in wire between 10-pin connector and horn harness connector.
12. Horn harness connector, blade side.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
13. Horn connector.	Battery voltage.	Check for corroded connections or break in wire between horn harness connector and horn. If wire and connectors are good, replace horn.

## ACCESSORY RELAY AND TRAILER CONNECTOR TEST POINTS



LV2243 -UN-08JAN98

OUO1085,000019E -19-22SEP00-1/3

CONDITIONS:

- Transmission in P, park position.
- PTO disengaged.
- Key switch in RUN position.
- Meter positive lead (red) on numbered test points.

- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Starter battery terminal.	Battery voltage.	Check for corroded connections or break in wire between battery and starter.
3. Left post of fuse link junction block.	Battery voltage.	Check for corroded terminal or break in wire between starter and fuse link junction block.
4. Right post of fuse link junction block.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
5. Top terminal of fuse, F6.	Battery voltage.	Check for corroded connections or break in wire or splice between fuse link junction block and 30-amp fuse F6.
6. Bottom terminal of fuse, F6.	Battery voltage.	Check for failed fuse, F6. If fuse is good, check for corroded or loose terminals.
7. BAT terminal of key switch.	Battery voltage.	Check for corroded connections or break in wire between fuse block and key switch.
8. IGN terminal of key switch.	Battery voltage.	Check that key switch is in RUN position. If switch is in RUN, switch is bad. Replace.
9. Terminal 86 of accessory relay.	Battery voltage.	Check for corroded connections or break in splice or wire between key switch and accessory relay.
10. Terminal 85 of accessory relay.	Less than 0.2 volt.	Check continuity to ground of black wire Nos. 010F and 010K. If black wires are good to ground, test accessory relay.
11. Bottom terminal of fuse, F8.	Battery voltage.	Check for failed fuse, F8. If fuse is good, check for corroded or loose terminals.
12. Terminal 30 of accessory relay.	Battery voltage.	Check for corroded connections or break in wire between fuse block and accessory relay.
13. Terminal 87 of accessory relay.	Battery voltage.	Check for corroded or loose terminals. Test accessory relay.
14. Terminal 7 (center) of trailer connector.	Battery voltage.	Check for corroded connections or break in splice or wire between accessory relay and trailer connector.
15. Terminal 4 of trailer connector.	Battery voltage.	Check for corroded connections or break in splice or wire between accessory relay and trailer connector.

CONDITIONS:

- Move turn signal knob to left turn position.

Continued on next page

OUC1085,000019E –19–22SEP00–2/3

Test Location	Normal	If Not Normal
16. Terminal 3 of trailer connector.	Battery voltage (pulsing).	Check for corroded connections or break in splice or wire between turn signal terminal 3 and trailer connector terminal 3.

CONDITIONS:

- Move turn signal knob to right turn position.

Test Location	Normal	If Not Normal
17. Terminal 5 of trailer connector.	Battery voltage (pulsing).	Check for corroded connections or break in splice or wire between turn signal terminal 4 and trailer connector terminal 5.

CONDITIONS:

- Move light switch to H<sub>1</sub> position.

Test Location	Normal	If Not Normal
18. Terminal 6 of trailer connector.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and trailer connector terminal 6.

CONDITIONS:

- Move light switch to F position.

Test Location	Normal	If Not Normal
19. Terminal 2 of trailer connector.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse block and trailer connector terminal 2.

CONDITIONS:


- Meter on 1X ohms scale.

Test Location	Normal	If Not Normal
20. Terminal 1 of trailer connector.	Maximum 0.5 ohm resistance.	Check for corroded connections or break in wire between trailer connector terminal 1 and connector mounting hardware. Check battery-to-frame ground cable and connections.

OUO1085,000019E -19-22SEP00-3/3

240  
15  
75

## BLOWER MOTOR TEST POINTS (TRACTORS WITH CAB)



LV1608 -19-15DEC97

OUO1085,00001A0 -19-25SEP00-1/5

CONDITIONS:

- Transmission in P, park position.
- PTO disengaged.
- Key switch in RUN position.
- Meter positive lead (red) on numbered test points.
- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

Continued on next page

OUC1085,00001A0 –19–25SEP00–2/5

240  
15  
77

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Left post of fuse link junction block.	Battery voltage.	Check for corroded terminal or break in wire between battery and fuse link.
3. Right post of fuse link junction block.	Battery voltage.	Check for loose or corroded terminal or replace fuse link.
4. Top terminal of fuse, F6.	Battery voltage.	Check for corroded connections or break in splice or wire between fuse link and fuse, F6.
5. Bottom terminal of fuse, F6.	Battery voltage.	Check for failed fuse, F6. If fuse is good, check for corroded or loose terminals.
6. BAT terminal of key switch.	Battery voltage.	Check for corroded connections or break in wire between fuse block and key switch.
7. ELX terminal of key switch.	Battery voltage.	Check that key switch is in RUN position. If switch is in RUN, switch is bad. Replace switch.
8. Terminal B of female side of 3-wire connector at bottom of right front cab post.	Battery voltage.	Check for loose or corroded terminal or break in splice or wire between fuse block and connector.
9. Terminal B of male side of 3-wire connector.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
10. Terminal 86 of HVAC relay.	Battery voltage.	Check for loose or corroded connection or break in splice or wire between 3-way connector and HVAC relay.
11. Terminal 85 of HVAC relay.	Less than 0.2 volt.	Check for continuity to ground of black wire No. 010. Test HVAC relay.
12. Left terminal of fuse, F13 (red wire No. 002) in overhead control panel.	Battery voltage.	Check for loose or corroded connection or break in wire between fuse link and fuse block.
13. Right terminal of fuse, F13 (red wire No. 042).	Battery voltage.	Check for failed fuse, F13. If fuse is good, check for loose or corroded terminals.
14. Right terminal of fuse, F15 (red wire No. 052).	Battery voltage.	Check for failed fuse, F15. If fuse is good, check for loose or corroded terminals.
15. Terminal 30 of HVAC relay.	Battery voltage.	Check for loose or corroded connection or break in splice or wire between fuse, F13 and HVAC relay.
16. Terminal 87 of HVAC relay.	Battery voltage.	Check for loose or corroded terminals. Test HVAC relay.
17. Terminal B of blower switch.	Battery voltage.	Check for loose or corroded connection or break in wire between HVAC relay and blower switch.

**CONDITIONS:**

- Blower switch in LOW position.

Continued on next page

OUO1085,00001A0 -19-25SEP00-3/5

Test Location	Normal	If Not Normal
18. Terminal 1 of blower switch.	Battery voltage.	Check for loose or corroded terminals. Test blower switch.

CONDITIONS:

- Cab front headliner removed.

Test Location	Normal	If Not Normal
19. Terminal 4 of blower motor resistor.	Battery voltage.	Check for loose or corroded connection or break in wire between blower switch and blower motor resistor.
20. Terminal 2 of blower motor resistor.	Lower than battery voltage.	Check for loose or corroded terminals. Test blower motor resistor.
21. Terminal 87A of right blower motor relay.	Lower than battery voltage.	Check for loose or corroded connection or break in splice or wire between blower motor resistor and right blower motor relay.
22. Terminal 30 of right blower motor relay.	Lower than battery voltage.	Check for loose or corroded terminals. Test right blower motor relay.
23. Terminal 87A of left blower motor relay.	Lower than battery voltage.	Check for loose or corroded connection or break in splice or wire between blower motor resistor and left blower motor relay.
24. Terminal 30 of left blower motor relay.	Lower than battery voltage.	Check for loose or corroded terminals. Test left blower motor relay.

CONDITIONS:

- Blower switch in MED position.

Test Location	Normal	If Not Normal
25. Terminal 2 of blower switch.	Battery voltage.	Check for loose or corroded terminals. Test blower switch.
26. Terminal 1 of blower motor resistor.	Battery voltage.	Check for loose or corroded terminals. Test blower motor resistor.

CONDITIONS:

- Blower switch in HIGH position.

Test Location	Normal	If Not Normal
27. Terminal 3 of blower switch.	Battery voltage.	Check for loose or corroded terminals. Test blower switch.
28. Terminal 3 of blower motor resistor.	Battery voltage.	Check for loose or corroded terminals or break in wire between blower switch and blower motor resistor.

CONDITIONS:

- Blower switch in PURGE position.




Test Location	Normal	If Not Normal
29. Terminal 4 of blower switch.	Battery voltage.	Check for loose or corroded terminals. Test blower switch.
30. Terminal 86 of right blower motor relay.	Battery voltage.	Check for loose or corroded connection or break in splice or wire between blower switch and relay.
31. Terminal 85 of right blower motor relay.	Less than 0.2 volt.	Check for continuity to ground of black wire No. 010. Test HVAC relay.
32. Terminal 86 of left blower motor relay.	Battery voltage.	Check for loose or corroded connection or break in splice or wire between blower switch and relay.
33. Terminal 85 of left blower motor relay.	Less than 0.2 volt.	Check for continuity to ground of black wire No. 010. Test HVAC relay.
34. Male side of single-wire connector between fuse, F13 and right blower motor relay.	Battery voltage.	Check for loose or corroded connection or break in splice or wire between fuse, F13 and connector.
35. Female side of single-wire connector.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
36. Terminal 87 of right blower motor relay.	Battery voltage.	Check for loose or corroded connection or break in wire connector and relay.
37. Terminal 30 of right blower motor relay.	Battery voltage.	Check for loose or corroded terminals. Test right motor blower relay.
38. Male side of single-wire connector between fuse, F13 and right motor blower relay.	Battery voltage.	Check for loose or corroded connection or break in splice or wire between fuse, F13, and connector.
39. Female side of single-wire connector.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
40. Terminal 87 of left blower motor relay.	Battery voltage.	Check for loose or corroded connection or break in wire between connector and relay.
41. Terminal 30 of left blower motor relay.	Battery voltage.	Check for loose or corroded terminals. Test left blower motor relay.

**NOTE:** If necessary to check circuit further, remove evaporator/heater core housing and remove cover from housing. Test blower motors individually with battery voltage. If blower motors are good, check continuity of red wires

Nos. 062 and 032 and ground wires. Check connectors inside housing for loose or corroded terminals. Repair or replace wires or connectors as necessary.

OUO1085,00001A0 -19-25SEP00-5/5

A/C Compressor Clutch Coil Test Points (Tractors With Cab)



A/C COMPRESSOR CLUTCH COIL TEST POINTS (TRACTORS WITH CAB)

LV1614

LV1614 -19-27JUN02

## CONDITIONS:

- Transmission in P, park position.
- PTO disengaged.
- Key switch in RUN position.
- Meter positive lead (red) on numbered test points.
- Engine running.
- A/C temperature control switch in MAX position (fully clockwise).
- Meter negative lead (black) on battery negative (–) post.


- Meter on DC volts.
- Electrical tests and adjustments in this section and group.
- Blower switch in LOW position.
- Ambient air temperature above 3°C (37°F).

**NOTE:** Perform steps 1 through 19 of **BLOWER MOTOR TEST POINTS** to verify circuits between battery and blower switch terminal B are functioning properly.

Test Location	Normal	If Not Normal
1. Terminal 1 of blower switch.	Battery voltage.	Check for loose or corroded connection. Test blower switch.
2. A/C temperature control switch terminal for purple wire No. 227.	Battery voltage.	Check for loose or corroded connection or break in splice or wire between blower switch and A/C temperature control switch.
3. A/C temperature control switch terminal for gray wire No. 228.	Battery voltage.	Check for loose or corroded connection. Test A/C temperature control switch.
4. Left terminal of fuse, F16 (gray wire No. 228).	Battery voltage.	Check for corroded connection or break in wire between A/C temperature control switch and fuse block.
5. Right terminal of fuse, F16 (purple wire No. 217).	Battery voltage.	Check for failed fuse, F16. If fuse is good, check for corroded or damaged terminals.
6. Male pin side of single-wire connector for A/C compressor clutch.	Battery voltage.	Test A/C compressor clutch coil. If good, test A/C high and low pressure switches (A and B). (See procedures in Section 290, Group 15 steps 37 and 38). If good, check continuity of wires and connectors between compressor clutch coil and fuse, F16. Check connections for loose, corroded, or damaged terminals.

OUO1085,00001A1 –19–25SEP00–2/2

### FRONT WIPER/WASHER TEST POINTS (TRACTORS WITH CAB)



LV1615

LV1615 -19-15DEC97

Continued on next page

OUO1085,00001A2 -19-25SEP00-1/4

CONDITIONS:

- Transmission in P, park position.
- PTO disengaged.
- Key switch in RUN position.
- Meter positive lead (red) on numbered test points.
- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

Continued on next page

OUO1085,00001A2 –19–25SEP00–2/4

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Left post of fuse link.	Battery voltage.	Check for loose or corroded terminal, or break in wire between battery and fuse link.
3. Right post of fuse link.	Battery voltage.	Check for loose or corroded terminal, or replace fuse link.
4. Top terminal of 30-amp fuse, F5.	Battery voltage.	Check for loose or corroded terminal or break in splice or wire between fuse link and fuse, F5.
5. Bottom terminal of fuse, F5.	Battery voltage.	Check for failed fuse, F5. If fuse is good, check for loose or corroded terminals.
6. BAT terminal of key switch.	Battery voltage.	Check for corroded connections or break in wire between fuse block and key switch.
7. ACC terminal of key switch.	Battery voltage.	Check that key switch is in the ACCESSORY or RUN position. If switch is in ACCESSORY or RUN, switch is bad. Replace.
8. Terminal 86 of accessory relay.	Battery voltage.	Check for loose or corroded connection or break in wire between relay and key switch.
9. Bottom terminal of fuse, F8.	Battery voltage.	Check for failed fuse, F8. If fuse is good, check for corroded or loose terminals.
10. Terminal 30 of accessory relay.	Battery voltage.	Check for loose or corroded connections or break in wire between relay and fuse block.
11. top terminal of fuse, F12.	Battery voltage.	Check for failed fuse, F12. If fuse is good, check for corroded or loose terminals.
12. Terminal 87 of accessory relay.	Battery voltage.	Check for loose or corroded connections or break in wire between relay fuse and fuse block.
13. Bottom terminal of fuse, F12.	Battery voltage.	Check for failed fuse, F12. If fuse is good, check for corroded or loose terminals.
14. Terminal A of female side of 3-wire connector at bottom of right front cab post.	Battery voltage.	Check for loose or corroded terminal or break in splice or wire between fuse block and connector.
15. Terminal A of male side of 3-wire connector.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
16. Left post of cab junction block (located behind overhead control panel).	Battery voltage.	Check for loose or corroded connection or break in wire between 3-wire connector and junction block.
17. Terminal B of front wiper/washer switch.	Battery voltage.	Check for loose or corroded connection or break in wire between junction block and wiper/washer switch.

Continued on next page

OUO1085,00001A2 -19-25SEP00-3/4

Test Location	Normal	If Not Normal
18. Terminal P of front wiper/washer switch.	Battery voltage.	Check for loose or corroded connections. Test switch.
19. Terminal P of front wiper motor.	Battery voltage.	Check for loose or corroded connection or break in wire between wiper switch and wiper motor.

CONDITIONS:

- Front wiper switch in LOW position.

Test Location	Normal	If Not Normal
20. Terminal L of front wiper/washer switch.	Battery voltage.	Check for loose or corroded connection. Test switch.
21. Terminal L of front wiper motor.	Battery voltage.	Check for loose or corroded connection or break in wire between wiper switch and wiper motor.

CONDITIONS:

- Front wiper switch in HIGH position.

Test Location	Normal	If Not Normal
22. Terminal H of front wiper/washer switch.	Battery voltage.	Check for loose or corroded connection. Test switch.
23. Terminal H of front wiper motor.	Battery voltage.	Check for loose or corroded connection or break in wire between wiper switch and wiper motor.


CONDITIONS:

- Push front wiper switch knob in and hold in WASHER position.

Test Location	Normal	If Not Normal
24. Terminal W of front wiper/washer switch.	Battery voltage.	Check for loose or corroded connection. Test switch.
25. Positive (+) terminal of front washer pump.	Battery voltage.	Check for loose or corroded connection or break in wire between wiper/washer switch and front washer pump.
26. Negative (–) terminal of front washer pump.	Less than 0.2 volt.	Check for loose or corroded connection. Check for continuity to ground through black wire. Test washer pump.

OUO1085,00001A2 –19–25SEP00–4/4

# Rear Wiper/Washer Test Points (Tractors With Cab)



REAR WIPER/WASHER TEST POINTS (TRACTORS WITH CAB)

LV1616

240  
15  
87

LV1616 -19-15DEC97

Continued on next page

OUC1085,00001A3 -19-25SEP00-1/4



CONDITIONS:

- Transmission in P, park position.
- PTO disengaged.
- Key switch in RUN position.
- Meter positive lead (red) on numbered test points.
- Meter negative lead (black) on battery negative (–) post.
- Meter on DC volts.
- Electrical tests and adjustments in this section and group.

Continued on next page

OUO1085,00001A3 –19–25SEP00–2/4

Test Location	Normal	If Not Normal
1. Battery positive post.	Minimum 11.8 VDC.	Test battery and charge if good. Replace bad battery.
2. Left post of fuse link.	Battery voltage.	Check for loose or corroded terminal, or break in wire between battery and fuse link.
3. Right post of fuse link.	Battery voltage.	Check for loose or corroded terminal, or replace fuse link.
4. Top terminal of 30-amp fuse, F5.	Battery voltage.	Check for loose or corroded terminal or break in splice or wire between fuse link and fuse, F5.
5. Bottom terminal of fuse, F5.	Battery voltage.	Check for failed fuse, F5. If fuse is good, check for loose or corroded terminals.
6. BAT terminal of key switch.	Battery voltage.	Check for corroded connections or break in wire between fuse block and key switch.
7. ACC terminal of key switch.	Battery voltage.	Check that key switch is in the ACCESSORY or RUN position. If switch is in ACCESSORY or RUN, switch is bad. Replace key switch.
8. Terminal 86 of accessory relay.	Battery voltage.	Check for loose or corroded connection or break in wire between relay and key switch.
9. Terminal 87 of accessory relay.	Battery voltage.	Check for loose or corroded connection or break in wire between relay and fuse block.
10. Top terminal of fuse, F12.	Battery voltage.	Check for failed fuse, F12. If fuse is good, check for corroded or loose terminals.
11. Bottom terminal of fuse, F8.	Battery voltage.	Check for failed fuse, F8. If fuse is good, check for corroded or loose terminals.
12. Bottom terminal of fuse, F12.	Battery voltage.	Check for failed fuse, F12. If fuse is good, check for corroded or loose terminals.
13. Terminal A of female side of 3-wire connector at bottom of right front cab post.	Battery voltage.	Check for loose or corroded terminal or break in splice or wire between fuse block and connector.
14. Terminal A of male side of 3-wire connector.	Battery voltage.	Make sure connector is fully pushed together. Check for corroded or damaged terminals. Repair or replace connector.
15. Left post of cab junction block (located behind overhead control panel).	Battery voltage.	Check for loose or corroded connection or break in wire between 3-wire connector and junction block.
16. Terminal B of front wiper/washer switch.	Battery voltage.	Check for loose or corroded connection or break in wire between junction block and front wiper/washer switch.
17. Terminal A of 3-wire connector for rear wiper/washer switch.	Battery voltage.	Check for loose or corroded connection or break in wire between front wiper/washer switch and rear wiper/washer switch.

**CONDITIONS:**

- Rear wiper/washer switch in ON position.

Continued on next page

OUO1085,00001A3 -19-25SEP00-3/4

Test Location	Normal	If Not Normal
18. Terminal B of 3-wire connector for rear wiper/washer switch.	Battery voltage.	Check for loose or corroded connection. Test rear wiper/washer switch.
19. Terminal at rear wiper motor.	Battery voltage.	Check for loose or corroded connection or break in wire between rear wiper/washer switch and rear wiper motor. Test motor.

CONDITIONS:

- Hold rear wiper/washer switch in WASHER position.

Test Location	Normal	If Not Normal
20. Terminal C of 3-wire connector for rear wiper/washer switch.	Battery voltage.	Check for loose or corroded connection. Test rear wiper/washer switch.
21. Positive (+) terminal of rear washer pump.	Battery voltage.	Check for loose or corroded connection or break in wire between wiper/washer switch and rear washer pump.
22. Negative (–) terminal of rear washer pump.	Less than 0.2 volt.	Check for loose or corroded connection. Check for continuity to ground through black wire. Test washer pump.

OUO1085,00001A3 –19–25SEP00–4/4

## Battery Voltage and Specific Gravity Tests

### REASON:

To determine condition of battery.

### EQUIPMENT:

- Voltmeter or JT05685 Load Tester
- Hydrometer

### PROCEDURE:


1. Clean battery terminals and top of battery.
2. Inspect battery terminals and case for breakage or cracks.
3. Check electrolyte level in each battery cell. Add clean, soft water as needed. If water is added, charge battery for 20 minutes at 10 amps.
4. If battery has been charged, remove surface charge by turning load knob of tester clockwise until ammeter reads 100 amps. Hold for 15 seconds then turn load knob to off.
5. Check battery voltage with voltmeter or Load Tester.
6. Check and record specific gravity of each cell with a hydrometer.

### Specification


Battery—Minimum Voltage..... 12.4 volts  
Minimum Specific Gravity..... 1.225 with less than 50-point variation

### RESULTS:

- Battery voltage less than 12.4 VDC, charge battery and test again. See Charge Battery in this group.
- Battery voltage more than 12.4 VDC, load test battery. See Battery Load Test in this group.
- All cells less than 1.225 with less than 50-point variation, charge battery at 10-amp rate and test again. See Charge Battery in this group.
- All cells more than 1.225 with less than 50-point variation, load test battery. See Battery Load Test in this group.



Checking Battery Voltage Using Load Tester



Checking Specific Gravity Using an Hydrometer

M49595 -UN-18SEP90

M49596 -UN-18SEP90

240  
15  
91

*Diagnosis, Test and Adjust*

- More than 50-point variation: replace battery.
- If battery fails voltage or specific gravity test after charging, replace battery.

OUO1085,000019F -19-25SEP00-2/2

240  
15  
92

## Charge Battery

### REASON:

To increase battery charge after battery has been discharged.

### EQUIPMENT:

Battery charger (variable rate)

*NOTE: See Battery Voltage and Specific Gravity Tests in this group before charging battery.*

### PROCEDURE:

1. Connect variable rate charger to battery.
2. Start charger at slow rate. Increase charge rate one setting at a time. Check charger ammeter after one minute at each setting. Maintain 10-amp charge rate.
3. Check if battery is accepting a 10-amp charge after 10 minutes.

Battery will not accept 10-amp charge after 10 minutes: replace battery.

Battery is accepting 10-amp charge after 10 minutes, and battery did not need water: go to steps 6 and 7.


Battery is accepting 10-amp charge after 10 minutes, but battery needed water or all cells were below 1.225: go to steps 4 and 5.

4. Set charger at 15—25 amps.

**IMPORTANT: Decrease charge rate if battery gases or bubbles excessively or becomes too warm to touch.**

5. Check specific gravity after 30 minutes (60 minutes for maintenance-free battery).

More than 50-point variation between cells: replace battery.



M49598 -UN-25SEP90

240  
15  
93

Continued on next page

OUO1085,00001A4 -19-25SEP00-1/2

Less than 50-point variation between cells: go to steps 6 and 7.

*NOTE: If battery was discharged at a slow or unknown rate, charge at 10—15 amps for 6—12 hours. (Maintenance-free battery: 12—24 hours.) If battery was discharged at fast rate, charge at 20—25 amps for 2—4 hours. (Maintenance-free battery: 4—8 hours.)*

6. Continue charging battery until specific gravity is 1.225—1.265 points.

7. Load test battery. See Battery Load Test in this group.

OUO1085,00001A4 -19-25SEP00-2/2

## Battery Load Test

### REASON:


To determine battery's ability to withstand a load.

### EQUIPMENT:

JT05685 Load Tester

### CONNECTIONS:

1. Turn load knob (A) of tester counterclockwise to OFF.
2. Connect tester red cable (B) to battery positive post.
3. Connect tester black cable (C) to battery negative (–) post.



A—Tester Load Knob  
B—Tester Red Cable  
C—Tester Black Cable  
D—Amperage  
E—Voltage

### PROCEDURE:

1. Make sure battery passes voltage and specific gravity tests before load testing. See Battery Voltage and Specific Gravity Tests in this group.

**IMPORTANT:** If using another battery tester without a blue, cold cranking rating scale, turn load knob until amperage is equal to **HALF** the battery cold cranking amperage (CCA) rating.

2. Turn load knob of tester clockwise until amperage reading (D) is equal to:
  - a. Cold cranking amperage rating (blue scale).

—OR—

  - b. Three times ampere hour rating (black scale).
3. Hold for 15 seconds, then note voltage reading and turn load knob of tester to off.

### Specification

Battery—Minimum Voltage..... 9.6 volts under load

### RESULTS:

- If the battery passes the test, battery is good.

Continued on next page

OUO1085,00001A5 –19–26SEP00–1/2




*Diagnosis, Test and Adjust*

- If the battery does not pass the test, replace battery.

OUO1085,00001A5 -19-26SEP00-2/2

240  
15  
96

## Starter Amp Draw/RPM Test



LV065AE

## STARTER AMP DRAW/RPM TEST

### REASON:

To determine condition of starter.

### EQUIPMENT:

- JT05685 Load Tester
- JT05719 Tachometer



**CAUTION:** Disconnect fuel shut off solenoid wiring to prevent engine from starting.

**IMPORTANT:** Turn load knob fully counterclockwise before making connections.

*NOTE:* Engine should be at normal operating temperature when performing this test.

### CONNECTIONS:

1. Turn load knob fully counterclockwise.

2. Connect load tester red cable to positive (+) terminal on battery.
3. Connect load tester black cable to negative (–) terminal.
4. Disconnect fuel shut-off solenoid wire from pump.

### PROCEDURE:

1. Check system ground connections. Be sure battery is fully charged.
2. Crank engine. Read and record voltage at meter.
3. Use tachometer to read and record cranking rpm.
4. Turn key switch OFF. Adjust load knob until battery voltage is the same as when engine is cranking. Read and record amperage on meter.

Continued on next page

OUO1085,00001A6 –19–26SEP00–1/2

**Specification**

Starter Draw—Amperage ..... 275 amps at 240 rpm.

5. Turn load knob fully counterclockwise.


- If amp reading is not to specification or to specification but rpm is low, remove starter and perform Starter No-Load Amp Draw RPM Test. (See Starter No-Load Amp Draw/RPM Test in this group.)

RESULTS:

OUO1085,00001A6 -19-26SEP00-2/2

240  
15  
98

## Starter No-Load Amp Draw/RPM Test



A—Jumper Wire

### REASON:

To determine condition of starter.

### EQUIPMENT:

- JT02153 Current Clamp-On Probe or Equivalent
- JT05719 Tachometer

### CONNECTIONS:

1. Disconnect battery negative (–) cable and remove starter from engine.

**NOTE:** Check that battery is fully charged to ensure accuracy of test.

2. Connect positive (+) cable to positive (battery) terminal on starter.
3. Connect negative (–) cable to starter body.
4. Connect jumper cables to battery.

5. Attach current probe to positive cable.

### PROCEDURE:

**IMPORTANT:** Complete this test in 20 seconds or less to prevent starter damage.

1. Use jumper wire (A) to briefly connect positive (+) starter terminal to solenoid terminal “S”.
2. Read and record starter amperage and rpm.


### Starter—Specification

No-Load Draw Maximum—	
Amperage .....	190 amp at 5600 rpm
No-Load Draw Minimum—	
Amperage .....	135 amp at 3600 rpm

### RESULTS:

- If starter amps or rpm are not to specification, repair or replace starter.

## Alternator/Regulator Test



### REASON:

To determine condition of alternator/regulator.

### EQUIPMENT:

- JT05685 Load Tester
- JT02153 Current Clamp-On Probe or equivalent

### CONNECTIONS:

1. Transmission in P, park position.
2. Be sure battery is fully charged and all tractor accessories are off.
3. Turn load knob of battery tester off (fully counterclockwise).
4. Connect red battery tester clamp to positive (+) post of battery.
5. Connect black battery tester clamp to negative (-) post of battery.

6. Attach current probe to large red cable between alternator and starter as shown.

### PROCEDURE:

1. Start and operate engine 2400 rpm.

**IMPORTANT:** Perform this test as quickly as possible to prevent damage to the electrical system components.

2. Slowly turn load knob clockwise until current gun displays maximum current output. Record reading.

**IMPORTANT:** Load system only as necessary to obtain maximum current output. Do not reduce system voltage any lower than 11 volts.

3. Turn load knob off (fully counterclockwise).
4. Let engine run and watch when current gun reading is 10 amps or less.

Continued on next page

OUC1085,00001A7 -19-26JUN02-1/2

LV6142 -JUN-31JAN01

5. Read and record meter voltage.

**Alternator/Regulator—Specification**

Current Output—Amperage..... 10 Amps Minimum at 2400 rpm  
Regulated Voltage—Voltage ..... 14.2—14.8 VDC at 2400 rpm

RESULTS:

- If alternator current output or regulated voltage is not to specifications, replace alternator.

OUO1085,00001A7 -19-26JUN02-2/2

**Starter Solenoid Test**

REASON:


To determine condition of starter solenoid.

PROCEDURE:

1. Test starting system to ensure voltage at solenoid.  
(See Starting System Test Points—Normal Operation in this group.)
2. Turn key to START and listen that solenoid engages and stays engaged.

RESULTS:

- If solenoid does not engage, chatter or click, check the ground cable near battery or replace solenoid.



LV067 -UN-24FEB92

AG,OUO1023,409 -19-26SEP00-1/1

240  
15  
,101

## Starter Relay Test

### REASON:

To check operation of starter relay.

### EQUIPMENT:


- Ohmmeter or continuity tester

### PROCEDURE:


1. Disconnect wires from relay.
2. Check for continuity between two smaller terminals (A).
3. Check for no continuity between two larger terminals (B).
4. Connect a jumper wire from battery positive (+) post to one small terminal. Connect a jumper wire from the other small terminal to negative (–) post. Continuity should now exist between two larger terminals.

### RESULTS:

- If continuity is not correct, replace starter relay.



LV068 –UN-24FEB92



LV069AE –UN-24FEB92

A—Smaller Terminal (2 used)  
B—Larger Terminal (2 used)

LV,24015HA,A44 –19-26SEP00-1/1

## Key Switch Test

### REASON:

To check operation of key switch.

### EQUIPMENT:

- Ohmmeter or continuity tester

### PROCEDURE:


1. Disconnect key switch connector.
2. Use ohmmeter to check continuity between switch terminals (A—G) in OFF, RUN, START, ACCESSORY and AID positions:

KEY SWITCH CONTINUITY	
Switch Position	Continuity Between Terminals
OFF	None
RUN	BAT-IGN-ACC
START	BAT-ST-IGN
ACCESSORY	BAT-ACC
AID-RUN	BAT-AID-IGN-ACC
AID-START	BAT-AID-ST-IGN

### RESULTS:

- If continuity is not present between terminals listed for each switch position, replace key switch.
- If continuity exists between terminals not listed for each switch position, replace switch.

<sup>1</sup>Used on cab tractors only.



A—BAT Terminal (Battery)  
 B—GND Terminal (Not Used)  
 C—AID Terminal (Aid)  
 D—ST Terminal (Start)  
 E—IGN Terminal (Ignition)  
 F—ELX Terminal (HVAC Relay<sup>1</sup>)  
 G—ACC Terminal (Accessory<sup>1</sup>)

LV070 -UN-24FEB92

240  
15  
103



## Plug-In Relay Test

**NOTE:** Manifold heater relay does not have terminal 87A.  
Heater relay can be tested using this test.

**REASON:** To check operation of modular relay.

**EQUIPMENT:**


- Ohmmeter or continuity tester

**PROCEDURE:**


1. Remove relay from connector.
2. Use ohmmeter or continuity tester to check continuity between relay terminals 87A and 30 (A and B); 85 and 86 (C and D).
3. Check for no continuity between terminals 30 and 87 (B and E).
4. Connect a jumper wire from battery positive (+) post to relay terminal 85. Connect a jumper wire from relay terminal 86 to ground (-). Continuity should now exist between terminals 30 and 87; no continuity between 30 and 87A.

**RESULTS:**

- If continuity is not correct, replace relay.



LV061 -UN-24FEB92



A—Terminal 87A  
B—Terminal 30  
C—Terminal 85  
D—Terminal 86  
E—Terminal 87

LV079AE -UN-24FEB92

LV,24015HA,A46 -19-26SEP00-1/1

## Diode Pack Test

### REASON:

To determine condition of diode pack.

### EQUIPMENT:

- Diode tester

### PROCEDURE:

**NOTE:** Terminal positions are indicated on diode pack.


*Not all terminals and diodes of diode pack are used for this tractor. Procedure will discuss only the terminals used.*

Connect meter or tester to each pair of terminals for diodes as indicated in table.

Diode Terminals		Continuity
Black Test Lead	Red Test Lead	
(-)	(+)	
1	2	Yes
2	1	No
2	3	No
3	2	Yes
4	5	Yes
5	4	No
6	5	Yes
5	6	No
7	8	Yes
8	7	No
9	8	Yes
8	9	No

### RESULTS:

- Each diode should have continuity in one direction only.
- If a diode has no continuity or has continuity in both directions, replace diode pack.



LV072 -UN-24FEB92

240  
15  
105

## Fuse Test

### REASON:

To determine if fuse has failed.

### EQUIPMENT:

- Ohmmeter


1. Set ohmmeter to 1X ohms scale.

*NOTE: On analog (swing needle) ohmmeters, set zero point before every test.*

2. Connect one meter lead to one post (A) of fuse.
3. Connect other meter lead to other post (B) of fuse.
4. Read meter.

### RESULTS:

- If there is no continuity between posts, replace fuse.



A—Fuse Post  
B—Fuse Post

M49586 -UN-25SEP90

LV,24015HA,A48 -19-26SEP00-1/1

## Neutral Start Switch Test

### REASON:

To check operation of neutral start switch.

### EQUIPMENT:

- Ohmmeter or continuity tester


### PROCEDURE:

**NOTE:** Test can be performed while switch is installed in transmission. Make sure shift lever is in N (neutral) or P (park) position and key switch is OFF. Plunger can be depressed by moving shift lever into neutral position.

1. Connect test leads to switch terminals (A).
2. Check for no continuity or open switch.
3. Depress switch plunger (B) and check for continuity or closed switch.

### RESULTS:

- If continuity is not correct, replace switch.
- If continuity is correct, check installation of switch or shifter linkage of transmission.



A—Switch Terminal  
B—Switch Plunger

LV073 -UN-24FEB92

240  
15  
107

AG,OUO1023,412 -19-26SEP00-1/1

## PTO Switch Test

### REASON:

To check operation of PTO switch.

### EQUIPMENT:

- Ohmmeter or continuity tester

### PROCEDURE:

1. Disconnect switch connector.


**NOTE:** Only terminals A, C, D, and E are used for this tractor.

2. Check continuity between pair of terminals A and C and terminals D and E with switch lever released and depressed.

Terminals	Switch Arm Position	
	Released	Depressed
A—C	Continuity	No Continuity
D—E	No Continuity	Continuity

### RESULTS:

- If continuity is not correct replace switch.
- If continuity is correct, check for proper installation or bent switch arm.



- A—Terminal A
- B—Terminal B
- C—Terminal C
- D—Terminal D
- E—Terminal E
- F—Terminal F (Not Used)

LV074 -UN-24FEB92

OUO1085,00001A9 -19-26SEP00-1/1

## PTO Seat Switch Test

### REASON:


To check operation of seat switch.

### EQUIPMENT:

- Ohmmeter or continuity tester

### PROCEDURE:

1. Disconnect switch wiring connector.
2. Check continuity between terminals A and B with switch lever released and depressed.



A—Terminal A  
B—Terminal B

Terminals	Switch Arm Position	
	Released	Depressed
A—B	No Continuity	Continuity

### RESULTS:

- If continuity is not correct, replace switch.

LV2335 -UN-20NOV97

240  
15  
,109

OUC1085,00001AA -19-26SEP00-1/1

## Light Switch Test

### REASON:

To check operation of light switch.

### EQUIPMENT:

- Ohmmeter or continuity tester


### PROCEDURE:

1. Disconnect light switch connector.
2. Check continuity between terminals as shown in table. Move switch knob to indicated position when making checks.

Switch Position	Terminals in Continuity
OFF	None
W (Warning)	B-W
F (Work)	B-FL-HD1
H <sub>1</sub> (High Beam)	B-W-HD1-TL
H <sub>2</sub> (Low Beam)	B-W-HD2-TL

### RESULTS:

- If continuity is not correct, replace switch.
- If continuity is correct, check for proper wire connections.



A—B Terminal (Battery)  
 B—FL Terminal (Work Light)  
 C—HD2 Terminal (High Beam)  
 D—TL Terminal (Tail Light)  
 E—HD1 Terminal (Low Beam)  
 F—W Terminal (Warning)

LV076 -UN-24FEB92

LV,24015HA,A52 -19-26SEP00-1/1

## Turn Signal Controller Test

### REASON:

To check operation of turn signal controller.

### EQUIPMENT:

- Ohmmeter or continuity tester


### PROCEDURE:

1. Disconnect turn signal controller connector.
2. Check continuity between terminals as shown in table.  
Move switch knob to indicated position when making checks.

Switch Position	Terminals in Continuity
Off	1-3-4 (through flasher)
Left Turn	1-3-6 (through flasher) 1-2-4 (not through flasher)
Right Turn	1-4-5 (through flasher) 1-2-3 (not through flasher)

### RESULTS:

- If continuity is not correct, replace switch.
- If continuity is correct, check for proper wire connections. If necessary, apply power to terminal 1 or 2 and a load to terminals 3 and 4 to check actual controller operation.



LV077 -UN-24FEB92

240  
15  
,111

LV,25015HA,A53 -19-26SEP00-1/1



## Fuel Shut-Off Solenoid Test

### REASON:

To check operation of fuel shut-off solenoid.

### EQUIPMENT:


- Jumper wire

### PROCEDURE:

1. Turn key switch off.
2. Connect jumper wire to battery positive (+) terminal.
3. Touch jumper wire to fuel shut-off solenoid terminal (A). Listen for the solenoid to “click”.
4. Remove jumper wire from fuel shut-off solenoid terminal. Listen for solenoid to “click” again.

### RESULTS:

- If solenoid does not “click”, service fuel injection pump.



A—Fuel Shut-Off Solenoid Terminal

LV2112 -UN-19MAY97

OUO1085,00001AB -19-26SEP00-1/1

Blower Switch Test

REASON:

To check operation of blower switch.

EQUIPMENT:

- Ohmmeter or continuity tester.


PROCEDURE:

1. Disconnect blower switch connector.
2. Check continuity between terminals as shown in table. Rotate switch knob to indicated position when making checks.

Switch Position	Terminals in Continuity
OFF	None
LOW	B-1-2-3-4
MEDIUM	B-2-3-4
HIGH	B-3-4
PURGE	B-4

RESULTS:

- If continuity is not correct, replace switch.
- If continuity is correct, check for proper wire connections.



Blower Switch Terminals Identification

- A—Terminal B
- B—Terminal #1
- C—Terminal #2
- D—Terminal #3
- E—Terminal #4
- F—W Terminal (Warning)

LV1618 -UN-12FEB96

240  
15  
,113

## Blower Motor Resistors

### REASON:

To check for proper resistance of blower motor resistors.

### EQUIPMENT:

- Ohmmeter

### PROCEDURE:

1. Disconnect connector from blower motor resistors.
2. Check resistance between terminals as shown in table.

Terminals	Resistance (Ohms)
0—1	0.400
0—2	0.000 <sup>a</sup>
0—3	0.175
0—4	0.840
1—2	0.400
1—3	0.225
1—4	0.440
2—3	0.175
2—4	0.840
3—4	0.665
<sup>a</sup> A thermal fuse is located between terminals 0 and 2. If meter reads an open circuit, replace the resistors.	

### RESULTS:

- If resistance is not correct, or if an open circuit is detected between terminals 0 and 2, replace the resistors.
- If resistance is correct, check for proper wire connections.



LV1625 -UN-12FEB96

QUO1085,00001AD -19-26SEP00-1/1

## A/C Thermostatic Control Switch Test

### REASON:

To check operation of thermostatic control switch.

### EQUIPMENT:


- Ohmmeter or continuity tester
- Ice and salt water solution
- Thermometer

### PROCEDURE:

1. Tag and disconnect wires from switch.
2. Carefully remove capillary tube from evaporator/heater core.
3. Connect ohmmeter across switch terminals.
4. Warm end of capillary tube between hands. There should be less than 0.5 ohms across switch terminals when capillary tube is warmed by hand.
5. Insert capillary tube into ice and salt water solution. Switch contacts should be open at minus 1°C (30°F) and close at 3°C (37°F).

### RESULTS:

- If continuity is not correct, replace switch.
- If continuity is correct, check for proper wire connections.



LV1619 -UN-12FEB96

240  
15  
,115

OUO1085,00001AE -19-26SEP00-1/1

## Front Wiper/Washer Switch Test

### REASON:

To check operation of front wiper/washer switch.

### EQUIPMENT:

- Ohmmeter or continuity tester


### PROCEDURE:

1. Tag and disconnect wire from switch.
2. Check continuity between terminals as shown in table. Rotate switch knob to indicated position when making checks. Push switch knob in to test WASHER position.

Switch Position	Terminals in Continuity
OFF	B-P
LOW	B-L
HIGH	B-H
WASHER	B-L-H-W

### RESULTS:

- If continuity is not correct, replace switch.
- If continuity is correct, check for proper wire connections.



A—Terminal B  
B—Terminal P  
C—Terminal L  
D—Terminal H  
E—Terminal W

LV1620 -UN-12FEB96

OUO1085,00001AF -19-26SEP00-1/1

## Rear Wiper/Washer Switch Test

### REASON:

To check operation of rear wiper/washer switch.

### EQUIPMENT:

- Ohmmeter or continuity tester


### PROCEDURE:

1. Disconnect wire connector from switch.
2. Check continuity between terminals as shown in table.  
Move switch to indicated position when making checks.

Switch Position	Terminals in Continuity
OFF	NONE
LOW	A-B
HIGH	A-C

### RESULTS:

- If continuity is not correct, replace switch.
- If continuity is correct, check for proper wire connections.



A—Terminal A  
B—Terminal B  
C—Terminal C

LV1621 -UN-12FEB96

240  
15  
,117

OUC1085,00001B0 -19-26SEP00-1/1

## Door Switch Test

### REASON:

To check operation of door switches.

### EQUIPMENT:


- Ohmmeter or continuity tester

### PROCEDURE:

1. Tag and disconnect wires from switch.
2. Check continuity between terminals with switch in both positions. There should be no continuity with switch in the pressed position (cab door closed). There should be continuity with switch not pressed (cab door open).

### RESULTS:

- If continuity is not correct, replace switch.
- If continuity is correct, check for proper wire connections.



LV1624 -UN-12FEB96

OUO1085,00001B1 -19-26SEP00-1/1

## Dome Light Switch Test

### REASON:

To check operation of dome light switch.

### EQUIPMENT:

- Ohmmeter or continuity tester

### PROCEDURE:


1. Tag and disconnect wires from dome light.

**NOTE:** Test dome light switch with a bulb known to be good. If condition of bulb is not known, test continuity across bulb terminals with switch ON.

2. Check continuity between ground terminal and dome light switch terminal with dome light switch in both ON positions. There should be continuity with switch in either of its two ON positions.

### RESULTS:

- If continuity is not correct, replace switch.
- If continuity is correct, check for proper wire connections.



A—Dome Light Switch Terminal  
B—Ground Terminal  
C—Door Switch Terminal

LV1623 -UN-12FEB96

240  
15  
,119

OUO1085,00001B2 -19-26SEP00-1/1



240  
15  
,120

Schematic Information

The wiring schematics are drawn with the battery positive circuit across the top and the ground, or battery negative, circuit across the bottom. The flow is then, as much as possible, from top to bottom through each circuit and component. All components are shown in their normal (de-energized) position.

The circuit numbers used in the schematics represent entire circuit sections using the same number. Actual circuits may have letter suffixes added to indicate specific portions of the circuit. For the exact designation, refer to Group 15 in this section or to the tractor wiring harness.

LV,24020HA,A0    –19–04JUN96–1/1

Component Identification Table

Each component (electrical device) and main connector will have an identification letter assigned to it. A number is added to the letter to separate and indicate the total components within that letter group.

Continued on next page                      TX,901505,QQ383    –19–26SEP00–1/2


240  
20  
1

## Wiring Schematics

Identification Letter	Type	Examples
A	System, subassembly, parts group	Control units, trigger boxes, two-way radios, logic module, FNR logic module
B	Transducer for conversion of non-electrical variables to electrical and vice versa	Speed sensors, pressure sensors, pressure switches, horns, sensors, pickups, limit-value sensors, pulse generators, loudspeakers, inductive pickups, probes, air-flow sensors, oil-pressure switches, temperature sensors, ignition-voltage pickups
C	Condenser, capacitor	Condensers and capacitors, general
D	Binary device, memory	Digital devices, integrated circuits, pulse counters, magnetic tape recorders
E	Various devices and equipment	Heating devices, air conditioners, light, headlights, spark plugs, ignition distributors
F	Protection device	Release mechanisms, polarity protection devices, fuses, current protection circuits
G	Power supply, generator	Batteries, generators, alternators, charging units
H	Monitor, alarm, signalling device	Audible alarms, indicator lights, turn-signal lights, brake lights, alarms, warning lights, buzzers
K	Relay	Battery relays, turn-signal relays, solenoid switches, starting relays, warning flashers
L	Inductor	Choke coils, coils, windings
M	Motor	Blower motors, fan motors, starter motors
N	Regulator, amplifier	Regulators (electronic or electromechanical), voltage stabilizers
P	Measuring instrument	Ammeter, diagnostic connectors, tachometers, fuel gauge, pressure gauges, measuring points, test points, speedometers
R	Resistor	Flame glow plugs, sheathed-element flame glow plugs, glow plugs, heating resistors, NTC resistors, PTC resistors, potentiometers, regulating resistors
S	Switch	Switches and pushbuttons, general key switch, light switch, horn switch, flasher switch
T	Transformer	Ignition coil, ignition transformer
U	Modulator, converter	DC transformers
V	Semiconductor, electron tubes	Transistors, diodes, electron tubes, rectifiers, semiconductors, thyristors, zener diodes
W	Transmission path, conductor, antenna	Antennas, shielding components, shielded conductors, cable harnesses, conductors, ground conductors
X	Terminal, plug, plug and socket connection	Terminal studs, electrical connections, connectors electrical line couplers, line connectors, sockets, plugs, terminals, plug-and-socket connections
Y	Electrically actuated mechanical device	Permanent magnets, (solenoid-operated) injection valves, electromagnetic clutches and brakes, air valves, fuel pumps, solenoids, switching valves, start valves, locking systems
Z	Electrical filter	Interference suppression filters








## SE1 - POWER AND STARTING CIRCUIT

LV2220

This page is intentionally left blank.




## SE2 - LIGHTING AND ACCESSORY CIRCUITS



This page is intentionally left blank.

**5510 Electrical Schematics and Legend (Tractors Without Cab)**

I-10JUL02

**SE3 – CHARGING AND INSTRUMENT CIRCUITS**

OUO1085,00001B3 -19-26SEP00-1/2

26APR04)

**240-20-4**

5210, 5310, 5410, and 5510 Tractors

**Page 240-20-4 C**042604  
PN=1008

This page is intentionally left blank.


B1—Horn/Timer	H3—Left Warn/Turn Light	X4—2-Wire Metripack Connector, Engine Speed Sensor	X19—1-Wire Bullet Connector, Chassis to Tail Light
B2—Horn (optional)	H4—Left Turn Indicator	X5—2-Wire Connector, at Alternator	X20—1-Wire Bullet Connector, Coolant Temperature Sender
B3—Coolant Temp Sender	H5—Right Warn/Turn Light	X6—2-Wire Metripack Connector, at Rear of Engine	X21—1-Wire Bullet Connector, Engine Oil Pressure Switch
B4—Engine Speed Sensor	H6—Right Turn Indicator	X7—10-Wire Metripack Connector, at Rear of Engine	X22—7-Wire Connector to Trailer Harness
B5—Engine Oil Pressure Switch	H7—Charge Indicator	X8—4-Wire Connector, at Fuel Shut-Off Relay	X23—2-Wire Weather Pack Connector at Neutral Start Switch
E1—Left Headlight	H8—Oil Pressure Indicator	X9—4-Wire Connector, at Bypass Start Relay	X24—2-Wire Metripack Connector at Horn/Timer
E2—Left Headlight	H9—Air Filter Restriction Indicator	X10—5-Wire Connector, at Diode Pack	X25—2-Wire Weather Pack Connector at Seat Switch
E3—Tail Light	K1—Manifold Heater Relay	X11—4-Wire Connector, to Accessory Relay	X26—1-Wire Bullet Connector, Left Fender Flood Light (+) <sup>1</sup>
E4—Rear Work Light	K2—Fuel Shut-Off Relay	X12—10-Wire Connector, Instrument Panel	X27—1-Wire Bullet Connector, Right Fender Flood Light (+) <sup>1</sup>
E5—Instrument Light	K3—Bypass Start Relay	X13—4-Wire Connector at Key Switch	X28—1-Wire Bullet Connector, Left Fender Flood Light (-) <sup>1</sup>
E6—Instrument Light	K4—Start Relay	X14—4-Wire Connector at Turn Signal Controller	X29—1-Wire Bullet Connector, Rear Work Light (-)
E7—Left Fender Flood Light <sup>1</sup>	K5—Accessory Relay	X15—4-Wire Metripack Connector, PTO Switch to Main Harness	X30—1-Wire Bullet Connector, Right Fender Flood Light (-) <sup>1</sup>
E8—Right Fender Flood Light <sup>1</sup>	K6—Turn Signal Controller	X16—1-Wire Bullet Connector, Right Turn Feed to ROPS Lead	X31—6-Wire Connector at Instrument Panel
F1—10-Amp Fuse	M1—Starter	X17—1-Wire Bullet Connector, Rear Work Light (+)	Y1—Fuel Shut-Off Solenoid
F2—20-Amp Fuse	P1—Hourmeter	X18—1-Wire Bullet Connector, Left Turn Feed to ROPS Lead	
F3—20-Amp Fuse	P2—Temperature Gauge		
F4—20-Amp Fuse	P3—Fuel Gauge		
F5—Optional 30-Amp Auxiliary Power Lead	P4—Fuel Level Sender		
F6—30-Amp Fuse	P5—Tachometer		
F7—30-Amp Fuse	R1—Manifold Heater		
F8—30-Amp Fuse	S1—Key Switch		
F9—20-Amp Fuse	S2—Rear PTO Switch		
F10—20-Amp Fuse	S3—Seat Safety Switch		
F11—20-Amp Fuse	S4—Neutral Start Switch		
F12—Optional 20-Amp Auxiliary Power Lead	S5—Light Switch		
F13—Fuse Link	S6—Horn Switch (Optional)		
G1—12-Volt Battery	S7—Air Filter Restriction Switch		
G2—Alternator/Regulator	V1—Diode Pack		
H1—PTO Indicator	X1—2-Wire Weather Pack Connector at Air Filter Restriction Switch		
H2—High Beam Indicator	X2—3-Wire Connector, Right Headlight		
	X3—3-Wire Connector, Left Headlight		

<sup>1</sup>5510 without cab only

OUO1085,00001B3 -19-26SEP00-2/2

# 5210—5510 Electrical Schematic and Legend (Tractors With Cab)

LV222 -JA-10A,02



## SE1 - POWER SUPPLY, STARTING AND CHARGING

## SE2 - LIGHTING AND ACCESSORIES

LV222

See Page 240-20-6 A

See Page 240-20-6 B

TM1716 (26APR04)


240-20-6

5210, 5310, 5410, and 5510 Tractors  
PN-1010

See Page 240-20-6 C



This page is intentionally left blank.






This page is intentionally left blank.

# 5510 Electrical Schematic and Legend (Tractors With Cab)

-UN-10JUL02



## LIGHTING AND ACCESSORIES

This page is intentionally left blank.

<b>B1</b> — Horn Timer	<b>G2</b> — Alternator/Regulator
<b>B2</b> — Horn (optional)	<b>H1</b> — PTO Indicator Light
<b>B3</b> — Coolant Temperature Sender	<b>H2</b> — Charge Indicator Light
<b>B4</b> — Fuel Level Sender	<b>H3</b> — High Beam Indicator
<b>B5</b> — Engine Speed Magnetic Pickup	<b>H4</b> — Left Turn Indicator
<b>B6</b> — Engine Oil Pressure Sender	<b>H5</b> — Right Turn Indicator
<b>B7</b> — Air Filter Restriction Switch	<b>H6</b> — Oil Pressure Indicator Light
<b>B8</b> — A/C Low Pressure Switch	<b>H7</b> — Air Filter Restriction Indicator Light
<b>B9</b> — A/C High Pressure Switch	<b>K1</b> — Manifold Heater Relay
<b>E1</b> — Left Front Low Beam Light	<b>K2</b> — Fuel Shutoff Relay
<b>E2</b> — Left Front High Beam Light	<b>K3</b> — Bypass Start Relay
<b>E3</b> — Right Front Low Beam Light	<b>K4</b> — Start Relay
<b>E4</b> — Right Front High Beam Light	<b>K5</b> — Accessory Relay
<b>E5</b> — Left Tail Light	<b>K6</b> — Turn Signal Controller
<b>E6</b> — Right Tail Light	<b>K7</b> — HVAC Relay
<b>E7</b> — Left Front Warn/Turn Light	<b>K8</b> — Blower Motor Relay #1
<b>E8</b> — Left Rear Warn/Turn Light	<b>K9</b> — Blower Motor Relay #2
<b>E9</b> — Right Front Warn/Turn Light	<b>K10</b> — Flood Light Relay
<b>E10</b> — Right Rear Warn/Turn Light	<b>M1</b> — Starter Motor
<b>E11</b> — Instrument Light	<b>M2</b> — Left Blower Motor
<b>E12</b> — Instrument Light	<b>M3</b> — Right Blower Motor
<b>E13</b> — Left Rear Flood Light	<b>M4</b> — Front Wiper Motor
<b>E14</b> — Right Rear Flood Light	<b>M5</b> — Front Washer Pump
<b>E15</b> — Left Front Flood Light	<b>M6</b> — Rear Wiper Motor
<b>E16</b> — Right Front Flood Light	<b>M7</b> — Rear Washer Pump
<b>E17</b> — Dome Light	<b>P1</b> — Hour Meter
<b>F1</b> — 10-Amp Fuse for Instrument Panel	<b>P2</b> — Temperature Gauge
<b>F2</b> — 20-Amp Fuse for Ignition Circuits	<b>P3</b> — Fuel Gauge
<b>F3</b> — 20-Amp Fuse for Warn/Turn Lights	<b>P4</b> — Tachometer
<b>F4</b> — 20-Amp Fuse for Flood Light Relay	<b>R1</b> — Manifold Heater
<b>F5</b> — 30-Amp Fuse for Dome Light and Convenience Outlet	<b>R2</b> — Blower Motor Resistor
<b>F6</b> — 30-Amp Fuse for Key Switch	<b>S1</b> — Key Switch
<b>F7</b> — 30-Amp Fuse for Light Switch	<b>S2</b> — Rear PTO Switch
<b>F8</b> — 30-Amp Fuse for Accessories	<b>S3</b> — Seat Switch
<b>F9</b> — 20-Amp Fuse for Tail Lights	<b>S4</b> — Neutral Start Switch
<b>F10</b> — 20-Amp Fuse for High Beam Head Lights	<b>S5</b> — Light Switch
<b>F11</b> — 20-Amp Fuse for Low Beam Head Lights	<b>S6</b> — Horn Switch (optional)
<b>F12</b> — 20-Amp Fuse for Radio and Wipers	<b>S7</b> — Blower Switch
<b>F13</b> — 30-Amp Fuse for Blower Switch and Left Blower Motor	<b>S8</b> — A/C Thermostatic Control
<b>F14</b> — 30-Amp Fuse for Flood Lights	<b>S9</b> — Front Wiper/Washer Switch
<b>F15</b> — 30-Amp Fuse for Right Blower Motor	<b>S10</b> — Rear Wiper/Washer Switch
<b>F16</b> — 10-Amp Fuse for A/C Compressor Clutch	<b>S12</b> — Dome Light Switch
<b>F17</b> — Fuse Link	<b>S13</b> — Left Door Switch
<b>G1</b> — Battery	<b>S14</b> — Right Door Switch
	<b>V1</b> — Diode Pack
	<b>X1</b> — Ring Terminals at Fuse Link (2 used)

Continued on next page

OUO1085,00001B4 -19-26SEP00-2/8

**X2** — 8-Wire Connector at Key Switch  
**X3** — 1-Wire Connector for Key Switch Ground  
**X4** — 10-Wire Connector, Rear Harness-to-Front Harness  
**X5** — Single Wire Connectors at Manifold Heater Relay (2 used)  
**X6** — Single Wire Connectors at Manifold Heater Relay (2 used)  
**X7** — Ring Terminal at Manifold Heater  
**X8** — 6-Wire Connector at Rear PTO Switch  
**X9** — 3-Wire Connector at Seat Switch  
**X10** — 2-Wire Connector at Horn Timer  
**X11** — 10-Wire Connector at Instrument Panel  
**X12** — 2-Wire Connector at Neutral Start Switch  
**X13** — Ring Terminal at Start Relay (4 used)  
**X14** — 5-Wire Connector at Bypass Start Relay #1  
**X15** — 9-Wire Connector at Diode Pack  
**X16** — 5-Wire Connector at Bypass Start Relay #2  
**X17** — Ring Terminal at Fuel Shut-Off Solenoid  
**X18** — Ring Terminal at Starter Motor (2 used)  
**X19** — Ring Terminal at Alternator  
**X20** — 2-Wire Connector, Rear Harness-to-Front Harness  
**X21** — 2-Wire Connector at Alternator  
**X22** — 1-Wire Connector at Light Switch (6 used)  
**X23** — 1-Wire Connector at Horn Switch (2 used)  
**X24** — 1-Wire Connector at Horn  
**X25** — 3-Wire Connector at Left Headlight  
**X26** — 3-Wire Connector at Right Headlight  
**X27** — 5-Wire Connector at Accessory Relay  
**X28** — 1-Wire Connector, Rear Harness-to-Tail Light Harness  
**X29** — 1-Wire Connector at Left Tail Light  
**X30** — 1-Wire Connector at Right Tail Light (—)  
**X31** — 1-Wire Connector at Left Tail Light Ground  
**X32** — 1-Wire Connector at Right Tail Light Ground  
**X33** — 6-Wire Connector at Turn Signal Controller  
**X34** — 1-Wire Connector, Rear Harness-to-Cab Harness, Left Cab Post  
**X35** — 1-Wire Connector, Rear Harness-to-Cab Harness, Right Cab Post  
**X36** — 2-Wire Connector at Left Front Warn/Turn Light  
**X37** — Ring Terminal at Left Front Warn/Turn Light Ground  
**X38** — 2-Wire Connector at Left Rear Warn/Turn Light

**X39** — Ring Terminal at Left Rear Warn/Turn Light Ground  
**X40** — 2-Wire Connector at Right Front Warn/Turn Light  
**X41** — Ring Terminal at Right Front Warn/Turn Light Ground  
**X42** — 2-Wire Connector at Right Rear Warn/Turn Light  
**X43** — Ring Terminal at Right Rear Warn/Turn Light Ground  
**X44** — 1-Wire Connector at Water Temperature Sender  
**X45** — Ring Terminals at Fuel Gauge Sender (2 used)  
**X46** — 2-Wire Connector at Engine Speed Magnetic Pickup  
**X47** — 1-Wire Connector at Engine Oil Pressure Sender  
**X48** — 2-Wire Connector at Air Filter Restriction Switch  
**X49** — 3-Wire Connector, Rear Harness-to-Cab Harness, Right Cab Post  
**X50** — 1-Wire Connector, Rear Harness-to-Cab Harness, Left Cab Post  
**X51** — 5-Wire Connector at HVAC Relay  
**X52** — Ring Terminal at HVAC Relay Ground  
**X53** — 5-Wire Connector at Blower Switch  
**X54** — 1-Wire Connector at Left Blower Relay  
**X55** — 1-Wire Connector at Right Blower Relay  
**X56** — 5-Wire Connector at Left Blower Relay  
**X57** — 5-Wire Connector at Right Blower Relay  
**X58** — 2-Wire Connector at Left Blower Motor  
**X59** — 2-Wire Connector at Right Blower Motor  
**X60** — 4-Wire Connector at Blower Motor Resistors  
**X61** — 1-Wire Connector at A/C Temperature Control  
**X62** — 1-Wire Connector at A/C Temperature Control  
**X63** — 1-Wire Connector, Rear Harness-to-Cab Harness, Right Cab Post  
**X64** — 1-Wire Connector, Rear Harness-to-Front Harness  
**X65** — 2-Wire Connector at A/C Low Pressure Switch  
**X66** — 2-Wire Connector at A/C High Pressure Switch  
**X67** — 1-Wire Connector at A/C Compressor Clutch  
**X68** — 1-Wire Connector at Front Wiper Switch (5 used)  
**X69** — 3-Wire Connector at Front Wiper Motor  
**X70** — 2-Wire Connector at Front Washer Pump

Continued on next page


OUO1085,00001B4 -19-26SEP00-3/8

<b>X71</b> — Ring Terminal at Front Washer Pump Ground	<b>X85</b> — 2-Wire Connector at Right Speaker
<b>X72</b> — 3-Wire Connector at Rear Wiper Switch	<b>X86</b> — 2-Wire Connector at Left Speaker
<b>X73</b> — 1-Wire Connector at Rear Wiper Motor	<b>X87</b> — 1-Wire Connector at Dome Light
<b>X74</b> — 2-Wire Connector Rear Washer Pump	<b>X88</b> — 1-Wire Connector at Left Door Switch
<b>X75</b> — Ring Terminal at Rear Washer Pump Ground	<b>X89</b> — Ring Terminal at Left Door Switch Ground
<b>X77</b> — 5-Wire Connector at Flood Light Relay	<b>X90</b> — 1-Wire Connector at Right Door Switch
<b>X80</b> — 1-Wire Connector at Left Rear Flood Light	<b>X91</b> — Ring Terminal at Right Door Switch Ground
<b>X81</b> — 1-Wire Connector at Right Rear Flood Light	<b>X92</b> — 7-Wire Trailer Outlet Connector
<b>X82</b> — 1-Wire Connector at Left Front Flood Light	<b>X93</b> — 6-Wire Connector at Instrument Panel
<b>X83</b> — 1-Wire Connector at Right Front Flood Light	<b>Y1</b> — Fuel Shut-Off Solenoid
<b>X84</b> — Ring Terminal at Radio (3 used)	<b>Y2</b> — A/C Compressor Clutch Coil

Continued on next page

OUC1085,00001B4 -19-26SEP00-4/8






SE3 - INSTRUMENTATION

SE4

LV2223




This page is intentionally left blank.



This page is intentionally left blank.

I-21NOV97



## SE5 - CAB ACCESSORIES

Continued on next page

OUC1085,00001B4 -19-26SEP00-5/8

26APR04)

240-20-10

5210, 5310, 5410, and 5510 Tractors

Page 240-20-10 C

042604  
PN=1014

This page is intentionally left blank.

<b>B1</b> — Horn Timer	<b>G2</b> — Alternator/Regulator
<b>B2</b> — Horn (optional)	<b>H1</b> — PTO Indicator Light
<b>B3</b> — Coolant Temperature Sender	<b>H2</b> — Charge Indicator Light
<b>B4</b> — Fuel Level Sender	<b>H3</b> — High Beam Indicator
<b>B5</b> — Engine Speed Magnetic Pickup	<b>H4</b> — Left Turn Indicator
<b>B6</b> — Engine Oil Pressure Sender	<b>H5</b> — Right Turn Indicator
<b>B7</b> — Air Filter Restriction Switch	<b>H6</b> — Oil Pressure Indicator Light
<b>B8</b> — A/C Low Pressure Switch	<b>H7</b> — Air Filter Restriction Indicator Light
<b>B9</b> — A/C High Pressure Switch	<b>K1</b> — Manifold Heater Relay
<b>E1</b> — Left Front Low Beam Light	<b>K2</b> — Fuel Shutoff Relay
<b>E2</b> — Left Front High Beam Light	<b>K3</b> — Bypass Start Relay
<b>E3</b> — Right Front Low Beam Light	<b>K4</b> — Start Relay
<b>E4</b> — Right Front High Beam Light	<b>K5</b> — Accessory Relay
<b>E5</b> — Left Tail Light	<b>K6</b> — Turn Signal Controller
<b>E6</b> — Right Tail Light	<b>K7</b> — HVAC Relay
<b>E7</b> — Left Front Warn/Turn Light	<b>K8</b> — Blower Motor Relay #1
<b>E8</b> — Left Rear Warn/Turn Light	<b>K9</b> — Blower Motor Relay #2
<b>E9</b> — Right Front Warn/Turn Light	<b>K10</b> — Flood Light Relay
<b>E10</b> — Right Rear Warn/Turn Light	<b>M1</b> — Starter Motor
<b>E11</b> — Instrument Light	<b>M2</b> — Left Blower Motor
<b>E12</b> — Instrument Light	<b>M3</b> — Right Blower Motor
<b>E13</b> — Left Rear Flood Light	<b>M4</b> — Front Wiper Motor
<b>E14</b> — Right Rear Flood Light	<b>M5</b> — Front Washer Pump
<b>E15</b> — Left Front Flood Light	<b>M6</b> — Rear Wiper Motor
<b>E16</b> — Right Front Flood Light	<b>M7</b> — Rear Washer Pump
<b>E17</b> — Dome Light	<b>P1</b> — Hour Meter
<b>F1</b> — 10-Amp Fuse for Instrument Panel	<b>P2</b> — Temperature Gauge
<b>F2</b> — 20-Amp Fuse for Ignition Circuits	<b>P3</b> — Fuel Gauge
<b>F3</b> — 20-Amp Fuse for Warn/Turn Lights	<b>P4</b> — Tachometer
<b>F4</b> — 20-Amp Fuse for Flood Light Relay	<b>R1</b> — Manifold Heater
<b>F5</b> — 30-Amp Fuse for Dome Light and Convenience Outlet	<b>R2</b> — Blower Motor Resistor
<b>F6</b> — 30-Amp Fuse for Key Switch	<b>S1</b> — Key Switch
<b>F7</b> — 30-Amp Fuse for Light Switch	<b>S2</b> — Rear PTO Switch
<b>F8</b> — 30-Amp Fuse for Accessories	<b>S3</b> — Seat Switch
<b>F9</b> — 20-Amp Fuse for Tail Lights	<b>S4</b> — Neutral Start Switch
<b>F10</b> — 20-Amp Fuse for High Beam Head Lights	<b>S5</b> — Light Switch
<b>F11</b> — 20-Amp Fuse for Low Beam Head Lights	<b>S6</b> — Horn Switch (optional)
<b>F12</b> — 20-Amp Fuse for Radio and Wipers	<b>S7</b> — Blower Switch
<b>F13</b> — 30-Amp Fuse for Blower Switch and Left Blower Motor	<b>S8</b> — A/C Thermostatic Control
<b>F14</b> — 30-Amp Fuse for Flood Lights	<b>S9</b> — Front Wiper/Washer Switch
<b>F15</b> — 30-Amp Fuse for Right Blower Motor	<b>S10</b> — Rear Wiper/Washer Switch
<b>F16</b> — 10-Amp Fuse for A/C Compressor Clutch	<b>S12</b> — Dome Light Switch
<b>F17</b> — Fuse Link	<b>S13</b> — Left Door Switch
<b>G1</b> — Battery	<b>S14</b> — Right Door Switch
	<b>V1</b> — Diode Pack
	<b>X1</b> — Ring Terminals at Fuse Link (2 used)

Continued on next page

OUO1085,00001B4 -19-26SEP00-6/8

- X2** — 8-Wire Connector at Key Switch  
**X3** — 1-Wire Connector for Key Switch Ground  
**X4** — 10-Wire Connector, Rear Harness-to-Front Harness  
**X5** — Single Wire Connectors at Manifold Heater Relay (2 used)  
**X6** — Single Wire Connectors at Manifold Heater Relay (2 used)  
**X7** — Ring Terminal at Manifold Heater  
**X8** — 6-Wire Connector at Rear PTO Switch  
**X9** — 3-Wire Connector at Seat Switch  
**X10** — 2-Wire Connector at Horn Timer  
**X11** — 10-Wire Connector at Instrument Panel  
**X12** — 2-Wire Connector at Neutral Start Switch  
**X13** — Ring Terminal at Start Relay (4 used)  
**X14** — 5-Wire Connector at Bypass Start Relay #1  
**X15** — 9-Wire Connector at Diode Pack  
**X16** — 5-Wire Connector at Bypass Start Relay #2  
**X17** — Ring Terminal at Fuel Shut-Off Solenoid  
**X18** — Ring Terminal at Starter Motor (2 used)  
**X19** — Ring Terminal at Alternator  
**X20** — 2-Wire Connector, Rear Harness-to-Front Harness  
**X21** — 2-Wire Connector at Alternator  
**X22** — 1-Wire Connector at Light Switch (6 used)  
**X23** — 1-Wire Connector at Horn Switch (2 used)  
**X24** — 1-Wire Connector at Horn  
**X25** — 3-Wire Connector at Left Headlight  
**X26** — 3-Wire Connector at Right Headlight  
**X27** — 5-Wire Connector at Accessory Relay  
**X28** — 1-Wire Connector, Rear Harness-to-Tail Light Harness  
**X29** — 1-Wire Connector at Left Tail Light  
**X30** — 1-Wire Connector at Right Tail Light (—)  
**X31** — 1-Wire Connector at Left Tail Light Ground  
**X32** — 1-Wire Connector at Right Tail Light Ground  
**X33** — 6-Wire Connector at Turn Signal Controller  
**X34** — 1-Wire Connector, Rear Harness-to-Cab Harness, Left Cab Post  
**X35** — 1-Wire Connector, Rear Harness-to-Cab Harness, Right Cab Post  
**X36** — 2-Wire Connector at Left Front Warn/Turn Light  
**X37** — Ring Terminal at Left Front Warn/Turn Light Ground  
**X38** — 2-Wire Connector at Left Rear Warn/Turn Light  
**X39** — Ring Terminal at Left Rear Warn/Turn Light Ground  
**X40** — 2-Wire Connector at Right Front Warn/Turn Light  
**X41** — Ring Terminal at Right Front Warn/Turn Light Ground  
**X42** — 2-Wire Connector at Right Rear Warn/Turn Light  
**X43** — Ring Terminal at Right Rear Warn/Turn Light Ground  
**X44** — 1-Wire Connector at Water Temperature Sender  
**X45** — Ring Terminals at Fuel Gauge Sender (2 used)  
**X46** — 2-Wire Connector at Engine Speed Magnetic Pickup  
**X47** — 1-Wire Connector at Engine Oil Pressure Sender  
**X48** — 2-Wire Connector at Air Filter Restriction Switch  
**X49** — 3-Wire Connector, Rear Harness-to-Cab Harness, Right Cab Post  
**X50** — 1-Wire Connector, Rear Harness-to-Cab Harness, Left Cab Post  
**X51** — 5-Wire Connector at HVAC Relay  
**X52** — Ring Terminal at HVAC Relay Ground  
**X53** — 5-Wire Connector at Blower Switch  
**X54** — 1-Wire Connector at Left Blower Relay  
**X55** — 1-Wire Connector at Right Blower Relay  
**X56** — 5-Wire Connector at Left Blower Relay  
**X57** — 5-Wire Connector at Right Blower Relay  
**X58** — 2-Wire Connector at Left Blower Motor  
**X59** — 2-Wire Connector at Right Blower Motor  
**X60** — 4-Wire Connector at Blower Motor Resistors  
**X61** — 1-Wire Connector at A/C Temperature Control  
**X62** — 1-Wire Connector at A/C Temperature Control  
**X63** — 1-Wire Connector, Rear Harness-to-Cab Harness, Right Cab Post  
**X64** — 1-Wire Connector, Rear Harness-to-Front Harness  
**X65** — 2-Wire Connector at A/C Low Pressure Switch  
**X66** — 2-Wire Connector at A/C High Pressure Switch  
**X67** — 1-Wire Connector at A/C Compressor Clutch  
**X68** — 1-Wire Connector at Front Wiper Switch (5 used)  
**X69** — 3-Wire Connector at Front Wiper Motor  
**X70** — 2-Wire Connector at Front Washer Pump

Continued on next page

OUO1085,00001B4 -19-26SEP00-7/8

<b>X71</b> — Ring Terminal at Front Washer Pump Ground	<b>X85</b> — 2-Wire Connector at Right Speaker
<b>X72</b> — 3-Wire Connector at Rear Wiper Switch	<b>X86</b> — 2-Wire Connector at Left Speaker
<b>X73</b> — 1-Wire Connector at Rear Wiper Motor	<b>X87</b> — 1-Wire Connector at Dome Light
<b>X74</b> — 2-Wire Connector Rear Washer Pump	<b>X88</b> — 1-Wire Connector at Left Door Switch
<b>X75</b> — Ring Terminal at Rear Washer Pump Ground	<b>X89</b> — Ring Terminal at Left Door Switch Ground
<b>X77</b> — 5-Wire Connector at Flood Light Relay	<b>X90</b> — 1-Wire Connector at Right Door Switch
<b>X80</b> — 1-Wire Connector at Left Rear Flood Light	<b>X91</b> — Ring Terminal at Right Door Switch Ground
<b>X81</b> — 1-Wire Connector at Right Rear Flood Light	<b>X92</b> — 7-Wire Trailer Outlet Connector
<b>X82</b> — 1-Wire Connector at Left Front Flood Light	<b>X93</b> — 6-Wire Connector at Instrument Panel
<b>X83</b> — 1-Wire Connector at Right Front Flood Light	<b>Y1</b> — Fuel Shut-Off Solenoid
<b>X84</b> — Ring Terminal at Radio (3 used)	<b>Y2</b> — A/C Compressor Clutch Coil

OUO1085,00001B4 -19-26SEP00-8/8





# Section 250

## Power Train Operation, Tests, and Adjustments

### Contents

	Page	Page
<b>Group 05—Component Location—Collar Shift and SyncShuttle™ Transmissions</b>		
Component Location Information . . . . .	250-05-1	
Power Train Components . . . . .	250-05-2	
Clutch Components . . . . .	250-05-4	
Transmission Components—Collar Shift . . . . .	250-05-6	
Transmission Components—SyncShuttle™ (SS) . . . . .	250-05-8	
Final Drive Components . . . . .	250-05-10	
Rear PTO Components . . . . .	250-05-11	
Rear 540/540E PTO Components (SyncShuttle™ Transmission Only) . . . . .	250-05-12	
<b>Group 06—Component Location—PowrReverser™ Transmission</b>		
Component Location Information . . . . .	250-06-1	
Power Train Components—PowrReverser™ Transmission . . . . .	250-06-2	
Clutch Components—PowrReverser™ Transmission . . . . .	250-06-4	
PowrReverser™ Components . . . . .	250-06-6	
Transmission Components—PowrReverser™ Transmission . . . . .	250-06-8	
Final Drive Components . . . . .	250-06-9	
Rear PTO Components . . . . .	250-06-9	
<b>Group 10—Theory of Operation—Collar Shift and SyncShuttle™ Transmissions</b>		
Theory of Operation Information . . . . .	250-10-1	
Clutch Operation . . . . .	250-10-2	
Transmission Lubrication System . . . . .	250-10-10	
Transmission Power Flow—Gear Shift (Collar) . . . . .	250-10-12	
Transmission Power Flow—Gear Shift (SyncShuttle™) . . . . .	250-10-14	
SyncShuttle™ Transmission Synchronizer Operation—Reverse and 2nd Gear (Disk-and-Plate Type Synchronizer) . . . . .	250-10-16	
SyncShuttle™ Transmission Synchronizer Operation—1st and 3rd Gear (Cone-Type Synchronizer) . . . . .	250-10-18	
Transmission Power Flow—Range Shift . . . . .	250-10-20	
Rear PTO Operation . . . . .	250-10-22	
Rear 540/540E PTO Operation (SyncShuttle™ Transmission Only) . . . . .	250-10-24	
Differential Power Flow . . . . .	250-10-26	
Differential Lock Operation . . . . .	250-10-28	
Final Drive Operation . . . . .	250-10-30	
Mechanical Front Wheel Drive (MFWD) Operation . . . . .	250-10-32	
<b>Group 11—Theory of Operation—PowrReverser™ Transmission</b>		
Theory of Operation Information . . . . .	250-11-1	
Clutch Operation—PTO Clutch Engaged (PowrReverser™ Transmission) . . . . .	250-11-2	
Clutch Operation—PTO Clutch Disengaged (PowrReverser™ Transmission) . . . . .	250-11-4	
PowrReverser™ General Information . . . . .	250-11-6	
PowrReverser™ Operation in Forward . . . . .	250-11-7	
PowrReverser™ Operation in Reverse . . . . .	250-11-10	
PowrReverser™ Power Flow . . . . .	250-11-12	
PowrReverser™ Control Valve Operation—Initial Engine Start-Up, Clutch Pedal Up . . . . .	250-11-14	
PowrReverser™ Control Valve Operation—F-N-R Lever in Neutral, Clutch Pedal Down . . . . .	250-11-16	
PowrReverser™ Control Valve Operation—F-N-R Lever in Neutral, Clutch Pedal Up . . . . .	250-11-18	
PowrReverser™ Control Valve Operation—F-N-R Lever in Forward, Clutch Pedal Up . . . . .	250-11-20	
PowrReverser™ Control Valve Operation—F-N-R Lever in Reverse, Clutch Pedal Up . . . . .	250-11-24	
Transmission Power Flow—Gear Shift . . . . .	250-11-26	
Gear Shift Synchronizer Operation . . . . .	250-11-28	
Transmission Power Flow—Range Shift . . . . .	250-11-30	
PowrReverser™ Transmission Lubrication System . . . . .	250-11-32	
Rear PTO Operation . . . . .	250-11-33	
Final Drive Operation . . . . .	250-11-34	
Differential Operation . . . . .	250-11-34	
MFWD Operation . . . . .	250-11-34	
<b>Group 15—Diagnosis, Tests, and Adjustments—CS/SS Transmissions</b>		
Diagnostic Information . . . . .	250-15-1	

Continued on next page

	Page		Page
Isolate the Problem Area . . . . .	250-15-2	Two Speeds Engage Together . . . . .	250-16-7
Traction Clutch Slips . . . . .	250-15-3	Transmission Will Not Stay in Gear . . . . .	250-16-8
Traction Clutch Dragging . . . . .	250-15-4	Transmission Noisy . . . . .	250-16-8
Traction Clutch Does Not Engage . . . . .	250-15-4	PTO Troubleshooting . . . . .	250-16-9
Traction Clutch Grabs . . . . .	250-15-5	Differential Troubleshooting . . . . .	250-16-9
Traction Clutch Squeaks . . . . .	250-15-5	Axle Troubleshooting . . . . .	250-16-9
Traction Clutch Does Not Release . . . . .	250-15-6	MFWD Troubleshooting . . . . .	250-16-9
Traction Clutch Chatters . . . . .	250-15-7	PowrReverser™ Control Valve Tests . . . . .	250-16-10
Traction Clutch Rattles . . . . .	250-15-8	Transmission Pump Flow Test . . . . .	250-16-17
Traction Clutch Engagement Is Noisy . . . . .	250-15-8	Forward-Neutral-Reverse Control Cable	
Excessive Vibration in Traction Clutch . . . . .	250-15-9	Adjustment . . . . .	250-16-18
Clutch Pedal Does Not Return . . . . .	250-15-9	Clutch Pedal Linkage Adjustment . . . . .	250-16-24
Clutch Pedal Loose . . . . .	250-15-10	Park Brake Cable Adjustment . . . . .	250-16-25
Clutch Pedal Pulsates . . . . .	250-15-10	PTO 540/540E Lever and Linkage	
Jerky or Rough Transmission of Power . . . . .	250-15-10	Adjustment . . . . .	250-16-27
Low Transmission Oil Level (Excessive Oil			
Leakage) . . . . .	250-15-11		
Gears Clash, Shift Hard, or Will Not			
Engage . . . . .	250-15-11		
Two Speeds Engage Together . . . . .	250-15-12		
Transmission Will Not Stay in Gear . . . . .	250-15-12		
Transmission Noisy . . . . .	250-15-13		
PTO Noisy . . . . .	250-15-13		
PTO Hard to Engage . . . . .	250-15-14		
PTO Will Not Operate . . . . .	250-15-14		
PTO Will Not Stay Engaged . . . . .	250-15-14		
Excessive Differential Noise . . . . .	250-15-15		
Differential Does Not Work . . . . .	250-15-15		
No Differential Lock . . . . .	250-15-16		
Differential Chatters . . . . .	250-15-16		
Axle Noise . . . . .	250-15-17		
Axle Shaft Will Not Turn . . . . .	250-15-17		
MFWD Lever is Hard to Engage . . . . .	250-15-18		
MFWD Lever Will Not Stay in "ON"			
Position . . . . .	250-15-18		
Noisy Front Wheel Drive Operation . . . . .	250-15-19		
Clutch Pedal Free Play Adjustment . . . . .	250-15-19		
PTO Clutch Lever Adjustment . . . . .	250-15-20		

**Group 16—Diagnosis, Tests, and Adjustments—  
PowrReverser™**

Diagnostic Information . . . . .	250-16-1
Isolate the Problem Area . . . . .	250-16-2
Low Transmission Oil Level (Excessive Oil	
Leakage) . . . . .	250-16-4
Clutch Pedal Does Not Return . . . . .	250-16-5
Tractor Does Not Move in Forward or	
Reverse . . . . .	250-16-5
PowrReverser™ Engages Too Quickly or Too	
Slowly . . . . .	250-16-6
PowrReverser™ Does Not Disengage . . . . .	250-16-6
Gears Clash, Shift Hard, or Will Not	
Engage . . . . .	250-16-7

# Component Location—Collar Shift and SyncShuttle™ Transmissions

## Component Location Information

This group contains component location drawings for the following power train components:


- Power Train Components
- Clutch
- Transmission—Collar Shift
- Transmission—SyncShuttle™
- Final Drive
- Rear PTO

Use the drawings when diagnosing a power train problem and to help locate the components to be tested.

OUO1085,00001B5 -19-28SEP00-1/1

250  
05  
1

Power Train Components



POWER TRAIN COMPONENTS

LV123AE

LV123AE -19-17DEC97

Continued on next page

OUC1085,00001B7 -19-28SEP00-1/2

Component Location—Collar Shift and SyncShuttle™ Transmissions

A—Range Shift Lever	E—Differential Lock Pedal	I—Axle	L—Drive Shaft (Optional)
B—Rear PTO Lever	F—Transmission	J—Final Drive	M—Clutch Pedal
C—MFWD Lever	G—Rear PTO	K—MFWD Drop Gearbox	N—Clutch Housing
D—Gear Shift Lever	H—Differential	(Optional)	O—MFWD Axle (Optional)

OUC1085,00001B7 -19-28SEP00-2/2

250  
05  
3

PTO CLUTCH FRONT (B) PRESSURE PLATE  
 FLYWHEEL (A)  
 PTO CLUTCH REAR PRESSURE PLATE (C)  
 PTO CLUTCH COIL SPRING (D)  
 TRACTION CLUTCH FRONT PRESSURE PLATE (E)  
 TRACTION CLUTCH REAR PRESSURE PLATE (F)  
 PTO CLUTCH RELEASE FINGER (G)  
 PTO CLUTCH RELEASE BEARING (H)  
 TRACTION CLUTCH SHAFT (I)  
 PTO CLUTCH SHAFT (J)  
 TRACTION CLUTCH ARM SHAFT (K)  
 PTO CLUTCH ARM SHAFT (L)  
 TRACTION CLUTCH RELEASE BEARING (M)  
 TRACTION CLUTCH RELEASE FINGER (N)  
 PTO CLUTCH DISK (O)  
 SPRING WASHER (P)  
 PTO CLUTCH DISK (Q)

## LV252AE

LV252AE -19-01JUL02

Continued on next page

OUO1085,00001B6 -19-28SEP00-1/2

Component Location—Collar Shift and SyncShuttle™ Transmissions


A—Flywheel	E—Traction Clutch Front Pressure Plate	I—Traction Clutch Shaft	N—Traction Clutch Release Finger
B—PTO Clutch Front Pressure Plate	F—Traction Clutch Rear Pressure Plate	J—PTO Clutch Shaft	O—Traction Clutch Disk
C—PTO Clutch Rear Pressure Plate	G—PTO Clutch Release Lever	K—Traction Clutch Armshaft	P—Spring Washer
D—Traction Clutch Coil Spring	H—PTO Clutch Release Bearing	L—PTO Clutch Armshaft	Q—PTO Clutch Disk
		M—Traction Clutch Release Bearing	

OUC1085,00001B6 -19-28SEP00-2/2

250  
05  
5



Transmission Components—Collar Shift



TRANSMISSION COMPONENTS — COLLAR SHIFT

LV9091

LV9091 -19-13APR04

Continued on next page

OOU1023,0000017 -19-12APR04-1/2


*Component Location—Collar Shift and SyncShuttle™ Transmissions*

A—PTO Shaft	H—1st and 3rd Gear Shift Collar	M—Range Reduction Shaft	S—C Range Driven Gear
B—Traction Clutch Shaft	I—3rd Speed Drive Gear	N—Differential Drive Shaft	T—3rd Speed Driven Gear
C—Transmission Top Shaft	J—Range Reduction Drive Gear	O—A Range and Creeper Shift Sliding Gear	U—1st Speed Driven Gear
D—Reverse Drive Gear	K—B Range Drive Gear	P—MFWD Gear	V—2nd Speed Driven Gear
E—Reverse and 2nd Gear Shift Collar	L—A Range Drive Gear	Q—B Range Driven Gear	W—Reverse Driven Gear
F—2nd Speed Drive Gear		R—B and C Range Shift Collar	X—Driven Shaft
G—1st Speed Drive Gear			Y—Reverse Idler Gear

OUO1023,0000017 -19-12APR04-2/2

250  
05  
7

# Transmission Components—SyncShuttle™ (SS)



TRANSMISSION COMPONENTS — SYNCSHUTTLE™

LV7987

LV7987 -19-12JUL02

Continued on next page

OUC1085,00001BA -19-28SEP00-1/2


*Component Location—Collar Shift and SyncShuttle™ Transmissions*

A—PTO Shaft	H—1st and 3rd Gear Synchronizer	M—Range Reduction Shaft	S—C Range Driven Gear
B—Traction Clutch Shaft	I—3rd Speed Drive Gear	N—Differential Drive Shaft	T—3rd Speed Driven Gear
C—Transmission Top Shaft	J—Range Reduction Drive Gear	O—A Range and Creeper Shift Sliding Gear	U—1st Speed Driven Gear
D—Reverse Drive Gear	K—B Range Drive Gear	P—MFWD Gear	V—2nd Speed Driven Gear
E—Reverse and 2nd Gear Synchronizer	L—A Range Drive Gear	Q—B Range Driven Gear	W—Reverse Driven Gear
F—2nd Speed Drive Gear		R—B and C Range Shift Collar	X—Driven Shaft
G—1st Speed Drive Gear			Y—Reverse Idler Gear

OUO1085,00001BA -19-28SEP00-2/2

250  
05  
9

## Final Drive Components



A—Planetary Carrier Assembly  
B—Differential Drive Shaft

C—Differential Ring Gear  
D—Axle Shaft

E—Final Drive Ring Gear  
F—Final Drive Pinion Shaft

G—Differential Carrier  
H—Differential Lock Collar


## FINAL DRIVE COMPONENTS

LV254AE

LV254AE -19-01JUL02

AG,OUO1023,429 -19-28SEP00-1/1

Rear PTO Components



LV255AE

REAR PTO COMPONENTS

A—PTO Shaft  
B—Intermediate Shaft

C—PTO Pinion Shaft  
D—PTO Output Shaft

E—PTO Drive Gear


F—Snubber

OUO1085,00001BB -19-28SEP00-1/1

250  
05  
11

LV255AE -19-02FEB01

Rear 540/540E PTO Components (SyncShuttle™ Transmission Only)



LV1005AE

REAR PTO COMPONENTS

A—PTO Shaft  
B—Snubber  
C—Intermediate Shaft

D—PTO Pinion Shaft  
E—PTO Output Shaft  
F—PTO Drive Gear for  
Standard (540) Mode

G—PTO Shift Collar

H—PTO Drive Gear for  
Economy (540E) Mode

OUO1085,00001BC -19-28SEP00-1/1

LV1005AE -19-14SEP00

## Component Location Information

This group contains component location drawings for the following power train components:

- Power Train Components
- Clutch Components
- PowrReverser™ Components
- Transmission Components

Use the drawings when diagnosing a power train problem and to help locate the components to be tested.


*NOTE: Final drive components and rear PTO components are the same as those on units with collar shift or SyncShuttle™ transmissions. See Group 05 for these component location drawings.*

OUC1085,00001BE -19-28SEP00-1/1

250  
06  
1



# Power Train Components—PowrReverser™ Transmission



## POWER TRAIN COMPONENTS — POWRREVERSER™ TRANSMISSION

LV1199AE

LV1199AE -19-24FEB98

Continued on next page

OOU1085,00001BF -19-28SEP00-1/2

*Component Location—PowrReverser™ Transmission*

A—F-N-R Lever  
B—Range Shift Lever  
C—Rear PTO Lever  
D—MFWD Lever  
E—Gear Shift Lever

F—Differential Lock Pedal  
G—Transmission  
H—PTO Shaft  
I—Differential Housing


J—Axle  
K—Final Drive  
L—MFWD Drop Gear Box  
M—Hydraulic Control Valve

N—Clutch Pedal  
O—Clutch Housing  
P—MFWD Drive Shaft  
Q—MFWD Axle

OUC1085,00001BF -19-28SEP00-2/2

250  
06  
3

# Clutch Components—PowrReverser™ Transmission



## CLUTCH COMPONENTS POWRREVERSER™ TRANSMISSION

LV1200AE

LV1200AE -19-24FEB98

Continued on next page

OUC1085,00001C0 -19-28SEP00-1/2


Component Location—PowrReverser™ Transmission

- |                        |                             |                       |                            |
|------------------------|-----------------------------|-----------------------|----------------------------|
| A—Flywheel             | D—Rear Pressure Plate       | G—PTO Clutch Armshaft | I—Transmission Drive Shaft |
| B—Front Pressure Plate | E—Belleville Washer         | H—PTO Clutch Release  | J—Torsional Damper         |
| C—PTO Clutch Disk      | F—PTO Clutch Release Finger | Bearing               | K—PTO Drive Shaft          |

OUO1085,00001C0 -19-28SEP00-2/2

250  
06  
5

## PowrReverser™ Components



LV1201AE

## POWRREVERSER™ COMPONENTS

Continued on next page

OOU1085,00001C1 -19-28SEP00-1/2

LV1201AE -19-24FEB98


Component Location—PowrReverser™ Transmission

A—Transmission Oil Pump	D—Forward and Reverse	F—Transmission Top Shaft	I—Reverse Counter Shaft
B—Traction Drive Shaft	Clutch Pack	G—Reverse Idler Gear	J—Driven Gear
C—Reverse Drive Gear	E—Transmission Drive Gear	H—Transfer Gear	

OUC1085,00001C1 -19-28SEP00-2/2

250  
06  
7

# Transmission Components—PowrReverser™ Transmission



## TRANSMISSION COMPONENTS — POWRRERVERSER™ TRANSMISSION

LV7988

LV7988 -19-12JUL02

Continued on next page

Ouo1085,00001C2 -19-28SEP00-1/2

## Component Location—PowrReverser™ Transmission

A—PTO Shaft	H—Range Reduction Shaft	N—B Range Driven Gear	S—4th Speed Driven Gear
B—Transmission Top Shaft	I—B Range Drive Gear	O—B and C Range Shift Collar	T—1st Speed Driven Gear
C—2nd Speed Drive Gear	J—A Range Drive Gear	P—C Range Drive Gear	U—1st and 2nd Gear Synchronizer
D—1st Speed Drive Gear	K—Differential Drive Shaft	Q—3rd Speed Driven Gear	V—2nd Speed Driven Gear
E—4th Speed Drive Gear	L—A Range and Creeper Shift Sliding Gear	R—3rd and 4th Gear Synchronizer	W—Driven Shaft
F—3rd Speed Drive Gear			
G—Range Reduction Driven Gear	M—MFWD Drive Gear		

OUO1085,00001C2 -19-28SEP00-2/2

### Final Drive Components

Final drive components for units with PowrReverser™ transmissions are the same as those on collar shift or SyncShuttle™ transmissions. See information in Group 05.

OUO1085,00001C3 -19-28SEP00-1/1

### Rear PTO Components

Rear PTO components for units with PowrReverser™ transmissions are the same as those on collar shift or SyncShuttle™ transmissions. See information in Group 05.

OUO1085,00001C4 -19-28SEP00-1/1

250  
06  
9



250  
06  
10

## Theory of Operation Information


This group divides the power train into individual components or systems by function. The story contains information on function, component, or system identification and theory of operation.

The following systems or components are covered:

- Clutch Operation
  - Traction Clutch Engaged and PTO Clutch Disengaged
  - Traction Clutch Engaged and PTO Clutch Engaged
  - Traction Clutch Disengaged and PTO Clutch Engaged
  - Traction Clutch Disengaged and PTO Clutch Disengaged
- Transmission
  - Lubrication System
  - Gear Shift Power Flow
  - Range Shift Power Flow
- Differential Power Flow
- Differential Lock Operation
- Final Drive Operation
- Rear PTO Operation
- Mechanical Front Wheel Drive Operation

OUC1085,00001BD –19–28SEP00–1/1

## Clutch Operation



LVC6684

### CLUTCH OPERATION TRACTION CLUTCH ENGAGED AND PTO CLUTCH DISENGAGED

LVC6684 -19-15MAY01

Continued on next page

AG,OUO1008,334 -19-13JAN00-1/8

A—Flywheel

B—PTO Clutch Pressure Plate

C—Spring Washer

D—Coil Spring

E—Traction Clutch Pressure Plate

F—Torsion Spring

G—PTO Clutch Release Bearing

H—Traction Clutch Shaft

I—PTO Clutch Shaft

J—Traction Clutch Armshaft

K—PTO Clutch Armshaft

L—Traction Clutch Release Bearing

M—Traction Clutch Disk

N—PTO Clutch Disk

#### FUNCTION:

Dry disk clutches provide a positive means of mechanically engaging and disengaging power flow between the engine and the transmission and PTO.

#### MAJOR COMPONENTS:

- Pressure Plates
- Clutch Disks
- Clutch Release Levers
- Clutch Release Bearings
- Armshafts
- Spring Washer
- Traction Clutch Shaft
- PTO Clutch Shaft

#### THEORY OF OPERATION:

The clutch assembly is attached to the rear of the engine flywheel (A). The traction (L) and the PTO (G) clutch release bearing mechanisms are operated independently of each other by means of armshafts (J

and K). Linkage rods connect the armshafts to the traction clutch pedal and the PTO clutch lever.

#### Traction Clutch Engaged:

When the traction clutch is engaged (clutch pedal released), spring washer (C) forces pressure plate (E) against traction clutch disk (M), causing the clutch disk to rotate with the flywheel. Because the traction clutch disk is splined to the traction clutch shaft (H), power is transmitted from the traction clutch disk to the traction clutch shaft. Torsion springs (F) dampen shock to the clutch disk facings during clutch engagement.


#### PTO Clutch Disengaged:

When the PTO clutch is disengaged (PTO lever released), pressure plate (B) is forced forward by coil springs (D), removing contact between the pressure plate and PTO clutch disk (N). In this mode, no power will be transmitted from the flywheel to the PTO clutch shaft (I), because the PTO clutch disk does not rotate with flywheel (A).

Continued on next page

AG,OUO1008,334 -19-13JAN00-2/8

250  
10  
3



LVC6685

## CLUTCH OPERATION TRACTION CLUTCH ENGAGED AND PTO CLUTCH ENGAGED

LVC6685 -19-07MAY01

Continued on next page

AG,OUO1008,334 -19-13JAN00-3/8

A—Flywheel	D—Spring Washer	G—Traction Clutch Shaft	J—PTO Clutch Armshaft
B—PTO Clutch Front Pressure Plate	E—PTO Clutch Release Finger	H—PTO Clutch Shaft	K—PTO Lever Linkage
C—PTO Clutch Rear Pressure Plate	F—PTO Clutch Release Bearing	I—Traction Clutch Armshaft	L—PTO Clutch Disk

### PTO Clutch Engaged:

Pushing the PTO clutch lever forward moves linkage (K) rearward, causing PTO clutch armshaft (J) to rotate and force PTO clutch release bearing (F) against PTO clutch release fingers (E). The clutch release bearing depresses the release fingers, causing PTO clutch pressure plate (B) to move rearward. Pressure plate (B) is forced against PTO clutch disk (L), clamping the PTO clutch disk between pressure plate (B) and rear plate (C).

This causes the PTO clutch disk to rotate with the flywheel. Because the PTO clutch disk is splined to the PTO clutch shaft (H), power is transmitted from the PTO clutch disk to the PTO clutch shaft and on to the rear PTO shaft.


### Traction Clutch Engaged:

The traction clutch power transmittal is uninterrupted by the PTO clutch engagement.

Continued on next page

AG,OUO1008,334 -19-13JAN00-4/8

250  
10  
5



LVC6686

## CLUTCH OPERATION TRACTION CLUTCH DISENGAGED AND PTO CLUTCH ENGAGED

LVC6686 -19-07MAY01

Continued on next page

AG,OUO1008,334 -19-13JAN00-5/8

A—Flywheel	D—Traction Clutch Release Bearing	F—Traction Clutch Shaft	I—Traction Clutch Disk
B—Spring Washer		G—Traction Clutch Armshaft	
C—Traction Clutch Pressure Plate	E—Clutch Pedal Linkage	H—Traction Clutch Release Finger	

**Traction Clutch Disengaged:**

Depressing the clutch pedal moves clutch pedal linkage (E) upward, causing the traction clutch armshaft (G) to rotate and force traction clutch release bearing (D) against traction clutch release fingers (H). The clutch release bearing depresses the release fingers, causing traction clutch pressure plate (C) to move rearward against spring washer (B), compressing the spring washer.

Since pressure plate (C) is no longer held against traction clutch disk (I) by the clamping force of spring washer (B), the traction clutch disk is no longer forced to turn with flywheel (A). The traction clutch shaft (F) stops turning.


**PTO Clutch Engaged:**

The PTO clutch power transmittal is uninterrupted by the traction clutch disengagement.

Continued on next page

AG,OUO1008,334 -19-13JAN00-6/8





LVC6683

## CLUTCH OPERATION

### TRACTION CLUTCH DISENGAGED AND PTO CLUTCH DISENGAGED

LVC6683 -19-15MAY01

Continued on next page

AG,OUO1008,334 -19-13JAN00-7/8

A—Flywheel	E—PTO Clutch Release Bearing	H—PTO Clutch Shaft	L—Traction Clutch Disk
B—PTO Clutch Front Pressure Plate	F—Clutch Pedal Linkage	I—Traction Clutch Armshaft	M—PTO Clutch Disk
C—Spring Washer	G—Traction Clutch Shaft	J—PTO Clutch Armshaft	
D—Traction Clutch Front Pressure Plate		K—Traction Clutch Release Bearing	

**Traction Clutch Disengaged and PTO Clutch Disengaged**

Depressing the clutch pedal moves clutch pedal linkage (F) upward, causing the traction clutch armshaft (I) to rotate and force traction clutch release bearing (K) against traction clutch release fingers. The clutch release bearing depresses the release fingers, causing traction clutch front pressure plate (D) to move forward against spring washer (C), compressing the spring washer.


Since pressure plate (D) is no longer held against traction clutch disk (L) by the clamping force of spring

washer (C), the traction clutch disk is no longer forced to turn with flywheel (A). The traction clutch shaft (G) stops turning.

When the PTO clutch is disengaged (PTO lever released), PTO clutch front pressure plate (B) is forced forward by coil springs, removing contact between the pressure plate and PTO clutch disk (M). In this mode, no power will be transmitted from the flywheel to the PTO clutch shaft (H), because the PTO clutch disk does not rotate with flywheel (A).

AG,OUO1008,334 -19-13JAN00-8/8

Transmission Lubrication System



TRANSMISSION LUBRICATION SYSTEM

LVC6128

LVC6128 -19-02JUL01

Continued on next page

OOU1085,00001C6 -19-29SEP00-1/2

A—Transmission Top Shaft  
B—Drive Gears

C—Range Reduction Shaft  
D—Return Oil From Steering Valve

E—PTO Shaft  
F—Pressure (Lubrication) Oil

G—Pressure Free Oil

**FUNCTION:**

The transmission case serves as the main oil reservoir for the hydraulic system, steering system, and brake system. The oil also acts as lubrication oil for transmission and differential components.

**MAJOR COMPONENTS:**

- Transmission Case
- Power Steering System Return/Transmission Lubrication Line
- Relief Valve
- Range Reduction Shaft
- Transmission Top Shaft

**THEORY OF OPERATION:**

During operation, pressure free oil (G) in the transmission case is thrown up by the turning gears to lubricate the transmission components. Pressurized return oil from the steering valve (D) enters the left

side of the differential case via the transmission lubrication line.


A passage in the differential case intersects the bearing bore at the end of range reduction shaft (C). The pressurized lube oil (F) flows around the PTO shaft (E) and through the hollow range reduction shaft (C) and transmission top shaft (A). Passages in the transmission top shaft provide lubrication for the 1st, 2nd, 3rd, and reverse drive gears (B) which rotate independently on the transmission top shaft unless engaged by one of the shift collars. The bearings for the transmission top shaft and range reduction shaft are also lubricated by this pressurized oil.

A transmission lube relief valve is located between return oil inlet and range reduction shaft bearing bore in differential case. An increase in oil pressure causes the relief valve spring to compress, unseating a poppet, allowing return oil to flow directly into the transmission case.

OUC1085,00001C6 -19-29SEP00-2/2

250  
10  
11

Transmission Power Flow—Gear Shift (Collar)



TRANSMISSION POWER FLOW — GEAR SHIFT (COLLAR)

LVC7989

LVC7989 -19-12JUL02

Continued on next page

OUC1085,00001C5 -19-29SEP00-1/2

A—PTO Shaft  
B—Traction Clutch Shaft  
C—Transmission Top Shaft  
D—Reverse and 2nd Gear Shift Collar

E—1st and 3rd Gear Shift Collar  
F—Range Reduction Drive Gear  
G—Range Reduction Shaft

H—Differential Drive Shaft  
I—MFWD Gear  
J—Driven Shaft  
K—Reverse Idler

L—Reverse Gear  
M—1st Gear  
N—2nd Gear  
O—3rd Gear

#### FUNCTION:

Provides three forward gears and reverse gear to the range section of the transmission.

#### MAJOR COMPONENTS:

- Traction Clutch Shaft
- Transmission Top Shaft
- Drive Gears
- Driven Gears
- Reverse Idler
- Gear Shift Collars
- Driven Shaft
- Range Reduction Drive Gear
- Range Reduction Shaft

#### THEORY OF OPERATION:

The transmission speed gears are constantly in mesh.  
The driven gears are splined to the driven shaft (J).

The drive gears rotate independently on the transmission top shaft (C) until a shift collar (D or E) is moved toward it. This engages the gear to the transmission top shaft through the collar.


Power will then flow from the top shaft through the selected gears to the driven shaft, through the range reduction drive gear (F) to the range reduction shaft (G).

When gearshift lever is moved into the park position, a mechanical park pawl assembly within the transmission meshes with mechanical front wheel drive (MFWD) gear (I). With MFWD gear splined to differential drive shaft (H), movement of machine is not possible.

OUC1085,00001C5 -19-29SEP00-2/2

250  
10  
13

Transmission Power Flow—Gear Shift (SyncShuttle™)



TRANSMISSION POWER FLOW — GEAR SHIFT (TSS)

LVC7990

LVC7990 -19-12JUL02

Continued on next page

OUC1085,00001C7 -19-29SEP00-1/2

A—PTO Shaft  
B—Traction Clutch Shaft  
C—Transmission Top Shaft  
D—Reverse and 2nd Gear Synchronizer

E—1st and 3rd Gear Synchronizer  
F—Range Reduction Drive Gear  
G—Range Reduction Shaft

H—Differential Drive Shaft  
I—MFWD Gear  
J—Driven Shaft  
K—Reverse Idler Gear

L—Reverse Gear  
M—1st Gear  
N—2nd Gear  
O—3rd Gear

#### FUNCTION:

Provides three forward gears and reverse gear to the range section of the transmission.

#### MAJOR COMPONENTS:

- Traction Clutch Shaft
- Drive Gears
- Driven Gears
- Reverse Idler
- Reverse and 2nd Gear Synchronizer
- 1st and 3rd Gear Synchronizer
- Driven Shaft
- Range Reduction Drive Gear
- Range Reduction Shaft

#### THEORY OF OPERATION:

The transmission speed drive gears are constantly in mesh. The driven gears are splined to the driven shaft (J).

The drive gears rotate independently on the transmission top shaft (C) until either synchronizer (D or E) moves toward it. The synchronizer then equalizes the shaft and drive gear speed before engaging the gear to the shaft through the shift collar/actuator hub. (See SyncShuttle™ Transmission Synchronizer Operation—Reverse and 2nd Gear (Disk-and-Plate Type Synchronizer) or SyncShuttle™ Transmission Synchronizer Operation—1st and 3rd Gear (Cone-Type Synchronizer) for further information.)

Power will then flow from the top shaft through the selected gear to the driven shaft, through the range reduction gear (F) to the range reduction shaft (G).


When the gearshift lever is moved into the park position, a mechanical park pawl assembly within the transmission meshes with the mechanical front wheel drive (MFWD) gear (I). With the MFWD splined to the differential drive shaft (H), movement of the machine is not possible.

OUC1085,00001C7 -19-29SEP00-2/2

250  
10  
15



# SyncShuttle™ Transmission Synchronizer Operation—Reverse and 2nd Gear (Disk-and-Plate Type Synchronizer)



## TSS TRANSMISSION SYNCHRONIZER OPERATION – REVERSE AND 2ND GEAR (DISK-AND-PLATE-TYPE SYNCHRONIZER)

LV622AE

LV622AE -19-09NOV94

Continued on next page

UU01085,00001C8 -19-29SEP00-1/2

A—Reverse Drive Gear  
B—Splined Coupler (2 used)  
C—Synchronizer Disk (8 used)

D—Separator Plate (6 used)  
E—Synchronizer Drum (2 used)

F—Blocker Tab  
G—Blocker Slot  
H—Shift Collar

I—Drive Hub  
J—2nd Speed Drive Gear  
K—Detent (3 used).

#### FUNCTION:

Synchronizer equalizes speeds of mating gears to allow a clash-free shift while the tractor is in motion.

#### MAJOR COMPONENTS:

- Reverse Drive Gear
- Splined Coupler
- Synchronizer Disc
- Separator Plates
- Synchronizer Drum
- Blocker Tab
- Blocker Slots
- Shift Collar
- Drive Hub
- Detent
- Transmission Drive Gear

#### THEORY OF OPERATION:

Drive hub (I) is splined to the traction clutch shaft, and is in motion when the traction clutch is engaged. To obtain a clash-free shift, reverse drive gear (A), splined coupler (B), shift collar (H), and drive hub (I) must be turning at the same rate of speed. When at the same

rate of speed, blocker tabs (F) will align with blocker slots (G) to allow a clash-free shift.

#### Reverse Gear Operation:

To make a reverse shift, shift collar (H) is moved forward by the shift fork. As the shift collar is moved forward, misalignment of the blocker tabs and blocker slots move synchronizer drum (E) forward. This puts pressure on separator plates (D) and synchronizer discs (C). This pressure brings splined coupler (B) and reverse drive gear (A) to the same speed as drive hub (I). Blocker tabs (F) align with blocker slots (G) and allow the splines on shift collar to engage splines on splined coupler placing transmission in reverse. Power flow for reverse gear selection is described and illustrated in Transmission Power Flow—Gear Shift (SyncShuttle™) in this group.


#### 2nd Gear Operation:

The operation of the synchronizer in 2nd gear is the same as reverse, except the shift collar is moved to the rear. Power flow for 2nd gear selection is described and illustrated in Transmission Power Flow—Gear Shift (SyncShuttle™) in this group.

OUO1085,00001C8 -19-29SEP00-2/2

250  
10  
17

**SyncShuttle™ Transmission Synchronizer Operation—1st and 3rd Gear (Cone-Type Synchronizer)**



**SYNCSHUTTLE™ TRANSMISSION SYNCHRONIZER OPERATION –  
1ST AND 3RD GEAR (CONE-TYPE SYNCHRONIZER)**

Continued on next page

OOU1085,00001C9 –19–29SEP00–1/2

250  
10  
18

LV623AE –19–02JUL01

A—1st Speed Drive Gear  
B—Outer Cone (2 used)  
C—Friction Ring and Blocker  
Pin Assembly (2 used)

D—Blocker Pin (3 used)  
E—Spring-Loaded Neutral  
Detent Pin (3 used)

F—3rd Speed Drive Gear  
G—Shift Collar

H—Drive Hub

#### FUNCTION:

Synchronizer equalizes speeds of mating gears to allow a clash-free shift while the tractor is in motion.

#### MAJOR COMPONENTS:

- 1st Speed Drive Gear
- Outer Cone
- Friction Ring and Blocker Assembly
- Neutral Detent Pins
- Blocker Pins
- Shift Collar
- Drive Hub
- 3rd Speed Drive Gear

#### THEORY OF OPERATION:

Drive hub (H) is splined to the transmission top shaft, and is in motion when the traction clutch is engaged. To obtain a clash-free shift, 1st speed drive gear (A), outer cone (B), friction ring, and blocker pin assembly (C), shift collar (G), and drive hub (H), must be turning at the same rate of speed. When at the same rate of speed, blocker pins (E) will allow a clash-free shift.

#### 1st Gear Operation:

To shift into first gear, shift collar (G) is moved forward by the shift fork. As the shift collar is moved forward, misalignment of the blocker pins and shift collar will move the friction ring and blocker pin assembly forward into outer cone (B). The friction between the friction ring assembly and the outer cone will bring 1st speed drive gear (A) to the same rate of speed as drive hub (H). When 1st speed drive gear is turning at the same rate of speed as the drive hub, the blocker pins will allow the shift collar to move forward. As the shift collar moves forward, it engages to the splines on the 1st speed drive gear to place the transmission into 1st gear. Power flow for 1st gear selection is described and illustrated in Transmission Power Flow—Gear Shift (SyncShuttle™) in this group.


#### 3rd Gear operation:

The operation of the synchronizer in 3rd gear is the same as 1st gear, except the actuator hub is moved to the rear. Power flow for 3rd gear selection is described and illustrated in Transmission Power Flow—Gear Shift (SyncShuttle™) in this group.

OUO1085,00001C9 -19-29SEP00-2/2

250  
10  
19

# Transmission Power Flow—Range Shift



TRANSMISSION POWER FLOW — RANGE SHIFT

LVC7991

LVC7991 -19-12JUL02

Continued on next page

OUO1085,00001CA -19-29SEP00-1/2

A—Range Reduction Drive Gear

B—B Range Drive Gear

C—A Range Drive Gear

D—Creeper Drive Gear

E—Creeper Driven Gear

F—Range Reduction Shaft

G—Differential Drive Shaft

H—A Range and Creeper Shift Sliding Gear

I—B Range Driven Gear

J—B and C Range Shift Collar

K—C Range Driven Gear

L—Driven Shaft

M—A Range

N—B Range

O—C Range

P—Creeper Range

## FUNCTION:

Provides three range speeds and an optional creeper speed.

## MAJOR COMPONENTS:

- Driven Shaft
- Range Reduction Drive Gear
- Range Reduction Shaft
- Drive Gears
- Driven Gears
- B and C Range Shift Collar
- A Range and Creeper Shift Sliding Gear
- Differential Drive Shaft
- Creeper Assembly (optional)

## THEORY OF OPERATION:

Range selection is achieved through a combination of the gears on the range reduction shaft (F) and the gears on the differential drive shaft (G).

The driven shaft (L) transmits power to the range reduction shaft (F) through the C range driven gear (K) and the range reduction drive gear (A) which are constantly in mesh. The C range driven gear is splined to the driven shaft, and the range reduction drive gear is splined to the range reduction shaft (F).

### C Range:

The C range driven gear (K) is splined to the end of the driven shaft (L). The B and C range shift collar (J) is splined to the differential drive shaft (G). When the 3rd range is selected, the range shift collar slides and

engages the splines on the end of the driven shaft (L) and power is transmitted to the differential drive shaft (G).

### B Range:

The B range drive gear (B) is splined to the range reduction shaft (F). The B range drive gear is constantly in mesh with the B range driven gear (I) which floats on the differential drive shaft (G). When the B range is selected, the shift collar (J) engages the B range driven gear and power is transmitted to the differential drive shaft.

### A Range:

The A range drive gear (C) is splined to the range reduction shaft (F). When the A range is selected, the 1st range and creeper shift sliding gear (H) slides and engages the A range drive gear (C).

### Optional Creeper Range:

When the optional creeper assembly is installed on the transmission, the A range drive gear (C) on the range reduction shaft (F) is constantly in mesh with the creeper drive gear (D).


When the creeper range is selected, the A range and creeper shift sliding gear (H) slides to engage the creeper driven gear (E).

Power flow is then transmitted from the range reduction shaft through the creeper assembly to the A range and creeper shift sliding gear and to the differential drive shaft (G).

OUO1085,00001CA -19-29SEP00-2/2

250  
10  
21

## Rear PTO Operation



LV268AE

## REAR PTO OPERATION

A—PTO Shaft  
B—Intermediate Shaft

C—PTO Pinion Shaft  
D—PTO Output Shaft

E—PTO Drive Gear

F—Snubber

### FUNCTION:

Transfers or relays engine power output to drive rear mounted implements or attachments.

### MAJOR COMPONENTS:

- PTO Clutch Disk
- PTO Drive Shaft
- PTO Shaft
- Intermediate Shaft
- PTO Pinion Shaft
- PTO Gear

Continued on next page

OUO1085,00001CB -19-29SEP00-1/2

- PTO Output Shaft
- Snubber

#### THEORY OF OPERATION:

Pushing the PTO lever forward to the engaged position provides PTO clutch engagement. The PTO clutch disk is splined to the PTO drive shaft. When the PTO clutch is engaged, power from the engine is transmitted through PTO shaft (A) and intermediate shaft (B) to the PTO pinion shaft (C).

The PTO pinion shaft turns the PTO drive gear (E) which then turns the PTO output shaft (D).

When the PTO lever is pulled to the disengaged position, the PTO clutch disengages and the PTO shaft stops turning.

Snubber (F) aids in bringing the PTO shaft to a stop when the PTO clutch is disengaged.


A safety switch on the PTO clutch linkage prevents starting the tractor when the PTO is engaged.

OUO1085,00001CB -19-29SEP00-2/2

250  
10  
23



## Rear 540/540E PTO Operation (SyncShuttle™ Transmission Only)



LV1005AE

### REAR PTO COMPONENTS

A—PTO Shaft  
B—Snubber  
C—Intermediate Shaft

D—PTO Pinion Shaft  
E—PTO Output Shaft  
F—PTO Drive Gear for  
Standard (540) Mode

G—PTO Shift Collar

H—PTO Drive Gear for  
Economy (540E) Mode

#### FUNCTION:

Transmits engine power output to drive rear mounted implements or attachments.

#### MAJOR COMPONENTS:

- PTO Clutch Disk
- PTO Shaft
- Intermediate Shaft
- PTO Pinion Shaft
- PTO Drive Gears

Continued on next page

OUO1085,00001CD -19-29SEP00-1/2

- PTO Output Shaft
- Snubber

#### THEORY OF OPERATION:

Pushing the PTO lever forward to the engaged position provides PTO clutch engagement. The PTO clutch disk is splined to the PTO drive shaft. When the PTO clutch is engaged, power from the engine is transmitted through PTO shaft (A) and intermediate shaft (C) to the PTO pinion shaft (D).

Tractors equipped with SyncShuttle™ transmission provide for 2 modes of PTO operation:

#### **Standard (540) Mode:**

When full engine power is required, standard 540 mode allows engine to run at rated speed of 2400 rpm and delivers output power to the PTO at 540 rpm.

#### **Economy (540E) Mode:**

For lighter loads, 540E mode allows engine to run at 1700 rpm to conserve fuel while still turning the PTO output shaft at 540 rpm.

The PTO pinion shaft (D) is in constant mesh with the PTO drive gears (F and H). The drive gears rotate freely on the PTO output shaft until engaged by the shift collar (G), which is splined to the output shaft.

When standard 540 mode is selected, the PTO shift collar slides toward rear of tractor and engages drive gear (F). When 540E mode is selected, the shift collar moves toward front of tractor and engages drive gear (H).

When the PTO lever is pulled to the disengaged position, the PTO clutch disengages and the PTO shaft stops turning.

Snubber (B) aids in bringing the PTO shaft to a stop when the PTO clutch is disengaged.


A safety switch on the PTO clutch linkage prevents starting the tractor when the PTO is engaged.

The linkage is also configured to prevent shifting into 540E mode when the throttle setting exceeds 1700 rpm, or raising the throttle above 1700 rpm while in 540E mode.

OUO1085,00001CD -19-29SEP00-2/2

250  
10  
25

## Differential Power Flow



LV269AE

## DIFFERENTIAL POWER FLOW

A—Differential Drive Shaft  
B—Bevel Pinion  
C—Differential Ring Gear

D—Planetary Carrier Assembly  
E—Axle Shaft

F—Final Drive Pinion Shaft  
G—Final Drive Ring Gear

H—Bevel Gear  
I—Differential Carrier

### FUNCTION:

The differential transmits power from the differential drive shaft to the final drive pinion shafts. It allows each wheel to rotate at varying speeds and still pull its own load.

### MAJOR COMPONENTS:

- Differential Drive Shaft
- Differential Ring Gear
- Differential Carrier Assembly
- Final Drive Pinion Shafts

Continued on next page

OUO1085,00001CF -19-02OCT00-1/2

- Final Drive Ring Gear
- Planetary Carrier Assembly
- Axle Shaft

#### THEORY OF OPERATION:

Power from the differential drive shaft (A) is transmitted through the differential assembly to the final drive pinion shaft (F). The final drive pinion shaft is in mesh with the three small gears on the planetary carrier assembly (D). These small gears walk around the inside of final drive ring gear (G). The result is rotation of the axle shaft (E).


The differential assembly is a ring gear (C) bolted to the carrier (I). Inside the carrier are two bevel gears (H) and four bevel pinions (B).

When the tractor turns sharply, one axle is held stationary. The result is that the bevel pinions rotate on their own axis and walk around the stationary bevel gears. The turning ring gear transmits power through the pinion to the opposite bevel gear.

QUO1085,00001CF -19-02OCT00-2/2

250  
10  
27

## Differential Lock Operation



LV270AE

## DIFFERENTIAL LOCK OPERATION

A—Fork  
B—Spring

C—Differential Lock Pedal  
D—Roller

E—Differential Lock Shaft  
F—Differential Carrier

G—Differential Lock Collar

### FUNCTION:

Engaging the differential lock pedal locks the two differential output shafts together. This ensures that an equal amount of power is transmitted to both rear axles (eliminating differential action).

### MAJOR COMPONENTS:

- Lock Pedal
- Lock Shaft
- Fork
- Lock Collar

Continued on next page

OUO1085,00001D0 -19-02OCT00-1/2

- Differential Carrier

**THEORY OF OPERATION:**

When the differential lock pedal (C) is pressed downward, a ramp on the end of pedal pivots against a roller (D) on the end of the differential lock shaft (E), and the shaft is forced to the right. As the shaft moves, spring (B) is compressed and fork (A) forces the differential lock collar (G) toward the differential carrier (F).


When the pins on the collar align with the slots in the carrier, the pins will slip into the slots. Since the collar is splined to the right differential output shaft, no differential action will take place and both output shafts turn equally.

Unequal traction will keep the lock engaged. When traction equalizes, lock will disengage itself by spring action. If lock does not disengage, depress one brake pedal and then the other.

OUO1085,00001D0 -19-02OCT00-2/2

250  
10  
29

## Final Drive Operation



LV271AE

## FINAL DRIVE OPERATION

A—Planetary Gears

C—Axle Shaft

D—Final Drive Ring Gear

E—Final Drive Pinion Shafts

B—Planetary Carrier Assembly

### FUNCTION:

The final drive planetary gives the drive wheels a final speed reduction and torque increases.

### MAJOR COMPONENTS:

- Final Drive Pinion Shafts
- Planetary Carrier Assembly
- Planetary Gears
- Final Drive Ring Gear
- Axle Shaft

Continued on next page

OUO1085,00001D1 -19-02OCT00-1/2

**THEORY OF OPERATION:**


The final drive is a planetary ring gear type system. The final drive pinion shafts (E) are in mesh with the planetary gears (A) attached to the planetary carrier assembly (B) and ride inside final drive ring gear (D).

The axle shafts (C) are splined to the planetary carrier. Power from the differential output shafts turns the planetary assembly, which rotates the planetary assembly, and, therefore, the axle shafts. This provides the proper gear reduction and high torque load capabilities required.

OUO1085,00001D1 -19-02OCT00-2/2



## Mechanical Front Wheel Drive (MFWD) Operation



LVC272

## MECHANICAL FRONT WHEEL DRIVE (MFWD) DROP GEARBOX OPERATION

A—Driven Gears  
B—MFWD Drive Gear  
C—Differential Drive Shaft

D—MFWD Drop Gearbox  
E—Idler Gear

F—Shift Collar  
G—Output Shaft

H—Power Flow  
I—MFWD Engagement

### FUNCTION:

Provides power to the MFWD housing for extra added traction.

### MAJOR COMPONENTS:

- Differential Drive Shaft
- MFWD Gear

Continued on next page

OUO1085,00001D2 -19-02OCT00-1/2

- MFWD Drop Gearbox
- Drive Shaft
- MFWD Axle

**THEORY OF OPERATION:**

The MFWD drive gear (B) on the differential drive shaft (C) of the transmission is constantly in mesh with driven gears (A) in the drop gearbox (D). These gears

transmit power (H) to the idler gear (E), which spins freely on the output shaft (G) until engaged by shift collar (F).

When the MFWD lever is pushed forward, the shift collar slides back and engages the idler gear. Power is then transmitted through the output shaft and drive shaft to the MFWD axle housing.

OUO1085,00001D2 -19-02OCT00-2/2

250  
10  
34

## Theory of Operation Information

This group divides the power train into individual components or systems by function. The story contains information on function, component, or system identification, and theory of operation.


The following systems or components are covered:

- Clutch Operation
- PowrReverser™
  - Operation (Forward and Reverse)
  - Power Flow
- Hydraulic Control Valve Operation
- Transmission
  - Power Flow—Gear Shift
  - Power Flow—Range Shift
  - Gear Shift Synchronizer Operation
  - Lubrication

OUC1085,00001D3 -19-02OCT00-1/1

250  
11  
1

# Clutch Operation—PTO Clutch Engaged (PowrReverser™ Transmission)



## PTO CLUTCH OPERATION — ENGAGED HYDRAULIC REVERSER TRANSMISSION

LVC7935

LVC7935 -19-02JUL02

Continued on next page

OUO1085,00001D5 -19-02OCT00-1/2

A—Flywheel  
B—Front Pressure Plate  
C—PTO Clutch Disk

D—Rear Pressure Plate  
E—Pivot Pin  
F—Belleville Washer

G—PTO Clutch Release Finger  
H—PTO Clutch Armshaft  
I—PTO Clutch Release Bearing

J—Transmission Drive Shaft  
K—Torsional Damper  
L—PTO Drive Shaft

#### FUNCTION:

The dry PTO clutch disk provides mechanical engagement and disengagement of the power flow between the engine and rear PTO.

#### MAJOR COMPONENTS:

- Pressure Plates
- Clutch Disk
- Belleville Washer
- Clutch Release Fingers
- PTO Clutch Linkage
- PTO Drive Shaft
- Torsional Damper
- Traction Drive Shaft

#### THEORY OF OPERATION:


The clutch assembly is attached to the rear of engine flywheel (A). Clutch disk (C) is splined to PTO drive shaft (L). PTO clutch armshaft (H) is connected by linkage to the PTO clutch lever at the operator's station. When the PTO lever is pushed forward, clutch release bearing (I) pushes clutch release fingers (G) forward and the front and rear pressure plates (B and D) are compressed through the clutch disk to the PTO drive shaft.

Torsional damper (K) is connected directly to the flywheel. The torsional damper is splined to transmission drive shaft (J), thus the traction drive shaft turns whenever the engine is running. Engagement and disengagement of the power flow between the engine and transmission is accomplished by the PowrReverser™. (See PowrReverser™ Operation later in this group.)

OUO1085,00001D5 -19-02OCT00-2/2

250  
11  
3

# Clutch Operation—PTO Clutch Disengaged (PowrReverser™ Transmission)



## PTO CLUTCH OPERATION — DISENGAGED HYDRAULIC REVERSER TRANSMISSION

LVC7936

LVC7936 -19-02JUL02

Continued on next page

OUC1043,0000EC1 -19-09JUL02-1/2

A—Flywheel  
B—Front Pressure Plate  
C—PTO Clutch Disk

D—Rear Pressure Plate  
E—Pivot Pin  
F—Belleville Washer

G—PTO Clutch Release Finger  
H—PTO Clutch Armshaft  
I—PTO Clutch Release Bearing

J—Transmission Drive Shaft  
K—Torsional Damper  
L—PTO Drive Shaft

#### FUNCTION:

The dry PTO clutch disk provides mechanical engagement and disengagement of the power flow between the engine and rear PTO.

#### MAJOR COMPONENTS:

- Pressure Plates
- Clutch Disk
- Belleville Washer
- Clutch Release Fingers
- PTO Clutch Linkage
- PTO Drive Shaft
- Torsional Damper
- Traction Drive Shaft

#### THEORY OF OPERATION:

The clutch assembly is attached to flywheel (A). Pushing the PTO clutch lever rearward, causing PTO clutch armshaft (H) to rotate and pull the PTO clutch release bearing (I) rearward away from the PTO clutch release fingers (G), causing the pressure plate (B) to move forward.

This causes the PTO clutch disk (C) not to rotate with the flywheel. Because the PTO clutch disk is splined to the PTO drive shaft (L), power is no longer transmitted from the PTO clutch disk to the PTO drive shaft and on to the rear PTO shaft. Engagement and disengagement of the power flow between the engine and transmission is accomplished by the PowrReverser™. (See PowrReverser™ Operation later in this group.)

OUO1043,0000EC1 -19-09JUL02-2/2

250  
11  
5



## **PowrReverser™ General Information**

The PowrReverser™ uses the same oil supply as the steering and hydraulic systems. An external tube between the right-side transmission housing and clutch housing provides oil supply to the PowrReverser™ transmission oil pump. The transmission oil pump is located inside the clutch housing and driven by the transmission drive shaft.


Operation of the PowrReverser™ is regulated by the control valve mounted to the left side of the clutch housing. The clutch pedal and F-N-R lever are connected to spools in the control valve that control the flow of oil to the forward and reverse clutch packs.

Cylinder is keyed to traction drive shaft. Piston, plates, and disks are assembled inside the cylinder and retained by snap ring. Snap ring retains support and spring on shaft. Spring forces piston to bottom of cylinder and keeps plates and disks separated when in neutral.

When forward or reverse is selected, pressurized oil flows through passages in the shaft to the inside of the cylinder, behind the piston. Oil pressure behind the piston overcomes the spring force and compresses the plates and disks together. Power from the engine is transmitted to the drive gear for the direction selected. Power flow through the PowrReverser™ clutch pack is described and illustrated later in this group.

QUO1085,00001D6 -19-02OCT00-1/1

## PowrReverser™ Operation in Forward



A—Transmission Drive Shaft  
B—Reverse Supply Pressure (From Control Valve)  
C—Reverse Drive Gear  
D—Plates and Disks

E—Reverse Piston  
F—PowrReverser™ Clutch Pack  
G—Forward Piston  
H—Transmission Drive Gear

I—Forward Supply Pressure (From Control Valve)  
J—Lubrication Supply Pressure (From Control Valve)

K—Pressure Oil  
L—Lubrication Oil  
M—Return Oil

FUNCTION:

## HYDRAULIC REVERSER OPERATION - FORWARD

LVC1204AE  
LVC1204A -19-21MAY96

Transmits power from engine to transmission when F-N-R lever is in forward position.

**MAJOR COMPONENTS:**

- Traction Drive Shaft
- PowrReverser™ Clutch Pack

**THEORY OF OPERATION:**


Pressure oil from the PowrReverser™ control valve is routed through passages in transmission drive shaft (A) to PowrReverser™ clutch pack (F). When forward

is selected, pressure oil (I) enters the clutch pack behind forward piston (G) and compresses plates and disks (D) together. Power is transmitted through transmission drive gear (H) to the transmission top shaft.

When the forward piston moves, a passage opens allowing pressurized lubrication oil to enter the clutch pack to lubricate the plates and disks. With reverse piston (E) retracted, lubrication passage to reverse clutch pack is significantly reduced. Oil in reverse side of clutch pack returns to sump.



# PowrReverser™ Operation in Reverse



LVC1205AE  
LVC1205A -19-21MAY96

Continued on next page

OUO1085,00001D8 -19-22MAY03-1/2

A—Transmission Drive Shaft  
B—Reverse Supply Pressure  
(From Control Valve)  
C—Reverse Drive Gear  
D—Plates and Disks

E—Reverse Piston  
F—PowrReverser™ Clutch  
Pack  
G—Forward Piston  
H—Transmission Drive Gear

I—Reverse Idler  
J—Forward Supply Pressure  
(From Control Valve)  
K—Lubrication Supply  
Pressure (From Control  
Valve)

L—Pressure Oil  
M—Lubrication Oil  
N—Return Oil

#### FUNCTION:

Transmits power from engine to transmission when F-N-R lever is in reverse position.

#### MAJOR COMPONENTS:

- Traction Drive Shaft
- PowrReverser™ Clutch Pack

#### THEORY OF OPERATION:

Pressure oil from the PowrReverser™ control valve is routed through passages in transmission drive shaft


(A) to PowrReverser™ clutch pack (F). When reverse is selected, pressure oil (B) enters the clutch pack behind reverse piston (E) and compresses plates and disks (D) together. Power is transmitted to reverse drive gear (C). Power flow through PowrReverser™ is described and illustrated later in this group.

When the reverse piston moves, a passage opens allowing pressurized lubrication oil to enter the clutch pack to lubricate the plates and disks. With forward piston (G) retracted, lubrication passage to forward clutch pack is significantly reduced. Oil in forward side of pack returns to sump.

OUO1085,00001D8 -19-22MAY03-2/2

250  
11  
11

# PowrReverser™ Power Flow



LVC1215AE

LVC1215A -19-21MAY96

Continued on next page

OUO1085,00001D9 -19-02OCT00-1/2

**A—Transmission Drive Shaft**  
**B—PowrReverser™**  
**C—Forward Clutch Pack**

**D—Transmission Drive Gear**  
**E—Transmission Top Shaft**  
**F—Reverse Drive Gear**

**G—Reverse Clutch Pack**  
**H—Transfer Gear**  
**I—Reverse Idler**

**J—Reverse Countershaft**  
**K—Driven Gear**

Power is transmitted from the clutch through transmission drive shaft (A) to the PowrReverser™ (B).

When the F-N-R lever is moved from neutral to forward, oil pressure compresses the plates and disks in forward clutch pack (C) and power is transmitted through transmission drive gear (D) to transmission top shaft (E).

When reverse is selected, the reverse clutch pack (G) is actuated and power is transmitted to reverse drive gear (F) which is in mesh with driven gear (K). The driven gear drives reverse countershaft (J) and transfer gear (H). Power is transmitted from the transfer gear, through reverse idler (I), to the transmission drive gear. Transmission top shaft (E) is driven in reverse direction.

OUO1085,00001D9 -19-02OCT00-2/2


250  
11  
13






250-11-14

See Page 250-11-14 C



LVC1206AE


This page is intentionally left blank.



This page is intentionally left blank.

# PowrReverser™ Control Valve Operation—Initial Engine Start-Up, Clutch Pedal Up

3AE -19-08FEB01



AGE

This page is intentionally left blank.

1—Engagement Override Piston	11—0.7 mm Orifice	C—Passage	N—Sump Passage
2—Lube Cut-Off Valve	12—Forward/Reverse Valve	D—Passage	O—Passage
3—Engagement Override Valve	13—Modulation Relief Valve	E—Passage	P—Sump Passage
4—Charge Pressure	14—Main Relief Valve	F—Passage	Q—Passage
5—Lube Pressure Test Port	15—Lube Relief Valve	G—Sump Passage	R—Passage
6—Forward Pressure Test Port	16—Spring	H—Passage	S—Sump Passage
7—System Pressure Test Port	17—Clutch Pedal Valve	I—Passage	T—Sump Passage
8—Reverse Pressure Test Port	18—Valve	J—Sump Passage	U—Passage
9—Modulation Piston	A—Lube Passage to Clutch Packs	K—Passage to Reverse Clutch	V—High Pressure Oil
10—Modulation Valve	B—Passage	L—Passage	W—Medium Pressure Oil
		M—Passage to Forward Clutch	X—Return Oil

#### FUNCTION:

Controls all functions of the PowrReverser™.

#### MAJOR COMPONENTS:

- Engagement Override Valve
- Clutch Pedal Valve
- Main Relief Valve
- Lubrication Relief Valve
- Lubrication Cut-Off Valve
- Modulation Valve
- Forward/Reverse Valve

#### THEORY OF OPERATION:

The engagement override valve (3) prevents tractor movement if the engine is started in gear with the clutch pedal raised. It is primarily a safety device to

prevent tractor movement if the vehicle is jump-started with the clutch pedal raised.

When the engine is off, spring (16) forces spool in engagement override valve (3) to close passage (C).

If the engine is started with the clutch pedal up, charge pressure entering passage (C) is blocked by the engagement override spool. System pressure opens main relief valve (14) and lube relief valve (15). All oil flow returns to sump through sump passage (P). The PowrReverser™ remains in neutral and tractor movement is prevented.


The clutch pedal must be fully depressed once after the engine is started to make system pressure available to the remainder of the PowrReverser™ control circuits.

OUO1085,00001DA -19-02OCT00-2/2



**PowrReverser™ Control Valve Operation—F-N-R Lever in Neutral, Clutch Pedal Down**

LVC1207AE -19-0081801




LVC1207AE

See Page 250-11-16 A

See Page 250-11-16 B

See Page 250-11-16 C




LVC1207AE



FOR


This page is intentionally left blank.



This page is intentionally left blank.

# everser™ Control Valve Operation—F-N-R Lever in Neutral, Clutch Pedal Down

—19-08FEB01



3E

This page is intentionally left blank.

1—Engagement Override Piston	11—0.7 mm Orifice	C—Passage	N—Sump Passage
2—Lube Cut-Off Valve	12—Forward/Reverse Valve	D—Passage	O—Passage
3—Engagement Override Valve	13—Modulation Relief Valve	E—Passage	P—Sump Passage
4—Charge Pressure	14—Main Relief Valve	F—Passage	Q—Passage
5—Lube Pressure Test Port	15—Lube Relief Valve	G—Sump Passage	R—Passage
6—Forward Pressure Test Port	16—Spring	H—Passage	S—Sump Passage
7—System Pressure Test Port	17—Clutch Pedal Valve	I—Passage	T—Sump Passage
8—Reverse Pressure Test Port	18—Valve	J—Sump Passage	U—Passage
9—Modulation Piston	A—Lube Passage to Clutch Packs	K—Passage to Reverse Clutch	V—High Pressure Oil
10—Modulation Valve	B—Passage	L—Passage	W—Medium Pressure Oil
		M—Passage to Forward Clutch	X—Return Oil

#### FUNCTION:

Controls all functions of the PowrReverser™.

#### MAJOR COMPONENTS:

- Engagement Override Valve
- Clutch Pedal Valve
- Main Relief Valve
- Lubrication Relief Valve
- Lubrication Cut-Off Valve
- Modulation Valve
- Forward/Reverse Valve

#### THEORY OF OPERATION:

When the engine is running and the clutch pedal is depressed for the first time, engagement override


piston (1) pushes the engagement override valve (3) to the end of its chamber which opens passage (C) to charge pump pressure. At the same time, clutch pedal valve (17) shifts and closes passage (Q). System pressure flows through orifice (10) to forward/reverse valve (12). With the forward/reverse valve in neutral, oil pressure returns to sump through sump passages (J and N).

When the clutch pedal is released, system pressure keeps the engagement override spool shifted until the engine is shut off. See PowrReverser™ Control Valve Operation—F-N-R Lever in Neutral, Clutch Pedal Up on the following pages.

OUO1085,00001DB -19-03OCT00-2/2




**PowrReverse™ Control Valve Operation—F-N-R Lever in Neutral, Clutch Pedal Up**  
LVC1203AE -19-08FEB01




See Page 250-11-18 A

See Page 250-11-18 B

See Page 250-11-18 C



This page is intentionally left blank.



This page is intentionally left blank.



This page is intentionally left blank.

1—Engagement Override Piston	11—0.7 mm Orifice	C—Passage	N—Sump Passage
2—Lube Cut-Off Valve	12—Forward/Reverse Valve	D—Passage	O—Passage
3—Engagement Override Valve	13—Modulation Relief Valve	E—Passage	P—Sump Passage
4—Charge Pressure	14—Main Relief Valve	F—Passage	Q—Passage
5—Lube Pressure Test Port	15—Lube Relief Valve	G—Sump Passage	R—Passage
6—Forward Pressure Test Port	16—Spring	H—Passage	S—Sump Passage
7—System Pressure Test Port	17—Clutch Pedal Valve	I—Passage	T—Sump Passage
8—Reverse Pressure Test Port	18—Valve	J—Sump Passage	U—Passage
9—Modulation Piston	A—Lube Passage to Clutch Packs	K—Passage to Reverse Clutch	V—Low Pressure Oil
10—Modulation Valve	B—Passage	L—Passage	W—Return Oil
		M—Passage to Forward Clutch	X—Trapped Oil

**FUNCTION:**

Controls all functions of the PowrReverser™.

**MAJOR COMPONENTS:**

- Engagement Override Valve
- Clutch Pedal Valve
- Main Relief Valve
- Lubrication Relief Valve
- Lubrication Cut-Off Valve
- Modulation Valve
- Forward/Reverse Valve

**THEORY OF OPERATION:**

When the clutch pedal is returned to the up position, low pressure oil in engagement override valve (3) keeps the spool shifted.

Oil from passage (D) flows to three places: passage (Q) of clutch pedal valve (17), passage (E) of

modulation relief valve (13), and through orifice (11) to modulation valve (10).

Oil entering passage (Q) of clutch pedal valve flows from passage (R) to passage (L) of forward/reverse valve (12). With forward/reverse valve in neutral, oil returns to sump through sump passages (J and N).

Oil entering passage (E) of modulation relief valve is insufficient to overcome spring pressure. Modulation relief valve (13) remains closed.

Oil flowing through orifice (11) enters forward/reverse valve at passage (I) and returns to sump through sump passages (J and N).

Low pressure oil at passage (O) is insufficient to overcome spring pressure of lube cut-off valve (2), thus oil is trapped between relief valves and lube cut-off valve. Oil at passage (A) returns to sump through forward/reverse clutch pack.


OUO1085,00001DC -19-03OCT00-2/2

250  
11  
19



**PowrReverser™ Control Valve Operation—F-N-R Lever in Forward, Clutch Pedal Up**

LVC1200AE -19-0011.01




LVC1200AE

See Page 250-11-20 A


See Page 250-11-20 B

See Page 250-11-20 C



LVC1209AE


This page is intentionally left blank.



This page is intentionally left blank.

# everser™ Control Valve Operation—F-N-R Lever in Forward, Clutch Pedal Up

—19-02JUL01



≡

This page is intentionally left blank.

1—Engagement Override Piston	11—0.7 mm Orifice	C—Passage	N—Sump Passage
2—Lube Cut-Off Valve	12—Forward/Reverse Valve	D—Passage	O—Passage
3—Engagement Override Valve	13—Modulation Relief Valve	E—Passage	P—Sump Passage
4—Charge Pressure	14—Main Relief Valve	F—Passage	Q—Passage
5—Lube Pressure Test Port	15—Lube Relief Valve	G—Sump Passage	R—Passage
6—Forward Pressure Test Port	16—Spring	H—Passage	S—Sump Passage
7—System Pressure Test Port	17—Clutch Pedal Valve	I—Passage	T—Sump Passage
8—Reverse Pressure Test Port	18—Valve	J—Sump Passage	U—Passage
9—Modulation Piston	A—Lube Passage to Clutch Packs	K—Passage to Reverse Clutch	V—High Pressure Oil
10—Modulation Valve	B—Passage	L—Passage	W—Return Oil
		M—Passage to Forward Clutch	X—Lubrication Oil

**FUNCTION:**

Controls all functions of the PowrReverser™.

**MAJOR COMPONENTS:**

- Engagement Override Valve
- Clutch Pedal Valve
- Main Relief Valve
- Lubrication Relief Valve
- Lubrication Cut-Off Valve
- Modulation Valve
- Forward/Reverse Valve

**THEORY OF OPERATION:****Engagement Oil Flow:**

When the F-N-R lever is in neutral, all system oil is returned to sump and there is no pressure in the modulation valve.

When the F-N-R lever is moved from neutral to forward, system pressure flows from passage (D) of engagement override valve (3) to three places: passage (Q) of clutch pedal valve (17), passage (E) of modulation relief valve (13), and through orifice (11) to modulation valve (10).

Oil pressure flowing through orifice (11) travels to passage (I) and is blocked by the spool of forward/reverse valve (12), causing pressure to push against piston (9) of modulation valve (10). The piston pushes against three nested springs, which at the

same time push the modulation relief valve (13) closed. This spring force increases the pressure at which the relief valve opens, so the pressure flowing through passage (I) to the forward clutch pack increases. The three springs also act as an accumulator, allowing oil pressure to increase at different rates, providing modulated engagement of the clutch pack.

As the pressure modulates, modulation relief valve opens and closes providing lubrication oil for the clutch packs. This oil flows from passage (H) to passage (U) of lube cut-off valve (2).

System pressure also flows from passage (R) of clutch pedal valve to passage (L) of forward/reverse valve (12). With the F-N-R lever in forward, the forward/reverse spool is shifted and oil flows from passage (M) to the PowrReverser™. See POWRREVERSER™ OPERATION and POWRREVERSER™ POWER FLOW earlier in this group.

**Lubrication Oil Flow:**

When forward or reverse is selected, and system pressure reaches approximately 255 kPa (37 psi), pressure in passage (O) opens lube cut-off valve (2) allowing pressurized oil that has been bypassed by the modulation valve into passage (A) to lubricate the clutch packs. This lubrication of oil flows through the clutch packs and then returns to sump. The lubrication oil pressure is controlled by the lube relief valve set at 196 kPa (28 psi).

Continued on next page

OUO1085,00001DD -19-03OCT00-2/3




When a direction change is initiated, the forward/reverse spool passes through its neutral position and system oil returns to sump. System pressure to the clutch pack again accumulates slowly

to prevent damage to the components from sudden direction changes. Also, when system pressure returns to sump, lube cut-off valve closes, thus stopping the flow of pressurized lubrication oil to the clutch pack.

OUO1085,00001DD -19-03OCT00-3/3



**PowrReverser™ Control Valve Operation—F-N-R Lever in Reverse, Clutch Pedal Up**  
LVC1210AE -19-02AL01




TM1716 (28APR04) 250-11-24 5210, 5310, 5410, and 5510 Tractors PN-1100

See Page 250-11-24 A


See Page 250-11-24 B

See Page 250-11-24 C



LVC1210AE

This page is intentionally left blank.




FORWARD/REVERSE LEVER IN REVERSE, CLUTCH PEDAL UP

This page is intentionally left blank.

# PowrReverser™ Control Valve Operation—F-N-R Lever in Reverse, Clutch Pedal Up

DAE -19-02JUL01





This page is intentionally left blank.

1—Engagement Override Piston	11—0.7 mm Orifice	C—Passage	N—Sump Passage
2—Lube Cut-Off Valve	12—Forward/Reverse Valve	D—Passage	O—Passage
3—Engagement Override Valve	13—Modulation Relief Valve	E—Passage	P—Sump Passage
4—Charge Pressure	14—Main Relief Valve	F—Passage	Q—Passage
5—Lube Pressure Test Port	15—Lube Relief Valve	G—Sump Passage	R—Passage
6—Forward Pressure Test Port	16—Spring	H—Passage	S—Sump Passage
7—System Pressure Test Port	17—Clutch Pedal Valve	I—Passage	T—Sump Passage
8—Reverse Pressure Test Port	18—Valve	J—Sump Passage	U—Passage
9—Modulation Piston	A—Lube Passage to Clutch Packs	K—Passage to Reverse Clutch	V—High Pressure Oil
10—Modulation Valve	B—Passage	L—Passage	W—Return Oil
		M—Passage to Forward Clutch	X—Lubrication Oil

#### FUNCTION:

Controls all functions of the PowrReverser™.

- Lubrication Cut-Off Valve
- Modulation Valve
- Forward/Reverse Valve

#### MAJOR COMPONENTS:


- Engagement Override Valve
- Clutch Pedal Valve
- Main Relief Valve
- Lubrication Relief Valve

#### THEORY OF OPERATION:

Theory of operation for reverse is the same as forward, except that the forward/reverse valve is shifted in the opposite direction and pressure oil flows from passage (K) to the reverse clutch pack.

OUO1085,00001DE -19-03OCT00-2/2

# Transmission Power Flow—Gear Shift



TRANSMISSION POWER FLOW — GEAR SHIFT

LVC7992

LVC7992 -19-12JUL02

Continued on next page

OUC1085,00001DF -19-03OCT00-1/2

**A—PowrReverser™  
Transmission Drive Gear**  
**B—Transmission Top Shaft**  
**C—2nd Speed Drive Gear**  
**D—1st Speed Drive Gear**  
**E—4th Speed Drive Gear**

**F—3rd Speed Drive Gear**  
**G—Range Reduction Driven  
Gear**  
**H—Range Reduction Shaft**  
**I—Differential Drive Shaft**  
**J—3rd Speed Driven Gear**

**K—3rd and 4th Gear  
Synchronizer**  
**L—4th Speed Driven Gear**  
**M—1st Speed Driven Gear**  
**N—1st and 2nd Gear  
Synchronizer**

**O—2nd Speed Driven Gear**  
**P—1st Gear**  
**Q—2nd Gear**  
**R—3rd Gear**  
**S—4th Gear**

#### FUNCTION:

Gear shift section of transmission provides four speeds (forward or reverse) to the range shift section of the transmission.

#### THEORY OF OPERATION:


Transmission speed drive gears (C—F) are splined to transmission top shaft (B). The driven gears rotate freely on driven shaft. Synchronizers (K and N) are

splined to the driven shaft. When a transmission speed is selected, synchronizer (K or N) engages the appropriate driven gear. Power is then transmitted from the top shaft through the selected drive and driven gears to the driven shaft, and through the range reduction drive gear (G) to the range reduction shaft (H).

Power flow through the range reduction section is explained later in this group.

OUO1085,00001DF -19-03OCT00-2/2

## Gear Shift Synchronizer Operation



## SYNCHRONIZER OPERATION

Continued on next page

OUO1085,00001E0 -19-03OCT00-1/2

LV1212AE -19-26SEP01

A—2nd or 4th Speed Driven Gear  
B—Outer Cone

C—Friction Ring and Blocker Pin Assembly  
D—Blocker Pin

E—Spring-Loaded Neutral Detent Pin  
F—1st or 3rd Speed Driven Gear

G—Shift Collar  
H—Drive Hub

**FUNCTION:**

Synchronizer equalizes speeds of mating gears to allow a clash-free shift while the tractor is in motion.

**MAJOR COMPONENTS:**

- 2nd Speed Drive Gear
- Outer Cone
- Friction Ring and Blocker Pin Assembly
- Blocker Pins
- Neutral Detent Pins
- 1st Speed Driven Gear
- Shift Collar
- Drive Hub

**THEORY OF OPERATION:**

Drive hub (H) is splined to the transmission bottom shaft, and is in motion when the traction clutch is engaged. To obtain a clash-free shift, 2nd speed driven gear (A), outer cone (B), friction ring and blocker pin assembly (C), shift collar (G), and drive hub (H) must be turning at the same rate of speed. When at the same rate of speed, blocker pins will allow a clash-free shift.

**1st Gear Operation:**

To shift into 1st gear, shift collar (G) will be moved toward the rear of the transmission by the shift fork.

As the shift collar is moved rearward, misalignment of the blocker pins and shift collar moves the friction ring and blocker pin assembly rearward into the outer cone. The friction between the friction ring assembly and the outer cone will bring 1st speed driven gear (F) to the same rate of speed as drive hub (H). When 1st speed driven gear is turning at the same rate of speed as the drive hub, the blocker pins will allow the shift collar to move rearward. As the shift collar moves rearward, it engages to the splines on the 1st speed driven gear to place the transmission into 1st gear.

**2nd Gear Operation:**

Operation of the synchronizer when 2nd gear is selected is the same as 1st gear, except the shift collar is moved toward the front of the transmission.


**3rd and 4th Gear Operation:**

Operation of the 3rd and 4th gear synchronizer is the same as described above. The shift collar is moved rearward to engage 3rd gear and forward to engage 4th gear.

250  
11  
29

OUO1085,00001E0 -19-03OCT00-2/2

# Transmission Power Flow—Range Shift



LVC7993

LVC7993 -19-12JUL02

TRANSMISSION POWER FLOW — RANGE SHIFT

Continued on next page

OOU1085,00001E1 -19-03OCT00-1/2

A—Range Reduction Driven Gear

B—B Range Drive Gear

C—A Range Drive Gear

D—Creeper Drive Gear

E—Creeper Driven Gear

F—Range Reduction Shaft

G—Differential Drive Shaft

H—A Range and Creeper Shift Sliding Gear

I—MFWD Driven Gear

J—B Range Driven Gear

K—B and C Range Shift Collar

L—C Range Drive Gear

M—Driven Shaft

N—A Range

O—B Range

P—C Range

Q—Creeper Range

#### FUNCTION:

Provides three range speeds and an optional creeper speed.

#### MAJOR COMPONENTS:

- Range Reduction Drive Gear
- Range Reduction Shaft
- Drive Gears
- Driven Gears
- B and C Range Shift Collar
- A Range and Creeper Shift Sliding Gear
- Driven Shaft
- Differential Drive Shaft

#### THEORY OF OPERATION:

Range selection is achieved through a combination of the drive gears on the range reduction shaft (F) and the driven gears on the differential drive shaft (G).

Driven shaft (M) transmits power to the range reduction shaft through C range drive gear (L) and range reduction driven gear (A) which are constantly in mesh. The C range drive gear is part of the driven shaft, and the range reduction driven gear (A) is splined to the range reduction shaft.

#### C Range:

C range drive gear (L) is machined on the end of driven shaft (M). B and C range shift collar (K) is splined to differential drive shaft (G). When the C range is selected, the range shift collar slides and engages the splines on the end of the driven shaft (M)

and power is transmitted to the differential drive shaft (G).

#### B Range:

The B range drive gear (B) is splined to the range reduction shaft (F). The B range drive gear is constantly in mesh with the B range driven gear (J) which floats on the differential drive shaft (G). When the B range is selected, the shift collar (K) engages the B range driven gear and power is transmitted to the differential drive shaft.

#### A Range:

The A range drive gear (C) is splined to the range reduction shaft (F). When the A range is selected, the A range and creeper shift sliding gear (H) slides and engages the A range drive gear (C).

#### Optional Creeper Range:


When the optional creeper assembly is installed on the transmission, the A range drive gear (C) on the range reduction shaft (F) is constantly in mesh with the creeper drive gear (D).

When the creeper range is selected, the A range and creeper shift sliding gear (H) slides to engage the creeper driven gear (E).

Power flow is then transmitted from the range reduction shaft through the creeper assembly to the A range and creeper shift sliding gear and to the differential drive shaft (G).



# PowrReverser™ Transmission Lubrication System



LVC7994

## TRANSMISSION LUBRICATION SYSTEM

LVC7994 -19-12JUL02

Continued on next page

OUO1085,00001E3 -19-03OCT00-1/2

A—Traction Drive Shaft  
B—PowrReverser™  
C—Transmission Top Shaft

D—Range Reduction Shaft  
E—Pressurized Return Oil  
From Steering Valve

F—PTO Shaft  
G—Pressurized Lube Oil From  
Hydraulic Reverser Control  
Valve

H—Pressure-Free Oil

**FUNCTION:**

The transmission case and clutch housing serve as the main reservoir for the hydraulic system, steering system, and brake system. The oil also acts as lubrication oil for the PowrReverser™, transmission, and differential components.

**MAJOR COMPONENTS:**

- Clutch Housing
- Transmission Case
- PowrReverser™
- Transmission Top Shaft
- Range Reduction Shaft

**THEORY OF OPERATION:**

During operation, pressure-free oil (H) in the clutch housing and transmission case is thrown up by the

turning gears to lubricate transmission and PowrReverser™ components.

Pressurized return oil (E) from the steering valve enters the left side of the differential case via the transmission lubrication line. A passage in the differential case intersects the bearing bore at the end of the range reduction shaft (D). The pressurized lube oil flows around the PTO shaft (F) and through the hollow range reduction shaft (D) and transmission top shaft (C) to lubricate the bearings for these shafts.

Pressurized lubrication oil (G) is also provided by the PowrReverser™ charge pump via the PowrReverser™ control valve. This oil flows through passages in the traction drive shaft (A) to lubricate the PowrReverser™ clutch packs.

OUO1085,00001E3 -19-03OCT00-2/2

**Rear PTO Operation**

Rear PTO operation for units with PowrReverser™ transmissions is the same as units with collar shift or SyncShuttle™ transmissions. See Group 10 for information.

OUO1085,00001E4 -19-03OCT00-1/1

## Final Drive Operation

Final drive operation for units with PowrReverser™ transmissions is the same as units with collar shift or SyncShuttle™ transmissions. See Group 10 for information.

OUO1085,00001E5 -19-03OCT00-1/1

## Differential Operation

Differential operation for units with PowrReverser™ transmissions is the same as units with collar shift or SyncShuttle™ transmissions. See Group 10 for information.

OUO1085,00001E6 -19-03OCT00-1/1

## MFWD Operation

MFWD operation for units with PowrReverser™ transmissions is the same as units with collar shift or SyncShuttle™ transmissions. See Group 10 for information.

OUO1085,00001E7 -19-03OCT00-1/1

## Diagnostic Information

The diagnostic information in this group is used to test components related to a specific problem or system. Select a symptom or system from the list and follow the test procedures under the heading. The symptom or system headings are:

Isolate the Problem Area

- Clutch
- Transmission
- Rear PTO
- Differential and Final Drive
- Mechanical Front Wheel Drive

The diagnostic procedure lists:

- Test conditions
- Test sequence
- Test location
- Normal reading
- Check or test to perform if reading is not normal

When performing the test or check, be sure to set your machine up to the test conditions listed and follow the sequence carefully. The middle “Normal” column gives the reading or condition that should be obtained when performing the test or check. If the results of the test or check are not normal, perform the test, check, or adjustment listed in the third “If Not Normal” column to repair the malfunction. The detailed tests or adjustments referred to in the “If Not Normal” column are located at the end of this group.

OUO1085,00001E8 -19-03OCT00-1/1

## Isolate the Problem Area

### CONDITIONS:

- Before starting, inspect the entire tractor for oil leakage. Locate the source of leakage, determine the cause and make the necessary repairs.
- During the tests you will be listening for abnormal noises. A mechanic's stethoscope may be helpful.
- Begin the test procedure with the gear shift lever and range shift lever in neutral, and the MFWD and rear PTO disengaged.

Test Location	Normal	If Not Normal
1. Check transmission oil.	Level not too low.	Check for leakage and refill.
	Level not too high.	Drain oil to proper level.
	Oil not contaminated with metal fragments or debris.	Drain oil and replace filter. Clean screen and determine cause of contamination.
	Oil not foamy or discolored.	Make sure type of oil is correct. Check for hydraulic cause of overheating.
2. Check all linkage operation and return it to the neutral or disengaged position.	No damage or binding.	Repair linkage.
3. Run engine with transmission clutch pedal disengaged.	No noise or vibration.	Inspect engine.
4. Partially engage clutch pedal and vary engine rpm.	No noise or vibration.	Inspect clutch. Inspect PTO drive shaft and bearings.
5. Fully engage clutch pedal and vary engine rpm.	No noise or vibration.	Inspect clutch. Inspect traction drive shaft.
6. Place gear shift lever in each forward gear and reverse. Leave range shift lever in neutral. Engage traction clutch pedal and vary engine rpm in each gear.	No noise or vibration.	Inspect gear mesh for speed selected when noise or vibration occurred. Inspect driven shaft or range reduction shaft bearing if noise occurred in all speeds. Inspect reverse idle shaft and bearing if problem occurred (only in reverse).
7. Place transmission in neutral, engage rear PTO, and vary engine rpm.	No noise or vibration.	Inspect rear PTO shaft, gears, and bearings.

Continued on next page

OUO1085,00001E9 -19-03OCT00-1/2

**NOTE:** From this point on you will be driving the tractor.  
Operate in an open level area and turn sharply  
from left to right periodically to observe any  
change in noise as you turn.

Test Location	Normal	If Not Normal
8. Place transmission in 2nd gear. Operate tractor in each range.	Tractor moves smoothly going straight.	Inspect gear mesh in range where problem was evident.
		Inspect differential drive shaft if problem was evident in all ranges.
	No change when making turns.	Inspect differential or final drive and axles.
9. Leave transmission in 2nd gear and low range and engage differential lock while operating at low engine rpm. Turn from left to right.	Tractor resists turning. Differential lock stays engaged. No noise.	Inspect differential lock and linkage.
10. Leave transmission in 2nd gear and low range. Release differential lock. Engage MFWD. Drive straight and turn left and right.	No noise or vibration.	Inspect gears and bearings in MFWD drop gearbox if problem was evident at all times.
		Inspect MFWD axles if problem was evident only when turning.

OUO1085,00001E9 -19-03OCT00-2/2

## Traction Clutch Slips

### CONDITIONS:

- Adjustments found in this group.
- Repair in Section 50, Group 10.

Test Location	Normal	If Not Normal
1. Clutch pedal.	Free play at correct specification.	Adjust pedal free play.
2. Traction clutch disk.	No oil or grease on facing.	Clean or replace disk.
	No evidence of wear or glazing on facing. No warpage.	Replace disk.
3. Traction clutch pressure plate.	Does not bind on operating bolts.	Clean or replace operating bolts or pressure plate.
	No evidence of warpage.	Replace pressure plate.
4. Traction clutch coil springs.	All springs same length. No evidence of bent or damaged condition.	Replace springs.
5. Traction clutch release fingers.	No binding or sticking.	Clean or replace fingers.
6. Spring washer under PTO clutch rear pressure plate.	Tractor moves forward and reverse with no clutch slippage.	Replace spring washer.

OUO1085,00001EA -19-03OCT00-1/1

**Traction Clutch Dragging****CONDITIONS:**

- Adjustments found in this group.
- Repair in Section 50, Group 10.

Test Location	Normal	If Not Normal
1. Clutch pedal.	Free play at correct specification.	Adjust free play if excessive.
2. Traction clutch release bearing.	Slides freely on shaft.	Clean, lubricate, or replace.
3. Traction clutch disk.	Slides freely on shaft splines.	Clean, lubricate, or replace.
	No warpage or damage.	Replace disk.
4. Traction clutch pressure plate.	No warpage.	Replace pressure plate.

OUO1085,00001EB -19-03OCT00-1/1

**Traction Clutch Does Not Engage****CONDITIONS:**

- Adjustments and repair in Section 50, Group 10.

Test Location	Normal	If Not Normal
1. Traction clutch release bearing.	Slides freely on shaft.	Clean, lubricate, or replace bearing.
2. Traction clutch release levers.	Adjusting screws adjusted for proper clearance.	Adjust screws.
3. Traction clutch disk.	No evidence of wear, scoring, or burning on disk faces.	Replace disk.
	No evidence of damage to disk hub.	Replace disk.

OUO1085,00001EC -19-03OCT00-1/1

## Traction Clutch Grabs

### CONDITIONS:

- Repair in Section 50, Group 10.

Test Location	Normal	If Not Normal
1. Clutch pedal linkage and armshaft.	Operates freely with no binding.	Clean, lubricate, or adjust.
2. Traction clutch disk.	Slides freely on shaft splines.	Clean, lubricate, or replace.
	No oil or grease on disk facing. No evidence of wear or glazing on disk face. No warpage or damage. Rivets at hub are tight.	Clean or replace disk.
3. Traction clutch pressure plate.	No warpage or damage.	Replace pressure plate.

QUO1085,00001ED -19-03OCT00-1/1

## Traction Clutch Squeaks

### CONDITIONS:

- Repair in Section 50, Group 10.

Test Location	Normal	If Not Normal
1. Flywheel pilot bearing.	Lubricated sufficiently.	Lubricate.
2. Traction clutch release bearing.	Lubricated sufficiently.	Lubricate.
	Bearing spins freely. No evidence of wear or damage.	Replace bearing.

QUO1085,00001EE -19-03OCT00-1/1

250  
15  
5



## Traction Clutch Does Not Release

### CONDITIONS:

- Repair in Section 50, Group 10.

Test Location	Normal	If Not Normal
1. Traction clutch disk and pressure plate.	Disk and pressure plate separate freely with no sticking.	Clean or replace disk and/or pressure plate. If storing tractor, block clutch pedal in disengaged position.

OUO1085,00001EF -19-03OCT00-1/1

## Traction Clutch Chatters

### CONDITIONS:

- Clutch repair in Section 50, Group 10.
- Rear axle repair in Section 50, Group 30.
- Transmission repair in Section 50, Group 15.

Test Location	Normal	If Not Normal
1. Clutch assembly.	Clean and free of rust.	Clean or replace clutch components or assembly.
2. Traction clutch disk.	No oil or grease on facing.	Clean or replace disk.
	No evidence of wear or glazing on facing. No evidence of warpage.	Replace disk.
3. Traction clutch pressure plate.	Not warped. No evidence of cracks or other damage.	Replace pressure plate.
4. Traction clutch operating levers.	Operate freely with no binding or sticking.	Clean, lubricate, or replace operating levers.
5. Traction clutch disk hub and shaft.	Hub slides freely on shaft. No evidence of wear or damage.	Clean, lubricate, or replace disk and/or shaft.
6. Traction clutch coil springs.	All springs are same length. No evidence of bent or damaged condition.	Replace springs.
7. Rear axles.	Rotate smoothly with little or no end play.	Lubricate bearings and/or adjust end play. Replace worn or damaged components.
8. Transmission.	Backlash is adjusted properly.	Adjust or repair transmission.
9. Spring washer under PTO clutch pressure plate.	Tractor moves forward and reverse with no clutch slippage or chatter.	Replace spring washer.

OUO1085,00001F0 -19-03OCT00-1/1

250  
15  
7

**Traction Clutch Rattles****CONDITIONS:**

- Repair and adjustment in Section 50, Group 10.

Test Location	Normal	If Not Normal
1. Traction clutch release bearing.	Bearing spins freely. No evidence of wear or damage.	Replace bearing.
2. Flywheel pilot bearing.	Bearing spins freely. No evidence of wear or damage.	Replace bearing.
3. Traction clutch release fingers.	Adjusting screws adjusted for proper clearance.	Adjust screws.
4. Clutch shaft.	No evidence of wear, damage, or bent condition.	Replace shaft.
5. Traction clutch disk.	Hub is tight on disk. All rivets are tight.	Replace disk.

QUO1085,00001F1 -19-03OCT00-1/1

**Traction Clutch Engagement Is Noisy****CONDITIONS:**

- Repair in Section 50, Group 10.

Test Location	Normal	If Not Normal
1. Clutch shaft.	No evidence of wear, damage, or bent condition.	Replace shaft.
2. Traction clutch disk.	Hub is tight on disk. All rivets are tight.	Replace disk.

QUO1085,00001F2 -19-03OCT00-1/1

**Excessive Vibration in Traction Clutch****CONDITIONS:**

- Repair in Section 50, Group 10.

Test Location	Normal	If Not Normal
1. Clutch assembly.	Clean and free of rust.	Clean or replace clutch.
2. Clutch shaft.	No evidence of wear, damage, or bent condition.	Replace shaft.
3. Traction clutch disk.	No evidence of wear or glazing on facing. No warpage.	Replace disk.
4. Traction clutch pressure plate.	No evidence of damage or warpage.	Replace pressure plate.
5. Flywheel pilot bearing.	Bearing spins freely. No evidence of wear or damage.	Replace bearing.

OUO1085,00001F3 -19-04OCT00-1/1

250  
15  
9**Clutch Pedal Does Not Return****CONDITIONS:**

- Repair in Section 50, Groups 05 and 10.
- Pedal adjustment in this group.

Test Location	Normal	If Not Normal
1. Clutch pedal linkage.	Operates freely and smoothly in both directions. No evidence of wear or damage.	Adjust or replace linkage components.
	Clutch pedal return spring is connected securely and not distorted or broken.	Connect or replace spring.
2. Traction clutch release bearing.	Bearing and sleeve operate smoothly without binding.	Clean, lubricate, or replace sleeve.

OUO1085,00001F4 -19-04OCT00-1/1

**Clutch Pedal Loose**

## CONDITIONS:

- Repair in Section 50, Groups 05 and 10.

Test Location	Normal	If Not Normal
1. Clutch pedal linkage.	Yoke and jam nut are tight on rod.	Tighten or replace yoke, nut, or rod.
	Pedal shaft bushings are not worn or damaged.	Replace bushings or pedal.
2. Traction clutch release linkage.	No evidence of wear or damage to yoke, shoes, armshaft, or bushings.	Replace worn or damaged components.

OUO1085,00001F5 -19-04OCT00-1/1

**Clutch Pedal Pulsates**

## CONDITIONS:

- Clutch repair in Section 50, Groups 05 and 10.
- Flywheel repair in CTM104 or CTM125.

Test Location	Normal	If Not Normal
1. Clutch pedal linkage.	Clutch pedal return spring is connected securely and not distorted or broken.	Connect or replace spring.
2. Clutch shaft.	Shaft is straight.	Replace shaft.
3. Traction clutch release linkage.	No evidence of wear or damage to yoke, shoes, armshaft, or bushings.	Replace worn or damaged components.
4. Flywheel.	Flywheel turns evenly. No evidence of warpage or uneven mounting.	Tighten, reinstall, or replace flywheel.

OUO1085,00001F6 -19-04OCT00-1/1

**Jerky or Rough Transmission of Power**

## CONDITIONS:

- Repair in Section 50, Group 10.

Test Location	Normal	If Not Normal
1. Traction clutch disk and pressure plate.	No evidence of warpage or uneven wear.	Replace disk and/or pressure plate.

OUO1085,00001F7 -19-04OCT00-1/1

## Low Transmission Oil Level (Excessive Oil Leakage)

### CONDITIONS:

- Repair in Section 50.

Test Location	Normal	If Not Normal
1. Clutch, transmission, and differential housings.	Power train housings are clean and dry, with no evidence of leakage from drain plugs, gaskets, or seals.	Tighten drain plug(s).
	All hardware securing housings and covers is tight.	Tighten all mounting hardware to correct torque. Replace missing hardware. Replace leaking seals or gaskets.
	Transmission oil has proper viscosity and grade.	Drain and refill.

OUO1085,00001F8 -19-04OCT00-1/1

250  
15  
11

## Gears Clash, Shift Hard, or Will Not Engage

### CONDITIONS:

- Clutch adjustment in Section 50, Group 10.
- Transmission and lever repair in Section 50, Group 15.

Test Location	Normal	If Not Normal
1. Clutch.	Clutch operates smoothly. All gears engage freely.	Adjust clutch.
2. Speed and range shifter linkage.	Linkage is adjusted properly.	Adjust.
	Linkage shows no evidence of wear or damage.	Replace worn or damaged components.
3. Speed and range shifter assemblies.	All shafts operate smoothly. No evidence of wear or damage to shifters, arms, forks, or detent balls and springs. Shifter forks are not loose on shafts.	Replace worn or damaged components.
4. Transmission.	No evidence of wear or damage to gear teeth or splines. Gears that are splined to shafts are not loose. Gears that float on shafts turn freely. Shift collars and/or synchronizers slide freely between gears with no binding.	Clean and lubricate any binding parts. Replace worn or damaged components.

OUO1085,00001F9 -19-04OCT00-1/1

## Two Speeds Engage Together

### CONDITIONS:

- Repair in Section 50, Group 15.

Test Location	Normal	If Not Normal
1. Speed and range shifter assemblies.	All shafts operate smoothly. No wear or damage to shaft detents. Detent ball assemblies installed properly and not worn or damaged. Springs not weak or broken.	Replace worn or damaged components.
2. Transmission.	No evidence of wear or damage to gear teeth or splines. Gears that are splined to shafts are not loose. Gears that float on shafts turn freely.	Replace worn or damaged components.
	All transmission components assembled correctly.	Reassemble.

OUO1085,00001FA -19-04OCT00-1/1

## Transmission Will Not Stay in Gear

### CONDITIONS:

- Repair in Section 50, Group 15.

Test Location	Normal	If Not Normal
1. Speed and range shifter assemblies.	All shafts operate smoothly. No wear or damage to shaft detents. Detent ball assemblies installed properly and not damaged. Springs not weak or broken.	Replace worn or damaged components.
2. Transmission.	No evidence of wear or damage to gear teeth, splines, shift collars, and/or synchronizers or shifter forks.	Replace worn or damaged components.

OUO1085,00001FB -19-04OCT00-1/1

**Transmission Noisy**

## CONDITIONS:

- Repair in Section 50, Group 15.

Test Location	Normal	If Not Normal
1. Transmission shafts.	Shafts and shaft bearings spin freely and without noise. No evidence of wear or damage to shaft splines or bearings.	Replace worn or damaged components.
2. Transmission gears.	Gears that are splined to shafts are not loose. Gears that float on shafts turn freely. Shift collars and/or synchronizers slide freely between gears with no binding. No evidence of wear or damage to gear teeth or splines.	Clean and lubricate any binding parts. Replace worn or damaged components.
3. Speed and range shift forks.	No evidence of wear, damage, or bent condition.	Replace worn or damaged components.
4. Park pawl assembly.	Park pawl retracts fully when disengaged.	Replace worn or damaged linkage or springs.

OUO1085,00001FC -19-04OCT00-1/1

**PTO Noisy**

## CONDITIONS:

- Repair in Section 50, Group 20.

Test Location	Normal	If Not Normal
1. PTO connection.	No noise from PTO, even when implements connected.	Disconnect implement and check for PTO noise.
2. PTO gears.	No evidence of wear or damage to gear teeth or splines.	Replace worn or damaged gears.
3. PTO shafts.	All shafts are straight. No evidence of wear or damage to splines or bearing surfaces.	Replace worn or damaged shafts.
4. PTO bearings.	All bearings spin freely. No wear or damage.	Replace worn or damaged bearings.

OUO1085,00001FD -19-04OCT00-1/1

250  
15  
13



## PTO Hard to Engage

### CONDITIONS:

- Adjustments in this group.
- Repair in Section 50, Group 20.

Test Location	Normal	If Not Normal
1. PTO lever linkage.	Operates freely with no binding. Linkage adjusted properly.	Adjust linkage.
2. PTO gears.	No wear or damage to gear teeth or splines.	Replace worn or damaged components.

QUO1085,00001FE -19-04OCT00-1/1

## PTO Will Not Operate

### CONDITIONS:

- Repair in Section 50, Group 20.

Test Location	Normal	If Not Normal
1. PTO shafts.	All shafts are straight. No wear or damage to shaft splines or bearing surfaces.	Replace worn or damaged components.
2. PTO assembly.	PTO is assembled correctly.	Reassemble.

QUO1085,00001FF -19-04OCT00-1/1

## PTO Will Not Stay Engaged

Test Location	Normal	If Not Normal
1. PTO gears.	No wear or damage to gear teeth or splines.	Replace worn or damaged components.

QUO1085,0000200 -19-04OCT00-1/1

**Excessive Differential Noise**

## CONDITIONS:

- Adjustments and repair in Section 50, Group 25.

Test Location	Normal	If Not Normal
1. Differential lock assembly.	Lock disengages fully when pedal is replaced.	Repair lock assembly.
2. Differential gears.	Cone point adjustment and backlash adjustment are correct.	Adjust.
	No wear or damage to gears or pinion teeth and splines.	Replace worn or damaged components.
3. Differential bearings.	All bearings spin freely. No evidence of wear or damage.	Replace worn or damaged components.

OUO1085,0000201 –19–04OCT00–1/1

250  
15  
15**Differential Does Not Work**

## CONDITIONS:

- Repair in Section 50, Group 25.

Test Location	Normal	If Not Normal
1. Differential lock.	Lock disengages when pedal is released.	Repair lock assembly.
2. Pinion shaft.	Shaft is straight. No wear or damage to teeth or splines.	Replace pinion shaft.
3. Bevel pinions and gears.	No wear or damage to teeth or splines.	Replace pinions and/or gears.
4. Thrust washers.	No wear or damage.	Replace thrust washers.
5. Differential housing.	Housing is not damaged or distorted.	Replace housing.

OUO1085,0000204 –19–04OCT00–1/1

**No Differential Lock**

## CONDITIONS:

- Repair in Section 50, Group 25.

Test Location	Normal	If Not Normal
1. Pedal.	Movement of pedal causes shaft to move out of housing. Pedal is not worn, bent, or damaged.	Replace pedal.
2. Lock shaft.	Roller at end of shaft turns freely on bolt. Roller is not worn or damaged.	Replace roller and/or bolt.
	Shaft slides freely and is not worn or damaged.	Replace lock shaft.

OUO1085,0000205 -19-04OCT00-1/1

**Differential Chatters**

## CONDITIONS:

- Axle repair in Section 50, Group 30.
- Differential repair in Section 50, Group 25.

Test Location	Normal	If Not Normal
1. Axles.	Axles are mounted securely and show no evidence of wear or damage.	Repair axle(s).
2. Differential gears and pinions.	No wear or damage to gear teeth or splines.	Replace gears or pinions.
3. Differential bearings.	Bearings spin freely. No wear or damage.	Replace bearings.

OUO1085,0000206 -19-04OCT00-1/1

## Axle Noise

### CONDITIONS:

- Repair in Section 50, Group 30.

Test Location	Normal	If Not Normal
1. Final drive pinion shaft.	No wear or damage.	Replace pinion shaft.
2. Planetary pinions.	No wear or damage.	Replace pinions.
3. Ring gear.	Adjusted properly. No wear or damage.	Adjust free play or replace ring gear.
4. Axle bearings.	All bearings spin freely. No wear or damage.	Replace bearings.

OUO1085,0000207 -19-04OCT00-1/1

## Axle Shaft Will Not Turn

### CONDITIONS:

- Brake repair in Section 60, Group 10.
- Axle repair in Section 50, Group 30.

Test Location	Normal	If Not Normal
1. Brakes.	Brakes disengage fully when pedal is released.	Adjust or repair brakes.
2. Axle shaft.	Axle shaft is not seized or broken.	Repair or replace axle.
3. Planetary unit.	Planetary is not seized or broken.	Repair or replace planetary.

OUO1085,0000208 -19-04OCT00-1/1

250  
15  
17

## MFWD Lever is Hard to Engage

### CONDITIONS:

- Repair in Section 50, Group 35.

Test Location	Normal	If Not Normal
1. MFWD shift linkage.	Linkage operates smoothly. No evidence of wear, damage or bent condition.	Repair or replace linkage.
2. Shift fork.	No evidence of wear, damage or bent condition.	Replace shift fork.
3. Shift collar.	Collar slides smoothly. No wear or damage to splines.	Clean and lubricate, or replace collar.
4. MFWD Shaft.	No wear or damage to splines.	Replace shaft.

QUO1085,0000209 -19-04OCT00-1/1

## MFWD Lever Will Not Stay in “ON” Position

### CONDITIONS:

- Repair in Section 50, Group 35.

Test Location	Normal	If Not Normal
1. MFWD shift linkage.	No evidence of wear, damage, or bent condition.	Repair or replace linkage.
2. Shift fork.	No evidence of wear, damage, or bent condition.	Replace shift fork.

QUO1085,000020A -19-04OCT00-1/1

## Noisy Front Wheel Drive Operation

### CONDITIONS:

- Repair in Section 50, Group 35.

Test Location	Normal	If Not Normal
1. MFWD shafts and gears.	No wear or damage to teeth or splines.	Replace shafts or gears.
2. Bearings.	All bearings spin freely. No wear or damage.	Replace bearings.

OUO1085,000020B -19-04OCT00-1/1

250  
15  
19

## Clutch Pedal Free Play Adjustment

### REASON:

To make sure traction clutch is fully engaged when clutch pedal is released and fully disengaged when pedal is depressed.


### PROCEDURE:

1. Depress clutch pedal to feel how far the pedal travels before resistance is felt. Measure free play distance (A).
2. If not within specifications, loosen lock nut (B), remove clip and pin (C) and rotate turnbuckle as necessary.


#### Specification

Pedal—Free Play Distance .....  $13 \pm 3$  mm ( $0.512 \pm 0.118$  in.)

- A—Pedal Free Play Distance  
B—Lock Nut  
C—Pin



LV274 -UN-18FEB92



LV275 -UN-18FEB92

OUO1085,000020C -19-04OCT00-1/1

## PTO Clutch Lever Adjustment

### REASON:


To make sure PTO clutch is fully engaged when lever is in full forward and fully disengaged when lever is full rearward.

### PROCEDURE:


**NOTE:** PTO lever should be in its rearward (disengaged) position for adjusting PTO clutch linkage.

1. Move PTO lever to rearward (disengaged) position.
2. Remove pin with clip (B) from forward end of PTO clutch rod.
3. Loosen jam nut (C) at front of PTO clutch rod.
4. Adjust initial rod length to 783 mm (30.8 in.) (A).
5. Adjust length of rod to eliminate free play. Lengthen rod by 1/2 turn of the clevis to provide a slight amount of lever free play.
6. Install clip pin (B) in the PTO link.
7. Check for equal thread engagement at each end of the PTO clutch rod. Jam nut (D) at the rear can be loosened and the rod turned to equalize thread engagement (PTO adjustment is not affected).
8. Tighten jam nuts (C and D) at each end of rod.


A—Initial Rod Length  
B—Pin With Clip  
C—Jam Nut  
D—Jam Nut



LV900AE -UN-10DEC94



LV277 -UN-18FEB92



LV278 -UN-18FEB92

QUO1085,000020D -19-04OCT00-1/1

## Diagnostic Information

The diagnostic information in this group is used to test components related to a specific problem or system. Select a symptom or system from the list and follow the test procedures under the heading. The symptom or system headings are:

Isolate the Problem Area

- Clutch Pedal
- PowrReverser™
- Transmission

The diagnostic procedure lists:

- Test conditions
- Test sequence
- Test location
- Normal reading
- Check or test to perform if reading is not normal


When performing the test or check, be sure to set your machine up to the test conditions listed and follow the sequence carefully. The middle “Normal” column gives the reading or condition that should be obtained when performing the test or check. If the results of the test or check are not normal, perform the test, check, or adjustment listed in the third “If Not Normal” column to repair the malfunction. The detailed tests or adjustments referred to in the “If Not Normal” column are located at the end of this group.

**NOTE:** *Diagnosis, Tests, and Adjustments for Rear PTO, Differential, Final Drive, and Mechanical Front Wheel Drive on units with PowrReverser™ transmissions is the same as on units with collar shift or SyncShuttle™ transmissions. See Group 15 for information.*

OUO1085,000020F –19–04OCT00–1/1



## Isolate the Problem Area



ISOLATE THE PROBLEM AREA

LV1217AE

LV1217AE -19-16DEC97

Continued on next page

OUC1085,0000210 -19-04OCT00-1/3

**A—F-N-R Lever**  
**B—Range Shift Lever**

**C—Rear PTO Lever**  
**D—MFWD Lever**

**E—Gear Shift Lever**  
**F—Differential Lock Pedal**

**G—Clutch Pedal**

During the tests, you will be using all of your senses to evaluate machine operation. Does something feel different or abnormal? Does something smell different? Observe gauges and indicator lights. Listen for abnormal noises. A mechanic's stethoscope may be helpful.

**CONDITIONS:**

- Begin test procedures with all levers in neutral, and with MFWD and PTO disengaged.

Test	Normal	If Not Normal
1. Check transmission oil.	Level not too low.	Check for leakage. Repair as necessary. Refill to proper level.
	Level not too high.	Drain oil to proper level.
	Oil not contaminated with metal fragments or debris.	Drain oil and replace filter. Clean screen in differential and filter screen in PowrReverser™ control valve.
	Oil not foamy or discolored.	Be sure oil is correct type and grade. Check for cause of hydraulic overheating.
2. Check all control linkage. Ensure proper adjustment and operation. Return all controls to the neutral or disengaged position.	No damage or binding.	Adjust or repair linkage.
3. Start engine without depressing clutch pedal.	No abnormal noise or vibration. No tractor movement.	Inspect traction drive shaft bearings in clutch housing. Inspect PowrReverser™ clutch packs.
4. Without depressing clutch pedal, place transmission in B-2 and place F-N-R lever in forward. Vary engine speed. Return all levers to neutral position.	No tractor movement.	Perform PowrReverser™ control valve tests.
5. Engage rear PTO and vary engine speed.	No abnormal noise or vibration.	Inspect rear PTO shaft, gears, and bearings (from clutch housing to PTO output shaft).
6. Press clutch pedal down once and release. Place F-N-R lever in forward. Leave range shift lever in neutral. Place gear shift lever in each speed and vary engine speed in each gear.	No abnormal noise or vibration.	Inspect gear mesh for speed selected when noise or vibration occurred. Inspect bearings for transmission top shaft, driven shaft, or range reduction shaft if noise occurs in all speeds.
7. Place transmission in 2nd gear. Leave range shift lever in neutral. Place F-N-R lever in reverse. Vary engine speed.	No abnormal noise or vibration.	Inspect mesh of reverse drive gear with driven gear and mesh of transfer gear, reverse idler, and transmission drive gear. Inspect bearings of driven shaft and reverse idler.

Continued on next page

OUC1085,0000210 -19-04OCT00-2/3

**NOTE:** From this point on you will be driving the tractor. Operate in an open level area and turn

sharply from left to right periodically to observe any change in noise as you turn.

Test	Normal	If Not Normal
8. Place transmission in 2nd gear and low range. Shift from neutral to forward and reverse at low idle and full speed.	Tractor moves smoothly from stop or changes direction smoothly after 1.5—2.5 second delay.	Perform PowrReverser™ control valve tests.
9. Place transmission in 2nd gear. Operate tractor in each range.	Tractor moves smoothly going straight.	Inspect gear mesh in range where problem was evident. Inspect differential drive shaft if problem is evident in all ranges.
	No abnormal noise or vibration when making turns.	Inspect differential or final drive and axles.
10. Leave transmission in 2nd gear and low range. Engage differential lock while operating at low engine speed. Turn from left to right.	Tractor resists turning. Differential lock stays engaged. No abnormal noise or vibration.	Inspect differential lock and linkage.
11. Leave transmission in 2nd gear and low range. Release differential lock. Engage MFWD. Drive straight and turn left and right.	No abnormal noise or vibration.	Inspect gears and bearings in MFWD drop gearbox if problem is evident at all times.
		Inspect MFWD axles if problem was evident only when turning.

OUO1085,0000210 -19-04OCT00-3/3

## Low Transmission Oil Level (Excessive Oil Leakage)

### CONDITIONS:

- Repair in Section 50.

Test Location	Normal	If Not Normal
1. Clutch, transmission, and differential housings.	Power train housings are clean and dry, with no evidence of leakage from drain plugs, gaskets, or seals.	Tighten drain plug(s).
	All hardware securing housings and covers is tight.	Tighten all mounting hardware to correct torque. Replace missing hardware. Replace leaking seals or gaskets.
	Transmission oil has proper viscosity and grade.	Drain and refill.

OUO1085,0000211 -19-04OCT00-1/1

**Clutch Pedal Does Not Return**

## CONDITIONS:

- Repair in Section 50, Group 06.
- Linkage adjustment in this group.

Test	Normal	If Not Normal
1. Clutch pedal linkage.	Operates freely and smoothly in both directions. No evidence of wear or damage.	Adjust or replace linkage components. Inspect clutch pedal valve spool for binding. Repair as necessary.
	Clutch pedal return spring is connected securely and not distorted or broken.	Connect or replace spring.

OUO1085,0000213 –19–04OCT00–1/1

250  
16  
5**Tractor Does Not Move in Forward or Reverse**

## CONDITIONS:

- Linkage adjustment and hydraulic tests in this group.
- Linkage and PowrReverser™ repair in Section 50, Group 12.

Test	Normal	If Not Normal
1. F-N-R linkage.	Linkage is adjusted properly and shows no evidence of wear or damage.	Adjust or repair linkage.
2. Hydraulic system.	All pressures within specifications. See PowrReverser™ Control Valve Tests later in this group.	Repair PowrReverser™ control valve.
3. PowrReverser™.	No evidence of wear or damage to PowrReverser™ components. Pistons, plates, and discs slide freely within cylinder.	Repair PowrReverser™.

OUO1085,0000214 –19–04OCT00–1/1

## PowrReverser™ Engages Too Quickly or Too Slowly

### CONDITIONS:

- Linkage adjustment and hydraulic tests in this group.
- Linkage and PowrReverser™ repair in Section 50, Group 12.

**NOTE:** Normal engagement of PowrReverser™ occurs within 1.5—2.5 seconds.

Test	Normal	If Not Normal
1. F-N-R linkage.	Linkage is adjusted properly and shows no evidence of wear or damage.	Adjust or repair linkage.
2. Hydraulic system.	All pressures within specifications. See PowrReverser™ Control Valve Tests later in this group.	Repair PowrReverser™ control valve.
3. PowrReverser™.	No evidence of wear or damage to PowrReverser™ components. Pistons, plates, and discs slide freely within cylinder.	Repair PowrReverser™.

OUO1085,0000215 -19-04OCT00-1/1

## PowrReverser™ Does Not Disengage

### CONDITIONS:

- Linkage adjustment and hydraulic tests in this group.
- Linkage and PowrReverser™ repair in Section 50, Group 12.

Test	Normal	If Not Normal
1. F-N-R linkage.	Linkage is adjusted properly and shows no evidence of wear or damage.	Adjust or repair linkage.
2. Hydraulic system.	All pressures within specifications. See PowrReverser™ Control Valve Tests later in this group.	Repair PowrReverser™ control valve.
3. PowrReverser™.	No evidence of wear or damage to PowrReverser™ components. Pistons, plates, and discs slide freely within cylinder.	Repair PowrReverser™.

OUO1085,0000216 -19-04OCT00-1/1

**Gears Clash, Shift Hard, or Will Not Engage**

## CONDITIONS:

- Transmission and lever repair in Section 50, Group 16.

Test	Normal	If Not Normal
1. Speed and range shifter linkage.	Linkage is adjusted properly.	Adjust.
	Linkage shows no evidence of wear or damage.	Replace worn or damaged components.
2. Speed and range shifter assemblies.	All shafts operate smoothly. No evidence of wear or damage to shifters, arms, forks, or detent balls and springs. Shifter forks are not loose on shafts.	Replace worn or damaged components.
3. Transmission.	No evidence of wear or damage to gear teeth or splines. Gears that are splined to shafts are not loose. Gears that float on shafts turn freely. Shift collars and/or synchronizers slide freely between gears with no binding.	Clean and lubricate any binding parts. Replace worn or damaged components.

OUO1085,0000218 -19-04OCT00-1/1

250  
16  
7**Two Speeds Engage Together**

## CONDITIONS:

- Repair in Section 50, Group 16.

Test Location	Normal	If Not Normal
1. Speed and range shifter assemblies.	All shafts operate smoothly. No wear or damage to shaft detents. Detent ball assemblies installed properly and not worn or damaged. Springs not weak or broken.	Replace worn or damaged components.
2. Transmission.	No evidence of wear or damage to gear teeth or splines. Gears that are splined to shafts are not loose. Gears that float on shafts turn freely.	Replace worn or damaged components.
	All transmission components assembled correctly.	Reassemble.

OUO1085,0000219 -19-04OCT00-1/1

**Transmission Will Not Stay in Gear****CONDITIONS:**

- Repair in Section 50, Group 16.

Test Location	Normal	If Not Normal
1. Speed and range shifter assemblies.	All shafts operate smoothly. No wear or damage to shaft detents. Detent ball assemblies installed properly and not damaged. Springs not weak or broken.	Replace worn or damaged components.
2. Transmission.	No evidence of wear or damage to gear teeth, splines, shift collars, and/or synchronizers or shifter forks.	Replace worn or damaged components.

QUO1085,000021A -19-04OCT00-1/1

**Transmission Noisy****CONDITIONS:**

- Repair in Section 50, Group 16.

Test Location	Normal	If Not Normal
1. Transmission shafts.	Shafts and shaft bearings spin freely and without noise. No evidence of wear or damage to shaft splines or bearings.	Replace worn or damaged components.
2. Transmission gears.	Gears that are splined to shafts are not loose. Gears that float on shafts turn freely. Shift collars and/or synchronizers slide freely between gears with no binding. No evidence of wear or damage to gear teeth or splines.	Clean and lubricate any binding parts. Replace worn or damaged components.
3. Speed and range shift forks.	No evidence of wear, damage, or bent condition.	Replace worn or damaged components.
4. Park pawl assembly.	Park pawl retracts fully when disengaged.	Replace worn or damaged linkage or springs.

QUO1085,000021B -19-04OCT00-1/1

## PTO Troubleshooting

PTO troubleshooting for units with PowrReverser™ transmission is the same as for units with collar shift or SyncShuttle™ transmissions. See Group 15 for information.

OUO1085,000021C –19–04OCT00–1/1

## Differential Troubleshooting

Differential troubleshooting for units with PowrReverser™ transmission is the same as for units with collar shift or SyncShuttle™ transmissions. See Group 15 for information.

OUO1085,000021D –19–04OCT00–1/1

## Axle Troubleshooting

Axle troubleshooting for units with PowrReverser™ transmission is the same as for units with collar shift or SyncShuttle™ transmissions. See Group 15 for information.

OUO1085,000021E –19–04OCT00–1/1

## MFWD Troubleshooting

MFWD troubleshooting for units with PowrReverser™ transmission is the same as for units with collar shift or SyncShuttle™ transmissions. See Group 15 for information.

OUO1085,000021F –19–04OCT00–1/1



## PowrReverser™ Control Valve Tests

**NOTE:** Tractor without cab shown; procedure for cab tractor is similar. Differences for cab tractors are noted below.

### REASON:

To determine if PowrReverser™ control valve is functioning properly.

### CONDITIONS:

Transmission pump producing correct flow and pressure. See Transmission Pump Flow Test later in this group.

Block front wheels (front and rear). Install suitable jack stands under rear axles to raise rear wheels off of floor.

If equipped with MFWD, be sure MFWD is disengaged (or support front of tractor on jack stands).

Ensure that F-N-R, gear shift, range shift, PTO, and MFWD levers are in neutral or disengaged positions.


If equipped with cab, remove floor mat, clutch housing floor plate, and battery access plate on cab floor.

### EQUIPMENT:


- JT07032 Gauge, 400 kPa (60 psi) (1 used)
- JT07041 Gauge, 2800 kPa (400 psi) (3 used)
- JT05498 Hose, 508 mm (20 in.) (4 used)
- JT03262 Adapter (4 used)
- JT03481 Hydraulic Test Kit, Includes:
  - JT03481-1, Male Quick Coupler (3)
  - JT03481-2, Male Quick Coupler Plug (1)
  - JT03481-3, Straight Fitting (1)
- JT03236 Elbow 45°, 1/8 M NPT, 1/8 F NPT (1 used)

### CONNECTIONS:

1. Assemble four hoses (C) with adapters (D) and gauges (E and F).



LV1300A -UN-24APR01



LV1304A -UN-19JAN95

- A—Adapter, JT03481-2 M20-1.5 x 1/8 FNPT (1 used)<sup>1</sup>
- B—Diagnostic Receptacle, JT03481-1 (4 used)<sup>1</sup>
- C—Hose, JT05498 (4 used)
- D—Adapter, JT03262 (4 used)
- E—Gauge, JT07041 (3 used)
- F—Gauge, JT07032 (1 used)
- G—Hangar, JDG196 (2 used)
- H—Elbow 45°, JT03236 (1 used on Cab Tractors Only) (Elbow Not Shown)

<sup>1</sup>Part of Kit JT03481

2. Install adapter (A) in top port “P” on PowrReverser™ control valve.

Continued on next page

OUC1085,0000220 -19-12APR04-2/7

250  
16  
11

- On tractors with cab, install 45° elbow in “FOW” port facing downward.

**NOTE:** On tractors equipped with cab, route one hose with 2800 kPa (400 psi) gauges to the “FOW” port through the battery access hole on cab floor.

- Install adapters (B) in “P”, “FOW”, “REV”, and “LUB” ports. Connect hoses with 2800 kPa (400 psi) gauges to “P”, “FOW”, and “REV” ports.
- Connect hose with 400 kPa (60 psi) gauge to “LUB” port.

#### PROCEDURES:

This procedure requires checking hydraulic pressures in each of five operating modes. Perform each test at 2400 rpm engine speed. Record pressures for each test, compare with specifications, and then proceed to the next test.

#### Test #1: Initial Start-Up, Clutch Pedal Up

- Start engine without depressing clutch pedal.
- Record pressures on all four gauges at 2400 rpm engine speed. Compare readings to specifications.

#### POWRREVERSER™ CONTROL VALVE TEST SPECIFICATIONS INITIAL START-UP, CLUTCH PEDAL UP


Engine	Pressure at test ports:				
RPM	P <sup>a</sup>	FOW	REV	LUB	
2400	2550±296	0	0	0	kPa
	(25.5±3)	0	0	0	(bar)
	(370±30)	0	0	0	(psi)

<sup>a</sup>Note “P” is pump pressure.


If pressures are within specifications, proceed to Test #2.

If pressures are low, minimum specification 2254 kPa (340 psi):

- Filter in Port P may be restricted.



LV1300A -UN-24APR01



LV1304A -UN-19JAN95

- A—Adapter, JT03481-2 M20-1.5 x 1/8 FNPT (1 used)<sup>1</sup>
- B—Diagnostic Receptacle, JT03481-1 (4 used)<sup>1</sup>
- C—Hose, JT05498 (4 used)
- D—Adapter, JT03262 (4 used)
- E—Gauge, JT07041 (3 used)
- F—Gauge, JT07032 (1 used)
- G—Hangar, JDG196 (2 used)
- H—Elbow 45°, JT03236 (1 used on Cab Tractors Only) (Elbow Not Shown)

<sup>1</sup>Part of Kit JT03481

- Main relief valve or engagement override valve may be leaking.
- Gaskets in PowrReverser™ control valve may be leaking.

### Test #2: F-N-R Lever in Neutral, Clutch Pedal Down

With F-N-R lever in neutral, hold clutch pedal down. Record pressures on all four gauges at 2400 rpm engine speed. Compare readings to specifications.

POWRREVERSER™ CONTROL VALVE TEST SPECIFICATIONS F-N-R LEVER IN NEUTRAL, CLUTCH PEDAL DOWN @ 140±23°F (60±10°C) OIL TEMPERATURE					
Engine	Pressure at test ports:				
RPM	P <sup>a</sup>	FOW	REV	LUB	
2400	510±200	0	0	0	kPa
	(5.10±2)	0	0	0	(bar)
	(74±30)	0	0	0	(psi)
<sup>a</sup> Note "P" is pump pressure.					

If pressures are within specifications, proceed to Test #3.

If pressures are low, minimum specification 310 kPa (34 psi):

- Clutch pedal valve or modulation relief valve may be leaking.
- Gaskets in PowrReverser™ control valve may be leaking.

If no pressure is recorded at port P:

- Check clutch pedal adjustment. The clutch pedal adjustment determines the engagement of the (EOV) engagement override valve.

### Test #3: F-N-R Lever in Neutral, Clutch Pedal Up

With F-N-R lever in neutral, return clutch pedal to raised position. Record pressures on all four gauges at 2400 rpm engine speed. Compare readings to specifications.

**POWRREVERSER™ CONTROL VALVE TEST SPECIFICATIONS  
F-N-R LEVER IN NEUTRAL, CLUTCH PEDAL UP**

Engine	Pressure at test ports:				
RPM	P <sup>a</sup>	FOW	REV	LUB	
2400	310±200	76±50	76±50	0	kPa
	(3.10±1.9)	(0.76±49)	(0.76±49)	0	(bar)
	(45±15)	(11±7)	(11±7)	0	(psi)

<sup>a</sup>Note "P" is pump pressure.

If pressures are within specifications, proceed to Test #4.

If pressures are low, minimum specification 110 kPa (30 psi):

- Modulation valve or lube cut-off valve may be leaking.
- Gaskets in PowrReverser™ control valve may be leaking.
- Seals on traction drive shaft may be leaking.
- PowrReverser™ piston(s) may be leaking.

If pressure is high in FOW or REV, maximum 126 kPa (18 psi):

- The F-N-R valve may not be in neutral. Inspect or adjust the F-N-R lever linkage.

**Test #4: F-N-R Lever in Forward, Clutch Pedal Up**

**CAUTION:** Be sure rear of tractor is supported on jack stands, and that MFWD (if equipped) is disengaged, or raise front wheels off of floor also.

Shift F-N-R lever to forward, and return clutch pedal to raised position. Record pressures on all four gauges at 2400 rpm engine speed. Compare readings to specifications.

Continued on next page

OUO1085,0000220 -19-12APR04-5/7

**POWRREVERSER™ CONTROL VALVE TEST SPECIFICATIONS  
F-N-R LEVER IN FORWARD, CLUTCH PEDAL UP**

Engine	Pressure at test ports:				
RPM	P <sup>a</sup>	FOW	REV	LUB	
2400	1950±150	1813±150	0	145±70	kPa
	(19.50±1.5)	(18.13±1.5)	0	(1.45±7)	(bar)
	(280±22)	(258±28)	0	(21±10)	(psi)

<sup>a</sup>Note "P" is pump pressure.

If pressures are within specifications, proceed to Test #5.

If pressures are low at test ports P or FOW, minimum 1663 kPa (230 psi):

- Modulation valve or lube cut-off valve may be leaking.
- Gaskets in PowrReverser™ control valve may be leaking.
- Seals on traction drive shaft may be leaking.
- PowrReverser™ piston may be leaking.

If pressures are low at test port LUB, minimum 75 kPa (11 psi):

- Modulation valve, lube relief valve, or lube cut-off valve may be leaking.
- Gaskets in PowrReverser™ control valve may be leaking.
- Seals on traction drive shaft may be leaking.

**Test #5: F-N-R Lever in Reverse, Clutch Pedal Up**

Shift F-N-R lever to reverse and return clutch pedal to raised position. Record pressures on all four gauges at 2400 rpm engine speed. Compare readings to specifications.

**POWRREVERSER™ CONTROL VALVE TEST SPECIFICATIONS  
F-N-R LEVER IN REVERSE, CLUTCH PEDAL UP**

Engine	Pressure at test ports:				
RPM	P <sup>a</sup>	FOW	REV	LUB	
2400	1950±150	0	1813±150	145±70	kPa
	(19.50±1.5)	0	(18.13±1.5)	(1.45±7)	(bar)
	(280±22)	0	(258±28)	(21±10)	(psi)

<sup>a</sup>Note "P" is pump pressure.

If pressures are low at test ports P or REV, minimum 1663 kPa (230 psi):

- Modulation valve or lube cut-off valve may be leaking.
- Gaskets in PowrReverser™ control valve may be leaking.
- Seals on traction drive shaft may be leaking.
- PowrReverser™ piston may be leaking.

If pressures are low at test port LUB, minimum 75 kPa (11 psi):

- Modulation valve, lube relief valve, or lube cut-off valve may be leaking.
- Gaskets in PowrReverser™ control valve may be leaking.
- Seals on traction drive shaft may be leaking.

OUC1085,0000220 -19-12APR04-7/7

## Transmission Pump Flow Test

**NOTE:** Tractor without cab shown, procedure for cab tractor is similar.

Differences for cab tractors are noted below.

### REASON:

To determine if transmission pump can provide adequate flow under pressure.

### EQUIPMENT:


- JT03481 Hydraulic Test Kit, Includes:
  - JT03481-1, Male Quick Coupler (3)
  - JT03481-2, Male Quick Coupler Plug (1)
  - JT03481-3, Straight Fitting (1)
- JT05469 Flowmeter

### CONNECTIONS:

1. If equipped with cab, remove floor mat and clutch housing floor plate.
2. Remove plug from port “P” on PowrReverser™ control valve.
3. Connect flowmeter hose to adapter.
4. Install adapter and flowmeter to control valve.
5. Insert flowmeter return hose into hydraulic oil fill at rear of tractor.

### PROCEDURE:

1. Fully open flowmeter control valve.
2. Start tractor without depressing clutch pedal and run engine at 2400 rpm.



A—JT03481-3 Adapter, M20-1.5 x 3/4 FNPT<sup>1</sup>  
 B—JT05531 Hose (2 used)<sup>2</sup>  
 C—Flowmeter<sup>2</sup>

<sup>1</sup>Part of JT03481 Hydraulic Test Kit

<sup>2</sup>Part of JT05469 Flowmeter Kit



3. Adjust flowmeter control valve until 1900 kPa (17 bar) (250 psi) shows on gauge.

4. Record flow, then release pressure.

#### RESULTS:

If flow is less than minimum 21.0 L/min (5.5 gpm) at 2400 rpm:

- The mesh filter in the differential case may be restricted.
- The transmission pump suction line may be restricted or leaking air.
- The seals in the transmission drive shaft (between the transmission pump and the PowrReverser™ control valve) may be leaking.
- The PowrReverser™ control valve gaskets may be leaking.
- The pump may be worn or damaged, requiring repair or replacement.

OUC1085,0000221 -19-05OCT00-2/2

## Forward-Neutral-Reverse Control Cable Adjustment

**IMPORTANT:** The following adjustments are critical for the proper operation of this equipment. This adjustment is done to center the forward and reverse free play of the control lever along the forward/reverse slot. Failure to follow the instructions below may result in personal injury and equipment damage.

1. Move the PowrReverser™ control lever (A) into the park slot.

A—PowrReverser™ Control Lever



LV6500 -UN-27AUG02

Continued on next page

OUC1023,0000412 -19-12APR04-1/7


2. Loosen jam nut (A) on forward-neutral-reverse cable yoke.
3. Remove cotter pin (C) and retaining pin (B).
4. Remove cap screws (D) and inspect cable clamp for wear or damage, replace if necessary. Apply medium strength thread lock and sealer to screws (D). Install cable clamp and cap screws (D). Tighten cap screws to specification.

**Specification**


Forward-Neutral-Reverse Cable  
 Clamp Cap Screws—Torque..... 11 N•m (8.5 lb-ft)

5. The control valve lever (F) must be set and remain in the neutral position for proper adjustment. Move the yoke (E) away from the lever. To ensure the lever is in neutral, move the lever to forward, to reverse, and then to the neutral position.

A—Jam Nut  
 B—Retaining Pin  
 C—Cotter Pin  
 D—Cap Screw (2 used)  
 E—Yoke  
 F—Control Valve Lever



LV7403 -UN-24AUG01




LV7404 -UN-24AUG01

OUC1023,0000412 -19-12APR04-2/7

6. Turn the yoke (A) on the forward-neutral-reverse cable in or out until the holes in the control valve lever (B) and the yoke (A) are aligned and the retaining pin (C) can be installed and slide freely into the holes. Install the retaining pin (C) but do not install cotter pin at this time.
7. Remove the neutral alignment tool from controller.

A—Yoke  
 B—Control Valve Lever  
 C—Retaining Pin




LV7405 -UN-24AUG01

Continued on next page


OUC1023,0000412 -19-12APR04-3/7

8. Position PowrReverser™ control lever in to the reverse position.
9. Place a piece of masking tape (B) over the neutral crossover slot. Make sure that the right edge (A) of masking tape (B) only covers one half of the neutral crossover tabs (C) as shown in photo.
10. Move the control lever (D) next to the neutral crossover slot. Slowly move the control lever into the neutral crossover slot just to the right edge (A) of the masking tape (B). Do not disturb the position of the masking tape.
11. Center the control lever (D) between the neutral crossover tabs (C), without touching the tabs.
12. While holding the control lever (D) centered between the neutral crossover tabs (C), place a mark on the masking tape as shown in photo along the top (E) and bottom (F) surfaces of the control lever.

A—Right Edge  
 B—Masking Tape  
 C—Neutral Crossover Tabs  
 D—Control Lever  
 E—Top Mark  
 F—Bottom Mark



LV7559 -UN-24JUN03



LV7560 -UN-24JUN03

Continued on next page

OUC1023,0000412 -19-12APR04-4/7

13. Move the control lever (A) slowly out of the neutral crossover slot and push the control lever forward until resistance is felt, this is the top of the neutral detent. Place a mark (B) on the masking tape along the top surface of the control lever as shown in photo.
14. Slowly pull control lever (A) rearward until resistance is felt, this is the bottom of the neutral detent. Place a mark (C) on the masking tape along the bottom surface of the control lever as shown in photo.

A—Control Lever  
B—Forward Tape Mark  
C—Rearward Tape Mark



LV7561 –UN-24JUN03



LV7562 –UN-24JUN03

Continued on next page


OUO1023,0000412 –19-12APR04-5/7

250  
16  
21




15. Position the control lever (A) in reverse.
16. Measure the distance between the top two marks (B) and the bottom two marks (C) on the masking tape.
17. Record and compare the two measurements. If measurements are not equal remove the retaining pin (D) and turn yoke (E) in or out until the two measurements (B and C) at control lever are equal.
18. Repeat steps 11 through 20 of Adjust Forward-Neutral-Reverse Cable using a new piece of masking tape if measurements are not equal.

A—Control Lever  
B—Top Two Marks  
C—Bottom Two Marks  
D—Retaining Pin



LV7532 -UN-24JUN03




LV7533 -UN-24JUN03

Continued on next page

OUO1023,0000412 -19-12APR04-6/7

19. Install retaining pin (B), cotter pin (C) and tighten jam nut (A) securely.

A—Jam Nut  
B—Retaining Pin  
C—Cotter Pin



LV7542 -UN-24AUG01

OUC1023,0000412 -19-12APR04-7/7

250  
16  
23

## Clutch Pedal Linkage Adjustment


1. Block tires (front and rear).
2. Remove left-hand dash cowl and disconnect clutch pedal return spring.
3. Disconnect long PTO rod assembly at both ends and remove assembly.
4. Remove left-hand step.
5. Remove clevis pin (A) and disconnect clevis from clutch control arm (B).
6. Push clutch pedal down fully and retain in this position.

**NOTE:** *The clutch control arm is spring loaded in both directions from its free position. You must feel the spring in both directions to assure that control arm is in its free position and not stuck in either direction, before linkage can be adjusted.*

7. Using a wrench, turn clutch control arm clockwise until it stops.
8. Loosen jam nut (C) on clutch rod and adjust rod length until clevis pin can be inserted through holes in clevis and hole in clutch control arm when clutch is fully depressed and control arm is rotated fully clockwise. Remove clevis pin and rotate clevis 1/2 turn (to lengthen rod) and tighten jam nut.
9. Install clevis pin and locking clip.
10. Install left-hand step and long PTO rod assembly. (See PTO Clutch Lever Adjustment in Group 15 for adjustment procedure.)

**NOTE:** *Whenever a tractor engine is started with PowrReverser™ lever in park or neutral, the tractor is designed not to move unless clutch pedal is fully depressed one time to cycle engagement override valve.*

11. Install clutch return spring and dash cowl. Test clutch operation or perform PowrReverser™ control valve tests.



A—Clevis Pin  
B—Clutch Control Arm  
C—Jam Nut


LV1303A -UN-19JAN95

## Park Brake Cable Adjustment

**IMPORTANT:** The following adjustments are critical for the proper operation of this equipment. Failure to follow the instructions below may result in personal injury and equipment damage.

1. Park tractor on flat level surface. Place wheel chucks in front and behind rear tiers.
2. Remove seat and support (See Remove and Install Seat and Support—Tractors Without Cab or Remove and Install Seat and Support Plate—Tractors With Cab in Section 90, Group 05.)
3. Remove spring locking pin (A) and loosen jam nut (B).

A—Spring Locking Pin  
B—Jam Nut






LV7980 -JN-20NOV02

Continued on next page

OUC1085,0000224 -19-13NOV02-1/2

250  
16  
25






4. Position and hold the shift control lever (A) in the bottom of park slot using a screwdriver (B) as a wedge.
5. Position and hold the park engagement lever (D) fully engaged to the left side of tractor using a wrench (C).
6. Pull cable toward park engagement lever (D) to remove any slack in cable.
7. Using the spring locking pin to check alignment, turn yoke (E) on park brake cable until hole in yoke aligns with hole in park engagement lever (D).
8. Shorten the cable by turning yoke (H) four full turns clockwise.
9. Remove wrench (C) from park engagement lever (D) and screwdriver (B) from shift control lever (A).
10. Move the shift control lever to the neutral position.
11. Install spring locking pin (F) and tighten jam nut (G) against back of yoke (H).
12. Install seat and support. (See Remove and Install Seat and Support—Tractors Without Cab or Remove and Install Seat and Support Plate—Tractors With Cab in Section 90, Group 05.)

A—Shift Control Lever  
 B—Screwdriver  
 C—Wrench  
 D—Park Engagement Lever  
 E—Yoke  
 F—Spring Locking Pin  
 G—Jam Nut  
 H—Yoke

## PTO 540/540E Lever and Linkage Adjustment



1—Nut  
2—Plate  
3—Adjustment Nut  
4—Nut (4 used)  
5—Control Cable

6—Knob  
7—Lever  
8—Yoke  
9—Rod  
10—Nut

11—Yoke  
12—Pin  
13—Arm  
14—Spring Locking Pin  
15—Washer

16—Retaining Clip  
17—Bolt  
18—Bracket  
19—Control Bracket

1. Remove spring locking pin (14) and disconnect yoke (11) from arm (13).
2. Shift arm (13) to forward position.
3. Position lever (7) approximately 15 degrees forward of vertical.
4. Adjust yoke (11) so spring locking pin (14) aligns with hole in yoke and arm (13). Install spring locking pin and tighten nut (10).

250  
16  
27

LV2463 -UN-05JAN98

250  
16  
28

# Section 260

## Steering and Brake Operation, Tests, and Adjustments

### Contents

#### Page

#### Group 05—Component Location

Component Location Information . . . . .	260-05-1
Steering System Components—5210, 5310, and 5410 Without Cab . . . . .	260-05-2
Steering System Components—5510 and All Cab Units . . . . .	260-05-4
Brake System Components . . . . .	260-05-6

#### Group 10—Theory of Operation

Theory of Operation Information . . . . .	260-10-1
Steering System Operation—5210, 5310, and 5410 Without Cab . . . . .	260-10-2
Steering System Operation—5510 and All Cab Units . . . . .	260-10-4
Steering Valve Operation—Neutral and Manual Turning . . . . .	260-10-6
Steering Valve Operation—Power Turning . . . . .	260-10-8
Brake System Operation . . . . .	260-10-10
Brake Valve Operation . . . . .	260-10-12

#### Group 15—Diagnosis, Tests and Adjustments

Diagnostic Information . . . . .	260-15-1
Isolate the Problem—Steering System . . . . .	260-15-2
Steering Sluggish or Loss of Steering . . . . .	260-15-3
Isolate the Problem—Brakes . . . . .	260-15-3
Excessive Brake Pedal Leak-Down . . . . .	260-15-4
Excessive Brake Chatter . . . . .	260-15-4
Steering Pump Flow Test . . . . .	260-15-5
Steering Valve Relief Test . . . . .	260-15-6
Steering Cylinder Leakage Test . . . . .	260-15-7
Steering Valve Leakage Test . . . . .	260-15-8
Toe-In Check and Adjustment—Standard Axle . . . . .	260-15-10
Toe-In Check and Adjustment—MFWD . . . . .	260-15-12
MFWD Steering Stop Adjustment . . . . .	260-15-14
Brake Pedal Adjustment . . . . .	260-15-15
Adjust Brake Drag . . . . .	260-15-16
Bleed Brake System . . . . .	260-15-17



### **Component Location Information**


This group contains component location drawings for the following steering and brake system components:

- Steering System—5210, 5310, 5410, and 5510 Tractors, With or Without Cab
- Brake System

Use the drawings when troubleshooting steering and brake problems to help locate the components to be tested.

OUO1085,0000226 –19–05OCT00–1/1

# Steering System Components—5210, 5310, and 5410 Without Cab



## STEERING SYSTEM COMPONENTS - 5210-5410 WITHOUT CAB

LV2204

LV2204 -UN-01JUL97

Continued on next page

OUC1085,0000227 -19-25JUL02-1/2

Component Location


A—Steering Valve Return Line	E—Supply Line to Brake Valve	I—Steering Cylinder	M—Suction Line
B—Steering Wheel	F—Steering Pump	J—Tie Rod End	N—Hydraulic Oil Filter
C—Steering Column	G—Pressure Line	K—Pressure Line	O—Pickup Screen
D—Steering Valve	H—Tie Rod End	L—Supply Line	

OUO1085,0000227 -19-25JUL02-2/2

260  
05  
3



# Steering System Components—5510 and All Cab Units



## STEERING SYSTEM COMPONENTS - 5510 AND ALL CAB UNITS

LV2205

LV2205 -UN-01JUL97

Steering System

Continued on next page

OUC1085,0000228 -19-06OCT00-1/2

Component Location


- |                              |                              |                     |                        |
|------------------------------|------------------------------|---------------------|------------------------|
| A—Steering Valve Return Line | E—Supply Line to Brake Valve | I—Tie Rod End       | M—Supply Line          |
| B—Steering Wheel             | F—Steering Pump              | J—Steering Cylinder | N—Suction Line         |
| C—Steering Column            | G—Pressure Line              | K—Tie Rod End       | O—Hydraulic Oil Filter |
| D—Steering Valve             | H—Hydraulic Oil Cooler       | L—Pressure Line     | P—Pickup Screen        |

NOTE: Model 5510 and all tractors with cab are equipped with hydraulic oil cooler.

OUO1085,0000228 -19-06OCT00-2/2

260  
05  
5

## Brake System Components



LV2208

## BRAKE SYSTEM COMPONENTS

Continued on next page

OOU1085,0000229 -19-06OCT00-1/2

Component Location

- |               |                     |                             |                             |
|---------------|---------------------|-----------------------------|-----------------------------|
| A—Piston      | D—Right Brake Pedal | G—Hydraulic Oil Supply Line | J—Brake Retractor           |
| B—Brake Disc  | E—Left Brake Pedal  | H—Left Brake Pressure Line  | K—Right Brake Pressure Line |
| C—Brake Plate | F—Brake Valve       | I—Hydraulic Oil Return Line |                             |

*NOTE: Brake valve supply line (G) is connected to steering valve return line.*

*The tractor is equipped with a mechanical park brake. The park brake linkage is part of the transmission assembly.*

OUC1085,0000229 -19-06OCT00-2/2

260  
05  
8

## **Theory of Operation Information**

This group divides the steering and brake system into individual components by function. The theory of operation story explains: function of the component, operating conditions, components used, and system operation.


The following systems or components are covered in this group:

- Power Steering System—5210, 5310, and 5410 Tractors Without Cab
- Power Steering System—5510 Tractors and All Units With Cab
- Power Steering Valve
- Brake System
- Brake Valve

OUO1085,000022A -19-25JUL02-1/1

260  
10  
1

## STEERING SYSTEM OPERATION - 5210-5410 WITHOUT CAB



**LVC2206**

LVC2206 -UN-01JUL97

Continued on next page

OUO1085,000022B -19-06OCT00-1/2

A—Steering Valve Return Line  
B—Steering Valve  
C—Supply Line to Brake Valve  
D—Steering Pump

E—Pressure Line (Right Turn)  
F—Tie Rod  
G—Steering Cylinder

H—Tie Rod  
I—Pressure Line (Left Turn)  
J—Suction Oil

K—Pump Pressure Oil  
L—Return Oil  
M—Trapped Oil

#### FUNCTION:

Offer hydraulic power steering for ease of operation.

#### MAJOR COMPONENTS:

- Steering Valve
- Hydraulic Pump
- Steering Cylinder

#### THEORY OF OPERATION:

The steering pump (D) takes filtered suction oil (J) from the transmission sump and pressurizes it. Pressure oil (K) is supplied to the steering valve (B). The steering valve distributes oil through pressure lines (E and I) to the steering cylinder (G) as needed.

Under neutral steer conditions (no steering wheel movement), the pressure lines and steering cylinder contain trapped oil (M), which maintains steering

direction. Turning the steering wheel to the right, even a slight amount, allows pressure oil to enter line (E), pushing the steering cylinder rod and left tie rod (F) outward (and pulling the right tie rod (H) inward). Under these conditions line (I) allows return oil to flow from the steering cylinder to the steering valve and through steering valve return line (A) to the transmission. This return oil lubricates the transmission top shaft before returning to sump.

When the steering wheel is turned to the left, pressure oil enters line (I) pushing the steering cylinder rod and right tie rod (H) outward (and pulling the left tie rod (F) inward). Return oil can flow through line (E) from the steering cylinder to the steering valve and through steering valve return line to the transmission.

**NOTE:** *The steering valve is designed to allow manual steering if the engine is not running or the hydraulic pump fails.*

OUC1085,000022B -19-06OCT00-2/2





A—Steering Valve Return Line  
(From Cooler)  
B—Steering Valve  
C—Supply Line to Brake Valve  
D—Steering Pump

E—Steering Valve Return Line  
(To Cooler)  
F—Hydraulic Oil Cooler  
G—Pressure Line (Right Turn)

H—Tie Rod  
I—Steering Cylinder  
J—Tie Rod  
K—Pressure Line (Left Turn)

L—Suction Oil  
M—Pump Pressure Oil  
N—Return Oil  
O—Trapped Oil

*NOTE: Model 5510 and all tractors with cab are equipped with hydraulic oil cooler.*

#### FUNCTION:

Offer hydraulic power steering for ease of operation.

#### MAJOR COMPONENTS:

- Steering Valve
- Steering Pump
- Steering Cylinder
- Hydraulic Oil Cooler

#### THEORY OF OPERATION:

The steering pump (D) takes filtered suction oil (L) from the transmission sump and pressurizes it. Pressure oil (M) is supplied to the steering valve (B). The steering valve distributes oil through pressure lines (G and K) to the steering cylinder (I) as needed.

Under neutral steer conditions (no steering wheel movement), the pressure lines and steering cylinder contain trapped oil (O), which maintains steering


direction. Turning the steering wheel to the right, even a slight amount, allows pressure oil to enter line (G), pushing the steering cylinder rod and left tie rod (H) outward (and pulling the right tie rod (J) inward). Under these conditions line (K) allows return oil to flow from the steering cylinder to the steering valve. From the steering valve, return oil flows through steering valve return line (E), hydraulic oil cooler (F) and steering valve return line (A) to the transmission. This return oil lubricates the transmission top shaft before returning to sump.

When the steering wheel is turned to the left, pressure oil enters line (K) pushing the steering cylinder rod and right tie rod (J) outward (and pulling the left tie rod (H) inward). Return oil can flow through line (G) from the steering cylinder to the steering valve. From the steering valve, return oil flows through steering valve return line (E), hydraulic oil cooler (F), and steering valve return line (A) to the transmission.

*NOTE: The steering valve is designed to allow manual steering if the engine is not running or the hydraulic pump fails.*

OUO1085,000022C -19-06OCT00-2/2

# Steering Valve Operation—Neutral and Manual Turning



## STEERING VALVE OPERATION — NEUTRAL AND MANUAL TURNING

LVC332AE

LVC332AE -19-21MAY96

Continued on next page

LV,26010HA,A5 -19-06OCT00-1/2

A—Valve Body  
B—Return Port  
C—Steering Relief Valve

D—Inlet Port  
E—Inlet Check  
F—Manual Steer Check

G—Neutral Mode  
H—Manual Turning (Left)  
I—Pressure Oil

J—Return Oil  
K—Trapped Oil

#### FUNCTION:

To block pressurized oil flow to the steering cylinder when no turning action is desired. To allow for manual turning of the machine when no power is available.

#### MAJOR COMPONENTS:

- Inlet Check
- Valve Body
- Manual Steer Check
- Spool
- Sleeve
- Gerotor
- Relief Valve

#### THEORY OF OPERATION:

Pressurized oil (I) opens the spring loaded inlet check (E) and flows into the valve body (A) through the inlet port (D). Oil then flows through the inlet passage to close the manual steer check (F) and reach the feed holes. The feed holes direct oil flow through the sleeve inlet groove to the spool inlet.

When the valve is in neutral mode (G), the return oil passages of the sleeve and spool are aligned and open, while the right turn and left turn passages are


blocked and closed. The open passage allows return oil (J) to travel through the center of the spool and leave the valve through the return port (B). Blocking the turn passages traps oil (K) in the gerotor cavities, hydraulic lines and the steering cylinder.

Should hydraulic pressure be lost (engine off or pump failure), the inlet check closes and manual steer check opens to create a closed-loop steering system. The closed-loop steering system uses trapped oil to allow for manual steering of the machine (no power). As the steering wheel is turned (right or left), trapped oil is forced from the gerotor cavities through the now-aligned turn passages of the sleeve and spool, and out of the valve to the pressure side of the steering cylinder piston, which moves the front wheels. Movement of the piston forces trapped oil from the non-pressure side of the piston to the return passage of the spool and sleeve and then to the gerotor cavities, where it replenishes the system and completes the closed-loop.

To prevent damage to hydraulic system components a relief valve (C) is installed in the valve body. Should the oil flow be blocked and hydraulic pressure rise above relief pressure, the relief valve will open and direct all oil flow to the return port.

LV,26010HA,A5 -19-06OCT00-2/2

# Steering Valve Operation—Power Turning



## STEERING VALVE OPERATION — POWER TURNING

LVC333AE

LVC333AE -19-07APR97

A—Left Turn Port  
B—Right Turn Port  
C—Sleeve/Spool (Control Valve)

D—Gerotor (Metering Pump)  
E—Valve Body  
F—Return Port

G—Left Turn  
H—Right Turn

I—Pressure Oil  
J—Return Oil

#### FUNCTION:

Supply hydraulic oil to the proper side of the steering cylinder to turn the wheels when the engine is running.

#### MAJOR COMPONENTS:

- Valve Body
- Spool Sleeve
- Gerotor

#### THEORY OF OPERATION:

Pressurized oil (I) is supplied to the sleeve inlet groove and spool inlet following the same path as when the valve is in neutral.

The steering wheel is mechanically connected to the valve spool and gerotor gear by the steering column. Turning the steering wheel (right or left) rotates the valve spool within the sleeve to align pressure and return passages.

Oil flows through the pressure passage to the gerotor where it fills the cavity between the gerotor gear and body.

The rotation of the gerotor gear is offset to the body to enlarge and reduce the size of the cavity as the gear

turns. The gerotor gear is timed to the valve body passages so the cavity is filled with oil when it is at its largest and emptied when it is smallest. By enlarging and then reducing the size of the gerotor cavities a greater volume of oil is metered to the steering cylinder, which improves steering efficiency. The gerotor cavities are filled and emptied six times faster when the steering wheel is turned.


Pressurized oil flows from the gerotor back to the sleeve and spool where it is directed out of the valve through the open turn passage and turn port (A). Oil then flows through a hydraulic line to the steering cylinder where it moves the piston which turns the front wheels.

Oil on the opposite side of the piston is forced from the cylinder and returns to the steering valve through a hydraulic line and the opposite turn port (B).

Return oil (J) flows through a valve passage to the open return passages in the sleeve and spool. Oil then flows to a common return passage located at the center of the spool. Oil leaves the valve by the common return passage and port (F).

LV,26010HA,A7 -19-06OCT00-2/2

## Brake System Operation



LVC2209

## BRAKE SYSTEM OPERATION

Continued on next page

OUC1085,000022D -19-06OCT00-1/2

A—Piston  
B—Brake Disc  
C—Brake Plate

D—Brake Pedals  
E—Brake Valve  
F—Supply Line

G—Brake Pressure Lines  
H—Return Line  
I—Brake Retractor

J—System Oil  
K—Pressure Oil  
L—Pressure-Free/Return Oil

#### FUNCTION:

To provide a means of stopping the tractor and assist the operator when maneuvering the tractor through tight turns.

#### MAJOR COMPONENTS:

- Brake Valve
- Piston
- Brake Plate
- Brake Disc
- Pressure Lines

#### THEORY OF OPERATION:

Pressing brake pedals (D) activates brake valve (E) which pressurizes the oil in lines (G). Pressurized oil

(K) forces piston (A) against brake disc (B), pressing it against brake plate (C). The brake plate is keyed to the final drive housing and cannot rotate. The brake disc is splined to the axle shaft and rotates with it. When the plate and disc are forced together by the piston, the friction surface of the disc causes it to bind against the plate and therefore stop axle shaft rotation. When pressure on the brake pedal is released, system pressure is released and the disc and axle are free to rotate.



Oil for the brake system is provided via a supply line (F) is branching off the transmission lubrication line at the steering valve. Excess oil (L) is vented to the transmission sump via return line (H).

Brake pedals can be activated individually to assist in turning, or together for equal braking.

OUC1085,000022D -19-06OCT00-2/2



# Brake Valve Operation



I PRESSURE - FREE OIL  
 J PRESSURE OIL

## BRAKE VALVE OPERATION—BRAKE PEDAL DEPRESSED

LVC321AE

LVC321AE -19-07APR97

Continued on next page

OUO1085,000022E -19-06OCT00-1/4

A—Reservoir  
B—Supply Oil  
C—Inlet Check Valve

D—Brake Piston  
E—Pressure Equalizing Valve  
F—Equalizing Passage

G—Outlet Check Valve  
H—To Brake Housing

I—Pressure-Free Oil  
J—Pressure Oil

#### FUNCTION:

To supply hydraulic oil allowing both individual and dual braking.

#### MAJOR COMPONENTS:

- Pistons
- Reservoir
- Inlet Check Valves
- Outlet Check Valves
- Equalizing Valves

#### THEORY OF OPERATION:

Supply oil is pressure-free oil in a sense, that it circulates through the brake valve acting as supply keeping the reservoir full.

#### Brake Pedal Depressed:

When either brake pedal is pressed, piston (D) is moved to the front, thereby closing inlet check valve

(C), which immediately closes brake valve reservoir (A). As it travel further, the piston opens pressure equalizing valve (E), trapping the oil in equalizing passage (F). The increase in pressure causes outlet check valve (G) to open and the oil is forced under pressure to either brake housing.

When both brake pedals are pressed, pressure oil flows through both outlet check valves to the brake housings causing the pistons to open both pressure equalizing valves (E), and the pressure in both brake cylinders is equalized.

The outlet check valves (G) ensure a simultaneous braking effect. The pressure equalizing valves and outlet check valves ensure equal braking.

Continued on next page

OUC1085,000022E -19-06OCT00-2/4

INLET CHECK VALVE

SUPPLY OIL

RESERVOIR

D SPRING

E BRAKE PISTON

F PRESSURE EQUALIZING VALVE

G SPRING

H EQUALIZING PASSAGE

I OUTLET CHECK VALVE

J TO BRAKE HOUSING

(K) PRESSURE - FREE OIL

(L) TRAPPED OIL

LVC322AE

LVC322AE -19-07APR97

## BRAKE VALVE OPERATION — BRAKE PEDAL RELEASED

A—Reservoir  
B—Supply Oil  
C—Inlet Check Valve

D—Spring  
E—Brake Piston  
F—Pressure Equalizing Valve

G—Spring  
H—Equalizing Passage  
I—Outlet Check Valve

J—To Brake Housing  
K—Pressure-Free Oil  
L—Trapped Oil

Continued on next page

OOU1085,000022E -19-06OCT00-3/4

**Brake Pedal Released:**

When brake pedals are released, oil in brake housing is pressure-free and flows back to main brake valve. At the same time brake piston (E) is forced back by spring (D). Just before the pistons reach their final position, inlet check valves (C) open and oil can flow back into the brake valve reservoir (A). The orifice in

outlet check valves (I) prevents the oil from returning to the brake valve reservoir too quickly and thus making an interruption in the oil flow.

As piston reaches its final position, spring (G) forces equalizing valve (F) closed, trapping oil in equalizing passage (H).

OUC1085,000022E -19-06OCT00-4/4



Diagnostic Information

The diagnostic information in this group is used to test components related to a specific problem. Select the appropriate symptom from the list that best matches your problem and follow the test procedures under that heading.

The symptom headings are:

- Steering System
- Brake System

The diagnostic procedure lists:

- Test conditions
- Test sequence
- Test location
- Normal reading
- Check or test to perform if reading is not normal

When performing the test or check, be sure to follow the test conditions and sequence carefully. The middle, “Normal” column gives the normal reading or condition that should be obtained when performing the test or check. If the results of the test or check are not normal, perform the operation listed in the third, “If Not Normal” column to repair the malfunction. The detailed tests or adjustments referred to in the “If Not Normal” column are located at the end of this group.

260

15

1

## Isolate the Problem—Steering System

### CONDITIONS:

- Make sure tire inflation is correct, front ballasting is not excessive and implements are properly fitted and adjusted.
- Inspect complete system for leakage. Locate the source of leakage and make any necessary repairs.
- On tractors with MFWD operate the tractor with MFWD engaged and disengaged. If a difference in steering is noticed, with the MFWD engaged, inspect the front axle.
- Make sure hydraulic oil level is correct.

**NOTE:** Perform tests 1 and 2 with front end blocked up.

Test Location	Normal	If Not Normal
1. Rotate front wheels.	Wheels rotate freely. (no rough areas)	Inspect front wheel bearings.
2. Disconnect steering cylinder and turn axle by hand.	Axle turns easily by hand.	Inspect spindle bearings.

**NOTE:** Lower front of tractor to ground. Warm up hydraulic oil to 43°C (110°F).

Test Location	Normal	If Not Normal
3. Check steering cylinder for leakage.	No leakage.	Replace cylinder.
4. Check steering relief valve pressure.	Relief pressure within specification.	Replace relief valve.
5. Check steering valve for leakage.	No external/internal leakage	Check valve for leakage (See Steering Valve Leakage Test in this group.)
6. Check steering pump flow.	5210 and 5310 model tractors 25.7 Lpm @ 2000 rpm (6.8 gpm @ 2000 rpm).	Clean mesh filter. Inspect suction line. Replace filter canister. Repair pump.
	5410 and 5510 model tractors 24.9 Lpm @ 2000 rpm (6.6 gpm @ 2000 rpm)	

AG,OUO1008,341 -19-17JUL02-1/1

## Steering Sluggish or Loss of Steering

### CONDITIONS:

- Key switch off (test 1—4).
- Engine running (test 5—7).

Test Location	Normal	If Not Normal
1. Transmission filter canister.	Filter passes oil freely.	Replace filter canister.
2. Dipstick.	Oil level full.	Add oil to full mark.
3. Transmission sump.	Oil of correct viscosity.	Replace with correct oil.
4. Mesh filter and pickup tube.	Filter clean of debris. Tube clear.	Clean or replace.
5. Hydraulic pump.	Pump pressure and flow within specifications.	Repair pump.
6. Steering valve.	No excessive internal or external leakage. Valve leakage test within specifications.	Repair steering valve.
7. Steering cylinder.	No excessive internal or external leaks. Cylinder leakage test within specifications.	Repair steering cylinder.
8. Hydraulic lines.	No leaks or kinks in lines.	Replace lines.
9. Transmission oil cooler. (Model 5510 and all tractors equipped with cab.)	No excessive build-up of debris in cooler fins.	Clean cooler fins.
	No leakage.	Repair or replace cooler.

OUO1085,0000230 -19-17JUL02-1/1

260  
15  
3

## Isolate the Problem—Brakes

Test Location	Normal	If Not Normal
1. Apply and release each brake individually to check pedal return.	Both pedals return smoothly.	Inspect pedal pivot for damage or binding. Inspect internal brake components.
2. Operate tractor on flat surface. Allow it to roll with clutch depressed.	Tractor does not pull to one side.	Inspect internal brake components on side tractor pulls toward.
3. Operate tractor on flat surface. Allow it to roll with clutch depressed and apply both brakes evenly.	Tractor stops without pulling to one side.	Inspect internal brake components on side opposite the direction the tractor pulled to.
4. Operate tractor on flat surface. Allow it to roll with clutch depressed and apply each brake separately.	Tractor slows and pulls slightly to one side without noise or vibration.	Inspect internal components on side indicating noise or vibration.

OUO1085,000022F -19-17JUL02-1/1



**Excessive Brake Pedal Leak-Down****CONDITIONS:**

- Operator on seat.
- Problem isolated to either brake valve or brake components.
- Brake repair in Section 60.

Test Location	Normal	If Not Normal
1. Brake valve.	No pedal leak-down when pedals are applied individually or simultaneously.	Pedal leak-down occurs both when pedals applied individually and simultaneously: repair reservoir check valves.
		Pedal leak-down occurs when pedals applied individually: repair equalizing check valve.
		Replace brake piston cylinder O-rings.
2. Pressure ring.	No pedal leak-down when pedal is applied.	Replace pressure ring O-rings.

OUO1085,0000231 -19-17JUL02-1/1

**Excessive Brake Chatter****CONDITIONS:**

- Key switch off.
- Bleed brake system found in this group.
- Brake repair in Section 60.

Test Location	Normal	If Not Normal
1. Transmission sump.	Clean oil of proper viscosity.	Replace with proper oil.
2. Bleed valves. (Located on top of final drive housing.)	No air in system.	Bleed brake system. Repair brakes.

OUO1085,0000232 -19-26JUL02-1/1

## Steering Pump Flow Test

### REASON:

To determine if steering pump can provide adequate flow under pressure.

### EQUIPMENT:

- JT05469 Flowmeter
- JT03368 Pump Adapter 3/4 FNPT x 13/16-16 FORFS 45° elbow (B)
- (Flowmeter with 37° flare hose) JT03336 Adapter 3/4 MNPT x 3/4-16 M 37° flare
- (Flowmeter with 3/4-16 M ORB hose) JT03123 Adapter 3/4 MNPT x 1/2 FNPT and JT03041 1/2 MNPT x 3/4-16 FORB

### CONNECTIONS:

1. Remove steering pump outlet line.
2. Connect flowmeter inlet hose (A) to adapter.
3. Install adapter (B) and flowmeter assembly.
4. Insert flowmeter return hose into hydraulic oil fill hole.

### PROCEDURE:


1. Fully open flowmeter control valve.
2. Start tractor and run at 2000 rpm.
3. Slowly close flowmeter control valve until 10345 kPa (103.5 bar) (1500 psi) shows on gauge.
4. Compare flow to specifications then release pressure.

#### Specification

Flowmeter Control Valve—Flow	
Rate (5210 and 5310 tractors).....	25.7 Lpm (6.8 gpm)
Flow Rate (5410 and 5510 tractors).....	24.9 Lpm (6.6 gpm)

### RESULTS:

If flow is less than minimum:



A—JT05469 Flowmeter  
B—JT03368 Pump Adapter

LV331 -UN-18FEB92

260  
15  
5

Continued on next page

OUC1085,0000233 -19-25JUL02-1/2

- The mesh filter may be restricted.
- The suction line may be restricted or leaking air.
- The pump may be worn or damaged, requiring repair or replacement.

OUC1085,0000233 -19-25JUL02-2/2

## Steering Valve Relief Test

### REASON:

To determine if manufacturer setting of relief valve maintains correct pressure or is leaking.

### EQUIPMENT:

- JT03345 Gauge with coupler 3000 psi (A)
- JT03364 Hose with coupler (B)
- JT03110 Adapter 7/16-20 m 37° Flare x 1/2 KNPT (C)
- JT03367 Connector 13/16-16 MORFS x 1/2 MNPT (D)

### CONNECTIONS:

1. Assemble gauge, hose, and adapter.
2. Disconnect hydraulic hose from left-hand side of steering cylinder.
3. Connect test equipment to hydraulic hose.

### PROCEDURE:


1. Run engine at fast idle
2. Turn steering wheel full left and continue turning while comparing gauge to specification.

#### Specification

Hydraulic Steering Hose—  
 Pressure ..... 12990—13493 kPa (130—135  
 bar) (1884—1957 psi)

### RESULTS:

- If pressure reading is not within specifications, replace relief valve assembly.



A—JT03345 Gauge  
 B—JT03364 Hose  
 C—JT03110 Adapter  
 D—JT03367 Connector

LV328 -UN-18FEB92

OUC1085,0000234 -19-26JUL02-1/1

## Steering Cylinder Leakage Test

### REASON:


To determine if leakage exists in steering cylinder.

### PROCEDURE:

1. Turn steering wheel to a full left to fully extend cylinder end.
2. Shut off engine.
3. Disconnect hydraulic hose (A) from right-hand side of steering cylinder (extended end).
4. Start engine and run at high idle.
5. Continue to turn steering wheel to the left.
6. Watch for any flow of oil out of cylinder at fitting (B).
7. Repeat steps 1—6 for right turn and left-hand side of cylinder.

### RESULTS:

- If any flow of oil out of cylinder occurred, there is internal leakage in the cylinder. Repair or replace cylinder.



A—Hydraulic Hose  
B—Cylinder Fitting

LV329 -UN-18FEB92

260  
15  
7

OUO1085,0000235 -19-26JUL02-1/1

## Steering Valve Leakage Test

### REASON:

To check the steering valve for internal leakage.

### EQUIPMENT:

- Torque wrench
- (2) 13/16-16 MORFS Plugs

**IMPORTANT:** O-ring seal (ORS) plugs must be used to plug pressurized hydraulic hoses.


### PROCEDURE:

1. Stop the engine.

**CAUTION:** Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.

2. Disconnect hoses from steering cylinder. Close all openings using caps and two 13/16-16 MORFS plugs.
3. Start engine and run at slow idle (800 rpm).



X9811 -UN-23AUG88

Continued on next page

OUC1085,0000236 -19-26JUL02-1/2

4. Turn steering wheel to the right, with a constant torque of 7 N•m (60 lb-in.).

5. Compare the number of rotations of the steering wheel that occur in one minute to specification.

**Specification**

Steering—Maximum Right Turn..... 5 rpm

6. Turn steering wheel to the left, with a constant torque of 7 N•m (60 lb-in.)


7. Compare the number of rotations of the steering wheel that occur in one minute to specification.

**Specification**

Steering—Maximum Left Turn ..... 5 rpm

**RESULTS:**

- If rpm is more than specifications, repair steering valve.  
Go to Section 60 and service as needed.



OUO1085,0000236 -19-26JUL02-2/2

260  
15  
9

## Toe-In Check and Adjustment—Standard Axle

### REASON:

To reduce tire wear.

### PROCEDURE:

1. Park machine on level surface.
2. Turn steering wheel so front wheels are in the straight-ahead position. Stop engine.
3. Measure distance (A) between tires at hub level in front of axle. Record measurement and mark the tires.
4. Move tractor back about 1 m (3 ft), so mark is at hub level behind the axle. Again measure distance between tires at same point on tire. Record measurement.

**NOTE:** When the front measurement is smaller than the rear measurement, this is called "toe-in."

5. Determine the difference between front and rear measurements. The toe-in difference should be between specifications.

#### Specification

Toe-In—Standard Axle—Distance ..... 3—6 mm (1/8—1/4 in.)

### RESULTS:


- If not according to specifications, loosen lock nuts (C) and back out cap screws (B). Adjust tie rods on both sides of tractor equally by turning the inner tube (D) to lengthen or shorten tie rod until toe-in is correct to specifications. Tighten cap screws to specifications.

#### Specification


Tie Rod-to-Inner Sleeve Cap

Screws—Torque..... 90 N•m (66 lb-ft)

- Tighten lock nuts (C) securely.



LV334 -UN-18FEB92



LV335 -UN-18FEB92

A—Distance  
B—Cap Screws  
C—Lock Nuts  
D—Tie Rod Inner Tube

Continued on next page

OUO1085,0000237 -19-26JUL02-1/2

*NOTE: One half turn of tie rod inner tube (D) equals 8 mm (5/16 in.) change of toe-in.*

*One turn of tie rod inner tube (D) equals 16 mm (5/8 in.) change of toe-in.*

OUO1085,0000237 -19-26JUL02-2/2

260  
15  
11



## Toe-In Check and Adjustment—MFWD

### REASON:


To reduce tire wear.

### PROCEDURE:


1. Disengage MFWD and park tractor on smooth, level surface. Steer front wheels straight ahead. Stop engine.
2. Measure distance (A) between centerline of tires at hub level in front of axle, using an outside bar of each tire or an inside bar of each tire. Record measurement.
3. Repeat step 2 at rear of axle.

**NOTE:** When the front measurement is smaller than the rear measurement, this is called "toe-in." If the front measurement is larger than the rear measurement, this is called "toe-out."

4. Determine the difference between front and rear measurements. The difference may be in either direction (toe-in or toe-out), but should be less than specification.



LV336 -UN-18FEB92



LV2210 -UN-01JUL97

A—Distance  
B—Ball Joint Stud  
C—Jam Nut

### Specification

Toe-In—MFWD Axle—Distance..... 3 mm (1/8 in.)

### RESULTS:

- If toe-in not to specifications:
  - Loosen jam nuts (C).
  - Turn ball joint stud (B) equally on both sides of tractor to lengthen or shorten tie rods.
  - Adjust tie rods until toe-in is to specification.
  - Tighten jam nuts to specification.

### Specification

Tie Rod Jam Nut—Torque ..... 120 N•m (88 lb-ft)

Continued on next page

OUC1085,0000238 -19-26JUL02-1/2

*NOTE: One eighth turn of ball joint stud (B) equals 4 mm (3/16 in.) change of toe-in or toe-out.*

*One quarter turn of inner rod equals 8 mm (3/8 in.) change of toe-in or toe-out.*

*One half turn of inner rod equals 16 mm (5/8 in.) change of toe-in or toe-out.*

OUO1085,0000238 -19-26JUL02-2/2

260  
15  
13


## MFWD Steering Stop Adjustment

### REASON:

To prevent interference between tire and tractor.

### PROCEDURE:

1. Raise and support the front of the tractor so the axle can be oscillated to its stops.
2. Slowly turn the steering wheel to the left until the steering cylinder travel has reached its limit, the steering stops, or the tires are within specification of the grille screen or the side panels.



A—Lock Nut  
B—Stop Bolt  
C—Stop

### Specification

Tire to Tractor Component—  
MFWD Axle—Clearance ..... 25 mm (1 in.)

3. Raise the left side of the axle against its axle pivot stop and measure the clearance between the tire and the nearest tractor component. The distance should not be less than specifications, as indicated above.
4. Repeat steps 2 and 3 for the right side.

### RESULTS:

- If not according to specifications, loosen lock nut (A) and adjust stop bolt (B) so it touches stop (C). Tighten lock nut to specifications.

### Specification

Steering Stop Lock Nut—MFWD  
Axle—Torque ..... 125 N•m (92 lb-ft)

**NOTE:** It may be necessary to shorten stop bolt (B) in order to obtain the maximum turning angle.

*Wide tread settings and large tire sizes will increase turn radius slightly.*

OUO1085,0000239 -19-26JUL02-1/1

## Brake Pedal Adjustment

### REASON:


To make sure brakes are fully engaged when brake pedals are depressed and fully disengaged when pedals are released.

To align slots in pedals for locking lever.

### PROCEDURE:

**NOTE:** This procedure can be done with brake valve assembly out of machine or in machine.  
Procedure is for brake valve assembly mounted in machine.

1. Remove right-hand dash cover.
2. Remove locking lever (D) from slot.
3. Loosen jam nut (A).
4. Turn screw (B) clockwise until pedal rests freely on valve piston (C).
5. Turn screw counterclockwise until it contacts brake pedal. Turn screw three additional flats or 1/2 turn counterclockwise and tighten jam nut.
6. Repeat procedure for other pedal.
7. Install right-hand dash cover.



A—Jam Nut  
B—Adjusting Screw  
C—Valve Piston  
D—Pedal Locking Lever

LV638 -UN-02AUG94

260  
15  
15

OUO1085,000023A -19-09OCT00-1/1

## Adjust Brake Drag

**NOTE:** Left rear tire shown removed for clarity of photo.

### REASON:

After reassembling brake components in axle, brake drag must be adjusted by pressurizing brake system and pressing brake retractors into rear axle housing.

### EQUIPMENT:

- JT03520 Special Adapter
- JT05634 Pressure Gauge 14 000 kPa (140 bar) (2000 psi)

### PROCEDURE:


1. Assemble special adapter (A) and pressure gauge (B).

**NOTE:** Two service technicians are needed to adjust brake drag: one to operate the brake pedals and the other to read pressure on gauge.

2. Remove socket head screw from left rear axle.
3. Install assembled special adapter and pressure gauge.
4. Bleed brakes. See Bleed Brake System in this group.

**NOTE:** If brake pedal goes to stop when depressed, let tractor sit overnight and bleed brakes again. Repeat brake drag adjustment procedure.

5. Start engine. With brake pedals unlocked, depress left brake pedal until pressure gauge reads 10 000 kPa (100 bar) (1450 psi). The applied pressure deflects the components to obtain proper working clearance.
6. Repeat brake drag adjustment for the other brake.



A—JT03520 Special Adapter  
B—JT05634 Pressure Gauge

LV7937 -UN-28JUN02

OUO1023,00003E2 -19-27JUN02-1/1

## Bleed Brake System

### REASON:

Any time the brake system has been opened up for service (lines disconnected), it will be necessary to bleed air from the system.


### CONNECTIONS:

1. Connect a clear plastic tube to the left brake bleed screw (A). Put the other end of tube into a bucket.

### PROCEDURE:

**NOTE:** *Two service technicians are needed to bleed the brake system: one to operate the brake pedals and the other to open and close bleed screws.*

1. Start the engine and run at slow idle to keep brake valve reservoir full of oil.
2. Pump brake pedal to obtain highest pedal position and hold. Loosen bleed screw 3/4 turn and slowly push on brake pedal. Before brake pedal completes full pedal travel, tighten bleed screw.
3. Let pedal return slowly to the top of its stroke. Continue this operation until the flow of oil in plastic tube is free of air bubbles.
4. When flow of oil is free of air bubbles hold the pedal down and tighten bleed screw.
5. Remove the plastic tube.
6. Repeat brake bleed procedure for the other brake.



A—Brake Bleed Screw

LV1109 -UN-01NOV94

260  
15  
17

OUC1085,000023B -19-26JUL02-1/1

260  
15  
18



# Section 270

# Hydraulic System Operation, Tests, and Adjustments

## Contents

	Page	Page
<b>Group 05—Component Location</b>		
Component Location Information . . . . .	270-05-1	
Hydraulic System Components—Without		
Oil Cooler . . . . .	270-05-2	
Hydraulic System Components—With Oil		
Cooler . . . . .	270-05-4	
Selective Control Valve Components . . . . .	270-05-6	
<b>Group 10—Theory of Operation</b>		
Theory of Operation Information . . . . .	270-10-1	
Hydraulic System Operation . . . . .	270-10-2	
Hydraulic Filter Operation—Early Model . . . . .	270-10-4	
Hydraulic Filter Operation—Later Model . . . . .	270-10-6	
Hydraulic Pump Operation . . . . .	270-10-8	
Rockshaft Control Valve Operation—Two		
Flow Regulator Valves . . . . .	270-10-10	
Rockshaft Control Valve Operation—Neutral		
Position . . . . .	270-10-12	
Rockshaft Control Valve Operation—Raise		
Position . . . . .	270-10-14	
Rockshaft Control Valve Operation—		
Lower Position . . . . .	270-10-16	
Surge Relief Valve Operation . . . . .	270-10-18	
Main Relief Valve Operation . . . . .	270-10-20	
Rate-of-Drop Valve Operation—Full Open. . . . .	270-10-22	
Rate-of-Drop Valve Operation—Full		
Closed . . . . .	270-10-24	
Rockshaft Draft-Sensing Operation . . . . .	270-10-25	
Selective Control Valve Operation—		
Neutral Position . . . . .	270-10-28	
Selective Control Valve Operation—		
Extend and Retract Positions . . . . .	270-10-30	
Selective Control Valve Operation—Boom		
Spool Float Position . . . . .	270-10-32	
Selective Control Valve Operation—		
Bucket Spool Regenerative Position . . . . .	270-10-34	
Quick Disconnect Coupler Operation . . . . .	270-10-36	
<b>Group 15—Diagnosis</b>		
Diagnostic Information . . . . .	270-15-1	
Preliminary Hydraulic System Inspection . . . . .	270-15-2	
Hydraulic Oil Warm-Up Procedure . . . . .	270-15-3	
Entire Hydraulic System Fails to		
Function/No Hydraulic Pump Output . . . . .	270-15-4	
Insufficient Pump Delivery . . . . .	270-15-5	
Hydraulic Functions Too Slow . . . . .	270-15-5	
Excessive Pump Pressure . . . . .	270-15-6	
Slow Hydraulic Pump Response . . . . .	270-15-7	
Excessive Pump Noise During Operation . . . . .	270-15-8	
Rockshaft Does Not Lift or Lifts Slowly . . . . .	270-15-8	
Rockshaft Does Not Lower or Lowers		
Slowly . . . . .	270-15-9	
Neutral Position Unstable, Rockshaft		
Drops after Engine Shut Down . . . . .	270-15-9	
SCV Joystick Does Not Return to Neutral		
Position—Single (Third) SCV . . . . .	270-15-10	
SCV Joystick Does Not Return to Neutral		
Position—Dual SCV . . . . .	270-15-10	
SCV Joystick Does Not Remain in Detent		
Position—Dual SCV . . . . .	270-15-11	
Remote Cylinder Does Not Extend or		
Retract . . . . .	270-15-11	
Remote Cylinder Settles Under Load . . . . .	270-15-12	
Remote Cylinder Operates Too Fast or		
Too Slow . . . . .	270-15-12	
<b>Group 16—Hydraulic Tests—Without SCV</b>		
Hydraulic System Tests—Without SCV . . . . .	270-16-1	
Pump Flow Test—Without SCV . . . . .	270-16-3	
Main Relief Valve Test—Without SCV . . . . .	270-16-5	
<b>Group 17—Hydraulic Tests—With SCV</b>		
Hydraulic System Tests—With SCV . . . . .	270-17-1	
Pump Flow Test—With SCV . . . . .	270-17-3	
Main Relief Valve Test—With SCV . . . . .	270-17-5	
SCV Leakage Test . . . . .	270-17-6	
<b>Group 18—Hydraulic Tests—All</b>		
Rockshaft Leakage Test . . . . .	270-18-1	
Rockshaft Lift Cycle Test . . . . .	270-18-3	
<b>Group 19—Adjustments</b>		
Rockshaft Control Lever Friction		
Adjustment . . . . .	270-19-1	
Rockshaft Position-Sensing Feedback		
Linkage Adjustment . . . . .	270-19-2	
Rockshaft Draft-Sensing Feedback Linkage		
Adjustment . . . . .	270-19-6	
Main Relief Valve Adjustment . . . . .	270-19-7	

Continued on next page



Page

**Group 20—Hydraulic Schematics**

Hydraulic Circuit Symbols . . . . .	270-20-1
Hydraulic Schematic—Without Selective Control Valves . . . . .	270-20-4
Hydraulic Schematic—With Selective Control Valves . . . . .	270-20-6
Power Beyond Hydraulic Schematic . . . . .	270-20-8

### **Component Location Information**


This group contains component location drawings for the following hydraulic components:

- Hydraulic System
- Selective Control Valve Components

Use the drawings when diagnosing a hydraulic problem and to help locate the components to be tested.

OUO1085,000023C -19-09OCT00-1/1

# Hydraulic System Components—Without Oil Cooler



HYDRAULIC SYSTEM COMPONENTS — WITHOUT OIL COOLER

LV040AE

LV040AE -19-16DEC97

Continued on next page


OUC1085,000023D -19-09OCT00-1/2

Component Location

A—Transmission Lubrication Line	F—Right Turn Pressure Line	M—Right Brake Pressure Line	T—Inlet Housing
B—Steering Valve	G—Steering Cylinder	N—Filter Canister	U—Rockshaft Draft-Sensing Lever
C—Brake Valve	H—Hydraulic Pump	O—Main Relief Valve	V—Hydraulic Reservoir (Transmission Case)
D—Supply Line to Steering Valve	I—Steering Pump	P—Mesh Filter	W—Rockshaft Position-Sensing Lever
E—Supply Line to Inlet Housing	J—Left Turn Pressure Line	Q—Rockshaft Housing	
	K—Suction Line	R—Left Brake Pressure Line	
	L—Return Line to Transmission Case	S—Rockshaft Valve	

OUC1085,000023D -19-09OCT00-2/2

# Hydraulic System Components—With Oil Cooler



LV2434

LV2434 -UN-16DEC97

Continued on next page


OUC1085,000023E -19-09OCT00-1/2

Component Location

A—Rockshaft Valve	G—Brake Valve	O—Left Turn Pressure Line	T—Supply Line to Inlet Housing
B—Inlet Housing	H—Hydraulic Oil Cooler	P—Supply Line to Steering Valve	U—Rockshaft Position-Sensing Lever
C—Left Brake Pressure Line	I—Cooler Inlet Line	Q—Suction Line	V—Hydraulic Oil Filter
D—Rockshaft Draft-Sensing Lever	J—Cooler Outlet Line	R—Right Brake Pressure Line	W—Main Relief Valve
E—Transmission Lubrication Line	K—Right Turn Pressure Line	S—Return Line to Transmission Case	X—Mesh Filter
F—Steering Valve	L—Hydraulic Pump		
	M—Steering Cylinder		
	N—Steering Pump		

OUC1085,000023E -19-09OCT00-2/2

# Selective Control Valve Components



## SELECTIVE CONTROL VALVE COMPONENTS

LV124AE

LV124AE -19-27/JAN92

Continued on next page

OUC1085,000023F -19-09OCT00-1/2

Component Location

- |                         |                                    |                                |                              |
|-------------------------|------------------------------------|--------------------------------|------------------------------|
| A—Rate-of-Drop Valve    | E—Rockshaft Position Control Lever | G—Single (Third) SCV Lever     | K—Single (Third) SCV Housing |
| B—Supply Line From Pump |                                    | H—Main Relief Valve            | L—Inlet Housing              |
| C—Dual SCV Joystick     | F—Rockshaft Draft Control Lever    | I—Dual SCV Housing             | M—Rockshaft Housing          |
| D—Joystick Cables       |                                    | J—Double-Acting Sleeve Coupler |                              |

NOTE: Dual SCV and single (third) SCV valve components are offered as optional field installed kits.

OUC1085,000023F -19-09OCT00-2/2

270  
05  
7



270  
05  
8

## Theory of Operation Information


This group divides the hydraulic system into individual components by function. The story contains information on function, component or system identification and theory of operation.

The following systems or components are covered in this group:

- Hydraulic System
- Hydraulic Filters
- Hydraulic Pump
- Rockshaft Control Valve
- Surge Relief Valve
- Main Relief Valve
- Rate-of-Drop Valve
- Rockshaft Draft-Sensing
- Selective Control Valves
- Double-Acting Sleeve Coupler

OUO1085,0000240 -19-10OCT00-1/1

# Hydraulic System Operation



## HYDRAULIC SYSTEM OPERATION

LVC125AE

LVC125AE -19-21MAY96

- |                                    |                                 |                     |                     |
|------------------------------------|---------------------------------|---------------------|---------------------|
| A—Hydraulic Pump                   | F—Rockshaft Draft Control Lever | I—Mesh Filter       | M—Transmission Case |
| B—Steering Pump                    | G—Filter Canister               | J—Inlet Housing     | N—Suction Oil       |
| C—Suction Line                     | H—Main Relief Valve             | K—Rockshaft Valve   | O—Pump Pressure Oil |
| D—Pressure Line                    |                                 | L—Rockshaft Housing | P—Return Oil        |
| E—Rockshaft Position Control Lever |                                 |                     |                     |

Continued on next page

OUC1085,0000241 -19-10OCT00-1/2

**FUNCTION:**

The hydraulic system provides:

- Filtered oil to the power steering system.
- Lubrication oil to the transmission.
- Hydraulic power to the rockshaft for hitch operation.
- Hydraulic power to the optional selective control valves.

**MAJOR COMPONENTS:**

- Hydraulic Pump
- Filter Canister
- Mesh Filter
- Reservoir (Transmission Case)
- Rockshaft
- Rockshaft Valve
- Pressure Lines
- Suction Line
- Rate-of-Drop Valve
- Rockshaft Control Levers

**THEORY OF OPERATION:**

The hydraulic system of 5210, 5310, 5410, and 5510 tractors is equipped with 12-cc and 20-cc or 12-cc and 29-cc external-gear, constant-displacement pumps. The 12-cc pump (B) provides fluid power to the power steering system and to lubricate the transmission.

The 20-cc or 29-cc hydraulic pump (A) provides hydraulic power to the rockshaft (L) for hitch operation and to optional selective control valves, if equipped. The hitch is category 2/1 with draft sensing through the center link.

The hydraulic system uses an open-center design. This means that low pressure oil flows continuously through the valves and lines as long as the valves are in a neutral position. Because of this flow of oil there always must be a way for the oil to return to the reservoir.

The transmission case (M) of the tractor serves as a reservoir for the hydraulic oil. Proper level must be maintained for adequate transmission lubrication and oil supply to the hydraulic pumps (A and B).

The engine drives the hydraulic pump from the camshaft drive gear. As the hydraulic pump turns, a low-pressure area develops in the suction line (C). Oil then moves from the transmission case through mesh filter (I) and 25-micron filter canister (G), then on through suction line (C) to the inlet side of the hydraulic pumps.

Oil flows from the outlet side of the hydraulic pump, through pressure line (D) to inlet housing (J). A relief valve (H) limits hydraulic system pressure to a range of 18995—19685 kPa (190.1—196.9 bar) (2755—2855 psi). If the system encounters sufficient resistance to oil flow due to a heavy load or restriction, the relief valve opens, allowing oil to return to the reservoir.


The inlet housing (J) also provides a mounting location for up to three optional selective control valves. (See this group for selective control valve oil flow.)

Oil flows from the inlet housing to the rockshaft valve (K). A flow regulating valve controls the amount of oil flow to the rockshaft (L) so it will rise at a constant rate regardless of engine speed.

When in neutral, the rockshaft control valve passes oil to the sump. When the control valve is actuated by movement of control lever (E) or by the draft sensing linkage, oil passes to or from the rockshaft cylinder, raising or lowering the 3-point hitch.

**NOTE:** See Section 260, Group 10 for steering and brake operation. See this group for hydraulic pump and rockshaft operation.

## Hydraulic Filter Operation—Early Model



LV126AE

### HYDRAULIC FILTER OPERATION

A—Mesh Filter

B—Outlet Port to Hydraulic Pump

C—Filter Canister

D—Filter Element

E—Filter Mount

#### FUNCTION:

Strains particles or contaminants from the oil.

#### MAJOR COMPONENTS:

- Filter Screen
- Filter Housing
- Filter Canister

#### THEORY OF OPERATION:

Continued on next page

OOU1085,0000242 -19-10OCT00-1/2

The filter system consists of a 150-mesh filter (A) and a filter canister (C). Hydraulic oil first moves through mesh filter (A) to strain large particles of debris before the oil leaves the transmission case. Oil then enters filter mount (E) and travels to the outside of filter element (D). The oil then passes through the element and out port (B) to the hydraulic pumps.


If the filter canister should plug and there is more than 55 kPa (0.5 bar) (8 psi) pressure differential, a relief

valve opens, allowing unfiltered oil to enter the hydraulic pumps.

**IMPORTANT: Hydraulic filters should be changed according to the maintenance schedule to prevent damage to the hydraulic system.**

OUO1085,0000242 -19-10OCT00-2/2

## Hydraulic Filter Operation—Later Model



 (A) SUCTION OIL

LVC7362

### HYDRAULIC FILTER OPERATION

A—Suction Oil  
B—Pick-Up Screen

C—Bypass Valve  
D—Filter Element

E—Filter  
F—Outlet to Hydraulic Pump

G—Filter Manifold

#### FUNCTION:

Strains particles or contaminants from the oil.

#### MAJOR COMPONENTS:

- Pickup Screen

- Filter Manifold
- Filter
- Bypass Valve

#### THEORY OF OPERATION:

Continued on next page

OUC1082,0000113 -19-08JUL02-1/2

The filter system consists of a 125 mesh pick-up screen (B), a 25-micron filter (E) and bypass valve (C). Hydraulic oil first moves through pickup screen (B) to strain large particles of debris before the oil leaves the transmission case. Oil then enters filter manifold (G) and travels to the outside of filter element (D). The oil then passes through the element and out port (F) to the hydraulic pumps.



If the filter should plug and there is more than 50 kPa (0.5 bar) (7 psi) pressure differential, bypass valve (C) opens allowing unfiltered oil to the hydraulic pumps.

**IMPORTANT: Hydraulic filters should be changed according to the maintenance schedule to prevent damage to the hydraulic system.**

OUO1082,0000113 -19-08JUL02-2/2



## Hydraulic Pump Operation



LVC127AE

## HYDRAULIC PUMP OPERATION

A—Pump Inlet  
B—Bushings

C—Gears  
D—Pump Outlet

E—Pump Housing  
F—Drive Shaft

G—Suction Oil  
H—System Oil

### FUNCTION:

Supplies a continuous flow of oil to operate the rockshaft and implements connected to optional

selective control valves. Also supplies oil for transmission lubrication and power steering.

### MAJOR COMPONENTS:

LVC127AE -19-07APR97

Continued on next page

OOU1085,0000243 -19-10OCT00-1/2

- Hydraulic Pump

**THEORY OF OPERATION:**

The hydraulic pump assembly contains two pumps, each of different displacements. The 20-cc or 29-cc hydraulic pump supplies oil for the rockshaft and other tractor hydraulics. The 12-cc pump supplies oil for the steering system and transmission lubrication.

Both pumps operate identically and use a positive-displacement, external-gear design that moves a set volume of fluid with each revolution. Output volume changes only when the speed of the pump changes.



The engine drives the hydraulic pumps from the camshaft drive gear. As the pump gears (C) rotate, they continuously move in and out of mesh with each other. When the gears separate, a vacuum develops which draws oil into the pump inlet (A). The oil continues to move with the gears as they turn.

As the gears come back into mesh, they form a seal which prevents oil from returning to the pump inlet. Further meshing forces oil out the pump outlet (D) and into the hydraulic system. This cycle repeats continuously as long as the pump turns.

OUO1085,0000243 -19-10OCT00-2/2

# Rockshaft Control Valve Operation—Two Flow Regulator Valves

LVC2211 -JUN-21JUN87



## ROCKSHAFT CONTROL VALVE OPERATION TWO FLOW REGULATOR VALVES


LVC2211

TM1716 (26APR04)

270-10-10 5210, 5310, 5410, and 5510 Tractors  
042604  
PN=1222

See Page 270-10-10 A

See Page 270-10-10 B




LVC2211

ROCKSHAFT CONTR  
TWO FLOW REG

This page is intentionally left blank.


## Rockshaft Control Valve Operation—Two Flow Regulator Valves

LVC2211 -UN-21JUN97



RED LOW  
RE FLOW

RETURN OIL



## CONTROL VALVE OPERATION TWO FLOW REGULATOR VALVES

This page is intentionally left blank.

A—Passage	F—Passage	K—Front of Machine	P—Unregulated Low Pressure Flow
B—Low Flow Regulator Valve	G—Inlet Port	L—Sump Passage	Q—Regulated Low Pressure Flow
C—Passage	H—High Flow Regulator Valve	M—Rockshaft Valve Housing	R—Return Oil
D—Bypass Control Orifice	I—Passage	N—Passage	
E—Metering Orifice	J—Raise Check Valve	O—Raise Valve	

**FUNCTION:**

The two flow regulator valves meter two separate oil supplies to the rockshaft control valve. This system compensates for variations in hitch load and pump output, to maintain a constant lift rate at the rockshaft cylinder. The rockshaft cylinder rises at one of two steady speeds regardless of engine speed and/or hitch load. The low flow regulator valve (B) meters oil for small hitch movements. The high flow regulator valve (H) meters oil flow for large hitch movements.

**MAJOR COMPONENTS:**

- Rockshaft Valve Housing
- Rockshaft Low Flow Regulator Valve
- Rockshaft High Flow Regulator Valve

**THEORY OF OPERATION:****Low Flow Regulator Valve:**

Oil from the hydraulic pump enters inlet port (G) near rear of low flow regulator valve (B). Oil continues

through center of valve, exiting through metering orifice (E) to passage (F). Hydraulic pump flow is reduced from a maximum of 47 L/m (12 gpm) to 4 L/m (1 gpm). This oil is supplied to raise valve (O) regardless of hitch or raise valve position. Remaining oil flows through the bypass control orifices (D) and back to sump through passage (L).

**High Flow Regulator Valve:**




Oil from the hydraulic pump enters inlet port (G) of high flow regulator valve (H). When the raise valve is moved more than 0.8 mm (0.030 in.), oil flow from sump passage (A) to sump passage (L) is blocked. Control oil in front of the high flow regulator valve shifts the spool and meters an additional 11 L/m (3 gpm) from inlet port (G) to passage (F). This oil combines with flow from low flow regulating valve (B) for a total flow of 14 L/m (4 gpm) to raise valve (O). Passages (C), (F), and (N) connect, providing a combined regulated supply of oil to raise valve (O).

OUO1085,0000244 -19-10OCT00-2/2



# Rockshaft Control Valve Operation—Neutral Position

LVC2212 -JUN-21JUN87




## ROCKSHAFT CONTROL VALVE OPERATION NEUTRAL POSITION

LVC2212

TM1716 (26APR04) 270-10-12 5210, 5310, 5410, and 5510 Tractors  
OUC1085,000245 -19-10CCT00-12  
042604  
PN=1224

See Page 270-10-12 A

See Page 270-10-12 B



**ROCKSHAFT CONTR  
NEUTRA**


LVC2212

This page is intentionally left blank.

# Rockshaft Control Valve Operation—Neutral Position


LVC2212 -UN-21JUN97

LOW  
ATOR



OIL (W) TRAPPED OIL

IL



## CONTROL VALVE OPERATION NEUTRAL POSITION

This page is intentionally left blank.

A—Pilot Chamber  
B—Passage  
C—Counterbored Passage  
D—Passage  
E—Neutral Flow Passages  
F—Rockshaft Valve Housing  
G—Sump Passage

H—High Flow Regulator Valve  
I—Inlet Port  
J—Passage  
K—Front of Machine  
L—Lowering Valve  
M—Passage

N—Lowering Valve Spring  
O—Passage  
P—Sump Passage  
Q—Raise Valve  
R—Raise Poppet  
S—Unregulated Low Pressure Flow

T—Regulated Low Pressure Flow  
U—Return Oil  
V—Pilot Oil  
W—Trapped Oil

#### FUNCTION:

Controls oil flow to the rockshaft cylinder.

#### MAJOR COMPONENTS:

- Rockshaft Valve Housing
- Rockshaft Valve

#### THEORY OF OPERATION:



With the rockshaft control valve in the neutral position, pressure from the lowering spring (N) keeps the

lowering valve (L) closed while applying light pressure to the raise valve (Q). Raise valve position allows the counterbored passage (C) to align with passage (O). Pilot pressure in the pilot chamber (A) vents to the sump, causing raise poppet (R) to open and route pump flow from passage (D) to sump through the neutral flow passages (E). Passage (M) connects to the cylinder side of the raise check valve and is blocked by the lowering valve (L) to maintain cylinder position.

OUO1085,0000245 -19-10OCT00-2/2

# Rockshaft Control Valve Operation—Raise Position

LVC2213 -JUN-21JUN87




## ROCKSHAFT CONTROL VALVE OPERATION RAISE POSITION

LVC2213

TM1716 (26APR04) 270-10-14 5210, 5310, 5410, and 5510 Tractors 042604 PN=1226

See Page 270-10-14 A

See Page 270-10-14 B



ROCKSHAFT CONTF  
RAISE


LVC2213



This page is intentionally left blank.


# Rockshaft Control Valve Operation—Raise Position

LVC2213 -UN-21JUN97



OIL

OIL



## CONTROL VALVE OPERATION RAISE POSITION

This page is intentionally left blank.

A—Pilot Chamber	I—Passage	P—Lowering Valve	W—Raise Valve
B—Passage	J—Inlet Port	Q—Passage	X—Unregulated High Pressure Flow
C—Passage	K—High Flow Regulator Valve	R—Lowering Valve Spring	Y—Regulated High Pressure Flow
D—Counterbored Passage	L—Passage	S—Neutral Flow Passage	Z—Return Oil
E—Passage	M—Raise Check Valve	T—Sump Passage	AA—Pilot Oil
F—Passage	N—Front of Machine	U—Raise Poppet	
G—Low Flow Regulator Valve	O—Rockshaft Valve Housing	V—Raise Poppet Spring	
H—Sump Passage			

#### FUNCTION:

Controls oil flow to the rockshaft cylinder with control lever in the raised position.

#### MAJOR COMPONENTS:

- Rockshaft Valve Housing
- Rockshaft Valve

#### THEORY OF OPERATION:

When the rockshaft control valve is placed in the raise position, raise valve (W) moves rearward, putting added pressure on lowering valve spring (R). Lowering valve (P) remains closed. As the raise valve moves, counterbored passages (D) align with passage (E)



instead of passage (C). This fills pilot chamber (A) with pressurized oil. Raise poppet (U) closes due to pressure in the pilot chamber, and force of raise poppet spring (V), which then blocks oil flow to neutral flow passage (S). Pressure increases at passages (E, F, I, and Q), opening raise check valve (M) and thereby supplying oil flow of 11 L/m (3 gpm) to the rockshaft cylinder.

When the raise valve is moved more than 0.8 mm (0.030 in.), oil flow from high flow regulator valve (K) to sump is blocked at sump passage (T). This causes pressure to build, moving the high flow regulator valve and diverting additional oil from inlet port (J) to passage (E). This oil combines with oil from low flow regulator valve (G) to increase total oil flow to the rockshaft cylinder to 14 L/m (4 gpm).

OUO1085,0000246 -19-10OCT00-2/2


# Rockshaft Control Valve Operation—Lower Position

LVC2214 -JUN-21JUN87



## ROCKSHAFT CONTROL VALVE OPERATION LOWER POSITION

LVC2214




**ROCKSHAFT CONTR  
LOWER**

LVC2214

This page is intentionally left blank.


## Rockshaft Control Valve Operation—Lower Position

LVC2214 -UN-21JUN97



OIL

L



## CONTROL VALVE OPERATION LOWER POSITION



This page is intentionally left blank.

## Theory of Operation

A—Pilot Chamber  
B—Passage  
C—Counterbored Passage  
D—Passage  
E—Passage  
F—Sump Passage  
G—Passage

H—Inlet Port  
I—High Flow Regulator Valve  
J—Passage  
K—Front of Machine  
L—Rockshaft Valve Housing  
M—Return Spring  
N—Lowering Valve

O—Passage  
P—Lowering Valve Spring  
Q—Neutral Flow Passage  
R—Passage  
S—Sump Passages  
T—Raise Poppet  
U—Raise Poppet Spring

V—Raise Valve  
W—Unregulated Low Pressure Flow  
X—Regulated Low Pressure Flow  
Y—Return Oil  
Z—Pilot Oil

### FUNCTION:

Controls oil flow from the rockshaft cylinder.

### MAJOR COMPONENTS:


- Rockshaft Valve Housing
- Rockshaft Valve

### THEORY OF OPERATION:


When the rockshaft control valve is moved forward to the lowering position, force from return spring (M) pushes lowering valve (N) open. Counterbored passages (C) in the raise valve align with passage (R) allowing pilot pressure to return to sump. Pressure at passage (D) opens raise poppet (T), venting pressurized oil through raised valve, out neutral flow passages (Q) to sump. Oil in rockshaft cylinder flows through passage (O) in lowering valve and returns to sump.

OUO1085,0000247 -19-10OCT00-2/2

## Surge Relief Valve Operation



**NORMAL MODE**



**RELIEF MODE**

-  (G) PRESSURE OIL
-  (H) RETURN OIL

LVC128AE

## SURGE RELIEF VALVE OPERATION

Continued on next page

OUC1085,0000248 -19-10OCT00-1/2

A—From Rockshaft Cylinder      D—Relief Spring      F—To Sump      H—Return Oil  
 B—Rockshaft Cylinder Casting      E—Relief Ball      G—Pressure Oil  
 C—Surge Relief Valve Cartridge

**FUNCTION:**

The surge relief valve threads into a passage at the end of the rockshaft cylinder. The valve protects the cylinder and its related parts from damage due to excessive pressure.

**MAJOR COMPONENTS:**


- Surge Relief Valve
- Rockshaft Cylinder
- Rockshaft Piston

**THEORY OF OPERATION:**


As long as pressure inside the rockshaft cylinder is less than 22994 to 22934 kPa (230 to 240 bar) (3335 to 3480 psi), tension from relief spring (D) holds relief ball (E) closed. If pressure increases suddenly and exceeds spring pressure, relief ball unseats, allowing oil back to sump. This condition can occur when the rockshaft encounters a sudden increase in implement load.

OUO1085,0000248 -19-10OCT00-2/2

## Main Relief Valve Operation




### NORMAL OPERATING MODE



### RELIEF MODE



(J) PRESSURE OIL



(K) REDUCED PRESSURE OIL



(L) RETURN OIL

LVC129AE

### RELIEF VALVE OPERATION

LVC129AE -19-18MAY01

Continued on next page

OUO1040,0000AF8 -19-24APR01-1/2

A—From Pump Inlet Passage  
B—Housing  
C—To Sump

D—Lock Nut  
E—Adjusting Screw  
F—Pilot Poppet Spring

G—Pilot Poppet  
H—Main Poppet Spring  
I—Main Poppet

J—Pressure Oil  
K—Reduced Pressure Oil  
L—Return Oil

**FUNCTION:**

The main relief valve serves two purposes:

- Protects the components of the hydraulic system from excessive pressure.
- Prevents overloading of the hydraulic system and tractor.

**MAJOR COMPONENTS:**

- Main Relief Valve


- Valve End Plate or SCV Assembly

**THEORY OF OPERATION:**

The system pressure reaches relief setting of 18995—19685 kPa(190—197 bar) (2755—2855 psi), pilot poppet (G) unseats. This drains pilot flow that has been allowed to pass to center of main poppet (I) causing pressure to drop at its back side. System pressure forces main poppet to move, opening passages back to sump.

OUO1040,0000AF8 -19-24APR01-2/2

## Rate-of-Drop Valve Operation—Full Open



LVC166AE

## RATE-OF-DROP VALVE OPERATION — FULL OPEN

A—Rate-of-Drop Valve  
B—Inlet Housing

C—Passage to Rockshaft  
Cylinder

D—Passage to Lowering Valve E—Return Oil

### FUNCTION:

Controls the lowering rate of implement attached to rockshaft.

### MAJOR COMPONENTS:

- Inlet Housing
- Rate-of-Drop Valve
- Lowering Valve

### THEORY OF OPERATION:

Continued on next page

OUC1085,0000249 -19-10OCT00-1/2

## *Theory of Operation*


Rate-of-drop valve (A) acts as a variable orifice for oil flow through the lowering valve. With valve in the fully open position, oil travels through valve opening from passage to rockshaft cylinder (C) to passage to

lowering valve (D) oil continues to flow back to sump through lowering valve. Rockshaft drops quickly due to large volume of oil returning to sump.

OUC1085,0000249 -19-10OCT00-2/2



## Rate-of-Drop Valve Operation—Full Closed



LVC168AE

## RATE-OF-DROP VALVE OPERATION — FULL CLOSED

A—Rate-of-Drop Valve  
B—Inlet Housing

C—Passage to Rockshaft  
Cylinder

D—Passage to Lowering Valve F—Return Oil  
E—Trapped Oil

## FUNCTION:

Controls the lowering rate of implement attached to rockshaft.

## MAJOR COMPONENTS:

- Inlet Housing
- Rate-of-Drop Valve


- Lowering Valve

## THEORY OF OPERATION:

Rate-of-drop valve (A) acts as a variable orifice for oil flow through the lowering valve. With valve in the closed position, oil is trapped between the rockshaft cylinder, raise check valve, and rate-of-drop valve. Rockshaft maintains its current position.

OUO1085,000024A -19-10OCT00-1/1

## Rockshaft Draft-Sensing Operation



LV169AE

## ROCKSHAFT DRAFT-SENSING OPERATION

A—Position Feedback Rod  
B—Control Shaft Lever  
C—Control Shaft

D—Valve Link  
E—Shaft Arm  
F—Draft Control Lever

G—Raise Valve  
H—Rockshaft Control Valve  
I—Center Link Bracket

J—Center Link  
K—Rod Bracket  
L—Draft-Sensing Rod

### FUNCTION:

Senses implement load and triggers rockshaft to rise if draft load is excessive.

### MAJOR COMPONENTS:

- Draft-Sensing Linkage
- Rockshaft Valve
- Rockshaft Cylinder

### THEORY OF OPERATION:

Continued on next page

OUO1085,000024B -19-10OCT00-1/2

System senses draft load through a linkage arrangement. As implement load increases, inward pressure on center link (J) pushes on center link bracket (I). In turn, rod bracket (K) moves draft-sensing rod (L) forward and pushes control shaft lever (B). Lever turns control shaft (C) and shaft arm (E), which moves valve link (D). Link moves raise valve (G) according to amount of draft load and lever position.


When draft control lever (F) is positioned completely forward, system does not respond to draft sensing. Large amount of clearance between valve link and raise valve prevents valve link from contacting raise valve.

As draft control lever is pulled back, clearance between valve link and raise valve decreases. Movement of the draft-sensing linkage now moves raise valve, which directs oil to rockshaft cylinder and lifts the 3-point hitch. Continued lever movement causes further reduction in clearance between valve link and raise valve, increasing system sensitivity to draft load. The center link can be attached in three different positions. Changing positions affects the draft sensing sensitivity.

QUO1085,000024B -19-10OCT00-2/2



# Selective Control Valve Operation—Neutral Position



## SELECTIVE CONTROL VALVE OPERATION — NEUTRAL POSITION

LVC243AE

LVC243AE -19-26JUN02

Continued on next page

OUO1085,000024C -19-10OCT00-1/2

**A—Valve Housing**  
**B—Sump Passage**  
**C—Neutral Passages**

**D—Spool**  
**E—Retract Port**  
**F—Inlet Passages**

**G—Load Check**  
**H—Extend Port**  
**I—System Neutral Flow**

**J—Trapped Oil**  
**K—Return Oil**

**FUNCTION:**

Control oil supply to cylinders of attached implements.

**MAJOR COMPONENTS:**

- Selective Control Valves
- Joystick or Lever
- Control Cables

**THEORY OF OPERATION:**


Tractor may be equipped with up to five optional selective control valves. Operation in neutral position is identical for all valves.

Oil from hydraulic pump enters valve at inlet passage (F). Oil continues to flow out of passage to other valves (if equipped) and to valve end plate or valve end housing, depending on number of valves used. After being redirected, oil moves back into neutral passages (C) of valve. Oil flow through neutral passages feeds rockshaft valve.

As long as spool (D) remains in neutral position, oil is trapped in extend port (H) and retract port (E), and load check is inactive.

OUC1085,000024C -19-10OCT00-2/2

## Selective Control Valve Operation—Extend and Retract Positions



## LVC244AE SELECTIVE CONTROL VALVE OPERATION — EXTEND AND RETRACT POSITIONS

LVC244AE —19-15JUL97

Continued on next page

OUO1085,000024D —19-10OCT00-1/2

A—Valve Housing  
B—Sump Passage  
C—Neutral Passages

D—Spool  
E—Retract Port  
F—Inlet Passage

G—Load Check  
H—Extend Port  
I—System Pressure Oil

J—Trapped Oil  
K—Return Oil

#### FUNCTION:

Control oil supply to cylinders of attached implements.

#### MAJOR COMPONENTS:

- Selective Control Valves
- Joystick or Lever
- Control Cable

#### THEORY OF OPERATION:

When the spool moves out, the neutral passages (C) are blocked, causing pressure to rise at the inlet

passage (F). Inlet passage is simultaneously connected to extend port (H), allowing inlet to open load check (G) and allow oil flow to extend port (H). With the spool in this position, the sump passage (B) is connected with retract port (E) allowing oil to return to sump.


When spool is moved past neutral, ports reverse flow and connected cylinder moves in the opposite direction.

*NOTE: Single (third) selective control valve is shown. Extend and retract positions for other valves are identical.*

OUC1085,000024D -19-10OCT00-2/2



## Selective Control Valve Operation—Boom Spool Float Position



## SELECTIVE CONTROL VALVE OPERATION — BOOM SPOOL FLOAT POSITION

LVC245AE

LVC245AE -19-08MAY01

Continued on next page

OUO1085,000024E -19-10OCT00-1/2

A—Valve Housing  
B—Sump Passages  
C—Neutral Passages

D—Boom Spool  
E—Retract Port  
F—Inlet Passage

G—Load Check  
H—Extend Port  
I—System Pressure Oil

J—Trapped Oil  
K—Return Oil

#### FUNCTION:

Allows boom to follow ground contour.

#### MAJOR COMPONENTS:

- Boom Spool
- Joystick
- Control Cable

#### THEORY OF OPERATION:

The boom spool is the outer spool valve of the dual selective control valve assembly. Besides the positions


of neutral, extend, and retract, the boom spool also has a float position.

When the boom spool (D) is moved fully inward, a detent engages the spool in the float position. This isolates the system pressure oil from retract port (E) and extend port (H) and connects both ports to their respective sump passages (B). With both ends of the boom cylinder connected to sump, oil can pass to sump freely allowing boom to follow the ground contour.

**NOTE:** *Detent locks boom spool in float position and must be released by operator.*

OUC1085,000024E -19-10OCT00-2/2

# Selective Control Valve Operation—Bucket Spool Regenerative Position



LVC246AE  
**SELECTIVE CONTROL VALVE OPERATION — BUCKET SPOOL REGENERATIVE POSITION**  
 LVC246AE -19-21MAY96

Continued on next page

OUC1085,000024F -19-10OCT00-1/2

A—Valve Housing  
B—Sump Passage  
C—Neutral Passages

D—Bucket Spool  
E—Retract Port  
F—Inlet Passage

G—Load Check  
H—Extend Port  
I—System Pressure Oil

J—Trapped Oil  
K—Return Oil

**FUNCTION:**

Increases bucket dumping speed.

**MAJOR COMPONENTS:**

- Bucket Spool
- Joystick
- Control Cable

**THEORY OF OPERATION:**


The bucket spool is the inner spool valve of the dual selective control valve assembly. Besides the positions

of neutral, extend, and retract, the bucket spool also has a regenerative position.

When the bucket spool (D) moves inward to the regenerative position, neutral passages (C) are blocked, causing a pressure rise at inlet passage (F). Oil flowing into inlet passage opens load check (G) which allows oil flow to spool. Oil flows out extend port (H) to head end of bucket cylinder. Oil returning through retract port (E) from rod end of cylinder enters extend port (H) and supplements flow passing to piston end of cylinder, causing bucket to dump faster.

OUC1085,000024F -19-10OCT00-2/2

## Quick Disconnect Coupler Operation



LV131AE

## DOUBLE-ACTING SLEEVE COUPLER OPERATION

A—Cylinder Hose Plug  
B—Rear Ramp  
C—Retaining Balls  
D—Plug Flange

E—Body Return Spring  
F—Check Valve Return Spring  
G—To Selective Control Valve  
H—Coupler Body

I—Coupler Sleeve  
J—Check Valves  
K—Front Ramp

L—Check Valve Return Spring  
M—To Remote Cylinder  
N—Oil Flow

## FUNCTION:

Tractors with SCV option use double-acting sleeve couplers to connect remote cylinder hoses. These couplers provide both a convenient method of

connecting hoses and a breakaway feature that releases the hoses when under excessive tension.

## MAJOR COMPONENTS:

Continued on next page

OUO1085,0000250 -19-10OCT00-1/2

- Coupler Sleeve
- Retaining Balls
- Check Valves
- Coupler Body
- Body Return Spring
- Check Valve Return Spring

#### THEORY OF OPERATION:

To connect remote cylinder hoses, push the cylinder hose plug (A) into coupler. This can be done with or without system pressurized.

As coupler body (H) moves toward front of tractor, retaining balls (C) roll down front ramp (K), allowing flange (D) of plug to move past retaining balls. Upon

releasing the cylinder hose plug, body return spring (E) moves coupler rearward, locking retaining balls in plug groove.

Once the mating halves of coupler are connected, both check valves (J) open, allowing oil to and from the remote cylinder (M).

Remote cylinder hose plug (A) releases automatically when pulled rearward with sufficient tension. Coupler body (H) moves rearward against spring until retaining balls (C) move into ramp area (B). Retaining balls move outward by releasing plug. Check valves (J) then seat under pressure from springs (F and L), shutting off oil flow.

OUO1085,0000250 -19-10OCT00-2/2



## Diagnostic Information

The diagnostic information in this group is used to test components related to a specific problem or symptom. Select a symptom from the list and follow the test procedures under the heading.

The symptom headings are:

- Entire Hydraulic System Fails to Function/No Hydraulic Pump Output
- Insufficient Pump Delivery
- Hydraulic Functions Too Slow
- Excessive Pump Pressure
- Slow Hydraulic Pump Response
- Excessive Pump Noise During Operation
- Rockshaft Does Not Lift or Lifts Slowly
- Rockshaft Does Not Lower or Lowers Slowly
- Neutral Position Unstable, Rockshaft Drops after Engine Shut Down
- SCV Joystick Does Not Return to Neutral Position
- SCV Joystick Does Not Remain in Detent Position
- Remote Cylinder Does Not Extend or Retract

- Remote Cylinder Settles Under Load
- Remote Cylinder Operates Too Fast or Too Slow

The diagnostic procedure lists:

- Test conditions
- Test sequence
- Test location
- Normal reading
- Check or test to perform if reading is not normal

When performing the test or check, be sure to set your machine up to the test conditions listed and follow the sequence carefully. The middle "Normal" column gives the reading or condition that should be obtained when performing the test or check. If the results of the test or check are not normal, perform the test, check, or adjustment listed in the third "If Not Normal" column to repair the malfunction. The detailed tests or adjustments referred to in the "If Not Normal" column are located in groups 16, 17, 18, and 19.



## Preliminary Hydraulic System Inspection

### CONDITIONS:

- Operate the tractor and make checks with the hydraulic oil warm.

Test Location	Normal	If Not Normal
1. Check entire machine for hydraulic oil leakage.	No leaks.	Repair cause of leakage.
2. Check oil level.	Level between marks on site gauge	Add oil if low.
3. Check oil condition.	Clear.	Milky—check for water in oil.
	Clean.	Dirty—change oil and filter.
	No metal particles.	Change oil, filter and check for mechanical failure.
	Not discolored.	Check for causes of oil overheating.
4. Operate all hydraulic functions.	All functions operate equally smooth and quick.	Change filter canister.
		Check mesh filter.
		Make sure oil is correct type.

**NOTE:** *If the tractor is equipped with SCV, operate each valve to determine if the problem affects complete system or only one valve.*

AG,OUO1023,537 -19-28FEB00-1/1

## Hydraulic Oil Warm-Up Procedure

### REASON:

When making hydraulic tests the oil must be heated to approximately 43°C (110°F) for accurate test results.

### EQUIPMENT:

- JDG282 Temperature Gauge


### CONNECTIONS:

Install JDG282 Temperature Gauge on suction line.

### PROCEDURE:

1. Lower the rockshaft.
2. Run engine at slow idle.
3. Pull SCV lever back to put system into relief.
4. Hold lever back until the suction line is too warm to hold.

At this point the oil temperature should be approximately 38—43°C (100—110°F).



Temperature Gauge

LV132 -UN-18FEB92

270  
15  
3

OUO1085,0000255 -19-05JUL02-1/1

## Entire Hydraulic System Fails to Function/No Hydraulic Pump Output

### CONDITIONS:

- Machine parked on level surface.
- Key switch in OFF position.
- Hydraulic tests and adjustments in this section.

Test Location	Normal	If Not Normal
1. Hydraulic dipstick.	Oil clean and up to proper level.	Add or change oil.
2. Filter canister.	Free of restrictions.	Replace filter.
3. Mesh filter.	Free of debris.	Clean filter.

### CONDITIONS:

- Engine idling.

Test Location	Normal	If Not Normal
4. Pump drive.	Drive gear and shaft in good condition.	Repair or replace pump.
5. Hydraulic diverter plug port.	No optional hydraulic equipment installed.	Remove diverter plug in end plate.

OUO1085,0000256 -19-11OCT00-1/1

## Insufficient Pump Delivery

### CONDITIONS:

- Machine parked on level surface.
- Engine at 2000 rpm.
- Hydraulic tests and adjustments in this section.

Test Location	Normal	If Not Normal
1. Filter canister.	Free of restrictions.	Replace filter.
2. Mesh filter.	Free of debris.	Clean filter.
3. Main relief valve.	System pressure within specifications. Relief valve not leaking.	Adjust relief valve. Repair or replace as needed.
4. Hydraulic pump.	Flow output within specifications. Good condition with minimal wear.	Perform Pump Flow Test. Repair or replace as needed.
5. Suction line.	No air leaks.	Repair or replace.

OUO1085,0000257 -19-11OCT00-1/1

## Hydraulic Functions Too Slow

### CONDITIONS:

- Machine parked on level surface.
- Hydraulic tests and adjustments in this section.
- Engine adjustments in Section 220, Group 15.

Test Location	Normal	If Not Normal
1. Mesh filter.	Free of debris.	Clean filter.
2. Filter canister.	Free of restrictions.	Replace filter.
3. Tachometer.	Reads 2000 rpm with full load.	Check and adjust fast idle.
4. Relief valve.	System pressure within specifications.	Adjust relief valve.
5. Hydraulic pump.	Flow output within specifications	Perform Pump Flow Test.
6. SCV, if equipped.	In neutral position.	Move control lever into neutral position. Inspect linkage. Repair or replace parts as necessary.

OUO1085,0000258 -19-25JUL02-1/1

## Excessive Pump Pressure

### CONDITIONS:

- Machine parked on level surface.
- Hydraulic tests and adjustments in this section.

Test Location	Normal	If Not Normal
1. Relief valve.	Pressure within specifications.	Adjust relief valve.
2. Outlet line.	Free of kinks and restrictions.	Replace line.
3. Rockshaft feedback linkage.	Proper hitch free-play.	Adjust linkage.
4. SCV, if equipped.	Free to return to neutral position.	Operate SCV levers. Check for pressure change. Repair or replace SCV valve.
5. Hydraulic diverter plug port.	No plug installed. No optional equipment installed or used.	Remove diverter plug in end plate. Remove any auxiliary hydraulic equipment.

OUO1085,0000259 -19-11OCT00-1/1

## Slow Hydraulic Pump Response

### CONDITIONS:

- Machine parked on level surface.
- Key switch in OFF position.
- Hydraulic tests and adjustments in this section.

Test Location	Normal	If Not Normal
1. Filter canister.	Free of restrictions.	Replace filter.
2. Mesh filter.	Free of debris.	Clean filter.
3. Hydraulic dipstick.	Oil of the proper type and viscosity.	Drain and refill with correct oil.
4. Pump suction line.	Oil at approximately 43°C (110°F).	Heat hydraulic oil per recommended procedure.
	Free of kinks and restrictions.	Repair or replace line.
5. SCV, if equipped.	Free to return to neutral position. Not leaking internally.	Operate SCV levers. Check for pressure change. Repair or replace SCV valve.
6. Main relief valve.	Pressure within specifications. Not leaking.	Test relief valve.
7. Hydraulic pump.	Flow output within specifications.	Perform Pump Flow Test.
8. Surge relief valve.	Not leaking.	Perform Rockshaft Leakage Test. Replace valve.

OUO1085,000025A -19-11OCT00-1/1

## Excessive Pump Noise During Operation

### CONDITIONS:

- Machine parked on level surface.
- Key switch in OFF position.
- Hydraulic tests and adjustments in this section.

Test Location	Normal	If Not Normal
1. Hydraulic dipstick.	Oil level up to marks.	Add oil as needed.
	Oil of the proper type.	Drain and refill with correct oil.
2. Pump suction line.	Secure and free of air leaks.	Tighten suction line clamps. Repair or replace line as needed.
3. Main relief valve.	Pressure within specifications.	Adjust. Replace if necessary.
4. SCV, if equipped.	Free to return to neutral position.	Operate SCV levers. Repair or replace valve.
5. Rockshaft valve.	Neutralizing.	Perform rockshaft leak test.
6. Hydraulic diverter plug port.	No plug installed.	Remove diverter plug in end plate.

OUO1085,000025B -19-11OCT00-1/1

## Rockshaft Does Not Lift or Lifts Slowly

### CONDITIONS:

- Machine parked on level surface.
- Hydraulic tests and adjustments in this section.

Test Location	Normal	If Not Normal
1. Rockshaft lift arms.	Rockshaft lift cycle within specifications.	Perform rockshaft lift cycle test. (See Rockshaft Lift Cycle Test in Group 18.)
2. Hydraulic dipstick.	Oil of proper type and viscosity.	Drain and refill hydraulic system.
3. Filter canister.	Free of restrictions.	Replace filter.
4. Mesh filter.	Free of debris.	Clean filter.
5. Hydraulic pump.	Flow within specifications.	Perform Pump Flow Test.
6. Relief valve.	System pressure within specifications.	Adjust relief valve.
7. Rockshaft.	Leakage within specifications.	Perform rockshaft leak test.
8. SCV, if equipped.	Free to return to neutral position.	Operate SCV levers. Repair or replace valve.

OUO1085,000025C -19-11OCT00-1/1

## Rockshaft Does Not Lower or Lowers Slowly

### CONDITIONS:

- Machine parked on level surface.
- Key switch in OFF position.
- Hydraulic tests and adjustments in this section.

Test Location	Normal	If Not Normal
1. Rate-of-drop valve.	Backed-out (open).	Open valve.
	Valve and passages clean.	Clean, repair, or replace valve as needed.
2. Rockshaft linkage.	Linkage connected and not binding, bent, or worn.	Repair or replace as needed.
3. Draft control linkage.	Linkage connected and not binding, bent, or worn.	Repair, replace, or adjust as needed.

OUO1085,000025D -19-11OCT00-1/1

## Neutral Position Unstable, Rockshaft Drops after Engine Shut Down

### CONDITIONS:

- Machine parked on level surface.
- Hydraulic tests and adjustments in this section.

Test Location	Normal	If Not Normal
1. Rockshaft.	Leakage within specifications.	Replace rockshaft piston O-ring. Check cylinder for scoring and other damage, replace if necessary.
	Attachment installed correctly.	Install as instructed by Operator's Manual or Installation Instruction.
2. Rate-of-drop valve.	Closes completely without leaks.	Repair or replace valve as needed.
3. Surge relief valve.	Not leaking.	Perform Rockshaft Leakage Test. Replace valve.

OUO1085,000025E -19-11OCT00-1/1



## SCV Joystick Does Not Return to Neutral Position—Single (Third) SCV

### CONDITIONS:

- Machine parked on level surface.
- Key switch in OFF position.
- Hydraulic tests and adjustments in this section.

Test Location	Normal	If Not Normal
1. SCV joystick.	Joystick not binding, bent, or worn.	Repair or replace as needed.
2. SCV.	Spool encounters spring resistance whether pushed or pulled.	Replace valve assembly.
	Spool slides back and forth through housing without binding.	Replace valve assembly.

OUO1085,000025F –19–11OCT00–1/1

## SCV Joystick Does Not Return to Neutral Position—Dual SCV

### CONDITIONS:

- Machine parked on level surface.
- Key switch in OFF position.
- Hydraulic tests and adjustments in this section.

Test Location	Normal	If Not Normal
1. Joystick.	Free from binding.	Repair or replace as needed.
2. Cables.	Free and properly lubricated.	Lubricate or replace cables as needed.
3. Dual SCV.	Spool releases when moved opposite of detent.	Replace SCV assembly.

**NOTE:** The dual SCVs employ a detent that engages when the joystick nears the end of its travel in two directions. This is normal. The above diagnostic routines apply when the joystick binds in the non-detent position.

OUO1085,0000260 –19–11OCT00–1/1

## SCV Joystick Does Not Remain in Detent Position—Dual SCV

### CONDITIONS:

- Machine parked on level surface.
- Key switch in OFF position.
- Hydraulic tests and adjustments in this section.

Test Location	Normal	If Not Normal
1. Joystick.	Full range of travel without binding.	Repair or replace as needed.
2. Cables.	Properly connected and free from binding.	Repair or replace as needed.
Dual SCVs.	Detent locks in when valve nears end of travel in forward direction.	Replace SCV assembly.

OUO1085,0000261 –19–11OCT00–1/1

## Remote Cylinder Does Not Extend or Retract

### CONDITIONS:

- Machine parked on level surface.
- Key switch in OFF position.
- Hydraulic tests and adjustments in this section.

Test Location	Normal	If Not Normal
1. Remote cylinder.	Cylinder piston O-ring in good condition and stop valve free.	Won't extend. Replace piston O-ring.
2. Double-acting sleeve couplers.	Cylinder hose ends fully seated in couplers.	Seat hose ends in couplers.
	Coupler tips not damaged or worn.	Replace couplers.

OUO1085,0000262 –19–11OCT00–1/1

270  
15  
11

## Remote Cylinder Settles Under Load

### CONDITIONS:

- Machine parked on level surface.
- Key switch in OFF position.
- Hydraulic tests and adjustments in this section.

Test Location	Normal	If Not Normal
1. Remote cylinder.	Cylinder piston O-ring in good condition.	Replace O-ring or cylinder if scored.
2. Double-acting sleeve couplers.	Couplers free from leakage.	Repair or replace coupler. If equipped with dual SCV, connect to additional couplers.
	SCV not leaking.	Excessive leakage at SCV. Perform Hydraulic System Tests—With SCV.

OUO1085,0000263 -19-11OCT00-1/1

## Remote Cylinder Operates Too Fast or Too Slow


### CONDITIONS:

- Machine parked on level surface.
- Key switch in OFF position.
- Hydraulic tests and adjustments in this section.

Test Location	Normal	If Not Normal
1. Remote cylinder.	Stop valve free.	Repair or replace stop valve.
2. SCV joystick cables.	Free and movable throughout range of travel.	Repair, replace, or lubricate cables and linkage.

OUO1085,0000264 -19-11OCT00-1/1

Hydraulic System Tests—Without SCV



HYDRAULIC SYSTEM TESTS – WITHOUT SCV

LV149AE

LV149AE -19-10FEB92

270  
16  
1

**NOTE:** For hydraulic system tests on tractors with SCV, see Group 17.

**CONDITIONS:**

- Hydraulic oil is correct type, clean and at proper level.

- No external hydraulic oil leaks.
- If oil filter was not replaced as part of preliminary inspection, replace it to ensure proper function.
- Rockshaft feedback linkage is properly adjusted.
- Hydraulic oil at approximately 43°C (110°F).

Test Location	Normal	If Not Normal
1. Check pump flow (at pump). Run engine at 2400 rpm and turn flowmeter restriction to 10345 kPa (1500 psi) (103 bar).	5210 and 5310 series tractors: 42 L/min (11 gpm) minimum.	Inspect mesh filter suction line pump.
	5410 and 5510 series tractors: 60 L/min (16 gpm) minimum.	
2. Install pipe plug below power beyond port and check main relief pressure at valve end plate with engine at slow idle.	18995—19685 kPa (190—197 bar) (2755—2855 psi)	High or low reading: adjust valve.
3. Leak test rockshaft with pipe plug installed in rockshaft passage.	Rockshaft holds steady under implement load.	Inspect rockshaft cylinder, seals, and piston, and surge relief valve.
4. Leak test rockshaft without pipe plug installed in rockshaft passage.	Rockshaft holds steady under implement load.	Replace rockshaft valve or seals.

OUO1085,0000265 -19-25JUL02-2/2


## Pump Flow Test—Without SCV

### REASON:

To determine if hydraulic pump can provide adequate flow under pressure.

### EQUIPMENT:

- JT05469 Flowmeter
- JT03468 Pump Adapter 3/4 F NPT Sw x M27 x 2.0 MORB 45° elbow (B)
- (Flowmeter with 37° flare hose) JT03336 Adapter 3/4 M NPT x 3/4 M 37° flare (A).
- (Flowmeter with 3/4-16 M ORB hose) JT03123 Adapter 3/4 M NPT x 1/2 F NPT and JT03041 1/2 M NPT x 3/4-16 F ORB



Flowmeter Connection

A—JT03336 Adapter  
B—JT03468 Adapter Elbow

### CONNECTIONS:

1. Remove pump outlet line.
2. Remove pump outlet fitting and install adapter elbow (B).
3. Connect flowmeter inlet hose adapter (A) to adapter elbow (B).
4. Insert flowmeter return hose into hydraulic oil fill hole.

### PROCEDURE:

1. Fully open flowmeter control valve.
2. Start tractor and run at 2000 rpm.
3. Slowly close flowmeter control valve until 10345 kPa (103.5 bar) (1500 psi) shows on gauge.
4. Observe flow, then release pressure.

### Specification

Pump Flow Test, Without SCV—

Flow Rate .....	33—42 Lpm (8.8—11 gpm) 5210 and 5310 series tractors
	47.6—60 Lpm (12.6—16 gpm) 5410 and 5510 series tractors

RESULTS: If flow is less than minimum

Continued on next page

OUC1085,0000266 -19-11OCT00-1/2

- The mesh filter may be restricted.
- The suction line may be restricted.
- The suction line may be leaking air. Tighten clamps on both ends of suction line.
- The pump may be worn or damaged, requiring repair or replacement.

OUO1085,0000266 -19-11OCT00-2/2

**Main Relief Valve Test—Without SCV****REASON:**

To determine if setting of relief valve maintains correct pressure.

**EQUIPMENT:**

- JT05473 Gauge 35000 kPa (5000 psi) (350 bar) (D).
- JT03364 Hose with coupler (G).
- JT03469A Adapter M22 M ORB x 7/16-20 M 37° Flare (E).
- JT05483 90° Elbow Adapter 7/16-20 M 37° Flare x 7/16-20 F 37° Flare Sw (F).
- 3/8 in. Pipe Plug.

**CONNECTIONS:**

1. Remove power-beyond plug (B) from end plate (A) and install 3/8 in. pipe plug in threads (C) located in passage.
2. Install adapter (E) into end plate.
3. Assemble gauge (D), hose (G), and adapter (F).
4. Connect test equipment to adapter (E).

**PROCEDURE:**

1. Start engine and let it idle.
2. Read pressure on gauge.
3. Shut engine off immediately after reading pressure.



**Specification**

Main Relief Valve—Pressure ..... 18995—19685 kPa (190—197 bar) (2755—2855 psi)

**RESULTS:**

- Pressure high or low—adjust relief valve. (See Main Relief Valve Adjustment in Group 19.)

**IMPORTANT:** Remove pipe plug after test is completed.



- A—End Plate  
 B—Power-Beyond Plug  
 C—Pipe Threads  
 D—JT05473 Gauge  
 E—JT03469A Adapter  
 F—JT05483 Adapter  
 G—JT03364 Hose with Coupler

LV260AE -UN-18FEB92


LV151 -UN-02AUG94

270  
16  
5





Hydraulic System Tests—With SCV



HYDRAULIC SYSTEM TESTS – WITH SCV

LV152AE

270  
17  
1

LV152AE –19–10FEB92

Continued on next page

OUO1085,0000268 –19–25JUL02–1/2

**NOTE:** For hydraulic system tests on tractors without SCV, see Group 16.

**CONDITIONS:**

- Hydraulic oil is correct type, clean and at the proper level.

- No external hydraulic oil leaks.
- If oil filter wasn't replaced during preliminary inspection, replace it to ensure proper function.
- Rockshaft feedback linkage is properly adjusted. Refer to Group 19 for procedure.
- Hydraulic oil at approximately 43°C (110°F).

Test Location	Normal	If Not Normal
1. Check pump flow (at rear couplers). Run engine at 2400 rpm and turn flowmeter restriction to 10345 kPa (103.5 bar) (1500 psi).	5210 and 5310 series tractors: 38 L/min (10 gpm) minimum.	Perform test 2.
	5410 and 5510 series tractors: 55 L/min (14 gpm) minimum.	
2. Check main relief pressure (at rear outlets) with engine at slow idle.	18995—19685 kPa (190—197 bar) (2755—2855 psi).	Reading low (test 1 and 2). Check main relief for leakage.
		Reading low (test 1 only). Inspect mesh filter. Inspect suction line. Inspect pump.
3. Test SCV leakage (at each rear outlet).	Pressure stays above 3448 kPa (34.5 bar) (500 psi) for at least 5 seconds.	Excessive drop at outlet 1 or 2: Repair boom spool.
		Excessive drop at outlet 3 or 4: Repair bucket spool.
	Excessive drop at outlet 5 or 6: Repair #3 SCV spool.	
4. Leak test rockshaft with pipe plug installed in rockshaft passage.	Rockshaft holds steady under implement load.	Inspect rockshaft in cylinder, seals, piston, or surge relief valve.
5. Leak test rockshaft without pipe plug installed in rockshaft passage.	Rockshaft holds steady under implement load.	Replace rockshaft valve or O-ring seals.

OUO1085,0000268 -19-25JUL02-2/2

## Pump Flow Test—With SCV

### REASON:

To determine if hydraulic pump can provide adequate flow under pressure.

### EQUIPMENT:

- JT05469 Flowmeter (A).
- AR94522 Coupler (internal half) (B).
- JT03082 Adapter 3/4-16 M ORB x 3/4 F NPT Sw (flowmeter that uses 37° flare hose also requires JT03049 Adapter 3/4-16 M ORB x 3/4-16 M 37°) (C).

### CONNECTIONS:

1. Assemble test equipment.
2. Connect flowmeter inlet hose to one of rear couplers.
3. Insert flowmeter return hose into transmission/hydraulic dipstick fill hole.

### PROCEDURE:

1. Fully open flowmeter control valve.
2. Start tractor and run at 2000 rpm.
3. Move joystick or single (third) SCV lever as necessary to pressurize test outlet. Slowly close flowmeter control valve until 10345 kPa (103.5 bar) (1500 psi) shows on gauge.
4. Observe flow, then release pressure.


#### 5210 and 5310 Series Tractors:—Specification

Control Valve—Maximum Flow	
Rate .....	42 L/min (11 gpm)
Control Valve—Minimum Flow	
Rate .....	40.0 L/min (8.8 gpm)

#### 5410 and 5510 Series Tractors:—Specification

Control Valve—Maximum Flow	
Rate .....	60 L/min (16 gpm)
Control Valve—Minimum Flow	
Rate .....	47.6 L/min (12.6 gpm)

### RESULTS:



A—JT05469 Flowmeter  
B—AR94522 Coupler  
C—JT03082 Adapter 3/4-16 M ORB x 3/4 NPT Sw

LV153 -UN-18FEB92

270  
17  
3

If flow is below minimum:

- Mesh filter may be restricted.
- Filter canister may be restricted.
- Suction line may be restricted.
- Suction line may be leaking air.  
Tighten clamps on both ends of suction line.
- Relief valve may be leaking.
- Control lever and cables not allowing full open valve.
- Coupler damaged. Try other outlets.
- SCV valve spool scored or leaking.
- Pump may be worn or damaged, requiring repair or replacement.

OUO1085,0000269 -19-11OCT00-2/2

## Main Relief Valve Test—With SCV

### REASON:

To determine if factory setting of relief valve maintains correct pressure.

### EQUIPMENT:

- JT05473 Gauge 35000 kPa (5000 psi) (350 bar) (A).
- JT03364 Hose with Coupler (B).
- AR94522 Coupler (internal half) (C).
- JT05494 Adapter 3/4-16 M ORB x 7/16-20 M 37° (D).

### CONNECTIONS:

1. Assemble gauge, hose and adapter.
2. Connect test equipment into any rear outlet.

### PROCEDURE:

1. Run engine at slow idle.
2. Move SCV joystick or lever to pressurize test outlet.  
Hold until you hear system go into relief.
3. Check pressure reading on gauge.


#### Specification

Main Relief Valve Test Outlet—

Pressure ..... 18995—19685 kPa (190—197  
bar) (2755—2855 psi)

### RESULTS:

Pressure high or low—adjust relief valve. (See Main Relief Valve Adjustment in Group 19.)



A—JT05473 Gauge  
B—JT03364 Hose with Coupler  
C—AR94522 Coupler  
D—JT05494 Adapter

LV154 -UN-18FEB92

270  
17  
5

OUO1085,000026A -19-11OCT00-1/1

## SCV Leakage Test

### REASON:

To determine if excessive leakage exists past spool valves.

### EQUIPMENT:

- JT05473 Gauge 35000 kPa (5000 psi) (350 bar) (A).
- JT03364 Hose with Coupler (B).
- AR94522 Coupler (internal half) (C).
- JT05494 Adapter 3/4-16 M ORB x 7/16-20 M 37° (D).

### CONNECTIONS:

1. Assemble gauge, hose, and adapter.
2. Connect test equipment into any rear outlet.

### PROCEDURE:


1. Run engine at fast idle.
2. Move SCV joystick or lever to pressurize test outlet.  
Hold until system goes into relief.
3. Release joystick or lever and note the time it takes for pressure to drop below 3450 kPa (34.5 bar) (500 psi).
4. Repeat for remaining valves and outlets.

### SPECIFICATIONS:

Pressure should stay above 3450 kPa (34.5 bar) (500 psi) for at least 5 seconds.

### RESULTS:


- Excessive drop at outlet 1 or 2:  
Service boom spool.
- Excessive drop at outlet 3 or 4:  
Service bucket spool.
- Excessive drop at outlet 5 or 6:  
Service single (third) SCV spool.



A—JT05473 Gauge  
B—JT03364 Hose with Coupler  
C—AR94522 Coupler  
D—JT05494 Adapter

LV154 -UN-18FEB92

## Rockshaft Leakage Test



A—Rate-of-Drop Valve

B—9/16-18 M ORB Access Plug

### REASON:

To determine if leakage exists in rockshaft cylinder, housing, or valve.

### EQUIPMENT:

- 1/8 in. M NPT Plug

### PROCEDURE:

1. With implement connected to rockshaft, raise to top of its travel.
2. Place blocks under implement to keep it raised.
3. Lower rockshaft so implement weight settles fully on blocks or stands.

4. Move rockshaft position lever all the way forward. Open rate-of-drop valve (A).
5. Remove right rear wheel, if necessary.
6. Remove 9/16-18 M ORB access plug (B).
7. Install 1/8 in. M NPT plug in passage behind plug (B) removed previously. Reinstall access plug.
8. Using jack or other lifting device, lift implement weight off blocks and allow implement to lower.
9. Rockshaft should drop slightly, then hold.

Continued on next page

OUC1085,000026C -19-11OCT00-1/2



**IMPORTANT: Jack up and support implement before removing plugs.**


10. Remove access and pipe plugs, then reinstall access plug.
11. Install wheel.
12. Repeat steps (1—4) and (8—9).

**RESULTS:**

- If rockshaft drops with plug in passage, there is leakage past rockshaft piston, seals, or surge relief valve. Remove rockshaft housing and inspect. Replace parts as necessary.
- If rockshaft drops without plug installed in passage, replace rockshaft valve and seals.

OUO1085,000026C -19-11OCT00-2/2

## Rockshaft Lift Cycle Test



M48462 -UN-12FEB90

### REASON:

To determine if hydraulic flow can provide enough force to lift the 3-point hitch arms as designed.

### PROCEDURE:

*NOTE: If equipped with SCVs, make sure all SCV spool valves are neutralized.*

1. Attach approximately 227 kg (500 lb) rear weight or implement.

*NOTE: BW13568 Ballast Box could be used.*

2. Open rate-of-drop valve completely.
3. Lower 3-point hitch completely.
4. Run engine at fast idle.
5. Observe the time it takes to completely raise the 3-point hitch arms after you pull the position lever all the way back.

### SPECIFICATIONS:

Item	Measurement	Specification
Full Lower to Full Raise	Time	2.5 to 3 seconds

Continued on next page

OUO1085,000026D -19-11OCT00-1/2

**NOTE:** *The speed at which the hitch arms rise during the last few inches of travel at the highest position is slower than the rate of movement from the bottom. The difference in raise rates is normal due to the action of the two flow regulator valves within the rockshaft control valve.*

**RESULTS:**

If the raise time is excessive, leakage exists.

Perform the rockshaft leakage test, pump flow test, and main relief valve test. If tractor passes these tests, the problem is the rockshaft valve, or a leaking seal or O-ring.

OUO1085,000026D -19-11OCT00-2/2


### Rockshaft Control Lever Friction Adjustment

#### REASON:

To keep the rockshaft position and draft-sensing levers in their set positions.

#### PROCEDURE:

1. Loosen jam nuts (A).
2. Turn adjusting cap screws (B) clockwise to increase friction, counterclockwise to decrease friction. Turn cap screws equal number of times.
3. Retighten jam nuts (A) when adjustment is complete.




LV156 -UN-18FEB92

A—Jam Nut  
B—Cap Screw

OUO1085,000026E -19-11OCT00-1/1

# Rockshaft Position-Sensing Feedback Linkage Adjustment



LV1882 -UN-18NOV96

LV1882

A—Jam Nut

B—Draft-Sensing Rod

C—Pin

D—Vertical Line

## REASON:

To ensure that the lift arms have the proper range of motion.


## PROCEDURE:

1. Tractors without cab, remove left-side fender.
2. Tractors with cab, remove fuel tank. (See Remove, Inspect and Install Fuel Tank—With Cab in Section 30, Group 05.)

3. Remove all weight from center link.
4. Loosen jam nut (A).
5. Turn draft-sensing rod (B) so that pin (C) is approximately 10° clockwise from vertical line (D).
6. Tighten jam nut (A).

Continued on next page

OOU1085,000026F -19-11OCT00-1/4



A—Nut

B—Arm

C—Pin

**IMPORTANT:** Loosen both nuts (A) to end of thread travel on rod to prevent damage to linkage.

*NOTE: After clearance specification of 3 mm has been made, this adjustment will not be done again.*

7. Loosen both nuts (A) to end of thread travel on rod.
8. Manually raise rockshaft arms up until the upper limit is reached.


9. Turn adjustment nuts (A) so there is 3 mm clearance between arm (B) and pin (C). Lengthen or shorten rod to specification as shown in photo.

Continued on next page

OUO1085,000026F -19-11OCT00-2/4

LV1883 -JUN-20NOV96

270  
19  
3



A—Vertical Distance  
B—Lift Arm Pin

C—Lift Arm

D—Rockshaft Housing

E—Drawbar Support Side Plate

10. Open rate-of-drop valve by turning knob fully counterclockwise.
11. Attach minimum weight of 20 to 35 kg (44 to 65 lb) to each draft link.
12. Push the position control lever and draft control levers fully forward.
13. Start and run engine at 1500 rpm.
14. Move the outer lever (position control lever) fully rearward and then fully forward five times to purge air from the rockshaft piston and oil lines.
15. Move position control lever fully rearward and allow lift arms (C) to rise to top. Shut off engine.

16. Measure vertical distance (A) from bottom side of the upper flange of drawbar support side plate (E) to center of lift arm pin (B). If measurement is within specifications, no adjustment is necessary. If distance is more or less than specification, continue with procedure on next page.
17. Tractors without cab, install left-side fender.


#### Specification

Vertical (A)—Distance .....  $416 \pm 4$  mm ( $16.400 \pm 0.157$  in.)

Continued on next page

OUC1085,000026F -19-11OCT00-3/4

18. Tractors without cab, remove right-side fender.
19. Tractors with cab, remove right-side control console and panel. (See Remove and Install Right-Side Control Console and Panel—Tractors With Cab in Section 90, Group 15.)
20. If distance measured earlier is greater than the specification 420 mm (16.535 in.), loosen two screws (A) and move outer lever (B) (position-sensing lever) rearward. This will move screws (A) clockwise in the adjustment slots (C).
21. If distance measured earlier is less than the specification 412 mm (16.220 in.), loosen two screws (A) and move outer lever (B) (position-sensing lever) forward. This will move screws (A) counterclockwise in the adjustment slots (C).
22. Tighten screws (A) and repeat step 15. Readjust if necessary.
23. Tractors without cab, install right-side fender.
24. Tractors with cab, install fuel tank and right-side control console.



A—Screw (2 used)  
B—Outer Lever  
C—Adjustment Slot

LV2445 -UN-15DEC97

270  
19  
5

OUO1085,000026F -19-11OCT00-4/4



## Rockshaft Draft-Sensing Feedback Linkage Adjustment

### REASON:


To ensure rockshaft draft system allows proper amount of implement control.

### PROCEDURE:


1. Remove right-side fender.
2. Move outer control lever fully forward. Make sure there is no load on the rockshaft centerlink. Slowly move the inner lever rearward until the rockshaft arms begin to rise. At this point, check the position of the rear edge of the inner pivot plate (A). It should align parallel (C) with flat surface on rear of friction plate (B). If surfaces of lever and plate align as shown, no adjustment is necessary. If adjustment is necessary, continue with procedure.
3. Loosen rod end lock nut (E) on the draft-sensing rod (D). If lift arms move before plates align, shorten rod using wrenching flats on rod (D). If lift arms move after plates align, lengthen rod.
4. Repeat procedure until adjustment is correct. Make sure lock nut (E) is tightened securely.

**NOTE:** With rockshaft completely raised and draft control lever fully rearward, system should not go into relief.

5. Install right-side fender.



LV1885 -UN-18NOV96



LV1115 -UN-01NOV94

A—Inner Level Pivot Plate  
B—Friction Plate  
C—Parallel Alignment  
D—Draft-Sensing Rod  
E—Lock Nut

OUO1085,0000270 -19-11OCT00-1/1

## Main Relief Valve Adjustment

### REASON:


Relief pressure high or low.

### PROCEDURE:

1. Loosen lock nut (A) and turn adjustment screw (B) clockwise to increase pressure, counterclockwise to decrease pressure.
2. Tighten lock nut.

### RESULTS:

- Main relief pressure should change. If not, inspect the valve for a damaged spring or leakage past the valve seal.



LV159 -UN-18FEB92

A—Lock Nut  
B—Adjustment Screw

OUO1085,0000271 -19-11OCT00-1/1

*Adjustments*

270  
19  
8

## Hydraulic Circuit Symbols

### LINES

1		WORKING (MAIN) LINES
2		PILOT CONTROL LINES
3		DRAIN LINE
4		HYDRAULIC } FLOW PNEUMATIC } DIRECTION
5		CROSSING LINES
6		JOINING LINES
7		FLEXIBLE LINE

### PUMPS

8		FIXED DISPLACEMENT
9		VARIABLE DISPLACEMENT

### MOTORS

10		FIXED DISPLACEMENT
11		VARIABLE DISPLACEMENT

### RESERVOIR

12		VENTED RESERVOIR
13		PRESSURIZED RESERVOIR
14		RESERVOIR RETURN - ABOVE FLUID LEVEL
15		RESERVOIR RETURN - BELOW FLUID LEVEL

### VALVES

16		CHECK VALVE
17		MANUAL ON/OFF VALVE
19		PRESSURE RELIEF VALVE
20		PRESSURE REDUCTION VALVE
21		TWO POSITION, TWO CONNECTION VALVE
22		TWO POSITION, THREE CONNECTION VALVE
23		TWO POSITION, FOUR CONNECTION VALVE
24		THREE POSITION, FOUR CONNECTION VALVE
25		TWO POSITION, FOUR CONNECTION VALVE WITH TRANSMISSION
26		THREE POSITION, FOUR CONNECTION VALVE WITH INFINITE POSITIONING
27		ADJUSTABLE FLOW CONTROL VALVE (TEMPERATURE AND PRESSURE COMPENSATED)
18		FIXED } VARIABLE } ORIFICE

Continued on next page

LV,27020HA,A1A -19-03AUG94-1/2

## VALVE OPERATORS

<b>28</b>		SPRING
<b>29</b>		MANUAL
<b>30</b>		PUSH BUTTON
<b>31</b>		PUSH/PULL LEVER
<b>32</b>		PEDAL OR TREADLE
<b>33</b>		MECHANICAL
<b>34</b>		DETENTS
<b>35</b>		PRESSURE COMPENSATED
<b>36</b>		SOLENOID-SINGLE WINDING
<b>37</b>		REVERSING MOTOR
<b>38</b>		PILOT PRESSURE -REMOTE SUPPLY
<b>39</b>		PILOT PRESSURE -INTERNAL SUPPLY

## CYLINDERS


<b>40</b>		SINGLE ACTING
<b>41</b>		DOUBLE ACTING, SINGLE ROD
<b>42</b>		DOUBLE ACTING, DOUBLE ROD
<b>43</b>		DOUBLE ACTING, ADJ. CUSHION, EXTEND ONLY
<b>44</b>		DOUBLE ACTING, DIFFERENTIAL PISTON


## MISCELLANEOUS

<b>45</b>		COOLER
<b>46</b>		FILTER, STRAINER
<b>47</b>		HEATER
<b>48</b>		TEMPERATURE CONTROLLER
<b>49</b>		PRESSURE SWITCH
<b>50</b>		PRESSURE INDICATOR
<b>51</b>		TEMPERATURE INDICATOR
<b>52</b>		PRESSURE COMPENSATED
<b>53</b>		VARIABLE COMPONENT (SYMBOL THRU COMPONENT)
<b>54</b>		PLUG, TEST PORT, PRESSURE SUPPLY TEST
<b>55</b>		GAS CHARGED ACCUMULATOR
<b>56</b>		SPRING LOADED ACCUMULATOR
<b>57</b>		ELECTRIC MOTOR
<b>58</b>		SHAFT ROTATION (ARROW ON NEAR SIDE OF SHAFT)
<b>59</b>		COMPONENT OUTLINE

M81440AE -19-19NOV92








LV2215

HYDRAULIC SYSTEM SCHEMA



This page is intentionally left blank.



RAT  
VAL


R  
C  
H

EMATIC—WITHOUT SELECTIVE CONTROL VALVES

This page is intentionally left blank.

# Hydraulic Schematic—Without Selective Control Valves

I-24FEB98



OUC1085,0000272 -19-05JUL02-1/2

26APR04)

270-20-4

5210, 5310, 5410, and 5510 Tractors

Page 270-20-4 C

042604  
PN=1290


This page is intentionally left blank.

1—Engine	14—Brake Piston	27—Hydraulic Oil Cooler (Used on 4-Cylinder and Tractors with Cab)	38—Power Beyond Pressure Port
2—Hydraulic Pump	15—Inlet Check Valve	28—Load Check Valve	39—Mesh Filter
3—Steering Pump	16—Equalizing Valve	29—Low Flow Regulator Valve	40—Drainback Check Valve
4—Steering Cylinder	17—Outlet Check Valve	30—Rockshaft Spool Valve	41—Hydraulic Filter Canister
5—Inlet Port	18—Right Brake Assembly	31—Rate-of-Drop Valve	42—Filter Relief Valve
6—Inlet Check Valve	19—Left Brake Assembly	32—Pressure Test Port	43—Hydraulic Filter Housing
7—Steering System Relief Valve	20—Brake Valve	33—Inlet Housing	44—End Plate
8—Manual Steer Check Valve	21—Transmission Case	34—Main Relief Valve	45—High Flow Regulator Plate
9—Steering Valve	22—Lube Relief Valve	35—Diverter Plug Port	46—Rockshaft Valve Housing
10—Control Valve	23—Transmission Lube Feed Housing	36—Power Beyond Tank Port	47—Raise Valve
11—Mechanical Link	24—Rockshaft Cylinder	37—Power Beyond Return Port	48—Lower Valve
12—Metering Pump	25—Surge Relief Valve		
13—Return Port	26—Rockshaft Cylinder		

OUO1085,0000272 -19-05JUL02-2/2

Hydraulic Schematic—With Selective Control Valves

LV2216 - 4A-1-15 JUL 02



LV2216

HYDRAULIC SYSTEM SCHEMATIC—WITH SELECTIVE CONTROL VALVES

TMT1716 (26APR04)


270-20-6

5210, 5310, 5410, and 5510 Tractors  
serial  
PN-1252

See Page 270-20-6 A

See Page 270-20-6 B

See Page 270-20-6 C




LV2216

HYDRAULIC SYSTEM SCHEMATIC



This page is intentionally left blank.




ATIC—WITH SELECTIVE CONTROL VALVES

This page is intentionally left blank.

# Hydraulic Schematic—With Selective Control Valves

—UN—15JUL02




OUO1085,0000273 —19—05JUL02—1/2

This page is intentionally left blank.

1—Engine	16—Equalizing Valve	28—Load Check Valve	42—Diverter Plug Port
2—Hydraulic Pump	17—Outlet Check Valve	29—Low Flow Regulator Valve	43—Power Beyond Tank Port
3—Steering Pump	18—Right Brake Assembly	30—Rockshaft Spool Valve	44—Power Beyond Return Port
4—Steering Cylinder	19—Left Brake Assembly	31—Rate-of-Drop Valve	45—Power Beyond Pressure Port
5—Inlet Port	20—Brake Valve	32—Pressure Test Port	46—Mesh Filter
6—Inlet Check Valve	21—Transmission Case	33—Inlet Housing	47—Drainback Check Valve
7—Steering System Relief Valve	22—Lube Relief Valve	34—Load Check Valve	48—Hydraulic Filter Canister
8—Manual Steer Check Valve	23—Transmission Lube Feed	35—Single (Third) SCV Housing	49—Filter Relief Valve
9—Steering Valve	24—Rockshaft Cylinder Housing	36—Single (Third) SCV Spool	50—Hydraulic Filter Housing
10—Control Valve	25—Surge Relief Valve	37—Bucket Spool	51—High Flow Regulator Valve
11—Mechanical Link	26—Rockshaft Cylinder	38—Rear Outlet Couplers	52—Raise Valve
12—Metering Pump	27—Hydraulic Oil Cooler (Used on 4-Cylinder and Tractors with Cab)	39—Dual SCV Housing	53—Rockshaft Valve Housing
13—Return Port		40—Boom Spool	54—Lower Valve
14—Brake Piston		41—Main Relief Valve	
15—Inlet Check Valve			

OUO1085.0000273 -19-05JUL02-2/2

# Power Beyond Hydraulic Schematic



LV2379

## POWER BEYOND HYDRAULIC SCHEMATIC

A—From Hydraulic Pump  
B—Pipe Plug (3/8 x 18)  
C—Hydraulic Supply Line

D—Flow Control Valve  
E—Hydraulic Pressure Valve  
F—Hydraulic Motor

G—Excess Flow Hydraulic Oil  
Return Line  
H—Hydraulic Oil  
Return-to-Tractor

I—Dual SCV Housing  
J—Single (Third) SCV Housing

OOU1085,0000274 -19-12OCT00-1/1

LV2379 -UN-15JUL02

# Section 290

## Operator Station

### Contents

#### Page

#### Group 05—Component Location

Air Conditioning System Components . . . . .290-05-2

#### Group 10—Theory of Operation

Refrigerant R134a . . . . .290-10-1  
Air Conditioning System Air Flow . . . . .290-10-2  
Air Conditioning System Cycle . . . . .290-10-3  
Compressor . . . . .290-10-4  
Condenser . . . . .290-10-5  
Receiver-Dryer . . . . .290-10-6  
Expansion Valve . . . . .290-10-7  
A/C Temperature Control Switch . . . . .290-10-8  
Evaporator . . . . .290-10-8  
Heater Temperature Control Knob . . . . .290-10-9  
High and Low Pressure Switches . . . . .290-10-9

#### Group 15—Diagnosis, Tests, and Adjustments


Essential Tools . . . . .290-15-1  
Service Equipment and Tools . . . . .290-15-1  
Other Material . . . . .290-15-3  
Specifications . . . . .290-15-4  
Diagnosis, Tests, and Adjustments . . . . .290-15-4  
Operator Station . . . . .290-15-4  
Adjust Heater Temperature Control Cable . . .290-15-22





290  
05  
1

## Air Conditioning System Components



## AIR CONDITIONING SYSTEM COMPONENTS

Slide LV1450

Continued on next page

OOU1085,0000276 -19-12OCT00-1/2

LV1450 -19-15DEC97

Component Location

- |                          |                           |                        |                       |
|--------------------------|---------------------------|------------------------|-----------------------|
| A—Expansion Valve        | D—Right Side Blower Motor | F—Condenser            | H—Low Pressure Switch |
| B—Evaporator/Heater Core | E—Compressor              | G—High Pressure Switch | I—Receiver-Dryer      |
| C—Left Side Blower Motor |                           |                        |                       |

OUC1085,0000276 -19-12OCT00-2/2

290  
05  
3

290  
05  
4

## Refrigerant R134a

**IMPORTANT:** To meet forthcoming Government standards relating to the use of refrigerants, the 5210, 5310, 5410, and 5510 tractors (with cab) use refrigerant R134a in their air conditioning system. Because it does not contain chlorine, R134a is not detrimental to the ozone in the atmosphere. However, it is illegal to discharge any refrigerant into the atmosphere. It must be recovered using the appropriate recovery stations.


The recovery, recycle, and charging stations for refrigerants R12 and R134a must NOT be interchanged. Refrigerant R134a is corrosive to copper as well as components used in R12 systems. Certain seals also are not compatible with refrigerant oil used in R134a systems. Therefore, NEVER use R134a in a system which previously contained R12.

Using the correct refrigerant oil is also important. R12 systems use a mineral oil and R134a systems require a polyalkleneglycol (PAG) oil (a synthetic oil). The two oils are not compatible and must NOT be interchanged.

OUO1085,0000277 -19-12OCT00-1/1

290  
10  
1

## Air Conditioning System Air Flow



## AIR CONDITIONING SYSTEM AIR FLOW

LVC1451

Slide LVC1451

A—Recirculating Air Intake Filter  
B—Outside Intake Air Filter

C—Circulator Blower Motor  
D—Evaporator Core  
E—Unfiltered Recirculated Air


F—Filtered Recirculated Air  
G—Conditioned Air

H—Unfiltered Outside Air  
I—Filtered Outside Air

LVC1451 -19-21MAY96

OUC1085,0000278 -19-12OCT00-1/1

## Air Conditioning System Cycle



Slide RWC20926

A—Evaporator Core  
B—Compressor  
C—Condenser

D—Circulation Blower Motors  
E—Expansion Valve  
F—High Pressure Liquid

G—High Pressure Gas  
H—Low Pressure Liquid

I—Low Pressure Gas  
J—Air Flow

The compressor (B) draws low pressure refrigerant gas (I) from the evaporator (A) and compresses it to a high pressure gas (G). This causes the temperature of the refrigerant to rise higher than that of the outside air. It goes to the condenser (C) as a high pressure gas.

As the high pressure gas passes through the condenser, heat is removed and transferred to the

outside air being drawn through the condenser core by the engine fan. This cools the gas and condenses it into a liquid, still under high pressure. It goes to the receiver-dryer as a high-pressure liquid (F).

The high pressure liquid then passes through the receiver-dryer where a special filter removes contaminants (moisture, acids, solids, etc.). The receiver-dryer also acts as a reservoir for refrigerant.

Continued on next page

OUO1085,000027A -19-12OCT00-1/2



The actual cooling and drying of cab air takes place at the evaporator (A). Flow of the high pressure liquid refrigerant through the evaporator is controlled by the expansion valve (E). The expansion valve causes the temperature and pressure of the refrigerant flowing into the evaporator to drop. The expansion valve is a diaphragm-type valve that uses a variable orifice to control the flow of low pressure liquid refrigerant (H) into the evaporator to maintain a constant pressure and temperature.

The circulation blower motors (D) pull a mixture of warm cab and outside air through the evaporator

where it is cooled by the refrigerant. The heat absorbed by the evaporator causes the refrigerant to boil and vaporize.

Moisture, from the warm air, is condensed as it contacts the cool evaporator core during the cooling process and is drained away through tubes connected to a drip pan under the evaporator. With the cab air cooled and dehumidified the air conditioning cycle is complete.

OUO1085,000027A -19-12OCT00-2/2

## Compressor


The compressor (A) is located at the front of the engine above the valve cover.

The compressor takes low pressure gas from the outlet of the evaporator and compresses it into a high pressure gas which is sent to the condenser. The temperature of the gas is increased during the compression phase.

It has a multiple groove pulley which is driven by a multiple groove drive belt. The pulley is attached to one side of an electromagnetic clutch. The compressor has five axial pistons that are driven by a swashplate, which is attached to the other side of the electromagnetic clutch. Applying battery voltage to the electromagnetic clutch engages the compressor and removing battery voltage disengages it. The air conditioning circuit automatically controls the compressor engagement/disengagement when the air conditioning system is in operation.

When the key switch is ON and the blower motor switch is in any ON position, the compressor may be operated manually also by using the A/C temperature control switch located on the overhead control panel.

The compressor housing also serves as a reservoir for refrigerant oil.



A—Compressor


OUO1085,000027B -19-17JUL02-1/1

## Condenser

The condenser (A) is located in front of the tractor radiator. It is a heat exchanging unit that receives high pressure and high temperature gas from the compressor and removes heat and condenses it to a high pressure liquid by the time it leaves the condenser. The condenser and transmission oil cooler are a single component and must be replaced as an assembly.

The heat is removed from the high pressure gas by the air drawn through the condenser by the engine fan. The condenser inlet is connected to the compressor outlet and its outlet is connected to the receiver-dryer inlet.

A—Condenser



OUC1085,000027C -19-17JUL02-1/1

## Receiver-Dryer


**IMPORTANT:** Receiver-dryers are NOT interchangeable between R12 and R134a refrigerant systems. The desiccant in each is different (SH5 for R12 and SH7 for R134a) and they are not compatible. When SH5 comes in contact with R134a, it breaks down into a powder that causes excessive wear in the compressor.

**NOTE:** The receiver-dryer is not repairable. If a malfunction is suspected, install a new receiver-dryer.

*If the air conditioning system is discharged for servicing and the receiver-dryer is two years old or older, it should be replaced. If it is less than two years old it should only be replaced if the system is contaminated.*

The receiver-dryer (A) is located under the right-side cab floor. Its inlet is connected to the condenser and its outlet is connected to the expansion valve. It performs two functions. One is to store high pressure liquid it receives from the condenser until the evaporator needs it. It also absorbs moisture and acid that would have a detrimental effect on the system's operation for a long period of time.

A sight glass in the line near the inlet to the receiver-dryer allows the operator or technician to observe the level of charge in the system, during normal operation or during test and service work.



A—Receiver-Dryer

LV2437 -UN-15DEC97


OUO1085,000027D -19-17JUL02-1/1

## Expansion Valve

The expansion valve (A) is located in the evaporator/heater core housing in the cab roof. Its inlet is connected to the receiver-dryer and its outlet is connected to the evaporator. It has two additional connections, one from the evaporator outlet and another to the compressor. This circuit is used to sense the outlet temperature and pressure of the evaporator to help modulate the opening of the expansion valve.

The expansion valve is a diaphragm valve with a stainless steel thermal head. The thermal head is filled with gas which expands and contracts as the temperature of the HVAC compartment rises and falls. The expansion valve uses a variable orifice to control the flow of refrigerant through the evaporator to maintain a constant, comfortable temperature in the cab. If the expansion valve is open too far, liquid can reach, and possibly damage, the compressor. If the valve is not open far enough, lack of cooling will be the result.

A ball and seat combination provides the variable orifice to control the flow of refrigerant into the evaporator. The position of the ball relative to its seat, determines the amount of refrigerant that flows into the evaporator. The position of the ball is controlled by an actuating pin. The movement of the actuating pin is controlled by the diaphragm. Gas in the thermal head and the temperature and pressure at the outlet of the evaporator act on the diaphragm to move the actuating pin.



A—Expansion Valve


RW21498 -UN-08JUL92

290  
10  
7

OUO1085,000027E -19-17JUL02-1/1

## A/C Temperature Control Switch

The thermostatic temperature control switch (A) is a rotary-type switch with a gas-filled temperature sensing tube inserted into the evaporator core. The switch end of the sensing tube uses a diaphragm to control two external contacts wired to the compressor clutch. When the cab air needs to be cooled (to a preselected temperature setting inside the cab), the gas in the sensing tube expands the diaphragm, completing the circuit in the switch and engaging the compressor clutch. The compressor continues to operate until the preselected cab temperature is reached.



A—Thermostatic Temperature Control Switch

OUO1085,000027F -19-17JUL02-1/1

## Evaporator


The evaporator (A) is located in the evaporator/heater core housing, in the cab roof. This is where the heat transfer, from cab air to the refrigerant, takes place.

The refrigerant is still a liquid (under low pressure) as it leaves the expansion valve. As it expands and becomes a gas in the evaporator, its temperature is reduced. This low temperature is transferred to the cooling fins. The air passing through the evaporator transfers its heat to the fins.

Also, because cool air can hold less moisture than warm air, moisture in the ambient air condenses when it comes into contact with the cold evaporator fins. The condensation is drained away by a drain hose.

The refrigerant flows from the evaporator outlet, through the expansion valve, and back to the compressor inlet.

The heater core is also part of the evaporator heat exchanger. The heater core uses engine coolant to heat the cab air as required. Coolant flow is regulated by the heater valve which is controlled by the operator control knob.



A—Evaporator


OUO1085,0000280 -19-17JUL02-1/1



## Heater Temperature Control Knob

The temperature control knob (A) is located on the overhead control panel. Its function is to turn the heater control valve on or off as necessary. It has a single cable that goes to the heater valve which is in the evaporator/heater core housing.

When the knob is fully counterclockwise, the heater valve is OFF. When it is fully clockwise, the heater valve is ON, or fully open. The control can be positioned anywhere within its range of travel to partially open the heater valve for blending heat with cold conditioned air from the evaporator to obtain a comfortable cab temperature.



A—Temperature Control Knob


OUO1085,0000281 -19-17JUL02-1/1

## High and Low Pressure Switches

The high and low pressure switches (B and C) are located behind the right-side crop guard on the line between the condenser and the receiver-dryer. The function of each is to protect the compressor by shutting it off if system pressure becomes too high or too low. If pressure exceeds 2480—2760 kPa (24.8—27.6 bar) (370—415 psi), or drops below 300—400 kPa (3—4 bar) (45—60 psi), the appropriate switch opens and shuts the compressor off.

**NOTE:** The high pressure switch (B) is toward the outside of the tractor, and the low pressure switch (C) is toward the inside.

B—High Pressure Switch  
C—Low Pressure Switch



OUO1085,0000282 -19-17JUL02-1/1

290  
10  
10

## Essential Tools


**NOTE:** Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company

OUO1080,0000282 -19-11JUL02-1/3

Recovery and Recycling Station . . . . . JT02050<sup>1</sup>

Servicing air conditioning system using R134a refrigerant.



<sup>1</sup>Used with JT02046 Charging Station, JT02047 Recovery, Recycling, and Charging Station can be substituted for JT02046 and JT02050.

OUO1080,0000282 -19-11JUL02-2/3

RW21613 -UN-17AUG92

Charging Station . . . . . JT02046<sup>1</sup>

Servicing air conditioning system using R134a refrigerant.



<sup>1</sup>Used with JT02050 Recovery and Recycling Station, JT02047 Recovery, Recycling, and Recharging Station can be substituted for JT02046 and JT02050.

OUO1080,0000282 -19-11JUL02-3/3

RW21595 -UN-17AUG92

290  
15  
1

## Service Equipment and Tools

**NOTE:** Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.

SERVICEGARD is a trademark of Deere & Company

Continued on next page

OUO1080,0000283 -19-11JUL02-1/8



Manifold Pressure Gauge Assembly . . . . .JT02051

Service air conditioning system (AQS).

OUO1080,0000283 -19-11JUL02-2/8

Electronic Leak Detector. . . . .JT02081

Detect refrigerant leaks.

OUO1080,0000283 -19-11JUL02-3/8

R12/R134a Master Fitting Kit<sup>1</sup> . . . . .JT02098

Flush and purge air conditioning system. Also check leak components.

<sup>1</sup>Use JT05419 and JT02138 together separately or JT02098 separately.

OUO1080,0000283 -19-11JUL02-4/8

Air Conditioning Service Fitting Kit (R12)<sup>1</sup>. . . . .JT05419

Connect flushing and purging test equipment. Use with JT02138 R134A Update Fitting Kit.

<sup>1</sup>Use JT05419 and JT02138 together separately or JT02098 separately.

OUO1080,0000283 -19-11JUL02-5/8

R134a Update Fitting Kit<sup>1</sup> . . . . .JT02138

Flush A/C system. Use with JT02078 A/C System Flushing Attachment Kit.

<sup>1</sup>Use JT05419 and JT02138 together separately or JT02098 separately.

OUO1080,0000283 -19-11JUL02-6/8

Continued on next page

290  
15  
2

A/C System Flushing Kit . . . . . JT02075

Flush air conditioning system. Use with JT02078 A/C System Flushing Attachment Kit.

OUO1080,0000283 -19-11JUL02-7/8

A/C System Flushing Attachment Kit . . . . . JT02078

Use with JT02075 to flush air conditioning system.

OUO1080,0000283 -19-11JUL02-8/8

## Other Material

Number	Name	Use
TY22025 (8.5 oz) (U.S.)	R134a Compressor Oil	Lubricate air conditioning system components.
TY15949 (12 oz) (U.S.)	Refrigerant R134a	Charge the air conditioning system.
TY15950 (15 lb) (U.S.)		
TY15951 (30 lb) (U.S.)		
N/A (U.S.)	GENESOLV 2004®	Flush air conditioning system.

GENESOLV 2004 is a trademark of Micro Care Corp.

OUO1080,0000284 -19-11JUL02-1/1

## Specifications

Item	Measurement	Specification
Compressor Clutch Coil	Resistance	3.5—4.0 Ohms
A/C Low Pressure Switch	Closing Pressure	300—400 kPa (3—4 bar) (45—60 psi)
A/C High Pressure Switch	Opening Pressure	2480—2760 kPa (24.8—27.6 bar) (370—415 psi)
Thermostatic Temperature Control Switch	Closing Temperature	Above 3°C (37°F)
Thermostatic Temperature Control Switch	Opening Temperature	At —1°C (30°F)
R134a	Refrigerant Charge	1.6—1.7 kg (3.5—3.75 lbs.)

OUO1080,0000286 –19–11JUL02–1/1

## Diagnosis, Tests, and Adjustments

OUO1085,0000283 –19–17JUL02–1/1

## Operator Station

-- -1/1

### ❶ Compressor Clutch Engagement Check

Open cab door. Turn key switch on but do NOT start engine.

Turn A/C switch ON.

Turn blower motor switch from OFF to LOW several times. Listen for click of compressor clutch as the switch is turned on.


*NOTE: The evaporator temperature must be above 3°C (37°F) so contacts of temperature control switch will be closed.*

*System must also be charged with 300—400 kPa (3—4 bar) (45—60 psi) so the A/C low pressure switch will be closed.*

**OK:** GO TO 9.

**NOT OK:** GO TO 2.

-- -1/1

<p>② Static Pressure Check</p>	<p><b>CAUTION:</b> Engine must be OFF.</p>  <p>A—Compressor Fitting B—Condenser Fitting</p> <p>Install JT02051 Manifold Gauge Set.</p> <ul style="list-style-type: none"> <li>• Connect suction side at compressor fitting (A).</li> <li>• Connect high pressure side at condenser fitting (B).</li> </ul> <p>Close center hose on gauge set. Open high and low side valves.</p> <p><i>NOTE: A/C system must have at least 300—400 kPa (3—4 bar) (45—60 psi) pressure to close the A/C low pressure switch.</i></p> <p>Open high and low side gauge set valves.</p> <p>Close both valves after static pressure check.</p> <p>LV2439 —UN—15DEC97</p>	<p><b>OK:</b> Pressure is good. GO TO 3.</p> <p><b>NOT OK:</b> Pressure is low. Do 13 and 15 and then repeat 1.</p> <p>— — 1/1</p>
<p>③ Isolate Malfunction</p>	<p><i>NOTE: Refer to Section 240—Electrical System Operation, Tests, and Adjustments.</i></p> <p>The following conditions must exist for the compressor clutch to operate:</p> <ul style="list-style-type: none"> <li>• Key switch must be ON.</li> <li>• Terminal “1” of blower motor switch must supply battery voltage across fuse F16 in all switch positions except OFF.</li> </ul>	<p><b>NOT OK:</b> Fuse is failed. (Circuit overloaded after fuse.) GO TO 4.</p> <p><b>NOT OK:</b> Fuse is good but no voltage at fuse. (Loss of power before fuse.) GO TO 5.</p> <p><b>NOT OK:</b> Fuse is good and voltage good at fuse. (Loss of power after fuse.) GO TO 4.</p> <p>— — 1/1</p>

**4 Check Voltage and Continuity**

Check for battery voltage at compressor clutch coil.

Resistance of compressor clutch coil is to specification.

**Specification**

Compressor Clutch Coil—Resistance ..... 3.5—4.0 Ohms

A/C temperature control switch should be open when the switch is OFF and have less than 0.5 ohms resistance when it is ON.

A/C low pressure switch should have less than 0.5 ohms resistance when system pressure is at or above specification. The switch should be open when system pressure is below specification.

**Specification**

A/C Low Pressure Switch—Closing

Pressure ..... 300—400 kPa (3—4 bar) (45—60 psi)

*NOTE: See 37 to check switch.*

A/C high pressure switch should have less than 0.5 ohms resistance when system pressure is below specification. The switch should be open when system pressure is above specification.

**Specification**

A/C High Pressure Switch—Opening

Pressure ..... 2480—2760 kPa (24.8—27.6 bar)  
(370—415 psi)

*NOTE: See 38 to check switch.*

The temperature control switch should have less than 0.5 ohms resistance when temperature surrounding the capillary tube is above specification. Switch should be open when temperature is below specification.

**Specification**

Thermostatic Temperature Control

Switch—Closing Temperature ..... Above 3°C (37°F)

Thermostatic Temperature Control

Switch—Opening Temperature ..... At —1°C (30°F)

*NOTE: See 39 to check switch.*

**NOT OK:** Repair the system and then GO TO 1.

-- 1/1

**5 Check Fuse F13**

*NOTE: Key switch and blower motor switch must be ON.*

Fuse F13 failed/not failed?

**NOT OK:** Fuse failed. (Circuit overloaded after fuse.) GO TO 6.

**NOT OK:** Fuse is good but no voltage before fuse. (Loss of power before fuse.) GO TO 7.

**NOT OK:** Fuse is good and voltage is good. (Loss of power after fuse.) GO TO 8.

-- 1/1



## Diagnosis, Tests, and Adjustments

### 9 System Cooling Check

Set tractor up as follows:

- Start engine and run at 2000 rpm.
- Temperature control knob must be CCW.
- Blower switch must be at PURGE.
- A/C compressor switch ON.
- Door and windows closed.

Sight glass must be clear (no bubbles).

Compressor suction line should be cool or cold.

Air from air ducts should be cold after about six minutes of operation.

**OK:** GO TO 10.

**NOT OK:** GO TO 12.

-- 1/1

### 10 Temperature Drop Check

Compare difference of temperature of ambient outside air (in shade), and conditioned air at vent, after 15—20 minutes of continuous operation. Refer to following chart for minimum temperature difference for measured ambient temperature.

Ambient Temperature	Minimum Temperature Difference
Below 24°C (75°F)	12°C (20°F)
Between 24—32°C (75—90°F)	14°C (25°F)
Above 32°C (90°F)	16°C (30°F)

**OK:** GO TO 11.

**NOT OK:** GO TO 12.

-- 1/1

### 11 Check Heater Valve Operation

Turn heater control CW approximately half way. Air from air ducts should begin to warm up within two minutes.

Turn heater control fully CCW. Air from air ducts should become cool within a few minutes.

**OK:** System is normal.  
Tractor may be released.

OPTIONAL: Go to 12 to perform the A/C gas system diagnosis.

**NOT OK:** GO TO 12.

-- 1/1






## Diagnosis, Tests, and Adjustments

<b>14 No Gauge Pressure</b>	<p>Check test hose coupler for missing or damaged valve depressor. Repair or replace as necessary and reconnect hose.</p> <p>Check depth of valve stem to outer end of test coupler (on tractor) with valve properly positioned in bore. Depth should be 7—8 mm (0.275—0.300 in).</p> <p>Check for restricted gauge orifices.</p> <p>Check gauges for pressure.</p>	<p><b>OK:</b> Pressure restricted on gauges. GO TO 13.</p> <p><b>NOT OK:</b> No pressure. GO TO 15.</p>
-----------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------


-- -1/1

<b>15 Low Pressure</b>	<p><i>NOTE: Make sure the problem is not an improperly connected coupler. See 14.</i></p> <p>Engine and compressor must be OFF.</p> <p>Connect refrigerant supply.</p> <p>Purge air from charging hose. Open low and high side gauge set valves.</p> <p>Open refrigerant container valve and add refrigerant until pressure stabilizes.</p> <p> <b>CAUTION: Close gauge set low and high side valves before operating the compressor.</b></p> <p>Use an electronic leak detector, or a 50-50 mix of soap and water, to check all components, fittings, and connections for leaks.</p> <p><i>NOTE: Discharging, evacuating, and charging may be required. If necessary, see Section 90.</i></p>	<p><b>OK:</b> No leaks. GO TO 16.</p> <p><b>NOT OK:</b> Repair leaks, the GO TO 16.</p>
------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------

-- -1/1

<b>16 Clutch Cycle Check</b>	<p>Close cab doors and window.</p> <p>A/C temperature control switch at ON position.</p> <p>Operate engine at 2000 rpm.</p> <p>Put blower motor switch at PURGE and temperature control at maximum cooling (CCW).</p> <p>Operate system for 10 minutes.</p> <p><i>NOTE: If discharge pressure is 2500—2800 kPa 25—28 bar) (370—415 psi) and the compressor stops operating, go to 21.</i></p> <p>Note the length of time the compressor is ON. It should be on a minimum of 25 seconds at 21—27°C (70—80°F).</p> <p><i>NOTE: The clutch may stay ON continuously when the temperature is above 27°C (80°F). It also may cycle more frequently at cooler temperatures.</i></p>	<p><b>OK:</b> GO TO 18.</p> <p><b>NOT OK:</b> GO TO 17.</p>
------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------

-- -1/1

<p><b>17 Causes of Frequent Clutch Cycling</b></p>	<p>A. Blower motor(s) inoperative.</p> <p>B. Fresh air and recirculating filters dirty.</p> <p>C. Refrigerant charge is low. Do steps 18, 19, and 20 and then repeat step 16.</p> <p>D. Temperature control switch temperature range is set too cold. Temporarily wire compressor clutch coil to starter solenoid. Continue to step 18.</p> <p><i>NOTE: See 39 to check switch.</i></p> <p>E. Evaporator is dirty.</p>	<p><b>NOT OK:</b> Repair as required and then GO TO 18.</p> <p>-- -1/1</p>
<p><b>18 Sight Glass Check</b></p>	<p><i>NOTE: Compressor may have to be temporarily wired directly to battery source for this system check. If necessary, disconnect the clutch coil lead at the compressor and connect a jumper wire from the clutch coil to the starter solenoid terminal.</i></p> <p>Run engine at 2000 rpm, with compressor operating.</p> <p> <b>CAUTION:</b> If discharge pressure is high and there are bubbles in sight glass, or there is a vacuum and very slow bubbles, GO TO 21.</p> <p>Observe gauge pressures. Check sight glass for bubbles.</p>	<p><b>OK:</b> No bubbles. GO TO 21.</p> <p><b>NOT OK:</b> Bubbles in sight glass. GO TO 19.</p> <p>-- -1/1</p>
<p><b>19 Leak System Check</b></p>	<p>Use JT02081 Leak Detector to check all components, fittings, and connections for leaks.</p> <p><i>NOTE: Use a 50—50 mixture of liquid soap and water if leaks are difficult to find.</i></p> <p>Check low and high sides with engine OFF. Repeat check on high side with engine running and compressor operating.</p> <p><i>NOTE: Any spot on connections, hoses, or components that is damp with oil and is collecting dust is an indication of refrigerant leakage.</i></p> <p>If leakage exceeds 0.5 kg (1 lb) of refrigerant per year and no other leak is found, replace the compressor shaft seal.</p> <p><i>NOTE: Discharging, evacuating, and charging may be required. If necessary, see Section 90.</i></p>	<p><b>OK:</b> No leaks found. GO TO 20.</p> <p><b>NOT OK:</b> Repair leaks and then GO TO 21.</p> <p>-- -1/1</p>

<b>20 Add Refrigerant</b>	<p><i>NOTE: Bubbles may appear in sight glass, of a fully charged system, when operating below 18° C (65° F) ambient. Bubbles will disappear at higher ambient temperatures.</i></p> <p>Close both valves on gauge set and connect refrigerant container to center hose. Open container valve and purge air from center (charging) hose.</p> <p><i>NOTE: Container must be upright when adding refrigerant.</i></p> <p>With engine at 2000 rpm and compressor operating, open low side valve.</p> <p>Add refrigerant until bubbles disappear from the sight glass, then add 475 ml (1 lb) more.</p> <p><b>IMPORTANT: Do not exceed 300 kPa (3 bar) (45 psi) while charging the system.</b></p> <p style="text-align: center;"><b>Specification</b></p> <p>R134a—Refrigerant Charge..... 1.6—1.7 kg (3.5—3.75 lbs.)</p>	<p><b>OK:</b> Repeat Step 18, then GO TO 21.</p>
---------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------

**21 System Pressure Check**

Doors and windows must be closed.

With engine at 2000 rpm and compressor operating, put blower motor switch at PURGE position.

*NOTE: At cool temperatures, compressor may have to be temporarily wired directly to battery source for this system check. If necessary, disconnect the clutch coil lead at the compressor and connect a jumper wire from the clutch coil to the starter solenoid terminal.*

*NOTE: Bubbles may appear in sight glass when operating below 18°C (65°F) ambient temperature. Bubbles will disappear with higher ambient temperatures.*

Check ambient temperature and gauge pressures. Compare temperature and pressure readings to following specification chart.


*NOTE: Lower figures in following table correspond to approximately 10% humidity. Higher figures correspond to approximately 90% humidity.*

System Pressure Table							
Temperature		Suction Pressure			Discharge Pressure		
°C	°F	kPa	Bar	PSI	kPa	Bar	PSI
11—16	51—60	7—40	0.07—0.4	1—6	760—1100	7.5—11.0	110—160
16—21	61—70	20—70	0.2—0.7	3—10	900—1280	9.0—12.8	130—185
22—27	71—80	40—100	0.4—1.0	6—14	1070—1480	10.7—14.8	155—215
27—32	81—90	60—120	0.6—1.2	9—18	1240—1720	12.4—17.2	180—250
33—38	91—100	80—150	0.8—1.5	12—22	1450—2000	14.5—20.0	210—290
39—43	101—110	100—180	1.0—1.8	15—26	1660—2280	16.6—22.8	240—330
44—49	111—120	120—200	1.2—2.0	18—30	1900—2590	19.0—25.9	275—375

Temperature and Pressure Application Chart		
Suction Pressure	Discharge Pressure	GO TO
NORMAL	NORMAL	30
Low, Normal, or High	High w/Bubbles	22
High	Low	23
Normal or High	High w/o Bubbles	24
Low or Vacuum	Normal or Low	28

*NOTE: Bubbles may appear in sight glass, of a fully charged system, when operating below 18°C (65°F) ambient. Bubbles will disappear at higher ambient temperatures.*

**OK:** Reconnect the compressor when testing and/or repair is completed.

<p><b>22 Possible Causes for Condition of “Suction Pressure Low, Normal, or High and Discharge Pressure High with Bubbles” Are:</b></p>	<p>Restrictions in the system at or between the following locations:</p> <p><i>NOTE: Feeling lines and condenser for temperature changes may or may not locate point of restriction.</i></p> <p> <b>CAUTION: These lines are normally hot.</b></p> <ol style="list-style-type: none"> <li>1. Refrigerant line between compressor and condenser.</li> <li>2. Condenser.</li> </ol> <p><i>NOTE: When feeling tube bends across top of condenser there should be a temperature drop after the fourth bend.</i></p> <ol style="list-style-type: none"> <li>3. Refrigerant line between condenser and sight glass.</li> <li>4. Inlet of receiver/dryer.</li> </ol> <p><i>NOTE: Discharging, flushing, evacuating, and charging may be required. If necessary, see Section 90.</i></p>	<p><b>NOT OK:</b> Inspect and repair as necessary. Then GO TO 21.</p> <p>— — 1/1</p>
<p><b>23 Possible Causes for Conditions of “Suction Pressure High, Discharge Pressure Low” Are:</b></p>	<ol style="list-style-type: none"> <li>1. Compressor clutch not engaged. Remove clutch cover to observe clutch operation.</li> <li>2. Compressor drive belt slipping. Check auto tensioning device for binding.</li> <li>3. Clutch slipping. Temporarily cover condenser to obtain higher compressor operating pressure to check for slippage.</li> </ol> <p><i>NOTE: If shaft seal leakage is cause of clutch slippage, discharge, repair, evacuate, and recharge system.</i></p> <ol style="list-style-type: none"> <li>4. Compressor has an internal failure.</li> </ol> <p><i>NOTE: Repair requires discharging, replacing receiver-dryer, flushing, purging, and charging system. Perform compressor volumetric efficiency test after removal and before installation. Refer to Section 90.</i></p>	<p><b>NOT OK:</b> Repair. Then GO TO 21.</p> <p>— — 1/1</p>

## Diagnosis, Tests, and Adjustments

<p><b>24 Possible Causes for Conditions of “Suction Pressure Normal or High and Discharge Pressure High Without Bubbles” Are:</b></p>	<ol style="list-style-type: none"> <li>1. Restricted air flow through the condenser, hydraulic oil cooler, or radiator.</li> <li>2. Leakage through the coolant shutoff valve. If both heater hoses, at right side of engine, are hot, check the shutoff valve at step 31.</li> <li>3. Restriction at inlet of receiver-dryer. Check for temperature drop from inlet to outlet of receiver-dryer.</li> <li>4. Expansion valve is stuck open. Check expansion valve operation at step 26.</li> </ol> <p><i>NOTE: If any of the conditions exist, as specified in steps “1” through “4” above, repair the problem and then GO TO 21. If all components/conditions are normal, continue at step “5” below.</i></p> <ol style="list-style-type: none"> <li>5. System is charged with a mixture of two refrigerants, or contaminated with nitrogen or air. Checking system static pressure (step 13) can help determine if system is contaminated. However, if system operation was originally normal and nothing has been added to the system, contamination is not the problem.</li> <li>6. System is overcharged with refrigerant. Remove refrigerant from system until bubbles appear in the sight glass. Check system pressures as recommended in step 21 and compare to the chart.</li> </ol>	<p><b>OK:</b> If all components/conditions are normal (1 through 6 above), GO TO step 25.</p> <p><b>NOT OK:</b> If pressures are not OK at 5 or 6 above, GO TO step 13.</p> <p style="text-align: right;">-- -1/1</p>
<p><b>25 Recharge System</b></p>	<p>With engine at 2000 rpm and compressor operating, open low side valve but do NOT exceed 400 kPa (4.0 bar) (60 psi).</p> <p>Add refrigerant until bubbles disappear in sight glass and then add 475 ml (16 oz) more.</p> <p>Recheck system pressures and compare readings to chart at step 21.</p>	<p><b>OK:</b> Pressure readings normal. GO TO 30.</p> <p><b>NOT OK:</b> Pressure readings high. GO TO 13.</p> <p style="text-align: right;">-- -1/1</p>

**26 Check Expansion Valve Operation**

Put gauge set close to cab for easy viewing from inside the cab.

*NOTE: Two people are required for this test if the gauge set cannot be placed close to the cab for clear viewing.*

With engine at 2000 rpm and compressor operating, put temperature control at the fully CW (heat) position to heat up the evaporator.

Remove plug (above expansion valve) from top of evaporator/heater core housing cover, at right side of housing.

*NOTE: Cab roof must be removed to access top of evaporator/heater core housing.*

*Reinstall plug after test or repair.*

Spray head of expansion valve with refrigerant R134a, using DFRW83 Nozzle Assembly, to close expansion valve. See Section 299 for fabrication of nozzle assembly. The recovery, recycle, and charging stations for refrigerants R12 and R134a must NOT be interchanged. Refrigerant R134a is corrosive to copper as well as components used in R12 systems. Certain seals also are not compatible with refrigerant oil used in R134a systems. Therefore, NEVER use R134a in a system which previously contained R12.

*NOTE: Any solution that does not contribute to deterioration of the ozone layer and can produce sub-zero cooling is acceptable for this test.*

Quickly check the suction pressure gauge for a decrease in pressure.

Pressure should decrease when expansion valve head is cold and increase when the head warms up.

*NOTE: At 24°C (75°F), the suction side normally goes to 10—15 in Hg vacuum.*

Repeat check two or three times to determine pattern of expansion valve operation. If the valve changes pressure very slowly, replace the valve.

*NOTE: To limit the amount of antifreeze entering the evaporator housing, see Section 90 for removal of the heater valve, expansion valve, and evaporator/heater core.*

Install T66355 plastic plug in hole after testing or repair.

**OK:** GO TO previous step (26 or 28).

**NOT OK:** GO TO 27.

-- -1/1

**27 Pressure Does Not Change**

Causes are:

- Restriction in receiver-dryer-to-expansion valve line.
- Restriction at inlet of expansion valve.
- If suction pressure is low, expansion valve is stuck closed or has lost its gas charge.
- If suction pressure is high, expansion valve is stuck open.

Inspect system for restriction and bench test expansion valve using JT02098 fitting kit.

*NOTE: Discharging, flushing, purging, evacuating, and charging may be required. If necessary, see Section 90.*

**NOT OK:** Repair as necessary and then GO TO 21.

-- -1/1

<b>28 Possible Causes for Conditions OF “Suction Low or Vacuum and Discharge Normal or Low” Are:</b>	<ol style="list-style-type: none"> <li>1. Blower motor inoperative. Check electrical circuits.</li> <li>2. Dirty recirculating or fresh air filters. Clear filter.</li> <li>3. Expansion valve stuck closed or gas in thermal head. See step 26 to check expansion valve.</li> <li>4. Restriction in system. Check along refrigerant lines for point where frost accumulates or feel for a temperature change to locate a restriction. <ul style="list-style-type: none"> <li>• Between condenser and receiver-dryer</li> <li>• At receiver-dryer</li> <li>• Between receiver-dryer and expansion valve</li> <li>• At inlet of expansion valve</li> <li>• Between evaporator and suction side of compressor</li> </ul> </li> </ol> <p><i>NOTE: A very slight temperature change usually indicates a restriction.</i></p>	<p><b>OK:</b> Conditions/components are OK. GO TO 29.</p> <p><b>NOT OK:</b> Conditions/components NOT OK. Repair and then GO TO 21.</p>
------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------

-- -1/1

<b>29 Defrost Evaporator</b>	<p>Turn A/C temperature control switch to OFF to stop the compressor.</p> <p>With engine running and the cab doors open, turn temperature control to maximum HEAT (CCW), for three minutes, to defrost the evaporator.</p> <p>With the engine at 2000 rpm, cab doors closed, and compressor operating, turn temperature control to maximum COOLING (CW).</p> <p>Read high and low pressure gauges after six minutes of operation and compare to chart in step 21.</p>	<p><b>OK:</b> Pressure readings normal. GO TO 30.</p> <p><b>NOT OK:</b> Pressure readings low. GO TO 35.</p>
------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------

-- -1/1

30
Temperature Drop Check

Record ambient outside temperature in the shade.

Cab doors and windows must be closed.

With engine at 2000 rpm and compressor operating, put blower motor switch at PURGE position.

Put thermometer in left air duct and operate system continuously for 20 minutes.

Record air duct temperature and compare it to the following table.

Ambient Temperature	Temperature Difference (Minimum)
Below 24°C (75°F)	12°C (20°F)
24—32°C (75—90°F)	14°C (25°F)
Above 32°C (90°F)	16°C (30°F)

**OK:** Temperature difference within specification. GO TO 40.


**NOT OK:** Temperature difference not within specification. GO TO 31.

-- -1/1



## Diagnosis, Tests, and Adjustments

<b>31 Engine Coolant Leak Check</b>	<p>With the engine at 2000 rpm and the compressor operating:</p> <p>Crimp heater hose (at right side of engine) using two flat washers and locking pliers.</p> <p><i>NOTE: Hose at rear of block is heater core inlet and hose at top front of engine to water pump is heater core outlet.</i></p> <p>Repeat Temperature Drop Check at 30.</p>	<p><b>OK:</b> Temperature difference within specification. GO TO 32.</p> <p><b>NOT OK:</b> Temperature difference not within specification. GO TO 33.</p> <p style="text-align: right;">-- -1/1</p>
<b>32 Engine Coolant Not Shut Off</b>	<p>Engine coolant is circulating for the following reason(s):</p> <ul style="list-style-type: none"> <li>• Heater valve control cable is out of adjustment and does not shut off valve.</li> <li>• Heater valve is leaking internally in the OFF position.</li> </ul> <p><i>NOTE: To avoid spilling antifreeze into the evaporator housing, see Section 90 for removal of heater valve, expansion valve and heater/evaporator core.</i></p>	<p><b>NOT OK:</b> Repair and then GO TO 30.</p> <p style="text-align: right;">-- -1/1</p>
<b>33 Excessive Air Leakage From the Cab</b>	<p>Check for excessive air leakage inside the cab at the following locations:</p> <ul style="list-style-type: none"> <li>• Cab door and window seals</li> <li>• Possible missing screws at blower motor flange inside evaporator housing</li> <li>• Possible missing grommets around hoses to and from expansion valve at right front of evaporator/heater core housing.</li> </ul>	<p><b>OK:</b> No leaks. GO TO 34.</p> <p><b>NOT OK:</b> Repair leaks and then GO TO 30.</p> <p style="text-align: right;">-- -1/1</p>
<b>34 Possible Causes for Lack of Cooling Are:</b>	<p>Lack of cooling can be caused by the following components if they are dirty or damaged.</p> <ul style="list-style-type: none"> <li>• Condenser, oil cooler, and radiator</li> <li>• Recirculating filter</li> <li>• Blower air duct and fan cages</li> <li>• Evaporator/heater core</li> </ul> <p><i>NOTE: Check condenser, radiator, and evaporator for damaged cooling fins.</i></p>	<p><b>OK:</b> Components not dirty. GO TO 35.</p> <p><b>NOT OK:</b> Clean appropriate components and then GO TO 30.</p> <p style="text-align: right;">-- -1/1</p>

<p><b>35 Internal Line Restriction Check</b></p>	<p> <b>CAUTION: High pressure side lines are normally HOT.</b></p> <p>With engine at 2000 rpm and the compressor operating, feel along the entire length of the high pressure side hose, from the compressor to the condensor and the expansion valve for a temperature change (point of restriction).</p> <p><i>NOTE: Dented or kinked tubing/hose may restrict flow of refrigerant.</i></p>	<p><b>OK:</b> No temperature change, no restriction. GO TO 36.</p> <p><b>NOT OK:</b> Temperature change. Repair restriction and then GO TO 21.</p> <p>-- -1/1</p>
<p><b>36 Possible Causes for Poor Cooling Are:</b></p>	<ol style="list-style-type: none"> <li>1. Evaporator freeze up. <ul style="list-style-type: none"> <li>• Temperature control does not blend heat. Check temperature control cable and coolant shut-off valve for operation and proper adjustment.</li> <li>• Temperature control switch stuck closed. Check switch opening limits as described in step 39.</li> </ul> </li> <li>2. System is contaminated with a mixture of nitrogen, air, two different refrigerants, or moisture in the system. Do number "3" of this step. Recover refrigerant, flush system, replace receiver-dryer, purge system with dry nitrogen, evacuate, and recharge the system.</li> <li>3. Compressor efficiency is low. Perform volumetric efficiency test as described in Section 90. <ul style="list-style-type: none"> <li>• If compressor efficiency is normal, poor cooling is a result of conditions in number 2 above.</li> <li>• If compressor efficiency is not normal, replace the compressor.</li> </ul> </li> </ol>	<p><b>OK:</b> After system/component is repaired, GO TO 21.</p> <p>-- -1/1</p>

**37 Refrigerant Loss Switch (Low Pressure) Check**

*NOTE: System pressure must be at least 300—400 kPa (3—4 bar) (45—60 psi) to keep switch contacts closed for normal operation.*

Remove refrigerant loss switch from tube at inlet to receiver-dryer. Install a jumper wire across connector to keep compressor clutch engaged.

Connect the refrigerant loss switch to the union connector JT02113 fitting.

Connect low side gauge hose to compressor suction quick coupler.

Remove hose from high side and close both valves of gauge set.

Install WEATHER PACK™ test leads on switch terminals and use an ohmmeter to check (at switch connector) the switch opening and closing action.

With engine OFF, slowly open low side valve and observe meter to note when switch contacts close.

*NOTE: If higher pressure is required to close the switch, connect to the compressor high side and start the engine.*

Disconnect quick coupler from pressure source and slowly open high side valve of gauge set to bleed pressure from switch.

**OK:** Switch operates within specification. Check connections, reinstall switch and then GO TO 1.

**NOT OK:** Switch does not operate within specification. Replace switch and then GO TO 1.

WEATHER PACK is a trademark of Packard Electric

-- -1/1

**38 High Pressure Switch Check**

*NOTE: When system pressure is above 2480—2760 kPa (24.8—27.6 bar) (370—415 psi) the high pressure switch opens to stop compressor operation.*

Remove high pressure switch from port at inlet of receiver-dryer and install a jumper wire in its place.

Connect the high pressure switch to the center connector of gauge set hose using JT02113 fitting.

Install WEATHER PACK™ test leads on switch terminals and use an ohmmeter to check (at switch connector) the switch opening and closing action.

Connect high side hose of gauge set to condensor inlet quick coupler.

Open high side valve and close low side valve.

Completely cover front of condenser with cardboard.

**IMPORTANT: Do not let pressure exceed 2900 kPa (29 bar) (435 psi).**

With engine at 2000 rpm and compressor operating, turn heater control CW to maximum heat to decrease running time.

Observe high pressure gauge for point at which switch contacts open.

After switch opens, stop engine and note pressure at which switch contacts close.

Remove cardboard from condenser.

**OK:** Switch operates within specification. Check connections and reinstall switch and then GO TO 1.

**NOT OK:** Switch does not operate within specification. Replace switch and then GO TO 1.

WEATHER PACK is a trademark of Packard Electric

-- -1/1

## Diagnosis, Tests, and Adjustments

<b>39 Temperature Control Switch Check</b>	<p>Start engine and run at 2000 rpm.</p> <p>Doors and window closed.</p> <ol style="list-style-type: none"> <li>1. Turn blower motor switch to PURGE (fully clockwise) and set temperature control switch for maximum cooling (fully clockwise).</li> <li>2. Operate system for 10 minutes. Observe time compressor clutch is ON.</li> </ol> <p>When ambient outside air temperature (in shade) is below 29°C (85°F), minimum compressor clutch cycle time should be 30 seconds.</p> <p><i>NOTE: The clutch may stay ON when ambient air outside temperature (in shade) is above 29°C (85°F).</i></p>	<p><b>NOT OK:</b> Clutch ON more than 30 seconds, GO TO 18.</p> <p><b>NOT OK:</b> Clutch ON less than 30 seconds, GO TO 17.</p> <p><b>NOT OK:</b> Discharge pressure 2500—2800 kPa (25—28 bar) (370—415 psi) and stops operating, GO TO 21.</p> <p style="text-align: right;">-- -1/1</p>
<b>40 System Testing Summary</b>	<ol style="list-style-type: none"> <li>1. If compressor clutch was hot wired earlier (to battery voltage source to keep compressor operating), check necessary switches at steps 37, 38, and 39.</li> <li>2. If the system checks out as NORMAL at this step and any problem (including cleaning filters) has been corrected, the system is NORMAL.</li> <li>3. If the system checks out to be NORMAL at this step and no problem has been corrected, there is the possibility of moisture in the system.</li> </ol> <p><i>NOTE: If the temperature control and low pressure switched are not functioning within their specified ranges, the conclusion of moisture in the system would be incorrect.</i></p>	<p><b>NOT OK:</b> If customer complaint is "System does not cool properly above approximately 27°C (80°F) ambient temperature," the problem is NOT moisture in the system. GO TO 9 to repeat diagnosis.</p> <p><b>NOT OK:</b> If the customer complaint is "System cools satisfactorily above approximately 27°C (80°F)," there IS moisture in the system. GO TO 41.</p> <p style="text-align: right;">-- -1/1</p>
<b>41 Remove Moisture from System</b>	<ul style="list-style-type: none"> <li>• Recover refrigerant from system.</li> <li>• Purge system with dry nitrogen while changing receiver-dryer.</li> <li>• Evacuate system.</li> <li>• Charge system with fresh refrigerant.</li> <li>• Repeat test sequence.</li> </ul> <p><i>NOTE: Refer to Section 90 for above procedures.</i></p>	<p><b>OK:</b> After charging GO TO 9.</p> <p style="text-align: right;">-- -1/1</p>


290  
15  
21

## Adjust Heater Temperature Control Cable


**NOTE:** Heater cable adjustment (A) is located behind right side cab intake filter.

1. Turn the heater temperature control knob (clockwise) to full heat and adjust cable (A) until the heater valve arm (B) is in the full open position.
2. Turn the heater temperature control knob (counterclockwise) until closed. Heater valve arm (C) should be in the full closed position. Adjust cable (A) as required.

A—Heater Cable  
B—Heater Valve Arm—Full Open Position  
C—Heater Valve Arm—Full Closed Position




LV1409 -UN-10NOV95



Full Open Position

LV1408 -UN-10NOV95



Full Closed Position

LV1410 -UN-10NOV95

OUO1085,0000284 -19-17JUL02-1/1

Section 299

Dealer Fabricated Tools

Contents


	Page
<b>Group 00—Dealer Fabricated Tools</b>	
JDG826—PTO Clutch Finger Height Gauge . . . . .	299-00-1
JDG827—Traction Clutch Finger Height Gauge . . . . .	299-00-1
JDG828—Traction Clutch Finger Height Adjustment Tool. . . . .	299-00-2
JDG919—Clutch Finger Height Gauge . . . . .	299-00-2
DFLV1A—Final Drive Turning Tool . . . . .	299-00-3
DFRW83—Nozzle Assembly . . . . .	299-00-4
DFRW20—Compressor Holding Fixture . . . . .	299-00-5



## JDG826—PTO Clutch Finger Height Gauge

PTO Clutch Finger Height Gauge JDG826

Measures PTO clutch finger height.



JDG826 -UN-01JUL97


Item	Measurement	Specification
Plate Minimum	Thickness	1.587 mm (0.0625 in.)
Dimension (A)	Thickness	124.617 mm (4.906 in.)
Dimension (B)	Thickness	65.087 mm (2.562 in.)
Dimension (C)	Thickness	19.842 mm (0.781 in.)
Dimension (D)	Thickness	41.275 mm (1.625 in.)

OUC1040,0000B04 -19-02MAY01-1/1

## JDG827—Traction Clutch Finger Height Gauge

JDG827—Traction Clutch Finger Height Gauge

Measures traction clutch finger height.



JDG827 -UN-01JUL97

Item	Measurement	Specification
Plate Minimum	Thickness	1.587 mm (0.0625 in.)
Dimension (A)	Thickness	157.162 mm (6.187 in.)
Dimension (B)	Thickness	34.925 mm (1.375 in.)
Dimension (C)	Thickness	19.842 mm (0.781 in.)
Dimension (D)	Thickness	15.875 mm (0.625 in.)

OUC1040,0000B05 -19-02MAY01-1/1



JDG828 -UN-24FEB98

**JDG828—Traction Clutch Finger Height Adjustment Tool**




JDG828 Traction Clutch Finger Height Adjustment Tool

Item	Measurement	Specification
Long Arm Metric Hex Key	Size	5 mm
Dimension (A)	Height	10 mm (0.393 in.)

OUC1040,0000B06 -19-02MAY01-1/1

**JDG919—Clutch Finger Height Gauge**




LV2127 -UN-01JUL97

Item	Measurement	Specification
Dimension (A)	Length	149.047 mm (5.858 in.)
Dimension (B)	Length	33.909 mm (1.335 in.)
Dimension (C)	Length	19.431 mm (0.765 in.)
Dimension (D)	Length	32.689 mm (1.27 in.)

OUC1040,0000B02 -19-22JUL02-1/1

## DFLV1A—Final Drive Turning Tool



Final Drive Turning Tool is used to rotate final drive housing to determine rolling drag torque.

Material required:

40 x 10 x 380 mm (1.575 x 0.394 x 14.961 in.) Flat Steel Stock.

12 x 50 mm long (0.472 x 1.969 in. long) Round Steel Stock (2 used).

M8 x 15 mm Cap Screw.


Weld rods (A) and cap screw (B) to flat steel stock as shown.

LV490AE -19-27FEB92

299  
00  
3

LV,29900HA,A4 -19-03AUG94-1/1

## DFRW83—Nozzle Assembly



A—Fitting  
B—Pressure Sensing Tube  
C—O-Ring

D—JT03232 Adapter  
E—JT02219 Fitting  
F—R134a Refrigerant Hose

G—R134a Refrigerant Hose Adapter  
H—Gas Shut-Off Valve

I—Compression Adapter (W/O Sleeve)  
J—Nozzle

**Use:** To apply refrigerant 134a while testing expansion valve operation on tractors with refrigerant 134a.

**NOTE:** Do NOT use a shop air blow gun because the stem is not sealed. Refrigerant will leak out around the stem when the valve is opened.

Refer to the following for materials required to fabricate the nozzle assembly.

Use a pressure sensing tube (B) with an O-ring (C) and fitting (A) from a non-functional R12 thermal expansion valve to make nozzle (J).

Brass compression adapter (I) is a 1/4 (male) NPT by 1/4 tube adapter available at local hardware stores. The sleeve from the adapter is not required.

Gas shut-off valve (H) is 1/4 (female) NPT at both ends, available at local hardware stores.

R134a refrigerant hose adapter (G) is cut off from an empty R134a tank and is brazed to a 1/8 in. (female) NPT by 1/4 in. (male) NPT adapter (D).

**NOTE:** JT03232 1/8 in. (female) NPT by 1/4 in. (male) NPT Adapter (D) and JT02219 1/8 in. (male) NPT by 1/2-16 Acme fitting (E) may be used to make hose adapter (G).

R134a refrigerant hose (F) can be purchased from SERVICEGARD™ or local supplier and should be 61—91 cm (24—36 in.) long.

Use by connecting the DFRW83 Nozzle Assembly to a refrigerant R134a source using hose (F), to apply refrigerant to expansion valve. Control flow of refrigerant using both valve on refrigerant source and shutoff valve (H).

Technical drawing of a mechanical assembly, likely a pump or motor component, showing dimensions A through K. The drawing includes a main view and a detail view of a corner.

- Dimensions:**
  - A:** Horizontal distance from the left edge to the start of the hatched section.
  - B:** Horizontal distance from the end of the hatched section to the right edge.
  - C:** Horizontal distance from the left edge to the center of the hatched section.
  - D:** Vertical distance from the top edge to the center of the hatched section.
  - E:** Vertical distance from the bottom edge to the center of the hatched section.
  - F:** Total vertical distance from the top edge to the bottom edge.
  - G:** Horizontal distance from the left edge to the center of the hatched section.
  - H:** Horizontal distance from the center of the hatched section to the right edge.
  - I:** Vertical distance from the top edge to the bottom edge of the detail view.
  - J:** Horizontal distance from the left edge to the center of the hatched section.
  - K:** Horizontal distance from the center of the hatched section to the right edge.
- Features:**
  - A hatched section is shown on the top surface.
  - A detail view of a corner is shown on the right, with dimensions I and J.
  - Dimension K is indicated by a dashed line and an arrow pointing to the center of the hatched section.

J—Weld  
K—Two Holes

- 2—Threaded Steel Rods (0.5 x 7 in.)
- 4—Matching Lock Washers and Nuts
- 2—Eye Bolts (6 x 1/4 in.)
- 2—Matching Washers and Nuts

- 2—Steel Plates (4 x 2.27 in.) and (10 x 6 in.)

299  
00  
5

299  
00  
6

# Index

	Page		Page
<b>A</b>			
A/C compressor clutch check . . . . .	210-10-15	Air intake system, 5510 machine	
A/C compressor operation		Install turbocharger . . . . .	30-10-9
Cab only . . . . .	240-10-42	Remove turbocharger . . . . .	30-10-8
A/C system operational check . . . . .	210-10-30	Air restriction indicator operation . . . . .	240-10-32
A/C temperature control switch		Alternator/regulator	
Theory of operation . . . . .	290-10-8	Replace . . . . .	40-05-6, 40-05-7
Accessory relay operation . . . . .	240-10-36	Antenna	
Air cleaner elements, 5210 and 5310 machines		Replace . . . . .	40-10-9
Remove/install . . . . .	30-10-2	Antenna/radio, cab wiring harness	
Air cleaner elements, 5410 and 5510 machines		Replace . . . . .	40-15-14
Remove/install . . . . .	30-10-4	Assemblies, gear shift shaft	
Air cleaner, 5210 and 5310 machines		Disassemble/inspect/assemble . . . . .	50-15-40, 50-16-44
Remove/inspect/install elements . . . . .	30-10-2	Assembly, axle housing, MFWD	
Air cleaner, 5410 and 5510 machines		Remove/install . . . . .	50-35-16
Remove/inspect/install elements . . . . .	30-10-4	Assembly, axle shaft	
Air conditioning		Remove/inspect/install . . . . .	50-30-8
Compressor, remove/inspect/install . . . . .	90-20-10	Assembly, clutch	
Condenser, remove/inspect/install . . . . .	90-20-8	Assemble . . . . .	50-10-8, 50-11-6
Flush system . . . . .	90-20-37	Disassemble/inspect . . . . .	50-10-5, 50-11-3
Hose and tubing o-ring connector		Remove/install . . . . .	50-11-3
torques . . . . .	90-20-5	Assembly, differential	
Receiver-dryer, replace . . . . .	90-20-7	Disassemble/inspect/assemble . . . . .	50-25-5
Refrigerant, recover/recycle . . . . .	90-20-6	Remove/install . . . . .	50-25-3
System information . . . . .	90-20-35	Assembly, differential carrier	
System, charge . . . . .	90-20-42	Remove/install . . . . .	50-35-29
System, evacuate . . . . .	90-20-41	Assembly, final drive	
Temperature control switch, replace . . . . .	40-10-23	Remove/install . . . . .	50-30-2
Air conditioning system		Assembly, lock, differential	
Air flow, theory of operation . . . . .	290-10-2	Remove/inspect/install . . . . .	50-25-11
Component location . . . . .	290-05-2	Assembly, MFWD differential carrier	
Cycle, theory of operation . . . . .	290-10-3	Assemble . . . . .	50-35-34
Air Filter		Disassemble/inspect . . . . .	50-35-30
Cab exterior, remove/inspect/install . . . . .	90-15-3	Assembly, planetary drive	
Cab interior, remove/inspect/install . . . . .	90-15-2	Install . . . . .	50-30-6
Air filter restriction switch, 5210 and 5310 machines		Remove/inspect . . . . .	50-30-4
Replace . . . . .	40-10-2	Assembly, rear PTO drive shaft	
Air filter restriction switch, 5410 and 5510 machines		Remove/install . . . . .	50-20-5
Replace . . . . .	40-10-2	Axle housing assembly, MFWD	
Air Intake heater		Remove/install . . . . .	50-35-16
Replace . . . . .	40-10-5	Axle shaft assembly	
Air intake heater relay		Remove/inspect/install . . . . .	50-30-8
Replace . . . . .	40-10-5	Axle shaft, MFWD	
Air intake system		Remove/inspect/install . . . . .	50-35-27
Components . . . . .	230-05-4, 230-05-5	Axle supports, MFWD	
Turbocharger break-in . . . . .	30-10-10	Remove/inspect/install . . . . .	50-35-18
Turbocharger, repair . . . . .	30-10-1	Axle, front 2WD	
Air intake system check . . . . .	210-10-9	Remove and install . . . . .	80-05-1
Air intake system operation . . . . .	230-10-8, 230-10-10		
Air intake system, 5310 machine		<b>B</b>	
Install turbocharger . . . . .	30-10-7	Backlash, differential	
Remove turbocharger . . . . .	30-10-6	Adjustment . . . . .	50-25-14

	Page		Page
Battery, charge . . . . .	240-15-93	Remove/install . . . . .	90-15-15
Battery, tractors with cab Remove/install . . . . .	 .40-05-3	Cab Blower motor check . . . . .	210-10-14
Battery, tractors without cab Remove/install . . . . .	 .40-05-2	Cab doors Remove/install . . . . .	 90-15-9
Belt tensioner Inspect/replace . . . . .	 20-10-10	Cab exterior Air filter, remove/inspect/install . . . . .	 90-15-3
Blade terminals, connector body Replace . . . . .	 .40-15-2	Cab heater valve check . . . . .	210-10-30
Bleed fuel system . . . . .	220-15-32	Cab interior Air filter, remove/inspect/install . . . . .	 90-15-2
Blower Motors, remove . . . . .	 90-20-23	Cab roof Remove/install . . . . .	 90-15-11
Blower control switch Replace . . . . .	 .40-10-22	Cab wiring harness lights Replace . . . . .	 .40-15-12
Blower motor operation Tractors with cab . . . . .	 240-10-40	Cab wiring harness radio/antenna Replace . . . . .	 40-15-14
Bottom shaft, transmission Disassemble/inspect/assemble . . . . .	 .50-16-46	Cab wiring harness, main Replace . . . . .	 40-15-16
Brake check . . . . .	210-10-27	Center link Inspect/repair . . . . .	 .80-15-6
Brake drag adjustment . . . . .	260-15-16	Charging system operation . . . . .	240-10-12
Brake hydraulic lines Inspect/replace . . . . .	 .60-10-15	Clutch Component location . . . . .	 250-05-4
Brake pedal Excessive leak-down . . . . .	 260-15-4	Component location, PowrReverser transmission . . . . .	 250-06-4
Brake pedal adjustment . . . . .	260-15-15	PTO clutch finger adjustment . . . . .	50-10-12, 50-11-10
Brake pedals Remove/install . . . . .	 .60-10-2	Remove and install . . . . .	50-10-4
Brake system Operation . . . . .	 260-10-10	Theory of operation . . . . .	250-10-2
Brake system components . . . . .	260-05-6	Traction clutch finger adjustment . . . . .	50-10-11
Brake valve Assemble . . . . .	 .60-10-8	Clutch assembly Assemble . . . . .	 50-10-8, 50-11-6
Cross section . . . . .	60-10-7	Disassemble/inspect . . . . .	50-10-5, 50-11-3
Disassemble/inspect . . . . .	60-10-4	Remove and install . . . . .	50-10-4
Operation . . . . .	260-10-12	Remove/install . . . . .	50-11-3
Pedal adustment . . . . .	260-15-15	Clutch check . . . . .	210-10-23
Remove/install . . . . .	60-10-2	Clutch gear Disassemble/inspect/repair . . . . .	 50-12-18
Brakes Bleed brake system . . . . .	 260-15-17	Clutch housing Install engine . . . . .	 50-05-19
Excessive chatter . . . . .	260-15-4	Install to engine . . . . .	50-05-8
Install . . . . .	60-10-12	Install to transmission . . . . .	50-15-7
Remove/inspect . . . . .	60-10-10	Separate from engine . . . . .	50-05-13
Brakes diagnostics Excessive brake chatter . . . . .	 260-15-4	Separate from transmiision . . . . .	50-15-3
Excessive brake pedal leak-down . . . . .	260-15-4	Separate from transmission . . . . .	50-16-2
Isolate the problem . . . . .	260-15-3	Clutch housing seal Replace . . . . .	 50-05-25
		Clutch housing, tractors without cab Separate from engine . . . . .	 50-05-2
		Clutch pedal free play adjustment . . . . .	250-15-19
		Clutch pedal linkage adjustment PowrReverser . . . . .	 250-16-24

Page	Page
Clutch pedal linkage, CollarShift/SyncShuttle transmission	Compressor belt
Inspect/repair . . . . .50-05-27	Check . . . . .210-10-7
Clutch pedal linkage, PowrReverser transmission	Compressor drive belt adjustment
Inspect/repair . . . . .50-05-29	3-cylinder . . . . .220-15-29
Clutch pedal, CollarShift/Sync Shuttle transmission	Compressor
Inspect/repair . . . . .50-05-27	Disassemble/inspect/assemble . . . . .90-20-16
Clutch pedal, PowrReverser transmission	Condenser
Inspect/repair . . . . .50-05-29	Air conditioning, remove/inspect/install . . . .90-20-8
Clutch release mechanism and shafts	Theory of operation. . . . .290-10-5
Install . . . . .50-10-17, 50-11-14	Cone point, differential
Remove/inspect . . . . .50-10-13, 50-11-11	Adjustment . . . . .50-25-13
CollarShift transmission top shaft	Connector body blade terminals
Disassemble/inspect/assemble . . . . .50-15-42	Replace . . . . .40-15-2
CollarShift/SyncShuttle transmission	Connector, WEATHER PACK
Instrument panel, replace . . . . .40-10-11	Replace . . . . .40-15-2
Component location	Contact, WEATHER PACK
Air intake system . . . . .230-05-4, 230-05-5	Install . . . . .40-15-3
Brake system . . . . .260-05-6	Control console and panel
Clutch . . . . .250-05-4	Left side, remove/install . . . . .90-06-3, 90-15-14
Clutch, PowrReverser transmission. . . . .250-06-4	Right side, remove/install . . . . .90-06-1, 90-15-12
Engine components, LH side . . . . .220-05-2	Tractors with cab, remove/install . . . . .90-15-12, 90-15-14
Engine components, RH side . . . . .220-05-3	Tractors without cab, remove/install . . . . .90-06-1, 90-06-3
Engine components, 4-cylinder LH side . . . . .220-05-4	Control switch, air conditioning temperature
Engine components, 4-cylinder RH side . . . . .220-05-5	Replace . . . . .40-10-23
Final drive . . . . .250-05-10, 250-06-9	Control valve
Fuel system . . . . .230-05-2	Heater, install . . . . .90-25-6
Hydraulic system, with oil cooler . . . . .270-05-4	Heater, leak test . . . . .90-25-6
Hydraulic system, without oil cooler . . . . .270-05-2	Heater, remove/test/install. . . . .90-25-5
Power train . . . . .250-05-2	Control valve, PowrReverser
Power train, PowrReverser transmission . . . . .250-06-2	Disassemble/inspect/repair . . . . .50-12-3
PowrReverser . . . . .250-06-6	Remove/install . . . . .50-12-2
Rear PTO . . . . .250-05-11, 250-06-9	Controller, turn signal
Rear PTO, SyncShuttle transmission . . . . .250-05-12	Replace . . . . .40-10-10
SCV . . . . .270-05-6	Coolant
Steering system, without cab . . . . .260-05-2	Diesel engine . . . . .10-20-4
Steering system, 5510 and cab tractors . . . . .260-05-4	Coolant conditioner. . . . .10-20-5
Transmission, collar shift. . . . .250-05-6	Coolant level and condition check . . . . .210-10-3
Transmission, PowrReverser. . . . .250-06-8	Coolant temperature sender, 5210 and 5310 machines
Transmission, SyncShuttle . . . . .250-05-8	Replace . . . . .40-10-3
Compressor	Coolant temperature sender, 5410 and 5510 machines
Air conditioning, remove/inspect/install . . .90-20-10	Replace . . . . .40-10-3
Clutch hub, check clearance . . . . .90-20-19	Cooling system
Clutch, disassemble/assemble . . . . .90-20-15	Belt tensioner, inspect/replace . . . . .20-10-10
Manifold, inspect. . . . .90-20-19	Engine water pump repair. . . . .20-10-1
Oil charge, check . . . . .90-20-31	Radiator, install. . . . .20-10-5
Relief valve, remove/install . . . . .90-20-20	Radiator, remove/inspect . . . . .20-10-2
Shaft seal, test leakage. . . . .90-20-14	Thermostat, replace . . . . .20-10-8
Test volumetric efficiency. . . . .90-20-12	Cooling system test . . . . .220-15-14



	Page		Page
Creep assembly		PTO clutch finger height gauge . . . . .	299-00-1
Disassemble, inspect, and assemble . . . .	50-40-5	Traction clutch finger height adjustment	
Remove and install . . . . .	50-40-2	tool . . . . .	299-00-2
CS/SS transmission adjustments		Traction clutch finger height gauge . . . .	299-00-1
Clutch pedal free play . . . . .	250-15-19	Diesel	
PTO clutch lever . . . . .	250-15-20	Fuel . . . . .	10-20-1
CS/SS transmission diagnostics		Diesel engine oil . . . . .	10-20-3
Axle shaft will not turn . . . . .	250-15-17	Differential	
Clutch chatters . . . . .	250-15-7	Theory of operation . . . . .	250-11-34
Clutch does not engage . . . . .	250-15-4	Differential assembly	
Clutch does not release . . . . .	250-15-6	Disassemble/inspect/assemble . . . . .	50-25-5
Clutch dragging . . . . .	250-15-4	Remove/install . . . . .	50-25-3
Clutch engagement noisy . . . . .	250-15-8	Differential backlash	
Clutch grabs . . . . .	250-15-5	Adjustment . . . . .	50-25-14
Clutch pedal does not return . . . . .	250-15-9	Differential carrier assembly, MFWD	
Clutch pedal loose . . . . .	250-15-10	Assemble . . . . .	50-35-34
Clutch pedal pulsates . . . . .	250-15-10	Disassemble/inspect . . . . .	50-35-30
Clutch rattles . . . . .	250-15-8	Remove/install . . . . .	50-35-29
Clutch slips . . . . .	250-15-3	Differential cone point	
Clutch squeaks . . . . .	250-15-5	Adjustment . . . . .	50-25-13
Differential chatters . . . . .	250-15-16	Differential drive shaft	
Differential does not work . . . . .	250-15-15	Install . . . . .	50-25-8
Differential excessive noise . . . . .	250-15-15	Remove/inspect . . . . .	50-25-6
Final drive axle noise . . . . .	250-15-17	Differential lock	
Gears clash/shift hard/will not engage . .	250-15-11	Theory of operation . . . . .	250-10-28
Isolate the problem area . . . . .	250-15-2	Differential lock assembly	
Low oil level . . . . .	250-15-11	Remove/inspect/install . . . . .	50-25-11
MFWD lever hard to engage . . . . .	250-15-18	Differential lock check . . . . .	210-10-21
MFWD lever will not stay "ON" . . . . .	250-15-18	Differential power flow	
MFWD noisy . . . . .	250-15-19	Theory of operation . . . . .	250-10-26
No differential lock . . . . .	250-15-16	Dome light	
Noisy . . . . .	250-15-13	Replace . . . . .	40-10-25
PTO hard to engage . . . . .	250-15-14	Dome light operation	
PTO noisy . . . . .	250-15-13	Cab only . . . . .	240-10-48
PTO will not operate . . . . .	250-15-14	Dome light switch	
PTO will not stay engaged . . . . .	250-15-14	Replace . . . . .	40-10-26
Rough or jerky movement . . . . .	250-15-10	Doors, cab	
Traction clutch, excessive vibration . . . .	250-15-9	Remove/install . . . . .	90-15-9
Two speeds engage . . . . .	250-15-12	Double-acting sleeve coupler operation . .	270-10-36
Will not stay in gear . . . . .	250-15-12	Draw bar and support	
Cutch housing		Remove/install . . . . .	80-15-8
Install to transmission . . . . .	50-16-7	Drive assembly, final	
Cylinder compression pressure test . . . .	220-15-18	Remove/install . . . . .	50-30-2
		Drive assembly, planetary	
		Install . . . . .	50-30-6
		Remove/inspect . . . . .	50-30-4
		Drive shaft, differential	
		Install . . . . .	50-25-8
		Remove/inspect . . . . .	50-25-6
		Drive shaft, MFWD	
		Remove/install . . . . .	50-35-15
		Drive, MFWD outer	
		Assemble . . . . .	50-35-22

## D

Dealer fabricated tools	
Compressor holding fixture . . . . .	299-00-5
Final drive turning tool . . . . .	299-00-3
JDG919 clutch finger height gauge . . . .	299-00-2
Nozzle assembly . . . . .	299-00-4

	Page		Page
Disassemble/inspect . . . . .	50-35-19	Rear work light, tractors without cab . . .	240-15-28
Driven shaft		Relay and trailer connector . . . . .	240-15-73
Disassemble/inspect/assemble . . . . .	50-15-48	Starting system, bypass attempt . . . . .	240-15-8
Disassemble/inspect/repair . . . . .	50-12-19	Starting system, normal operation . . . . .	240-15-4
Drop gearbox, MFWD		Tachometer/hourmeter . . . . .	240-15-51
Assemble . . . . .	50-35-11	Tail lights, tractors with cab . . . . .	240-15-40
Cross section . . . . .	50-35-10	Tail lights, tractors without cab . . . . .	240-15-37
Disassemble/inspect . . . . .	50-35-7	Temperature gauge . . . . .	240-15-57
Remove/install . . . . .	50-35-6	Turn signals, tractors with cab . . . . .	240-15-21
Dual selective control valve		Turn signals, tractors without cab . . . . .	240-15-18
Disassemble/inspect/assemble . . . . .	70-15-11	Warning lights . . . . .	240-15-26
Hydraulic hoses, inspect/replace . . . . .	70-15-14	Electrical system tests	
Remove/install . . . . .	70-15-9	A/C thermostatic control switch . . . . .	240-15-115
		Alternator/regulator . . . . .	240-15-100
<b>E</b>		Battery load . . . . .	240-15-95
Electrical		Battery voltage and specific gravity . . . .	240-15-91
Component identification . . . . .	240-20-1	Blower motor resistors . . . . .	240-15-114
Electrical components		Blower switch . . . . .	240-15-113
Cab control panel . . . . .	240-05-10	Charge battery . . . . .	240-15-93
Dash . . . . .	240-05-3	Diode pack . . . . .	240-15-105
Engine, 4-cylinder . . . . .	240-05-2	Dome light switch . . . . .	240-15-119
Tractor with cab . . . . .	240-05-8	Door switch . . . . .	240-15-118
Tractor without cab . . . . .	240-05-5, 240-05-6	Front wiper/washer switch . . . . .	240-15-116
Electrical repair		Fuel shut-off solenoid . . . . .	240-15-112
Alternator/regulator, replace . . . . .	40-05-6, 40-05-7	Key switch . . . . .	240-15-103
Battery, remove/install . . . . .	40-05-2, 40-05-3	Light switch . . . . .	240-15-110
Starter . . . . .	40-05-1	Neutral start switch . . . . .	240-15-107
Starter, remove/install . . . . .	40-05-4, 40-05-5	Plug-in relay . . . . .	240-15-104
Electrical schematics		PTO seat switch . . . . .	240-15-109
Models with cab . . . . .	240-20-6	PTO switch . . . . .	240-15-108
Models without cab . . . . .	240-20-4	Rear wiper/washer switch . . . . .	240-15-117
Electrical system check . . . . .	210-10-10	Starter amp draw/rpm . . . . .	240-15-97
Electrical system diagnostics		Starter no-load amp draw/rpm . . . . .	240-15-99
A/C compressor clutch coil test points (with		Starter relay . . . . .	240-15-102
cab) . . . . .	240-15-81	Starter solenoid . . . . .	240-15-101
Air filter restriction . . . . .	240-15-67	Turn signal controller . . . . .	240-15-111
Blower motor test points (with cab) . . . .	240-15-76	Electrical wire color chart . . . . .	240-15-2
Charging system . . . . .	240-15-14	Elements, air cleaner, 5210 and 5310 machines	
Dome light, tractors with cab . . . . .	240-15-48	Remove/inspect/install . . . . .	30-10-2
Flood lights, tractors with cab . . . . .	240-15-31	Elements, air cleaner, 5410 and 5510 machines	
Front wiper/washer test points (with		Remove/inspect/install . . . . .	30-10-4
cab) . . . . .	240-15-83	Engine	
Fuel gauge . . . . .	240-15-54	Install, tractors with cab . . . . .	20-05-22
Headlights and instrument lights . . . . .	240-15-43	Install, tractors without cab . . . . .	20-05-9
Manifold heater . . . . .	240-15-11	Remove, tractors with cab . . . . .	20-05-14
Oil pressure . . . . .	240-15-60	Remove, tractors without cab . . . . .	20-05-3
Optional horn . . . . .	240-15-71	Repair . . . . .	20-05-2
PTO warning system . . . . .	240-15-64	Water pump repair . . . . .	20-10-1
Rear wiper/washer test points (with		Engine coolant	
cab) . . . . .	240-15-87	Conditioner . . . . .	10-20-5
		Engine cooling system operation	
		3-cylinder . . . . .	220-10-6
		4-cylinder . . . . .	220-10-8

	Page
Engine diagnostics	
Coolant in oil . . . . .	220-15-12
Coolant temperature incorrect . . . . .	220-15-11
Excess noise or vibration . . . . .	220-15-9
Low oil pressure . . . . .	220-15-10
Low power . . . . .	220-15-4
Oil in coolant . . . . .	220-15-12
Runs irregularly . . . . .	220-15-3
Runs rough . . . . .	220-15-4
Smokes black or grey . . . . .	220-15-6
Smokes blue . . . . .	220-15-10
Smokes excessively white . . . . .	220-15-7
Stalls frequently . . . . .	220-15-3
Starts hard . . . . .	220-15-2
Turns over, will not start . . . . .	220-15-2
Uses excess fuel . . . . .	220-15-8
Uses excess oil . . . . .	220-15-10
Engine external component location	
Left-hand side . . . . .	220-05-2
Right-hand side . . . . .	220-05-3
4-cylinder left-hand side . . . . .	220-05-4
4-cylinder right-hand side . . . . .	220-05-5
Engine fast and slow idle operation . . . . .	210-10-19
Engine lubrication system operation . . . . .	220-10-2
Engine oil	
Diesel . . . . .	10-20-3
Engine oil level and condition check . . . . .	210-10-2
Engine oil pressure switch	
Replace . . . . .	40-10-4
Engine oil pressure test . . . . .	220-15-16
Engine speed sensor	
Replace . . . . .	40-10-4
Engine start check . . . . .	210-10-16
Engine, tractors with cab	
Install to clutch housing . . . . .	50-05-19
Separate from clutch housing . . . . .	50-05-13
Engine, tractors without cab . . . . .	50-05-8
Separate from clutch housing . . . . .	50-05-2
Evaporator	
Theory of operation . . . . .	290-10-8
Evaporator/heater	
Core housing cover, remove/install . . . . .	90-20-21
Core, install . . . . .	90-20-26
Core, leak test . . . . .	90-20-25
Core, remove . . . . .	90-20-24
Expansion valve	
Bench test . . . . .	90-20-29
Bench test, diagram . . . . .	90-20-28
Service . . . . .	90-20-27
Theory of operation . . . . .	290-10-7

## F

F-N-R Control Lever	
Remove and replace . . . . .	50-16-53
Fan and serpentine belt check . . . . .	210-10-6
Fan and V-belt check . . . . .	210-10-5
Fan/alternator V-belt adjustment . . . . .	220-15-27
Fast idle adjustment . . . . .	220-15-22
Feedback linkage, rockshaft	
Draft-sensing adjustment . . . . .	270-19-6
Position-sensing adjustment . . . . .	270-19-2
Filter, air	
Restriction switch, replace . . . . .	40-10-2
Filter, fuel, 5410 and 5510 machines	
Replace . . . . .	30-05-9
Filter, fuel/primer pump assembly, 5210 and 5310 machines	
Remove/install . . . . .	30-05-8
Filter, fuel/primer pump assembly, 5410 and 5510 machines	
Remove/install . . . . .	30-05-9
Final drive	
Component location . . . . .	250-05-10, 250-06-9
Theory of operation . . . . .	250-10-30, 250-11-34
Final drive assembly	
Remove/install . . . . .	50-30-2
Fixed draft links	
Inspect/repair . . . . .	80-15-2
Flood light operation	
Tractors with cab . . . . .	240-10-38
Flood lights	
Tractors with cab . . . . .	240-15-31
Floor plate, cab	
Early model tractors, remove/install . . . . .	90-15-35
Later model tractors, remove/install . . . . .	90-15-29
Forward-Neutral-Reverse Cable	
adjustment . . . . .	250-16-18
Front axle, 2WD	
Remove and install . . . . .	80-05-1
Front axle, 2WD pivot pin and bushing	
Inspect/replace . . . . .	80-05-4
Front axle, 2WD spindle assembly	
Remove/install . . . . .	80-05-5
Front axle, 2WD spindle shaft bushings	
Inspect/replace . . . . .	80-05-6
Front axle, 2WD wheel bearings	
Inspect/replace . . . . .	80-10-2
Front headliner	
Remove/install . . . . .	90-15-3
Front wiper/washer operation	
Cab only . . . . .	240-10-44
Front wiring harness, 3-cylinder engine	
Replace . . . . .	40-15-6

Indx  
7

	Page		Page
Hydraulic filter operation (later model tractors) . . . . .	270-10-6	Remote cylinder operates too slow . . . . .	270-15-12
Hydraulic filter/manifold (early model tractors)		Remote cylinder settles under load . . . . .	270-15-12
Remove/install . . . . .	70-05-15	Rockshaft does not lift. . . . .	270-15-8
Hydraulic filter/manifold (later model tractors)		Rockshaft does not lower . . . . .	270-15-9
Remove/install . . . . .	70-05-16	Rockshaft drops/unstable . . . . .	270-15-9
Hydraulic oil check . . . . .	210-10-4	Rockshaft lifts slowly. . . . .	270-15-8
Hydraulic oil cooler		Rockshaft lowers slowly . . . . .	270-15-9
Remove/inspect/install. . . . .	70-06-1	SCV joystick does not remain in	
Hydraulic oil pick-up screen		detent . . . . .	270-15-11
Remove/inspect/install. . . . .	70-05-2	SCV joystick does not return. . . . .	270-15-10
Hydraulic pump		Slow pump response . . . . .	270-15-7
Assemble, 5210 and 5310 machines . . . . .	70-05-7	Hydraulic system operation . . . . .	270-10-2
Assemble, 5410 and 5510 machines . . . . .	70-05-13	Hydraulic system tests, all	
Disassemble/inspect, 5210 and 5310 machines. . . . .	70-05-5	Rockshaft leakage . . . . .	270-18-1
Disassemble/inspect, 5410 and 5510 machines. . . . .	70-05-11	Rockshaft lift cycle . . . . .	270-18-3
Install external components, 5210 and 5310 machines. . . . .	70-05-8	Hydraulic system tests, with SCV	
Install external components, 5410 and 5510 machines. . . . .	70-05-14	Hydraulic system. . . . .	270-17-1
Install, 5410 and 5510 machines. . . . .	70-05-9	Main relief valve . . . . .	270-17-5
Remove external components, 5210 and 5310 machines. . . . .	70-05-4	Pump flow. . . . .	270-17-3
Remove external components, 5410 and 5510 machines. . . . .	70-05-10	SCV leakage. . . . .	270-17-6
Remove/install, 5210 and 5310 machines. . . . .	70-05-3	Hydraulic system tests, without SCV	
Hydraulic pump operation. . . . .	270-10-8	Hydraulic system. . . . .	270-16-1
Hydraulic reverser control lever		Main relief valve . . . . .	270-16-5
Remove and replace. . . . .	50-16-53	Pump flow. . . . .	270-16-3
Hydraulic schematic			
Power beyond. . . . .	270-20-8		
With selective control valves . . . . .	270-20-6		
Without selective control valves . . . . .	270-20-4		
Hydraulic supply/return line			
Inspect/replace . . . . .	70-05-17		
Hydraulic system check . . . . .	210-10-11		
Hydraulic system components			
With oil cooler. . . . .	270-05-4		
Without oil cooler . . . . .	270-05-2		
Hydraulic system diagnostics			
Entire system fails to function . . . . .	270-15-4		
Excessive pump noise . . . . .	270-15-8		
Excessive pump pressure . . . . .	270-15-6		
Hydraulic functions too slow . . . . .	270-15-5		
Hydraulic oil warm-up . . . . .	270-15-3		
Insufficient pump delivery . . . . .	270-15-5		
Preliminary system inspection. . . . .	270-15-2		
Remote cylinder does not extend . . . . .	270-15-11		
Remote cylinder does not retract . . . . .	270-15-11		
Remote cylinder operates too fast. . . . .	270-15-12		

## I

Inch torque values . . . . .	10-10-26
Indicator lamps check. . . . .	210-10-13
Injection nozzle	
Repair. . . . .	30-05-1
Injection pump	
Repair. . . . .	30-05-1
Injection pump timing adjustment . . . . .	220-15-23
Instrument panel	
CollerShift/SyncShuttle, replace . . . . .	40-10-11
PowrReverser, replace . . . . .	40-10-13
Instrument panel system operation	
Fuel gauge . . . . .	240-10-24
Hourmeter. . . . .	240-10-28
Tachometer. . . . .	240-10-22
Temperature gauge. . . . .	240-10-26

## J

Joystick and linkage	
Inspect/repair, tractors with cab . . . . .	70-15-5
Inspect/repair, tractors without cab . . . . .	70-15-3



	Page		Page
<b>K</b>			
Key switch		Main relief valve	
Replace . . . . .	40-10-6	Adjustment . . . . .	270-19-7
Kits		Main relief valve operation . . . . .	270-10-20
Service Parts . . . . .	50-10-3	Manifold heater system operation . . . . .	240-10-10
Kits and accessories . . . . .	10-30-6	Metric torque values . . . . .	10-10-25
<b>L</b>		MFWD	
Lever and linkage, MFWD		Gear oil. . . . .	10-20-7
Inspect/repair . . . . .	50-35-5	Gear oil, check . . . . .	210-10-12
Lever and linkage, rear PTO		Operational check . . . . .	210-10-26
Inspect/repair . . . . .	50-20-2	Theory of operation . . . . .	250-10-32, 250-11-34
Lever, gear shift		MFWD and range gears	
Inspect/repair . . . . .	50-15-11	Remove/inspect/install. . . . .	50-15-50, 50-16-52
Lever, range shift		MFWD axle housing assembly	
Inspect/repair . . . . .	50-15-13	Remove/install . . . . .	50-35-16
Lift link adjustable		MFWD axle shaft	
Inspect/repair . . . . .	80-15-5	Remove/inspect/install. . . . .	50-35-27
Lift link standard		MFWD axle supports	
Inspect/repair . . . . .	80-15-4	Remove/install . . . . .	50-35-18
Light switch, dome		MFWD differential carrier assembly	
Replace . . . . .	40-10-26	Assemble . . . . .	50-35-34
Light switch, tractor		Disassemble/inspect . . . . .	50-35-30
Replace . . . . .	40-10-7	Remove/install . . . . .	50-35-29
Light, dome		MFWD drive shaft	
Replace . . . . .	40-10-25	Remove/install . . . . .	50-35-15
Lighting system operation		MFWD drop gearbox	
Headlights . . . . .	240-10-20	Assemble . . . . .	50-35-11
Instrument lights . . . . .	240-10-20	Cross section . . . . .	50-35-10
Tail light . . . . .	240-10-18	Disassemble/inspect . . . . .	50-35-7
Turn signals . . . . .	240-10-14	Remove/install . . . . .	50-35-6
Warning lights . . . . .	240-10-16	MFWD lever and linkage	
Lights, cab wiring harness		Inspect/repair . . . . .	50-35-5
Replace . . . . .	40-15-12	MFWD outer drive	
Linkage and lever, MFWD		Assemble . . . . .	50-35-22
Inspect/repair . . . . .	50-35-5	Disassemble/inspect . . . . .	50-35-19
Linkage and lever, rear PTO		MFWD steering stop adjustment . . . . .	260-15-14
Inspect/repair . . . . .	50-20-2	MFWD swivel housing	
Linkage, speed control		Remove/inspect/install. . . . .	50-35-24
Inspect/repair . . . . .	30-15-1, 30-15-2	Mid mount coupler	
Lock assembly, differential		Hydraulic hoses, inspect/replace (with	
Remove/inspect/install. . . . .	50-25-11	cab) . . . . .	70-20-4
Lubricant		Hydraulic hoses, inspect/replace (without	
Storage . . . . .	10-20-9	cab) . . . . .	70-20-2
Lubrication system, PowrReverser		Miscellaneous checks . . . . .	210-10-31
Theory of operation . . . . .	250-11-32	Motor, wiper	
<b>M</b>		Replace . . . . .	40-10-22
Main cab wiring harness		<b>N</b>	
Replace . . . . .	40-15-16	Neutral start switch	
		Replace . . . . .	40-10-17

	Page		Page
<b>O</b>			
O-ring boss fittings . . . . .	10-10-21	Park brake cable adjustment	
Oil pressure switch, engine		PowrReverser . . . . .	250-16-25
Replace . . . . .	40-10-4	Pivot pin and bushings, 2WD Axle	
Operational tests and checks		Inspect/replace . . . . .	80-05-4
A/C compressor clutch . . . . .	210-10-15	Planetary drive assembly	
A/C system . . . . .	210-10-30	Install . . . . .	50-30-6
Air intake system . . . . .	210-10-9	Remove/inspect . . . . .	50-30-4
Brakes . . . . .	210-10-27	Power beyond	
Cab blower motor . . . . .	210-10-14	Hydraulic lines/fittings, inspect and	
Cab heater valve . . . . .	210-10-30	replace . . . . .	70-25-2
Clutch . . . . .	210-10-23	Hydraulic schematic . . . . .	270-20-8
Compressor belt . . . . .	210-10-7	Power beyond hydraulic lines	
Coolant level and condition . . . . .	210-10-3	Inspect and replace . . . . .	70-25-7
Differential lock . . . . .	210-10-21	Power steering check . . . . .	210-10-20
Electrical system . . . . .	210-10-10	Power train	
Engine fast and slow idle . . . . .	210-10-19	Component location . . . . .	250-05-2
Engine oil level and condition . . . . .	210-10-2	Component location, PowrReverser	
Engine start . . . . .	210-10-16	transmission . . . . .	250-06-2
Fan and serpentine belt . . . . .	210-10-6	PowrReverser	
Fan and V-belt . . . . .	210-10-5	Disassemble/inspect/repair . . . . .	50-12-20
Fuel system . . . . .	210-10-8	Remove/install . . . . .	50-12-13
Hydraulic system . . . . .	210-10-11	PowrReverser control valve	
Indicator lamps . . . . .	210-10-13	Disassemble/inspect/repair . . . . .	50-12-3
MFWD drive . . . . .	210-10-26	Remove/install . . . . .	50-12-2
MFWD oil . . . . .	210-10-12	Theory of operation . . . . .	250-11-14, 250-11-16, 250-11-18, 250-11-20, 250-11-24
Miscellaneous . . . . .	210-10-31	PowrReverser diagnostics	
Power steering . . . . .	210-10-20	Axle troubleshooting . . . . .	250-16-9
PTO engagement . . . . .	210-10-22	Clutch pedal does not return . . . . .	250-16-5
PTO neutral start . . . . .	210-10-18	Clutch pedal linkage adjustment . . . . .	250-16-24
Range lever shift . . . . .	210-10-25	Control valve tests . . . . .	250-16-10
Rockshaft . . . . .	210-10-28	Differential troubleshooting . . . . .	250-16-9
Selective Control Valve . . . . .	210-10-29	Does not disengage . . . . .	250-16-6
Transmission neutral start . . . . .	210-10-17	Engages too quickly or too slowly . . . . .	250-16-6
Transmission shift . . . . .	210-10-24	Gears clash/shift hard/will not engage . . . . .	250-16-7
Transmission/hydraulic oil . . . . .	210-10-4	Isolate the problem area . . . . .	250-16-2
Operator station		Low oil level . . . . .	250-16-4
Component location, air conditioning . . . . .	290-05-2	MFWD troubleshooting . . . . .	250-16-9
Optional equipment		Park brake cable adjustment . . . . .	250-16-25
Field installed . . . . .	10-30-6	PTO lever and linkage adjustment . . . . .	250-16-27
Outer drive, MFWD		PTO troubleshooting . . . . .	250-16-9
Assemble . . . . .	50-35-22	Pump flow test . . . . .	250-16-17
Disassemble/inspect . . . . .	50-35-19	Tractor does not move in forward or	
		reverse . . . . .	250-16-5
		Transmission noisy . . . . .	250-16-8
		Two speeds engage . . . . .	250-16-7
		Will not stay in gear . . . . .	250-16-8
		PowrReverser F-N-R Shift Control Lever Cable	
		adjust . . . . .	250-16-18
		PowrReverser in forward	
		Theory of operation . . . . .	250-11-7
		PowrReverser in reverse	
		Theory of operation . . . . .	250-11-10
<b>P</b>			
Panel, instrument			
CollerShift/SyncShuttle, replace . . . . .	40-10-11		
PowrReverser, replace . . . . .	40-10-13		

	Page		Page
PowrReverser power flow		Range and MFWD gears	
Theory of operation . . . . .	250-11-12	Remove/inspect/install. . . . .	50-15-50, 50-16-52
PowrReverser Transmission		Range lever shift check. . . . .	210-10-25
Instrument panel, replace . . . . .	40-10-13	Range reduction shaft	
PowrReverser, general information		Disassemble/inspect/assemble . . . . .	50-15-47, 50-16-49
Theory of operation . . . . .	250-11-6	Range shift lever	
Preliminary system inspection . . . . .	270-15-2	Inspect/repair . . . . .	50-15-13
Primer pump assembly, 5210 and 5310 machines		Range shift power flow, PowrReverser	
Remove/install . . . . .	30-05-8	Theory of operation . . . . .	250-11-30
Primer pump assembly, 5410 and 5510 machines		Rate-of-drop valve operation	
Remove/install . . . . .	30-05-9	Full closed . . . . .	270-10-24
PTO Clutch disengaged (PowrReverser™)		Full open. . . . .	270-10-22
Theory of operation . . . . .	250-11-4	Rear headliner	
PTO Clutch engaged (PowrReverser™)		Remove/install . . . . .	90-15-4
Theory of operation . . . . .	250-11-2	Rear PTO	
PTO clutch finger		Component location . . . . .	250-05-11, 250-06-9
Adjustment . . . . .	50-10-12, 50-11-10	Component location, SyncShuttle	
PTO clutch lever adjustment. . . . .	250-15-20	transmission . . . . .	250-05-12
PTO drive shaft assembly, rear		Theory of operation . . . . .	250-10-22, 250-11-33
Remove/install . . . . .	50-20-5	Rear PTO drive shaft assembly	
PTO drive shaft assembly, rear, 540/540E		Remove/install . . . . .	50-20-5
Disassemble/inspect/assemble . . . . .	50-20-10	Rear PTO drive shaft assembly, standard	
Remove/install . . . . .	50-20-9	Disassemble/inspect/assemble . . . . .	50-20-6
PTO drive shaft assembly, standard rear		Rear PTO drive shaft assembly, 540/540E	
Disassemble/inspect/assemble . . . . .	50-20-6	Disassemble/inspect/assemble . . . . .	50-20-10
PTO engagement check. . . . .	210-10-22	Remove/install . . . . .	50-20-9
PTO lever and linkage adjustment		Rear PTO lever and linkage	
PowrReverser . . . . .	250-16-27	Inspect/repair . . . . .	50-20-2
PTO lever and linkage, rear		Rear PTO switch, tractors with cab	
Inspect/repair . . . . .	50-20-2	replace . . . . .	40-10-16
PTO neutral start check . . . . .	210-10-18	Rear PTO switch, tractors without cab	
PTO switch, rear		Replace . . . . .	40-10-16
Replace . . . . .	40-10-16	Rear PTO, SyncShuttle	
replace . . . . .	40-10-16	Theory of operation . . . . .	250-10-24
PTO warning system operation. . . . .	240-10-30	Rear wiper/washer operation	
PTO 540/540E shift lever and linkage		Cab only . . . . .	240-10-46
Inspect/repair . . . . .	50-20-4	Rear wiring harness, tractors with cab	
Pump, transmission		Replace . . . . .	40-15-10
Remove/inspect/repair. . . . .	50-11-16	Rear wiring harness, tractors without cab	
		Replace . . . . .	40-15-8
		Rear work light	
		Tractors without cab . . . . .	240-15-28
		Rear work light operation . . . . .	240-10-34
		Rear 540/540E PTO drive shaft assembly	
		Disassemble/inspect/assemble . . . . .	50-20-10
		Receiver-dryer	
		Air conditioning, replace . . . . .	90-20-7
		Theory of operation . . . . .	290-10-6
		Refrigerant	
		Air conditioning, recover/recycle . . . . .	90-20-6
		Refrigerant oil	
		Add to system. . . . .	90-20-34

## R

Radiator	
Install . . . . .	20-10-5
Remove/inspect . . . . .	20-10-2
Radiator bubble test . . . . .	220-15-13
Radiator cap pressure test . . . . .	220-15-15
Radio	
Replace . . . . .	40-10-8
Radio/antenna, cab wiring harness	
Replace . . . . .	40-15-14





	Page		Page
Shaft, range reduction		Steering pump flow test . . . . .	260-15-5
Disassemble/inspect/assemble . . . . .	50-15-47, 50-16-49	Steering system	
Shaft, reverse idler		Component location, without cab . . . . .	260-05-2
Remove/inspect/install. . . . .	50-15-51	Component location, 5510 and cab tractors . . . . .	260-05-4
Shaft, top		Operation, without cab . . . . .	260-10-2
Disassemble/inspect/assemble . . . . .	50-16-50	Operation, 5510 and cab tractors . . . . .	260-10-4
Shift lever and linkage, PTO 540/540E		Steering system tests	
Inspect/repair . . . . .	50-20-4	Cylinder leakage . . . . .	260-15-7
Slow idle adjustment . . . . .	220-15-21	Pump flow . . . . .	260-15-5
Speakers		Steering valve relief . . . . .	260-15-6
Replace . . . . .	40-10-8	Valve leakage . . . . .	260-15-8
Specifications		Steering valve	
5210 and 5310 . . . . .	10-10-1	Assemble . . . . .	60-05-7
5410 . . . . .	10-10-10	Disassemble/inspect . . . . .	60-05-4
5510 . . . . .	10-10-16	Remove/install . . . . .	60-05-3
Speed control linkage		Steering valve leakage test . . . . .	260-15-8
Inspect/repair . . . . .	30-15-1, 30-15-2	Steering valve operation	
Speed sensor, engine		Neutral and manual turning . . . . .	260-10-6
Replace . . . . .	40-10-4	Power turning . . . . .	260-10-8
Spindle assembly, 2WD axle		Steering valve relief test . . . . .	260-15-6
Inspect/replace bushings. . . . .	80-05-6	Storing lubricants . . . . .	10-20-9
Remove/install . . . . .	80-05-5	Supports, MFWD axle	
Standard features		Remove/install . . . . .	50-35-18
5210 and 5310 machines . . . . .	10-30-2	Surge relief valve operation . . . . .	270-10-18
Standard rear PTO drive shaft assembly		Switch, air conditioning temperature control	
Disassemble/inspect/assemble . . . . .	50-20-6	Replace . . . . .	40-10-23
Start system operation		Switch, air filter restriction	
Bypass attempt . . . . .	240-10-8	Replace . . . . .	40-10-2
Normal . . . . .	240-10-6	Switch, blower control	
Starter		Replace . . . . .	40-10-22
Repair . . . . .	40-05-1	Switch, dome light	
Starter, 5210 and 5310 machines		Replace . . . . .	40-10-26
Remove/install . . . . .	40-05-4	Switch, engine oil pressure	
Starter, 5410 and 5510 machines		Replace . . . . .	40-10-4
Remove/install . . . . .	40-05-5	Switch, key	
Steering column		Replace . . . . .	40-10-6
Remove/install . . . . .	60-05-3	Switch, neutral start	
Steering cylinder		Replace . . . . .	40-10-17
Disassemble/inspect/assemble, MFWD		Switch, PTO, rear	
axle . . . . .	60-05-15	Replace . . . . .	40-10-16
Disassemble/inspect/assemble, 2WD		Switch, seat	
axle . . . . .	60-05-12	Replace . . . . .	40-10-17
Remove/install, MFWD axle . . . . .	60-05-13	Switch, tractor light	
Remove/install, 2WD axle . . . . .	60-05-11	Replace . . . . .	40-10-7
Steering cylinder leakage test . . . . .	260-15-7	Switch, wiper control	
Steering diagnostics		Replace . . . . .	40-10-21
Isolate the problem . . . . .	260-15-2	Swivel housing, MFWD	
Loss of steering . . . . .	260-15-3	Remove/inspect/install. . . . .	50-35-24
Sluggish . . . . .	260-15-3	SyncShuttle transmission top shaft	
Steering hydraulic lines		Disassemble/inspect/assemble . . . . .	50-15-44
Inspect/replace, with oil cooler . . . . .	60-05-20		
Inspect/replace, without oil cooler . . . . .	60-05-18		

	Page		Page
<b>T</b>		Transmission, gear shift	
Tail lights		(SyncShuttle) . . . . .	250-10-14
Tractors with cab . . . . .	240-15-40	Transmission, range shift . . . . .	250-10-20
Tractors without cab . . . . .	240-15-37	Theory of operation, electrical	
Telescoping draft links		A/C compressor, cab only . . . . .	240-10-42
Inspect/repair . . . . .	80-15-3	Accessory relay . . . . .	240-10-36
Temperature control switch, air conditioning		Air filter indicator . . . . .	240-10-32
Replace . . . . .	40-10-23	Blower motor, tractors with cab . . . . .	240-10-40
Terminals, blade, connector body		Charging system . . . . .	240-10-12
Replace . . . . .	40-15-2	Dome light, cab only . . . . .	240-10-48
Theory of operation		Flood light, tractors with cab . . . . .	240-10-38
A/C temperature control switch . . . . .	290-10-8	Front wiper/washer, cab only . . . . .	240-10-44
Air conditioning system air flow . . . . .	290-10-2	Fuel gauge . . . . .	240-10-24
Air conditioning system cycle . . . . .	290-10-3	Headlights . . . . .	240-10-20
Brake system . . . . .	260-10-10	Horn . . . . .	240-10-35
Brake valve . . . . .	260-10-12	Hourmeter . . . . .	240-10-28
Clutch . . . . .	250-10-2	Instrument lights . . . . .	240-10-20
Compressor . . . . .	290-10-4	Manifold heater . . . . .	240-10-10
Condenser . . . . .	290-10-5	PTO warning . . . . .	240-10-30
Differential . . . . .	250-11-34	Rear wiper/washer, cab only . . . . .	240-10-46
Differential lock . . . . .	250-10-28	Rear work light operation . . . . .	240-10-34
Differential power flow . . . . .	250-10-26	Relays . . . . .	240-10-5
Evaporator . . . . .	290-10-8	Start system, bypass . . . . .	240-10-8
Expansion valve . . . . .	290-10-7	Start system, normal . . . . .	240-10-6
Final drive . . . . .	250-10-30, 250-11-34	Tachometer . . . . .	240-10-22
Gear shift power flow, PowrReverser . . . . .	250-11-26	Tail light . . . . .	240-10-18
Gear shift synchronizer,		Temperature gauge . . . . .	240-10-26
PowrReverser . . . . .	250-11-28	Trailer connector . . . . .	240-10-36
Heater temp control knob . . . . .	290-10-9	Turn signals . . . . .	240-10-14
High/low pressure switches . . . . .	290-10-9	Warning lights . . . . .	240-10-16
Lubrication system, PowrReverser . . . . .	250-11-32	Theory of operation, engine	
MFWD . . . . .	250-10-32, 250-11-34	Lubrication system . . . . .	220-10-2
PowrReverser control valve . . . . .	250-11-14,	3-cylinder cooling system . . . . .	220-10-6
250-11-16, 250-11-18, 250-11-20, 250-11-24		4-cylinder cooling system . . . . .	220-10-8
PowrReverser in forward . . . . .	250-11-7	Theory of operation, fuel/air	
PowrReverser in reverse . . . . .	250-11-10	Air intake . . . . .	230-10-8, 230-10-10
PowrReverser power flow . . . . .	250-11-12	Fuel filter/priming pump . . . . .	230-10-4
PowrReverser, general information . . . . .	250-11-6	Fuel injection nozzle . . . . .	230-10-6
Range shift power flow,		Fuel system . . . . .	230-10-2
PowrReverser . . . . .	250-11-30	Turbocharger . . . . .	230-10-12
Rear PTO . . . . .	250-10-22, 250-11-33	Theory of operation, hydraulics	
Rear PTO, SyncShuttle . . . . .	250-10-24	Double-acting sleeve coupler . . . . .	270-10-36
Receiver-dryer . . . . .	290-10-6	Filter (early model tractors) . . . . .	270-10-4
Refrigerant R134a . . . . .	290-10-1	Filter (later model tractors) . . . . .	270-10-6
Steering system, without cab . . . . .	260-10-2	Main relief valve . . . . .	270-10-20
Steering system, 5510 and cab		Pump . . . . .	270-10-8
tractors . . . . .	260-10-4	Rate-of-drop full closed . . . . .	270-10-24
Steering valve, neutral and manual		Rate-of-drop full open . . . . .	270-10-22
turning . . . . .	260-10-6	Rockshaft draft-sensing . . . . .	270-10-25
Steering valve, power turning . . . . .	260-10-8	Rockshaft valve, lower . . . . .	270-10-16
Transmission lubrication system . . . . .	250-10-10	Rockshaft valve, neutral . . . . .	270-10-12
Transmission, gear shift (collar) . . . . .	250-10-12	Rockshaft valve, raise . . . . .	270-10-14
		Rockshaft valves, flow regulator . . . . .	270-10-10

Page	Page
SCV, boom spool float . . . . .270-10-32	Component location, SyncShuttle . . . . .250-05-8
SCV, bucket spool regenerative position . . . . .270-10-34	Disassemble and inspect . . . . .50-15-19
SCV, extend/retract. . . . .270-10-30	Disassemble/inspect . . . . .50-16-19
SCV, neutral . . . . .270-10-28	Install . . . . .50-15-32
Surge relief valve . . . . .270-10-18	Install clutch housing. . . . .50-15-7, 50-16-7
System . . . . .270-10-2	Remove . . . . .50-15-15
Theory of operation, power train	Separate clutch housing . . . . .50-15-3, 50-16-2
PowrReverser™	Transmission bottom shaft
Clutch disengaged. . . . .250-11-4	Disassemble/inspect/assemble . . . . .50-16-46
Clutch engaged . . . . .250-11-2	Transmission gear shift (SyncShuttle)
Theory of operation, transmission synchronizer	Theory of operation. . . . .250-10-14
Reverse and 2nd gear, SyncShuttle . . .250-10-16	Transmission (Hyd Rev)
1st and 3rd gear, SyncShuttle. . . . .250-10-18	Install . . . . .50-16-30
Thermostat	Remove . . . . .50-16-12
Replace . . . . .20-10-8	Transmission lubrication system
Three-point hitch	Theory of operation. . . . .250-10-10
Adjustable lift link, inspect/repair . . . . .80-15-5	Transmission neutral start check . . . . .210-10-17
Center link, inspect/repair . . . . .80-15-6	Transmission oil check. . . . .210-10-4
Fixed draft links, inspect/repair . . . . .80-15-2	Transmission pump
Standard lift link, inspect/repair . . . . .80-15-4	Remove/inspect/repair. . . . .50-11-16
Telescoping draft links, inspect/repair . . .80-15-3	Transmission range shift
Throttle lever adjustment . . . . .220-15-20	Theory of operation. . . . .250-10-20
Tie rod assembly	Transmission shift check . . . . .210-10-24
Remove/inspect/install, MFWD axle . . . .60-05-17	Transmission synchronizer operation
Remove/inspect/install, 2WD axle . . . .60-05-16	Cone-type . . . . .250-10-18
Toe-in check and adjustment	Disk-and-plate type . . . . .250-10-16
MFWD . . . . .260-15-12	Reverse and 2nd gear, SyncShuttle . . .250-10-16
Standard axle . . . . .260-15-10	1st and 3rd gear, SyncShuttle. . . . .250-10-18
Top shaft	Transmission top shaft, CollarShift
Disassemble/inspect/assemble . . . . .50-16-50	Disassemble/inspect/assemble . . . . .50-15-42
Top shaft, CollarShift transmission	Transmission top shaft, SyncShuttle
Disassemble/inspect/assemble . . . . .50-15-42	Disassemble/inspect/assemble . . . . .50-15-44
Top shaft, SyncShuttle transmission	Transmission, gear shift (collar)
Disassemble/inspect/assemble . . . . .50-15-44	Theory of operation. . . . .250-10-12
Torque value	Travel speeds
Flat face O-ring seal fitting . . . . .10-10-23	5210 and 5310 . . . . .10-10-7
Torque Value	5410 . . . . .10-10-13
Metric . . . . .10-10-24	5510 . . . . .10-10-19
Torque value	Turbocharger
O-ring boss fitting . . . . .10-10-21	Break-in . . . . .30-10-10
Torque values	Repair. . . . .30-10-1
Inch. . . . .10-10-26	Turbocharger boost pressure test. . . . .220-15-30
Metric . . . . .10-10-25	Turbocharger operation . . . . .230-10-12
Traction clutch finger	Turbocharger, 5310 machine
Adjustment . . . . .50-10-11	Install . . . . .30-10-7
Tractor light switch	Remove . . . . .30-10-6
Replace . . . . .40-10-7	Turbocharger, 5510 machine
Trailer connector operation. . . . .240-10-36	Install . . . . .30-10-9
Transmission	Remove . . . . .30-10-8
Assemble . . . . .50-15-24, 50-16-23	Turn signal controller
Component location, collar shift . . . . .250-05-6	Replace . . . . .40-10-10
Component location, PowrReverser . . . .250-06-8	Turn signals
	Tractors cab . . . . .240-15-21

## Page

Tractors without cab . . . . .240-15-18

**V**

Valve clearance

Adjustment . . . . .220-15-24

Volumetric efficiency

Compressor, test. . . . .90-20-12

**W**

Warning lights . . . . .240-15-26

WEATHER PACK connector

Replace . . . . .40-15-2

WEATHER PACK contact

Install . . . . .40-15-3

Wheel bearings, 2WD axle

Inspect/replace . . . . .80-10-2

Window

Rear, remove/install . . . . .90-15-8

Windowpanes

Remove/install . . . . .90-15-7

Windows

Lower front, remove/install . . . . .90-15-6

Wiper control switch

Replace . . . . .40-10-21

Wiper motor

Replace . . . . .40-10-22

Wire color chart, electrical . . . . .240-15-2

Wiring harness, cab

Replace lights . . . . .40-15-12

Replace radio/antenna . . . . .40-15-14

Wiring harness, cab, main

Replace . . . . .40-15-16

Wiring harness, front

Replace . . . . .40-15-6, 40-15-7

Wiring harness, rear

Replace . . . . .40-15-8, 40-15-10

540/540E rear PTO drive shaft assembly

Disassemble/inspect/assemble . . . . .50-20-10

Remove/install . . . . .50-20-9